

Operating Instructions (Overall)

AC Servo Motor & Driver MINAS A5-series



* This product image is 200W type of A5-series.

- Thank you for purchasing this Panasonic product.
- Before operating this product, please read the instructions carefully, and save this manual for future use.

Thank you for purchasing Digital AC Servo Motor & Driver, MINAS A5-series. This instruction manual contains information necessary to correctly and safely use the MINAS A5-series motor and driver. By reading this instruction manual, you will learn how to identify the model of the motor and driver that will be best suitable your application, how to wire and set up them, how to set parameters, and how to locate possible cause of symptom and to take corrective action.

This is the original instruction.

Caution ⚠

- 1) Any part or whole of this document shall not be reproduced without written permission from us.
- 2) Contents of this document are subject to change without notice.

1. Before Using the Products

Check of the Driver Model ... Installation

Describes how to identify and select the desired product and components, how to read the specifications, and how to install the equipment.

2. Preparation

Operating requirements and procedure

Shows the timing chart and the list of parameters, and describes how to make wiring and to use the front panel.

3. Connection

Wiring ... I/O settings

Shows block diagrams for each control mode and connection diagrams to the host controller, I/O settings.

4. Setup

Describes parameters ... JOG running

Shows describes parameters and procedure of test operation.

5. Adjustment

Gain adjustment ... Auto tuning

Describes various adjusting method including auto tuning and manual gain tuning.

6. When in Trouble

Read this section when you encounter trouble or error.

7. Supplement

Contains S-T characteristic diagram, dimensional outline drawing, supplemental description on communications and operation.

	page
Organization of this manual	3
Safety Precautions	6
Conformance to international standards	10
Maintenance and Inspections	11
1. Before Using the Products	1-1
1. Introduction	1-2
2. Driver	1-3
3. Motor	1-21
4. Check of the Combination of the Driver and the Motor	1-23
6. Installation	1-28
7. Permissible Load at Output Shaft	1-35
2. Preparation	2-1
1. Conformance to international standards	2-2
2. System Configuration and Wiring	2-10
3. Wiring to the Connector, X1	2-51
4. Wiring to the Connector, X2	2-51
5. Wiring to the Connector, X3	2-53
6. Wiring to the Connector, X4	2-54
7. Wiring to the Connector, X5	2-55
8. Wiring to the Connector, X6	2-57
9. Wiring to the Connector, X7	2-60
10. Timing Chart	2-61
11. Built-in Holding Brake	2-65
12. Dynamic Brake.....	2-67
13. Setup of Parameter and Mode	2-72
14. Setup of command division and multiplication ratio (electronic gear ratio)	2-84
15. How to Use the Front Panel	2-86
3. Connection	3-1
1. Outline of mode	3-2
2. Control Block Diagram	3-14
3. Wiring to the Connector, X4	3-18
4. Inputs and outputs on connector X4	3-30
5. IF Monitor Settings	3-50

	page
4. Setup	4-1
1. Describes parameters	4-2
2. JOG running	4-59
5. Adjustment	5-1
1. Gain Adjustment	5-2
2. Real-Time Auto-Gain Tuning	5-4
3. Adaptive Filter	5-10
4. Manual Auto-Gain Tuning (Basic)	5-13
5. Manual Auto-Gain Tuning (Application)	5-24
6. About Homing Operation	5-39
6. When in Trouble	6-1
1. When in Trouble	6-2
2. Setup of gain pre-adjustment protection	6-18
3. Troubleshooting	6-21
7. Supplement	7-1
1. Safety function	7-2
2. Absolute System	7-10
3. Setup Support Software, PANATERM	7-26
4. Communication	7-27
5. Motor Characteristics (S-T Characteristics)	7-55
6. Dimensions	7-73
7. Options	7-92
Warranty	7-126
Cautions for Proper Use	7-127
After-Sale Service	Back cover

Safety Precautions

Please observe safety precautions fully.

The following explanations are for things that must be observed in order to prevent harm to people and damage to property.

- Misuses that could result in harm or damage are shown as follows, classified according to the degree of potential harm or damage.



Danger

Indicates great possibility of death or serious injury.



Caution

Indicates the possibility of injury or property damage.

- The following indications show things that must be observed.



Indicates something that must not be done.



Indicates something that must be done.



Danger



Do not subject the Product to water, corrosive or flammable gases, and combustibles.

Do not place combustibles near by the motor, driverd regenerative resistor and dynamic brake resister..

Failure to observe this instruction could result in fire, electrical shocks, damages and break-downs.

Don't use the motor in a place subject to excessive vibration or shock.

Failure to observe this instruction could result in electrical shock, injury or fire.

Don't use cables soaked in water or oil.

Failure to observe this instruction could result in electrical shocks, damages and break-downs.

The installation area should be away from heat generating objects such as a heater and a large wire wound resistor.

Never connect the motor directly to the commercial power supply.



Failure to observe this instruction could result in fire and breakdowns.

Don't attempt to carry out wiring or manual operation with wet hand.

Failure to observe this instruction could result in electrical shock, injury or fire.

Do not put your hands in the servo driver.

Failure to observe this instruction could result in burn and electrical shocks.

	In the case of the motor with shaft end keyway, do not touch the keyway with bare hands.	Failure to observe this instruction could result in personal injury.
	Do not touch the rotating portion of the motor while it is running. Failure to observe this instruction could result in damages and breakdowns.	
	Do not touch the motor, servo driver, heat sink, regenerative resistor and dynamic brake resistor, since they become very hot.	Failure to observe this instruction could result in burns.
	Do not drive the motor with external power.	Failure to observe this instruction could result in fire.
	Do not subject the cables to excessive force, heavy object, or pinching force, nor damage the cables.	Failure to observe this instruction could result in electrical shocks, damages and breakdowns.
	Installation area should be free from excessive dust, and from splashing water and oil.	Failure to heed this precaution will result in electric shock, personal injury, fire, malfunction or damage.
	Mount the motor, driver and peripheral equipments on incombustible material such as metal.	Installation on a flammable material may cause fire.
	Wiring has to be carried out by the qualified and authorized specialist.	Allowing a person with no expertise to carry out wiring will result in electrical shocks.
	Correctly run and arrange wiring.	Incorrect wiring will result in short circuit, electric shock, personal injury, etc.
	After correctly connecting cables, insulate the live parts with insulator.	Incorrect wiring will result short circuit, electric shock, fire or malfunction.
	Ground the earth terminal of the motor and driver without fail.	Floating ground circuit will cause electric shock.
	Install and mount the Product and machinery securely to prevent any possible fire or accidents incurred by earthquake.	Failure to heed this requirement will result in electric shock, personal injury, fire, malfunction or damage.
	Install an emergency stop circuit externally so that you can stop the operation and shut off the power immediately.	
	Install an overcurrent protection, earth leakage breaker, over-temperature protection and emergency stop apparatus without fail.	Failure to heed these requirements will result in electric shock, personal injury or fire.
	Check and confirm the safety of the operation after the earthquake.	
	Before transporting, wiring and inspecting the driver, turn off power and wait for a time longer than that specified on the name plate on the side panel of the product; and make sure that there is no risk of electrical shock.	Energized circuit will cause electric shock.

Safety Precautions


Please observe safety precautions fully.



Caution



	Do not hold the motor cable or motor shaft during the transportation.	Failure to observe this instruction could result in injuries.
	Don't drop or cause topple over of something during transportation or installation.	Failure to observe this instruction could result in injuries and breakdowns.
	Do not step on the Product nor place the heavy object on them.	Failure to observe this instruction could result in electrical shocks, injuries, breakdowns and damages.
	Don't use the equipment under direct sunshine.	Failure to heed these instructions will cause personal injury or fire.
	Do not block the heat dissipating holes or put the foreign particles into them.	Failure to observe this instruction could result in electrical shocks and fire.
	Do not give strong impact shock to the Product.	Failure to observe this instruction could result in breakdowns.
	Do not give strong impact shock to the motor shaft.	Failure to observe this instruction could result in a failure of the detector etc.
	Do not turn on and off the main power of the driver repeatedly.	Failure to observe this instruction could result in breakdowns.
	Never run or stop the motor with the electro-magnetic contactor installed in the main power side.	
	Do not make an extreme gain adjustment or change of the drive. Do not keep the machine running/operating unstably.	Failure to observe this instruction could result in injuries.
	Do not use the built-in brake as a "Braking" to stop the moving load.	Failure to observe this instruction could result in injuries and breakdowns.
	Do not approach to the machine since it may suddenly restart after the power resumption. Design the machine to secure the safety for the operator even at a sudden restart.	Failure to observe this instruction could result in injuries.
	Never attempt to perform modification, dismantle or repair.	Failure to heed this instruction will result in fire, electric shock, personal injury or malfunction.

	Make an appropriate mounting of the Product matching to its wight and output rating.	Failure to heed these requirements will result in personal injury or malfunction.
	Observe the specified mounting method and direction.	
	Use the eye bolt of the motor for transportation of the motor only, and never use this for transportation of the machine.	Using it for transportation of the machine will cause personal injury or malfunction.
	Don't place any obstacle object around the motor and peripheral, which blocks air passage.	Temperature rise will cause burn injury or fire.
	Adjust the motor and driver ambient environmental condition to match the motor operating temperature and humidity.	Failure to heed these requirements will result in personal injury or malfunction.
	Create the specified clearance between the driver and the control panel inner surface or other devices.	
	Observe the specified voltage.	Operation from a voltage outside the rated voltage will cause electric shock, personal injury or fire.
	Connect the brake control relay to the relay which is to shut off at emergency stop in series.	Missing of one of these devices will result in personal injury or malfunction.
	Provide protection device against idling of electromagnetic brake or gear head, or grease leakage from gear head.	No protection will cause personal injury, damage, pollution or fire.
	Use the motor and the driver in the specified combination.	Not using the motor and the driver in the specified combination will result in fire.
	Test-run the securely fixed motor without loading to verify normal operation, and then connect it to the mechanical system.	Operation using a wrong model or wrong wiring connection will result in personal injury.
	When any error occurs, remove the cause and release the error after securing the safety, then restart.	Not removing the cause of the error will result in personal injury.
	If the driver fails, shut off the power on the power supply side of the driver.	Allowing a large current to continue to pass will result in fire.
	Maintenance must be performed by an experienced personnel.	Wrong wiring will cause personal injury or electric shock.
	Always keep power disconnected when the power is not necessary for a long time.	Improper operation will cause personal injury.
When you dispose the batteries, observe any applicable regulations or laws after insulating them with tape.		
This Product shall be treated as Industrial Waste when you dispose.		

Conformance to international standards



Conformed Standards

		Driver	Motor
EC Direc- tives	EMC Directives	EN55011 EN61000-6-2 EN61800-3	—
	Low-Voltage Directives	EN61800-5-1	EN60034-1 EN60034-5
	Machinery Directives	EN954-1 (Cat. 3) ISO13849-1 (PL c,d)(Cat. 3) EN61508 (SIL 2)	—
	Functional safety (*1)	EN62061 (SIL 2) EN61800-5-2 (STO) IEC61326-3-1	
UL Standards		UL508C (E164620)	UL1004-1 (E327868: to 750W (200V) from 6.0kW) UL1004 (E327868: 400W (400V) 600W (400V), 750W (400V) 0.9kW to 5.0kW)
CSA Standards		C22.2 No.14	C22.2 No.100

IEC : International Electrotechnical Commission

EN : Europaischen Normen

EMC : Electromagnetic Compatibility

UL : Underwriters Laboratories

CSA : Canadian Standards Association

Pursuant to the directive 2004/108/EC, article 9(2)

Panasonic Testing Centre

Panasonic Service Europe, a division of

Panasonic Marketing Europe GmbH

Winsbergring 15, 22525 Hamburg, F.R. Germany

* Products shall conform to the statutory regulations applied in the place of destination.

* Only for position control type does not support functional safety^(*1) standards.

Note

For details on compatibility with international standard, refer to P.2-2 Conformance to international standards.

Routine maintenance and inspection of the driver and motor are essential for the proper and safe operation.

Notes on Maintenance and Inspection

- 1) Turn on and turn off should be done by operators or inspectors themselves. When establishing a system using safety functions, completely understand the applicable safety standards and the operating instruction manual or technical documents for the product.
- 2) Internal circuit of the driver is kept charged with high voltage for a while even after power-off. Turn off the power and allow 15 minutes or longer after LED display of the front panel has gone off, before performing maintenance and inspection.
- 3) Disconnect all of the connection to the driver when performing megger test (Insulation resistance measurement) to the driver, otherwise it could result in breakdown of the driver.
- 4) Do not use benzine, thinner, alcohol, acidic cleaner and alkaline cleaner because they can discolor or damage the exterior case.
- 5) The upper fan on H-frame driver is kept deactivated while servo is off, for the purpose of energy saving. This is normal.

Inspection Items and Cycles

General and normal running condition

Ambient conditions : 30°C (annual average), load factor of 80% or lower, operating hours of 20 hours or less per day.

Perform the daily and periodical inspection as per the items below.


Type	Cycles	Items to be inspected
Daily inspection	Daily	<ul style="list-style-type: none">• Ambient temperature, humidity, speck, dust or foreign object• Abnormal vibration and noise• Main circuit voltage• Odor• Lint or other particles at air holes• Cleanness at front portion of the driver and connector• Damage of the cables• Loose connection or misalignment between the motor and machine or equipment• Pinching of foreign object at the load
Motor with Gear Reducer	Annual	<ul style="list-style-type: none">• Loose tightening• Trace of overheat• Damage to the terminal block• Loose fasteners on terminal block

Note Inspection cycle may change when the running conditions of the above change.

Maintenance and Inspections

Guideline for Parts Replacement

Use the table below for a reference. Parts replacement cycle varies depending on the actual operating conditions. Defective parts should be replaced or repaired when any error have occurred.

 Prohibited	Disassembling for inspection and repair should be carried out only by authorized dealers or service company.
---	---

Product	Component	Standard replacement cycles (hour)	Note
Driver	Smoothing condenser	Approx. 5 years	These hours or cycles are reference. When you experience any error, replacement is required even before this standard replacement cycle.
	Cooling fan	2 to 3 years (10,000 to 30,000 hours)	
	Aluminum electrolytic capacitor (on PCB)	Approx. 5 years	
	Rush current preventive relay	Approx. 100,000 times (depending on working condition)	
	Rush current preventive resistor	Approx. 20,000 times (depending on working condition)	
Motor	Bearing	3 to 5 years (20,000 to 30,000 hours)	
	Oil seal	5000 hours	
	Encoder	3 to 5 years (20,000 to 30,000 hours)	
	Battery for absolute encoder	Life time varies depending on working conditions. Refer to the Operating Instructions attached to the battery for absolute encoder.	

1 . Before Using the Products

1. Introduction

Outline	1-2
On Opening the Product Package	1-2

2. Driver

Check of the Model.....	1-3
Parts Description	
A to E-frame.....	1-4
F-frame	1-5
G-frame.....	1-6
H-frame.....	1-7
D to F-frame (400 V).....	1-8
G-frame (400 V).....	1-9
H-frame (400 V).....	1-10
Specifications.....	1-11
Block Diagram	1-15

3. Motor

Check of the Model.....	1-21
Parts Description	1-22

4. Check of the Combination of the Driver and the Motor

Incremental Specifications, 20-bit.....	1-23
Absolute Specifications, 17-bit.....	1-25
Junction cable for motor	1-27

5. Installation

Driver	1-28
Motor.....	1-32

6. Permissible Load at Output Shaft

Motor.....	1-35
------------	------

The AC Servo Motor & Driver, MINAS A5-series is the latest servo system that meets all demands from a variety of machines which require high speed, high precision and high performance or which require simplified settings.

Compared with the preceding A4-series, product of A5-series offers superior performance while requiring simple setup and adjustment by the user.

Newly designed motors have wide range of outputs from 50 W to 15.0 kW, associated with 20-bit incremental encoder and reduced cogging torque.

(Only for position control type have range of outputs from 50 W to 5.0 kW.)

They are compatible with 2 closed controls (serial communication type and A-/B-phase output type) and provided with various automatic adjusting functions such as real time auto tuning with many automatic setting parameters to make complex tuning easy.

(Only for position control type do not conform to full-closed control.)

These motors assure higher stability with low stiffness machine and high-speed, high accurate operation with high stiffness machine. They can be used in combination with a wide variety of machines.

This manual is written as a complete guide for you so that you can fully and correctly make use of all functions available from MINAS A5.

- Make sure that the model is what you have ordered.
- Check if the product is damaged or not during transportation.
- Check if the Operating Instructions (safety) are included or not.
- Check if the power connector, motor connectors, connector for external regenerative resistor connection (D-frame (400 V) and E-frame) and safety by-pass plug are included or not.

(Neither the power connector nor motor connector are included to F-frame to H-frame.)

(Safety bypass plug is not supplied with only for position control type because it does not use this plug.)


Contact to a dealer if you find any failures.

1 Before Using the Products

2. Driver

Check of the Model

Contents of Name Plate



Model Designation

Velocity, position, torque and full-closed control type

M A D H T 1 5 0 5 * * *

1 to 4 5 to 6 7 8 to 9 10 to 12

Special specifications (letters and numbers)

Only for position control type

M A D H T 1 5 0 5 E * *

1 to 4 5 to 6 7 8 to 9 10 11 to 12

Special specifications (letters and numbers)

Only for position control type

Frame-size symbol

Symbol	Frame
MADH	A5-series, A-frame
MBDH	A5-series, B-frame
MCDH	A5-series, C-frame
MDDH	A5-series, D-frame
MEDH	A5-series, E-frame
MFDH	A5-series, F-frame
MGDH	A5-series, G-frame
MHDH	A5-series, H-frame

NOTE)

Only for position control type is provided A-Frame to F-frame.

Max. current rating of power device

Symbol	Current rating
T1	10A
T2	15A
T3	30A
T4	35A
T5	50A
T7	70A
TA	100A
TB	150A
TC	300A

Current detector rating

Symbol	Current rating
05	5A
07	7.5A
10	10A
12	12A
20	20A
30	30A
40	40A
64	64A
90	90A
A2	120A
B4	240A

Power supply


Symbol	Specifications
1	Single phase, 100V
3	3-phase, 200V
4	3-phase, 400V
5	Single/3-phase, 200V

Related page • P.1-23 "Check of the Combination of the Driver and the Motor"


1 Before Using the Products

2. Driver Parts Description

A to D-frame



E-frame




Note

- Connector XA and XB are attached in A to D-frame driver.
- Connector XA, XB and XC are attached in E-frame driver.
- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

2. Driver

Parts Description

F-frame



Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.


Related page

- P.1-23 "Check of the Combination of the Driver and the Motor" • P.1-28 "Installation"
- P.2-10 "Driver and List of Applicable Peripheral Equipments" • P.7-73 to 7-78 "Dimensions"


2. Driver

Parts Description


G-frame



Details of terminal block



* NC is no connect.



Note

The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.


Related page

P.1-23 "Check of the Combination of the Driver and the Motor" • P.1-28 "Installation"
P.2-10 "Driver and List of Applicable Peripheral Equipments" • P.7-73 to 7-78 "Dimensions"



2. Driver

Parts Description

H-frame



Details of terminal block



Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

Related page

- P.1-23 "Check of the Combination of the Driver and the Motor" • P.1-28 "Installation"
- P.2-10 "Driver and List of Applicable Peripheral Equipments" • P.7-73 to 7-78 "Dimensions"

2. Driver

Parts Description

D, E-frame (400 V)

Connector XA:
for main power connection

03JFAT-SAYGSA-L (JST)

Connector XD:
Control power input terminals

02MJFAT-SAGF (JST)

Control power
input terminals

24V

0V

Main power
input terminals

L1

L2

L3

Terminals for external
regenerative resistor
(Normally short-circuit
B3 to B2)

B1

B3

B2

NC*

Terminals for
motor connection

U

V

W

Connector XB:
for motor connection

03JFAT-SAXGSA-L (JST)

Connector XC:
Connector for external
regenerative resistor

04JFAT-SAXGSA-L (JST)

Screws for earth
(x2)

* NC is no connect.

Front panel

Connector X7: Monitor connector

Connector X1: USB connector


Connector X2: for Serial bus

Connector X3: Safety function connector

Connector X4: Parallel I/O connector

Connector X5:
for feedback scale
connection

Connector X6:
for encoder
connection



LED cover

Safety by-pass plug

F-frame (400 V)

Details of terminal block

Control power
input terminals

24V

0V

Main power
input terminals

L1

L2

L3

Terminals for external
regenerative resistor
(Normally short-circuit
B3 to B2)

B1

B3

B2

NC*

Terminals for motor
connection

U

V

W

* NC is no connect.

Front panel

Connector X7: Monitor connector

Connector X1: USB connector

Connector X2: for Serial bus

Connector X3: Safety function connector

Connector X4: Parallel I/O connector

Connector X5:
for feedback scale
connection

Connector X6:
for encoder
connection

Charge lamp

Screws for earth (x2)

Safety by-pass plug

Terminal cover

LED cover


Note

- Connector X1 and X2 are attached in A to D-frame driver.
- Connector XA, XB, XC and XD are attached in D and E-frame (400 V) driver.
- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.


2. Driver

Parts Description


G-frame (400 V)



Details of terminal block



* NC is no connect.



Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.


Related page

- P.1-23 "Check of the Combination of the Driver and the Motor" • P.1-28 "Installation"
- P.2-10 "Driver and List of Applicable Peripheral Equipments" • P.7-73 to 7-78 "Dimensions"



2. Driver

Parts Description

H-frame (400 V)



Details of terminal block



Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

Related page

- P.1-23 "Check of the Combination of the Driver and the Motor" • P.1-28 "Installation"
- P.2-10 "Driver and List of Applicable Peripheral Equipments" • P.7-73 to 7-78 "Dimensions"

1 Before Using the Products

2. Driver

Specifications (Velocity, position, torque, full-closed control type)

Basic Specifications	Input power	100V	Main circuit		Single phase, 100 to 120V	+10% -15%	50/60Hz	
			Control circuit		Single phase, 100 to 120V	+10% -15%	50/60Hz	
		200V	Main circuit	A to D-frame	Single/3-phase, 200 to 240V	+10% -15%	50/60Hz	
				E to H-frame	3-phase, 200 to 230V	+10% -15%	50/60Hz	
			Control circuit	A to D-frame	Single phase, 200 to 240V	+10% -15%	50/60Hz	
				E to H-frame	Single phase, 200 to 230V	+10% -15%	50/60Hz	
		400V *1	Main circuit		3-phase, 380 to 480V	+10% -15%	50/60Hz	
			Control circuit		DC24V ± 15%			
	Withstand voltage					Primary to earth: withstand 1500 VAC, 1 min, (sensed current: 20 mA) [100V/200V] withstand 1960 VAC, 1 min, (sensed current: 20 mA) [400V] * 400V control circuit is excluded.		
	Environment	temperature		Ambient temperature: 0°C to 55°C (free from freezing) Storage temperature: -20°C to 65°C (Max. temperature guarantee: 80°C for 72 hours free from condensation ²)				
		humidity		Both operating and storage : 20 to 85%RH or less (free from condensation ²)				
		Altitude		Lower than 1000m				
		Vibration		5.88m/s ² or less, 10 to 60Hz (No continuous use at resonance frequency)				
	Control method					IGBT PWM Sinusoidal wave drive		
	Encoder feedback					17-bit (131072 resolution) absolute encoder, 7-wire serial 20-bit (1048576 resolution) incremental encoder, 5-wire serial		
	Feedback scale feedback					A/B phase, initialization signal defferential input. Manufacturers that support serial communication scale: Mitsutoyo Corp. Magscale Co., Ltd. (old Sony Manufacturing Systems Corp.)		
	Parallel I/O connector	Control signal	Input	General purpose 10 inputs The function of general-purpose input is selected by parameters.				
			Output	General purpose 6 outputs The function of general-purpose input is selected by parameters.				
		Analog signal	Input	3 inputs (16Bit A/D : 1 input, 12Bit A/D : 2 inputs)				
			Output	2 outputs (Analog monitor: 2 output)				
		Pulse signal	Input	2 inputs (Photo-coupler input, Line receiver input) Photocoupler input is compatible with both line driver I/F and open collector I/F. Line receiver input is compatible with line driver I/F.				
			Output	4 outputs (Line driver: 3 output, open collector: 1 output) Feed out the encoder feedback pulse (A, B and Z-phase) or feedback scale pulse (EXA, EXB and EXZ-phase) in line driver. Z-phase and EXZ-phase pulse is also fed out in open collector.				
	Communication function		USB	Connection with PC etc.				
			RS232	1 : 1 communication to a host.				
			RS485	1 : n communication to a host.				
	Safety function					Used for functional safety.		
	Front panel					(1) 5 keys (MODE, SET, UP, DOWN, SHIFT) (2) LED (6-digit) (3) Monitor connector (Analog monitor output (2ch), Digital monitor output (1ch))		
	Regeneration					A, B, G and H-frame: no built-in regenerative resistor (external resistor only) C to F-frame: Built-in regenerative resistor (external resistor is also enabled.)		
	Dynamic brake					A to G-frame: Built-in (external resistor is also available to G-frame) H-frame: External only		
	Control mode					Switching among the following 7 mode is enabled, (1) Position control (2) Velocity control (3) Toque control (4) Position/Velocity control (5) Position/Torque control (6) Velocity/Torque control (7) Full-closed control		

Caution

*1 The specification out of Japan.

*2 Air containing water vapor will become saturated with water vapor as the temperature falls, causing dew.

Related page

• P.1-28 "Installation of Driver" • P.1-32 "Installation of Motor"

2. Driver

Specifications (Velocity, position, torque, full-closed control type)

Function	Control input		(1) Servo-ON input (2) Alarm clear input (3) Gain switching input (4) Positive direction over-travel inhibition input (5) Negative direction over-travel inhibition input (6) Forced alarm input (7) Inertia ratio switching input
	Control output		(1) Servo-Alarm output (2) Servo-Ready output (3) External brake release signal (4) Speed arrival output (5) Torque in-limit signal output (6) Zero-speed detection output signal (7) Alarm output (8) Alarm attribute output
	Position control	Control input	(1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increase switching (4) Damping control switching (5) Torque limit switching (6) Control mode switching
		Control output	(1) Positioning complete (In-position) (2) Positional command ON/OFF output
		Pulse input	Max. command pulse frequency
			Exclusive interface for Photo-coupler: 500kpps Exclusive interface for line driver : 4Mpps
			Input pulse signal format
			Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction)
			Electronic gear (Division/Multiplication of command pulse)
			Process command pulse frequency × electronic gear ratio $\left(\frac{1}{1} \text{ to } \frac{2^{30}}{1}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 to 1000 times.
			Smoothing filter
			Primary delay filter or FIR type filter is adaptable to the command input
		Analog input	Torque limit command input
			Individual torque limit for both positive and negative direction is enabled.
		Torque feed forward input	
		Analog voltage can be used as torque feed forward input.	
		Instantaneous Speed Observer	
		Available	
		Damping Control	
		Available	
	Velocity control	Control input	(1) Selection of internal velocity setup (2) Speed zero clamp (3) Speed command sign input (4) Control mode switching
		Control output	(1) Speed coincidence output (2) Speed command ON/OFF output
		Analog input	Velocity command input
			Speed command input can be provided by means of analog voltage. Parameters are used for scale setting and command polarity. (6V/Rated rotational speed Default)
			Torque limit command input
			Individual torque limit for both positive and negative direction is enabled.
		Torque feed forward input	
		Analog voltage can be used as torque feed forward input.	
		Internal velocity command	
		Switching the internal 8speed is enabled by command input.	
		Soft-start/down function	
		Individual setup of acceleration and deceleration is enabled, with 0 to 10s/1000r/min. Sigmoid acceleration/deceleration is also enabled.	
		Zero-speed clamp	
		0-clamp of internal velocity command with speed zero clamp input is enabled.	
		Instantaneous Speed Observer	
		Available	
	Torque control	Control input	(1) Speed zero clamp (2) Torque command sign input (3) Control mode switching
		Control output	(1) Speed coincidence output (2) Speed in-limit output
		Analog input	Torque command input
			Torque command input can be provided by means of analog voltage. Parameters are used for scale setting and command polarity. (3V/rated torque Default)
		Speed limit function	
		Speed limit value with parameter t is enabled.	
	Full-closed control	Control input	(1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increase switching (4) Damping control switching (5) Torque limit switching
		Control output	(1) Full-closed positioning complete (2) Positional command ON/OFF output
		Pulse input	Max. command pulse frequency
			Exclusive interface for Photo-coupler: 500kpps Exclusive interface for line driver : 4Mpps
			Input pulse signal format
			Differential input. Selectable with parameter. ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction)
			Electronic gear (Division/Multiplication of command pulse)
			Process command pulse frequency × electronic gear ratio $\left(\frac{1}{1} \text{ to } \frac{2^{30}}{1}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 to 1000 times.
			Smoothing filter
			Primary delay filter or FIR type filter is adaptable to the command input
		Analog input	Torque limit command input
			Individual torque limit for both positive and negative direction is enabled.
		Torque feed forward input	
		Analog voltage can be used as torque feed forward input.	
		Setup range of division/multiplication of feedback scale	
		1/40 to 160 times The ratio of encoder pulse (numerator) to external scale pulse (denominator) can be set to 1 to 2 ²⁰ (numerator) to 1 to 2 ²⁰ (denominator), but should be set to a ratio within the range shown above.	
	Common	Auto tuning	
		The load inertia is identified in real time by the driving state of the motor operating according to the command given by the controlling device and set up support software "PANATERM". The gain is set automatically in accordance with the rigidity setting.	
		Division of encoder feedback pulse	
		Set up of any value is enabled (encoder feedback pulses count is the max.).	
	Protective function	Hard error	Over-voltage, under-voltage, over-speed, over-load, over-heat, over-current and encoder error etc.
			Soft error
		Excess position deviation, command pulse division error, EEPROM error etc.	
	Traceability of alarm data		The alarm data history can be referred to.

1 Before Using the Products

2. Driver

Specifications (Only for position control type)

Basic Specifications	Input power	100V	Main circuit		Single phase, 100 to 120V	+10% -15%	50/60Hz
			Control circuit		Single phase, 100 to 120V	+10% -15%	50/60Hz
		200V	Main circuit	A to D-frame	Single/3-phase, 200 to 240V	+10% -15%	50/60Hz
				E to F-frame	3-phase, 200 to 230V	+10% -15%	50/60Hz
			Control circuit	A to D-frame	Single phase, 200 to 240V	+10% -15%	50/60Hz
				E to F-frame	Single phase, 200 to 230V	+10% -15%	50/60Hz
		400V	Main circuit	D to F-frame	3-phase, 380 to 480V	+10% -15%	50/60Hz
			Control circuit	D to F-frame	DC 24V ± 15%		
	Withstand voltage				Primary to earth: withstand 1500 VAC, 1 min, (sensed current: 20 mA) [100V/200V] withstand 1960 VAC, 1 min, (sensed current: 20 mA) [400V] * 400V control circuit is excluded.		
	Environment	temperature		Ambient temperature: 0°C to 55°C (free from freezing) Storage temperature: -20°C to 65°C (Max. temperature guarantee: 80°C for 72 hours free from condensation ²⁾)			
		humidity		Both operating and storage : 20 to 85%RH or less (free from condensation)			
		Altitude		Lower than 1000m			
		Vibration		5.88m/s ² or less, 10 to 60Hz (No continuous use at resonance frequency)			
	Control method				IGBT PWM Sinusoidal wave drive		
	Encoder feedback				20-bit (1048576 resolution) incremental encoder, 5-wire serial		
	Parallel I/O connector	Control signal	Input	General purpose 10 inputs The function of general-purpose input is selected by parameters.			
			Output	General purpose 6 outputs The function of general-purpose input is selected by parameters.			
		Analog signal	Output	2 outputs (Analog monitor: 2 output)			
		Pulse signal	Input	2 inputs (Photo-coupler input, Line receiver input) Photocoupler input is compatible with both line driver I/F and open collector I/F. Line receiver input is compatible with line driver I/F.			
			Output	4 outputs (Line driver: 3 output, open collector: 1 output) Feed out the encoder feedback pulse (A, B and Z-phase) or feedback scale pulse (EXA, EXB and EXZ-phase) in line driver. Z-phase and EXZ-phase pulse is also fed out in open collector.			
	Communication function		USB	Connection with PC etc.			
	Front panel				(1) 5 keys (2) LED (6-digit) (3) Analog monitor output (2ch)		
	Regeneration				A, B-frame: no built-in regenerative resistor (external resistor only) C to F-frame: Built-in regenerative resistor (external resistor is also enabled.)		
	Dynamic brake				A to F-frame: Built-in		
	Control mode				(1) Position control (2) Internal velocity control (3) Position/ Internal velocity control		

Caution

*1 The specification out of Japan.

*2 Air containing water vapor will become saturated with water vapor as the temperature falls, causing dew.

Related page

• P.1-28 "Installation of Driver" • P.1-32 "Installation of Motor"

Caution

Only for position control type is provided A-Frame to F-frame.

2. Driver


Specifications (Only for position control type)

Function	Position control	Control input		(1) Deviation counter clear (2) Command pulse inhibition (3) Command dividing gradual increase switching (4) Damping control switching etc.
		Control output		Positioning complete (In-position) etc.
		Pulse input	Max. command pulse frequency	Exclusive interface for Photo-coupler: 500kpps Exclusive interface for line driver : 4Mpps
			Input pulse signal format	Differential input ((1) Positive and Negative direction, (2) A and B-phase, (3) Command and direction)
			Electronic gear (Division/ Multiplication of command pulse)	Process command pulse frequency × electronic gear ratio $\left(\frac{1 \text{ to } 2^{30}}{1 \text{ to } 2^{30}}\right)$ as positional command input. Use electronic gear ratio in the range 1/1000 to 1000 times.
			Smoothing filter	Primary delay filter or FIR type filter is adaptable to the command input
		Instantaneous Speed Observer		Available
		Damping Control		Available
	Internal velocity control	Control input		(1) Selection of internal velocity setup (2) Speed zero clamp
		Control output		Speed arrival
		Internal velocity command		Switching the internal 8speed is enabled by command input.
		Soft-start/down function		Individual setup of acceleration and deceleration is enabled, with 0 to 10s/1000r/min. Sigmoid acceleration/deceleration is also enabled.
		Zero-speed clamp		0-clamp of internal velocity command with speed zero clamp input is enabled.
		Instantaneous Speed Observer		Available
	Common	Auto tuning		The load inertia is identified in real time by the driving state of the motor operating according to the command given by the controlling device and set up support software "PANATERM". The gain is set automatically in accordance with the rigidity setting.
		Division of encoder feedback pulse		Set up of any value is enabled (encoder pulses count is the max.).
		Protective function	Hard error	Over-voltage, under-voltage, over-speed, over-load, over-heat, over-current and encoder error etc.
			Soft error	Excess position deviation, command pulse division error, EEPROM error etc.
		Traceability of alarm data		The alarm data history can be referred to.


1 Before Using the Products

2. Driver Block Diagram

A, B-frame (100/200 V)



C, D-frame (100/200 V)




Note

The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.


2. Driver

Block Diagram

E-frame (200 V)



F-frame (200 V)




Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.


2. Driver

Block Diagram

G-frame (200 V)



H-frame (200 V)




Note


The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.

Block Diagram

D-frame (400 V)



E-frame (400 V)




Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.


2. Driver

Block Diagram

F-frame (400 V)



G-frame (400 V)




Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided with X2, X3 and X5.
- G-frame: Only for position control type is not provided.

2. Driver

Block Diagram

H-frame (400 V)




Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver. Only for position control type is not provided.


1 Before Using the Products

3. Motor Check of the Model

Contents of Name Plate



Model Designation



Motor structure

MSME (50W to 750W)

Symbol	Shaft		Holding brake		Oil seal	
	Round	Key way	Without	With	Without	With ^{*4}
A	●		●		●	
B	●			●	●	
S		● ^{*5}	●		●	
T		● ^{*5}		●	●	

MSME (750W(400V), 1.0kW to 5.0kW), MDME, MFME, MGME, MHME

Symbol	Shaft		Holding brake		Oil seal	
	Round	Key way	Without	With	Without	With
C	●		●			●
D	●			●		●
G		●	●			●
H		●		●		●

^{*4} The product with oil seal is a special order product. ^{*5} Key way with center tap
[Products are standard stock items or manufactured by order. For details, inquire the dealer.]

Note

Related page


• For details of specific model, refer to the Dimensions of Supplement.

• P.1-23 "Check of the Combination of the Driver and the Motor" • P.7-79 to 7-93 "Dimensions"


1 Before Using the Products

3. Motor Parts Description

- MSME 50W to 750W




[with Brake]



e.g.) : Low inertia type (MSME series, 50W)

- MSME 750W(400V), 1.0kW to 5.0kW
- MDME 400W to 15.0kW
- MFME 1.5kW to 4.5kW
- MGMA 0.9kW to 6.0kW
- MHME 1.0kW to 7.5kW



e.g.) : Middle inertia type (MDME series, 1.0kW)

Note

For details of specific model, refer to the Dimensions of Supplement. (P.7-79 to 7-93)

1 Before Using the Products

4. Check of the Combination of the Driver and the Motor Incremental Specifications, 20-bit

This driver is designed to be used in a combination with the motor which are specified by us. Check the series name of the motor, rated output torque, voltage specifications and encoder specifications.

Remarks

Do not use in other combinations than those listed below.

Motor					Driver				
Power supply	Type	Rated rotational speed	Model	Rated output	Model of velocity, position, torque and full-closed control type	Model of Only for position control type	Frame		
Single phase, 100V	MSMD Low inertia	3000r/min	MSMD5AZG1 *	50W	MADHT1105	MADHT1105E	A-frame		
			MSMD011G1 *	100W	MADHT1107	MADHT1107E			
			MSMD021G1 *	200W	MBDHT2110	MBDHT2110E	B-frame		
			MSMD041G1 *	400W	MCDHT3120	MCDHT3120E	C-frame		
Single/ 3-phase, 200V			MSME5AZG1 *	50W	MADHT1505	MADHT1505E	A-frame		
			MSME012G1 *	100W					
			MSME022G1 *	200W					
			MSME042G1 *	400W					
			MSME082G1 *	750W	MCDHT3520	MCDHT3520E	C-frame		
Single phase, 100V	MSME Low inertia	3000r/min	MSME5AZG1 *	50W	MADHT1105	MADHT1105E	A-frame		
			MSME011G1 *	100W	MADHT1107	MADHT1107E			
			MSME021G1 *	200W	MBDHT2110	MBDHT2110E	B-frame		
			MSME041G1 *	400W	MCDHT3120	MCDHT3120E	C-frame		
Single/ 3-phase, 200V			MSME5AZG1 *	50W	MADHT1505	MADHT1505E	A-frame		
			MSME012G1 *	100W					
			MSME022G1 *	200W					
			MSME042G1 *	400W					
					MSME082G1 *	750W	MCDHT3520	MCDHT3520E	C-frame
			MSME102G□ *	1.0kW	MDDHT5540	MDDHT5540E	D-frame		
			MSME152G□ *	1.5kW					
			3-phase, 200V	MSME202G□ *	2.0kW	MEDHT7364	MEDHT7364E	E-frame	
				MSME302G□ *	3.0kW	MFDHTA390	MFDHTA390E	F-frame	
MSME402G□ *				4.0kW	MFDHTB3A2	MFDHTB3A2E			
MSME502G□ *				5.0kW					
3-phase, 400V			MSME084G1 *	750W	MDDHT2412	MDDHT2412E	D-frame		
			MSME104G□ *	1.0kW	MDDHT3420	MDDHT3420E			
			MSME154G□ *	1.5kW	MDDHT3420	MDDHT3420E			
			MSME204G□ *	2.0kW	MEDHT4430	MEDHT4430E	E-frame		
			MSME304G□ *	3.0kW	MFDHT5440	MFDHT5440E	F-frame		
			MSME404G□ *	4.0kW	MFDHTA464	MFDHTA464E			
			MSME504G□ *	5.0kW					
			Single/ 3-phase, 200V	MDME Middle inertia	2000r/min	MDME102G□ *	1.0kW	MDDHT3530	MDDHT3530E
MDME152G□ *						1.5kW	MDDHT5540	MDDHT5540E	
MDME202G□ *			2.0kW			MEDHT7364	MEDHT7364E	E-frame	
MDME302G□ *			3.0kW			MFDHTA390	MFDHTA390E	F-frame	
MDME402G□ *	4.0kW	MFDHTB3A2	MFDHTB3A2E						
MDME502G□ *	5.0kW								
1500r/min	MDME752G1 *	7.5kW	MGDHTC3B4			—	G-frame		
	MDMEC12G1 *	11.0kW	MHDHTC3B4				H-frame		
	MDMEC52G1 *	15.0kW							
	3-phase, 400V	MDME044G1 *	400W			MDDHT2407	MDDHT2407E	D-frame	
MDME064G1 *		600W							
MDME104G□ *		1.0kW	MDDHT2412			MDDHT2412E			
MDME154G□ *		1.5kW	MDDHT3420		MDDHT3420E				
MDME204G□ *		2.0kW	MEDHT4430		MEDHT4430E	E-frame			
MDME304G□ *		3.0kW	MFDHT5440		MFDHT5440E	F-frame			
MDME404G□ *		4.0kW	MFDHTA464		MFDHTA464E				
MDME504G□ *		5.0kW							
1500r/min	MDME754G1 *	7.5kW	MGDHTB4A2		—	G-frame			
	MDMEC14G1 *	11.0kW	MHDHTB4A2			H-frame			
	MDMEC54G1 *	15.0kW							

Note

- Suffix of "□" in the applicable motor model represents design order.
- Suffix of " * " in the applicable motor model represents the motor structure.

4. Check of the Combination of the Driver and the Motor

Incremental Specifications, 20-bit

Motor					Driver		
Power supply	Type	Rated rotational speed	Model	Rated output	Model of velocity, position, torque and full-closed control type	Model of Only for position control type	Frame
Single/ 3-phase, 200V	MFME Middle inertia	2000r/min	MFME152G1 *	1.5kW	MDDHT5540	MDDHT5540E	D-frame
3-phase, 200V			MFME252G1 *	2.5kW	MEDHT7364	MEDHT7364E	E-frame
3-phase, 400V			MFME452G1 *	4.5kW	MFDHTB3A2	MFDHTB3A2E	F-frame
			MFME154G1 *	1.5kW	MDDHT3420	MDDHT3420E	D-frame
			MFME254G1 *	2.5kW	MEDHT4430	MEDHT4430E	E-frame
			MFME454G1 *	4.5kW	MFDHTA464	MFDHTA464E	F-frame
Single/ 3-phase, 200V	MGME Middle inertia	1000r/min	MGME092G□ *	0.9kW	MDDHT5540	MDDHT5540E	D-frame
3-phase, 200V			MGME202G□ *	2.0kW	MFDHTA390	MFDHTA390E	F-frame
			MGME302G□ *	3.0kW	MFDHTB3A2	MFDHTB3A2E	
			MGME452G1 *	4.5kW			MGDHTC3B4
			MGME602G1 *	6.0kW	MDDHT3420	MDDHT3420E	
3-phase, 400V			MGME094G□ *	0.9kW	MDDHT3420	MDDHT3420E	F-frame
			MGME204G□ *	2.0kW	MFDHT5440	MFDHT5440E	
			MGME304G□ *	3.0kW	MFDHTA464	MFDHTA464E	
			MGME454G1 *	4.5kW			
			MGME604G1 *	6.0kW	MGDHTB4A2	—	G-frame
Single phase, 100V	MHMD High inertia	2000r/min	MHMD021G1 *	200W	MBDHT2110	MBDHT2110E	B-frame
Single/ 3-phase, 200V			MHMD041G1 *	400W	MCDHT3120	MCDHT3120E	C-frame
			MHMD022G1 *	200W	MADHT1507	MADHT1507E	A-frame
			MHMD042G1 *	400W	MBDHT2510	MBDHT2510E	B-frame
			MHMD082G1 *	750W	MCDHT3520	MCDHT3520E	C-frame
Single/ 3-phase, 200V	MHME High inertia	2000r/min	MHME102G□ *	1.0kW	MDDHT3530	MDDHT3530E	D-frame
3-phase, 200V			MHME152G□ *	1.5kW	MDDHT5540	MDDHT5540E	
			MHME202G□ *	2.0kW	MEDHT7364	MEDHT7364E	F-frame
			MHME302G□ *	3.0kW	MFDHTA390	MFDHTA390E	
			MHME402G□ *	4.0kW	MFDHTB3A2	MFDHTB3A2E	
			MHME502G□ *	5.0kW			
3-phase, 400V		1500r/min	MHME752G1 *	7.5kW	MGDHTC3B4	—	G-frame
		2000r/min	MHME104G□ *	1.0kW	MDDHT2412	MDDHT2412E	D-frame
			MHME154G□ *	1.5kW	MDDHT3420	MDDHT3420E	
			MHME204G□ *	2.0kW	MEDHT4430	MEDHT4430E	F-frame
			MHME304G□ *	3.0kW	MFDHT5440	MFDHT5440E	
			MHME404G□ *	4.0kW	MFDHTA464	MFDHTA464E	
			MHME504G□ *	5.0kW			
		1500r/min	MHME754G1 *	7.5kW	MGDHTB4A2	—	G-frame

Note

- Suffix of "□" in the applicable motor model represents design order.
- Suffix of " * " in the applicable motor model represents the motor structure.

This driver is designed to be used in a combination with the motor which are specified by us. Check the series name of the motor, rated output torque, voltage specifications and encoder specifications.

Remarks Do not use in other combinations than those listed below.

Motor					Driver		
Power supply	Type	Rated rotational speed	Model	Rated output	Model of velocity, position, torque and full-closed control type	Frame	
Single phase, 100V	MSME Low inertia	3000r/min	MSME5AZS1 *	50W	MADHT1105	A-frame	
			MSME011S1 *	100W	MADHT1107		
			MSME021S1 *	200W	MBDHT2110	B-frame	
			MSME041S1 *	400W	MCDHT3120	C-frame	
MSME5AZS1 *			50W	MADHT1505	A-frame		
MSME012S1 *			100W				
MSME022S1 *			200W	MADHT1507			
MSME042S1 *			400W	MBDHT2510	B-frame		
MSME082S1 *			750W	MCDHT3520	C-frame		
MSME102S□ *			1.0kW	MDDHT5540	D-frame		
MSME152S□ *			1.5kW				
MSME202S□ *			2.0kW	MEDHT7364	E-frame		
MSME302S□ *			3.0kW	MFDHTA390	F-frame		
MSME402S□ *			4.0kW				
MSME502S□ *			5.0kW				
3-phase, 400V			MSME084S1 *	750W	MDDHT2412	D-frame	
			MSME104S□ *	1.0kW	MDDHT3420		
			MSME154S□ *	1.5kW	MDDHT3420		
			MSME204S□ *	2.0kW	MEDHT4430	E-frame	
			MSME304S□ *	3.0kW	MFDHT5440	F-frame	
			MSME404S□ *	4.0kW			
			MSME504S□ *	5.0kW			
	Single/3-phase, 200V	MDME Middle inertia	2000r/min	MDME102S□ *	1.0kW	MDDHT3530	D-frame
MDME152S□ *				1.5kW	MDDHT5540		
MDME202S□ *	2.0kW			MEDHT7364	E-frame		
MDME302S□ *	3.0kW			MFDHTA390			
MDME402S□ *	4.0kW			MFDHTB3A2	F-frame		
MDME502S□ *	5.0kW						
1500r/min	MDME752S1 *		7.5kW	MGDHTC3B4	G-frame		
	MDMEC12S1 *		11.0kW	MHDHTC3B4	H-frame		
	MDMEC52S1 *		15.0kW				
3-phase, 400V	2000r/min		MDME044S1 *	400W	MDDHT2407	D-frame	
			MDME064S1 *	600W			
			MDME104S□ *	1.0kW	MDDHT2412		
			MDME154S□ *	1.5kW	MDDHT3420		
			MDME204S□ *	2.0kW	MEDHT4430	E-frame	
			MDME304S□ *	3.0kW	MFDHT5440	F-frame	
			MDME404S□ *	4.0kW			
			MDME504S□ *	5.0kW			
			1500r/min	MDME754S1 *	7.5kW		MGDHTB4A2
				MDMEC14S1 *	11.0kW	MHDHTB4A2	H-frame
MDMEC54S1 *				15.0kW			

Note

- Suffix of "□" in the applicable motor model represents design order.
- Suffix of " * " in the applicable motor model represents the motor structure.
- Default of the driver is set for the incremental encoder specifications.
When you use in absolute, make the following operations.
 - Install a battery for absolute encoder.
 - Switch the parameter Pr0.15 (Absolute encoder setup) from "1 (default)" to "0".
- Only for position control type does not support the 17-bit absolute specification.
It supports only 20-bit incremental specification.

4. Check of the Combination of the Driver and the Motor

Absolute Specifications, 17-bit

Motor					Driver	
Power supply	Type	Rated rotational speed	Model	Rated output	Model of velocity, position, torque and full-closed control type	Frame
Single/3-phase, 200V	MFME Middle inertia	2000r/min	MFME152S1 *	1.5kW	MDDHT5540	D-frame
3-phase, 200V			MFME252S1 *	2.5kW	MEDHT7364	E-frame
3-phase, 400V			MFME452S1 *	4.5kW	MFDHTB3A2	F-frame
			MFME154S1 *	1.5kW	MDDHT3420	D-frame
			MFME254S1 *	2.5kW	MEDHT4430	E-frame
			MFME454S1 *	4.5kW	MFDHTA464	F-frame
Single/3-phase, 200V	MGME Middle inertia	1000r/min	MGME092S□ *	0.9kW	MDDHT5540	D-frame
3-phase, 200V			MGME202S□ *	2.0kW	MFDHTA390	F-frame
			MGME302S□ *	3.0kW	MFDHTB3A2	
			MGME452S1 *	4.5kW		
			3-phase, 400V	MGME602S1 *	6.0kW	MGDHTC3B4
MGME094S□ *				0.9kW	MDDHT3420	D-frame
MGME204S□ *				2.0kW	MFDHT5440	F-frame
MGME304S□ *				3.0kW	MFDHTA464	
MGME454S1 *				4.5kW		
MGME604S1 *				6.0kW	MGDHTB4A2	G-frame
Single/3-phase, 200V	MHME High inertia	2000r/min	MHME102S□ *	1.0kW	MDDHT3530	D-frame
3-phase, 200V			MHME152S□ *	1.5kW	MDDHT5540	
			MHME202S□ *	2.0kW	MEDHT7364	E-frame
			MHME302S□ *	3.0kW	MFDHTA390	F-frame
			MHME402S□ *	4.0kW	MFDHTB3A2	
			MHME502S□ *	5.0kW		
3-phase, 400V		1500r/min	MHME752S1 *	7.5kW	MGDHTC3B4	G-frame
		2000r/min	MHME104S□ *	1.0kW	MDDHT2412	D-frame
			MHME154S□ *	1.5kW	MDDHT3420	
			MHME204S□ *	2.0kW	MEDHT4430	E-frame
			MHME304S□ *	3.0kW	MFDHT5440	F-frame
			MHME404S□ *	4.0kW	MFDHTA464	
			MHME504S□ *	5.0kW		
		1500r/min	MHME754S1 *	7.5kW	MGDHTB4A2	G-frame

Note

- Suffix of "□" in the applicable motor model represents design order.
- Suffix of " * " in the applicable motor model represents the motor structure.
- Default of the driver is set for the incremental encoder specifications.
When you use in absolute, make the following operations.
 - a) Install a battery for absolute encoder.
 - b) Switch the parameter Pr0.15 (Absolute encoder setup) from "1 (default)" to "0".
- Only for position control type does not support the 17-bit absolute specification.
It supports only 20-bit incremental specification.

1 Before Using the Products

4. Check of the Combination of the Driver and the Motor

Junction cable for motor

Encoder cable

Motor series	Incremental Specifications, 20-bit ^{Note)1}	Absolute Specifications, 17-bit ^{Note)1}	Detail page
MSMD 50W to 750W	MFECA0 ** 0EAM	—	7-98
MSME 50W to 750W (200V)	MFECA0 ** 0MJD (Highly bendable type, Direction of motor shaft)	MFECA0 ** 0MJE (Highly bendable type, Direction of motor shaft)	7-98 7-99
	MFECA0 ** 0MKD (Highly bendable type, Opposite direction of motor shaft)	MFECA0 ** 0MKE (Highly bendable type, Opposite direction of motor shaft)	
	MFECA0 ** 0TJD (Standard bendable type, Direction of motor shaft)	MFECA0 ** 0TJE (Standard bendable type, Direction of motor shaft)	
	MFECA0 ** 0TKD (Standard bendable type, Opposite direction of motor shaft)	MFECA0 ** 0TKE (Standard bendable type, Opposite direction of motor shaft)	
MSME 750W (400V), 1.0kW to 5.0kW	MFECA0 ** 0ESD ^{note)2} MFECA0 ** 0ETD ^{note)3}	MFECA0 ** 0ESE ^{note)2} MFECA0 ** 0ETE ^{note)3}	7-99 to 7-100
MDME 400W to 15.0kW	MFECA0 ** 0ESD ^{note)2} MFECA0 ** 0ETD ^{note)3}	MFECA0 ** 0ESE ^{note)2} MFECA0 ** 0ETE ^{note)3}	
MFME 1.5kW to 4.5kW	MFECA0 ** 0ETD	MFECA0 ** 0ETE	
MGME 0.9kW to 6.0kW	MFECA0 ** 0ESD ^{note)2} MFECA0 ** 0ETD ^{note)3}	MFECA0 ** 0ESE ^{note)2} MFECA0 ** 0ETE ^{note)3}	
MHMD 200W to 750W	MFECA0 ** 0EAM	—	
MHME 1.0kW to 7.5kW	MFECA0 ** 0ESD ^{note)2} MFECA0 ** 0ETD ^{note)3}	MFECA0 ** 0ESE ^{note)2} MFECA0 ** 0ETE ^{note)3}	

Note)1 “ ** ” represents the cable length. Note)2 Design order: C (0.9kW to 5.0kW (MGME: to 3.0kW)) Note)3 Design order:1


Motor cable/ Brake cable

Motor series	Motor cable ^{Note)1}		Brake cable ^{Note)1}	Detail page
	without Brake	with Brake		
MSMD 50W to 750W	MFMC A0 ** 0EED	—	MFMC B0 ** 0GET	7-101 7-106
MSME 50W to 750W	MFMC A0 ** 0NJD (Highly bendable type, Direction of motor shaft)	—	MFMC B0 ** 0PJT (Highly bendable type, Direction of motor shaft)	7-101 7-106
	MFMC A0 ** 0NKD (Highly bendable type, Opposite direction of motor shaft)		MFMC B0 ** 0PKT (Highly bendable type, Opposite direction of motor shaft)	
	MFMC A0 ** 0RJ D (Standard bendable type, Direction of motor shaft)		MFMC B0 ** 0SJT (Standard bendable type, Direction of motor shaft)	
	MFMC A0 ** 0RKD (Standard bendable type, Opposite direction of motor shaft)		MFMC B0 ** 0SKT (Standard bendable type, Opposite direction of motor shaft)	
MSME 1.0kW to 2.0kW (200V)	MFMC D0 ** 2ECD	MFMC A0 ** 2FCD	—	7-102 to 7-106
MSME 750W to 2.0kW (400V)		MFMC E0 ** 2FCD		
MSME 3.0kW to 5.0kW	MFMC A0 ** 3ECT	MFMC A0 ** 3FCT		
MDME 1.0kW to 2.0kW (200V)	MFMC D0 ** 2ECD	MFMC A0 ** 2FCD	—	
MDME 400W to 2.0kW (400V)		MFMC E0 ** 2FCD		
MDME 3.0kW to 5.0kW	MFMC A0 ** 3ECT	MFMC A0 ** 3FCT		
MFME 1.5kW (200V)	MFMC A0 ** 2ECD	MFMC A0 ** 2FCD		
MFME 1.5kW (400V)	MFMC F0 ** 2ECD	MFMC E0 ** 2FCD	—	
MFME 2.5kW				
MFME 4.5kW	MFMC D0 ** 3ECT	MFMC A0 ** 3FCT		
MGME 0.9kW (200V)	MFMC D0 ** 2ECD	MFMC A0 ** 2FCD	—	
MGME 0.9kW (400V)		MFMC E0 ** 2FCD		
MGME 2.0kW to 4.5kW	MFMC A0 ** 3ECT	MFMC A0 ** 3FCT		
MHMD 200W to 750W	MFMC A0 ** 0EED	—	MFMC B0 ** 0GET	
MHME 1.0kW, 1.5kW (200V)	MFMC D0 ** 2ECD	MFMC A0 ** 2FCD	—	
MHME 1.0kW, 1.5kW (400V)		MFMC E0 ** 2FCD		
MHME 2.0kW	MFMC E0 ** 2ECD			
MHME 3.0kW to 5.0kW	MFMC A0 ** 3ECT	MFMC A0 ** 3FCT		

Note)1 “ ** ” represents the cable length.



• Motor cable (for MHME 7.5kW, MGME 6.0kW, MDME 7.5kW to 15.0kW) is not prepared in option.



• For other cable, connector and connector kit, refer to P.7-100 “Options”

1 Before Using the Products

5. Installation Driver

Install the driver properly to avoid a breakdown or an accident.

Installation Place

- 1) Install the driver in a control panel enclosed in noncombustible material and placed indoor where the product is not subjected to rain or direct sunlight. The products are not waterproof.
- 2) Where the products are not subjected to corrosive atmospheres such as hydrogen sulfide, sulfurous acid, chlorine, ammonia, sulfur, chloric gas, sulfuric gas, acid, alkaline and salt and so on, and are free from splash of inflammable gas.
- 3) Where the motor is free from grinding oil, oil mist, iron powder or chips.
- 4) Well-ventilated and low humidity and dust-free place.
- 5) Vibration-free place.
- 6) Do not use benzine, thinner, alcohol, acidic cleaner and alkaline cleaner because they can discolor or damage the exterior case.

Environmental Conditions

Item	Conditions
Ambient temperature	0°C to 55°C (free from freezing)
Ambient humidity	20% to 85% RH (free from condensation)
Storage temperature*1	-20°C to 65°C (Max. temperature guarantee: 80°C for 72 hours free from condensation*2)
Storage humidity	20% to 85% RH (free from condensation*2)
Vibration	Lower than 5.88m/s ² (0.6G), 10 to 60Hz
Altitude	Lower than 1000m

*1 Extreme temperatures are permissible only for short period such as during transportation.

*2 Air containing water vapor will become saturated with water vapor as the temperature falls, causing dew.

How to Install

- 1) Rack-mount type. Install in vertical position, and reserve enough space around the servo driver for ventilation.
- 2) Base mount (rear mount) is standard for A/B/C/D-frame driver.
- 3) To change the mounting surface of A/B/C/D-frame driver, use the optional mounting bracket. For choosing the correct optional mounting bracket, refer to P.7-119 "Mounting Bracket".
- 4) In consideration of strength of the screws and the material of the mounting base, select appropriate fastening torque for the product mounting screws, so that the screws will not be loosened or damaged.

Example) To tighten a steel screw into a steel base

A to G-frame: M5 2.7 to 3.3 N·m, H-frame: M6 4.68 to 5.72 N·m

A to D-frame

Basemount (Standard)
[Rear mount]

Frontmount

[Use mounting bracket]


E to G-frame

Front or rear mount


[Use mounting bracket]

H-frame

Rearmount [Basemount]




Fastening torque of ground terminal (M4)
to be 0.7 to 0.8 N·m.



Mounting bracket
(optional parts)


<E-frame>



Mounting bracket
(Attachment)

Fastening torque of ground terminal (M4)
to be 0.7 to 0.8 N·m.

<F, G-frame> Fastening torque of ground terminal (M5)
to be 1.4 to 1.6 N·m.




Fastening torque of
ground terminal (M6)
to be 2.4 to 2.6 N·m.

5. Installation

Driver

Mounting Direction and Spacing

- Reserve enough surrounding space for effective cooling.
- Install fans to provide uniform distribution of temperature in the control panel.
- D to H-frame is provided with a cooling fan at the bottom. (On the H-frame, the cooling fan is also installed on the upper side.)
- Observe the environmental conditions of the control panel described in the previous page.



Note

It is recommended to use the conductive paint when you make your own mounting bracket, or repaint after peeling off the paint on the machine for installing the products, in order to make noise countermeasure.

Caution on Installation

Caution

- Whenever lifting the product (during transportation/installation of H frame servo driver), two or more persons should hold it by metallic member, not by **plastic member**.
- We have been making the best effort to ensure the highest quality, however, application of exceptionally large external noise disturbance and static electricity, or failure in input power, wiring and components may result in unexpected action. It is highly recommended that you make a fail-safe design and secure the safety in the operative range.
- If stranded wires are used as the cable, bunch the conductors of the cable using a rod terminals or a round terminals. If stranded wires are used as they are, unexpected accidents such as an electric shock and short circuit or injury may result.
- There might be a chance of smoke generation due to the failure of these products. Pay an extra attention when you apply these products in a clean room environment.
- Be sure to install a no-fuse breaker in the power supply. In addition, be sure to ground the grounding terminal or grounding wire provided. (In order to prevent electric shock and malfunctions, Class D grounding (grounding resistance of 100Ω or less) is recommended.)
If the product is grounded insufficiently, not only the driver may not deliver its performance sufficiently, but also safety hazards such as a malfunction due to a electrification or a disturbance may be caused.
- If electric wires are bound and run through metal duct, they cannot carry the rated current due to temperature rise. If they are forced to carry the rated current, they may burn. When determining size of the wire.
- Do not use or store the product in a place subject to 5.88 m/s² or more vibration or shock, foreign materials such as dust, metallic powder and oilmist, liquids such as water, oil and grinding fluid, close to flammable materials, or in an atmosphere of corrosive gas (H₂S, SO₂, NO₂, Cl₂, etc.) or inflammable gas under any circumstance.

Related page

- P.1-11 "Specifications" • P.1-32 "Installation of motor"
- P.7-73 "Dimensions" • P.7-119 "Mounting bracket"

5. Installation

Driver

- Be sure to conduct wiring properly and securely. Insecure or improper wiring may cause the motor running out of control or being damaged from overheating. In addition, pay attention not to allow conductive materials, such as wire chips, entering the driver during the installation and wiring.
- Secure the screws and earth screw on the terminal block with the torque specified in the specification.
- When establishing a system using safety functions, completely understand the applicable safety standards and the operating instruction manual or technical documents for the product.
- Never make an approach to the motor and the machine(s) driven by the motor while power is applied because they may become failure or malfunction.
- Do not use servo-on signal (SRV-ON) as the start/stop signal. Doing so may damage the built-in dynamic brake circuit in the driver.
- Pay attention to the heat dissipation. The driver will generate heat while the motor is in operation. Using the driver in a sealed control box may cause an abnormal heating of the control box. A proper consideration should be given to cool the driver so that the ambient temperature matches the specified operating temperature range.
- There is a possibility that the motor will be damaged by heat or emit smoke or dust due to a fault in the motor itself or the driver coupled with it. A proper consideration should be given if the motor is used in a clean room or similar environment.
- The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal.
- If the dynamic brake is applied during operation at a high speed, provide approx. 10-minute dwell period.
Restarting the motor earlier may cause a broken wire in the dynamic brake making the brake inoperable.
- The capacitance of capacitor in the power supply rectifier circuit decreases its capacitance with age.
To prevent a secondary accident due to malfunction, it should be replaced with new one after 5-year use.
Replacement should be performed by us or our authorized distributor.
- Before using the product, be sure to read the instruction manual (Safety part).

Recommended Electric Wires for Driver

- For the main circuit, use electric wire that withstands at least 600 VAC with temperature rating 75°C or higher.
- When using bundled wires running through metallic conduit, the amounts of current determined according to the reduction rate must be subtracted from the nominal allowable current.
- Electric wires
 - <In high ambient temperature>**
Use heat resistant wire.
Common polyvinyl chloride wires will deteriorate by heat at a higher rate.
 - <In low ambient temperature>**
The surface of vinyl chloride insulation becomes hardened and brittle at low temperature and needs specific protective measure when used in cold region.
- Bend radius of the cable must be 10 times or more its finish outside diameter.
- Cables cannot be used for continuous regeneration because they are not designed for such application.

5. Installation

Driver

Relationship between Wire Diameter and Permissible Current

- When selecting a cable, refer to the following selection guide showing relationship between cable specification and current carrying capacity.

Example: Power supply 3-phase, 200 V, 35 A, ambient temperature 30°C

Determine the fundamental permissible current according to the cable conductor material (example: stranded copper wire). (For the purpose of this example, the ampere indicated by ◇ is selected from the table right.)

Next, determine the number of conductors. (In this example, the cable contains 4 conductors (3 + ground).) Determine the applicable permissible current using the following formula.

Applicable permissible current

= fundamental permissible current x current reduction coefficient x current correction coefficient
= 37 x 0.7 x 1.414
= 36.6 (A)

This permissible value is larger than 35 A to be carried though the cable. Therefore, according to the list of recommended eco-cables, the cable to be selected for the cable with nominal cross section 3.5 mm² is a polyethylene-insulated heat-resistant 4-conductor power cable having 13.5 mm finish O.D. (approx. 14.5 mm with shield).

Fundamental permissible current

Stranded conductor (nominal cross section: mm ²)	Copper wire (unit: A)
2 to 3.5 (excl.)	27
3.5 to 5.5 (excl.)	37
5.5 to 8 (excl.)	49
8 to 14 (excl.)	61
14 to 22 (excl.)	88
11 to 30 (excl.)	115
30 to 38 (excl.)	139
38 to 68 (excl.)	162
60 to 100 (excl.)	217
100 to 150 (excl.)	298
150 to 200 (excl.)	395

<Supplement>

- The current correction coefficient is determined using the following formula:

$$\sqrt{(\text{Max. permissible temp.} - \text{ambient temp.}) \div 30}$$

Caution

The current correction coefficient is determined according to the cable. Check the specification of the cable used.

- The current reduction coefficient is provided for the case where the cable (4-conductor cable in the case of example), is housed in plastic race/sheath, plastic tube, metal race/sheath, metal tube or flexible conduit.

Caution

Because the neutral conductor is not counted as a wire, the current reduction coefficient for "3 or less" is applied as indicated by (◎) in the table right.

Current reduction coefficient

No. of wires in a tube	Coefficient
Up to 3	0.70
4	0.63
5 or 6	0.56
7 to 15	0.49
16 to 40	0.43
41 to 60	0.39
61 or more	0.34

Recommended eco-cable

Wire category: 4-conductor polyethylene-insulated power cable with heat-resistant polyethylene sheath (Standard: EM JIS C 3605) Maximum permissible temperature: 90°C

Conductor			Insulation thickness (mm)	Sheath thickness (mm)	(Reference) Finish O.D. (mm)	Max. conductor resistance (20°C) (W/km)	Test voltage (V/1 min.)	Minimum insulation resistance (MW·km)	(Reference) Approx. mass (kg/km)
Nominal cross section (mm ²)	Structure or shape (wires/mm ²)	Outside diameter (mm)							
2	7/0.6	1.8	0.8	1.5	12.0	9.42	1500	2500	170
3.5	7/0.8	2.4	0.8	1.5	13.5	5.30	1500	2500	250
5.5	7/1.0	3.0	1.0	1.5	16.0	3.40	1500	2500	360
8	7/1.2	3.6	1.0	1.5	17.0	2.36	1500	2000	475
14	Circular compression	4.4	1.0	1.5	19.0	1.34	2000	1500	730
22	Circular compression	5.5	1.2	1.6	23	0.849	2000	1500	1100
38	Circular compression	7.3	1.2	1.8	28	0.491	2500	1500	1800
60	Circular compression	9.3	1.5	2.0	35	0.311	2500	1500	2790
100	Circular compression	12.0	2.0	2.4	44	0.187	2500	1500	4630
150	Circular compression	14.7	2.0	2.6	51	0.124	3000	1000	6710
200	Circular compression	17.0	2.5	2.9	60	0.0933	3000	1500	8990

Caution

Shield will increase finish outside diameter by approx. 1 mm.

Note

- Appropriate cable should be selected to have sufficient allowance for parameters such as operating ambient temperature and current.
- Current reduction coefficient, fundamental permissible current, etc., stated on this page are subject to change due to e.g. standard revision. Consult cable manufacturers for the latest information.

Install the motor properly to avoid a breakdown or an accident.

Installation Place

Since the conditions of location affect a lot to the motor life, select a place which meets the conditions below.

- 1) Indoors, where the products are not subjected to rain or direct sun beam. The products are not waterproof.
- 2) Where the products are not subjected to corrosive atmospheres such as hydrogen sulfide, sulfurous acid, chlorine, ammonia, sulfur, chloric gas, sulfuric gas, acid, alkaline and salt and so on, and are free from splash of inflammable gas.
- 3) Where the motor is free from grinding oil, oil mist, iron powder or chips.
- 4) Well-ventilated and humid and dust-free place, far apart from the heat source such as a furnace.
- 5) Easy-to-access place for inspection and cleaning
- 6) Vibration-free place.
- 7) Avoid enclosed place. Motor may get hot in those enclosure and shorten the motor life.

Environmental Conditions

Item		Conditions
Ambient temperature*1		0°C to 40°C (free from freezing)
Ambient humidity		20% to 85% RH (free from condensation)
Storage temperature*2		-20°C to 65°C (Max. temperature guarantee: 80°C for 72 hours free from condensation*5)
Storage humidity		20% to 85% RH (free from condensation*5)
Vibration	Motor only	Lower than 49m/s ² (5G) at running, 24.5m/s ² (2.5G) at stall
Impact	Motor only	Lower than 98m/s ² (10G)
Enclosure rating	Motor only (Connector type)	IP67 (except rotating portion of output shaft and connecting pin part of the motor connector and the encoder connector)*3*4
Altitude		Lower than 1000m

*1 Ambient temperature to be measured at 5cm away from the motor.

*2 Permissible temperature for short duration such as transportation.

*3 These motors conform to the test conditions specified in EN standards (EN60529, EN60034-5). Do not use these motors in application where water proof performance is required such as continuous wash-down operation.

*4 This condition is applied when the connector mounting screw in case of motor 750W or less are tightened to the recommended tightening torque (Refer to P.2-11, 2-48). Be sure to use mounting screw supplied with the connector. Correctly install and secure the gasket supplied with the cable connector.

*5 Air containing water vapor will become saturated with water vapor as the temperature falls, causing dew.

How to Install

You can mount the motor either horizontally or vertically as long as you observe the followings.

1) Horizontal mounting

- Mount the motor with cable outlet facing downward for water/oil countermeasure.

2) Vertical mounting


- Use the motor with oil seal (make-to-order in case of motor 750W or less) when mounting the motor with gear reducer to prevent the reducer oil/grease from entering to the motor.

5. Installation

Motor

Oil/Water Protection

- 1) Don't submerge the motor cable to water or oil.
- 2) Install the motor with the cable outlet facing downward.
- 3) Avoid a place where the motor is always subjected to oil or water.
- 4) Use the motor with an oil seal when used with the gear reducer, so that the oil may not enter to the motor through shaft.



Stress to Cables

- 1) Avoid a stress application to the cable outlet and connecting portion by bending or self-weight.
- 2) Especially in an application where the motor itself travels, fix the junction cable into the bearer so that the stress by bending can be minimized.
- 3) Take the cable bending radius as large as possible. (When you use our optional cable, Minimum R20mm)

Permissible Load to Output Shaft


- 1) Design the mechanical system so that the applied radial load and/or thrust load to the motor shaft at installation and at normal operation can meet the permissible value specified to each model.
- 2) Pay an extra attention when you use a rigid coupling. (Excess bending load may damage the shaft or deteriorate the bearing life.)
- 3) Use a flexible coupling with high stiffness designed exclusively for servo application in order to make a radial thrust caused by micro misalignment smaller than the permissible value.

Note

For permissible load of each model, refer to P.1-35, "Permissible Load at Output Shaft".

Notes on Installation

- 1) Do not apply direct impact to the shaft by hammer while attaching/detaching a coupling to and from the motor shaft.
(Or it may damage the encoder mounted on the other side of the shaft.)
- 2) Make a full alignment. (incomplete alignment may cause vibration and damage the bearing.)
- 3) If the motor shaft is not electrically grounded, it may cause electrolytic corrosion to the bearing depending on the condition of the machine and its mounting environment, and may result in the bearing noise. Check and verification by customer is required.



Related page

- P.1-27 "Junction cable for motor" • P.1-28 "Installation of driver"
- P.1-35 "Permissible Load at Output Shaft" • P.7-79 "Dimensions"

Wiring Precautions on Movable Section

When wiring cable bear, take the following precautions:

- **Cable bear wiring**


The bend radius of the cable must be 10 times or more its finish outside diameter.

(For finish outside diameter, refer to P.1-31 How to Install, “Relationship between Wire Diameter and Permissible Current” and associated tables.)

Do not fix or bundle wires in the cable bear.

When securing the cable, fix it only at non-movable ends of the cable bear where the cable is free from any stress (e.g. tension). (Avoid tight lock.)

[Recommended cable bear wiring]



Caution

Do not keep the cable loosened (too long) or under tension (too short).

Otherwise, the sheath will be cracked by internal wall of the cable bear, tangled by other cable, etc., causing unpredictable troubles.

- **Cable distortion**

Keep the cable free from twists or kinks.

Distorted cable will cause loose connection, lowering performance and reliability.


- **Lamination factor of cable in cable bear**

Place cables on a flat surface in parallel without bringing them into contact with each other and measure the dimension necessary to cover these cables. Then select a cable bear which is wider than the measured dimension.


The lamination factor of cables should be lower than 60% (recommended factor is 30% or below).

Do not run smaller and larger size cables in the same cable bear. Thin cables may break under the pressure of thick cables. If it is necessary to mix cables of different size, isolate them by using suitable separating material such as partition.


[Wiring arrangement in cable bear – example]



Radial load (P) direction



Thrust load (A and B) direction



Unit : N (1kgf=9.8N)


Motor series	Motor output	At assembly			During running	
		Radial thrust	Thrust load		Radial thrust	Thrust load A and B-direction
			A-direction	B-direction		
MSMD	50W, 100W	147	88	117.6	68.6	58.8
	200W, 400W	392	147	196	245	98
	750W	686	294	392	392	147
MSME	50W, 100W	147	88	117.6	68.6	58.8
	200W, 400W	392	147	196	245	98
	750W (200V)	686	294	392	392	147
	750W (400V), 1.0kW, 1.5kW, 2.0kW, 3.0kW	980	588	686	490	196
	4.0kW, 5.0kW				784	343
MDME	400W to 2.0kW	980	588	686	490	196
	3.0kW				784	343
	4.0kW	1666	784	980		
	5.0kW			2058	980	1176
	7.5kW	2058	980			
	11.0kW, 15.0kW	4508	1470	1764	2254	686
MGME	0.9kW	980	588	686	686	196
	2.0kW	1666	784	980	1176	490
	3.0kW	2058	980	1176	1470	
	4.5kW				1764	588
	6.0kW					
MFME	1.5kW	980	588	686	490	196
	2.5kW, 4.0kW	1862	686		784	294
MHMD	200W, 400W	392	147	196	245	98
	750W	686	294	392	392	147
MHME	1.0kW, 1.5kW	980	588	686	490	196
	2.0kW to 5.0kW	1666	784	980	784	343
	7.5kW	2058	980	1176	1176	490

Note

When the load point varies, calculate the permissible radial load, P (N) from the distance of the load point, L (mm) from the mounting flange based on the formula of the right table, and make it smaller than the calculated result.

6. Permissible Load at Output Shaft

Motor



Motor series	Motor output	Formula of Load and load point relation	Motor series	Motor output	Formula of Load and load point relation
MSMD	50W	$P = \frac{3533}{L+39}$	MGME	0.9kW	$P = \frac{33957}{L+14.5}$
	100W	$P = \frac{4905}{L+59}$		2.0kW	$P = \frac{69384}{L+19}$
	200W	$P = \frac{14945}{L+46}$		3.0kW	$P = \frac{86730}{L+19}$
	400W	$P = \frac{19723}{L+65.5}$		4.5kW 6.0kW	$P = \frac{89964}{L+20}$
	750W	$P = \frac{37044}{L+77}$	MFME	1.5kW	$P = \frac{25235}{L+19}$
MSME	50W	$P = \frac{3533}{L+39}$		2.5kW	$P = \frac{40376}{L+19}$
	100W	$P = \frac{4905}{L+59}$		4.0kW	$P = \frac{42336}{L+19}$
	200W	$P = \frac{14945}{L+46}$	MHMD	200W	$P = \frac{14945}{L+46}$
	400W	$P = \frac{19723}{L+65.5}$		400W	$P = \frac{19723}{L+65.5}$
	750W (200V)	$P = \frac{37044}{L+77}$		750W	$P = \frac{37044}{L+77}$
	750W (400V) 1.0kW to 3.0kW	$P = \frac{20090}{L+13.5}$	MHME	1.0kW 1.5kW	$P = \frac{24255}{L+14.5}$
	4.0kW 5.0kW	$P = \frac{36848}{L+14.5}$		2.0kW to 5.0kW	$P = \frac{46256}{L+19}$
MDME	400W 600W	$P = \frac{20090}{L+13.5}$		7.5kW	$P = \frac{89964}{L+20}$
	1.0kW to 2.0kW	$P = \frac{20580}{L+14.5}$			
	3.0kW	$P = \frac{36848}{L+14.5}$			
	4.0kW 5.0kW	$P = \frac{42336}{L+19}$			
	7.5kW	$P = \frac{89946}{L+20}$			
	11.0kW 15.0kW	$P = \frac{200606}{L+31}$			

2. Preparation

1. Conformance to international standards	
EC Directives	2-2
Composition of Peripheral Equipments	2-6
2. System Configuration and Wiring	
Driver and List of Applicable Peripheral Equipments	2-10
A to G-frame, 100/200 V type:	
Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram	2-12
E-frame, 200 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram	2-16
F-frame, 200 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram	2-20
G-frame, 200 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram	2-24
H-frame, 200 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram	2-28
D, E-frame, 400 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram	2-32
F-frame, 400 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram	2-36
G-frame, 400 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram	2-40
H-frame, 400 V type: Overall Wiring/ Wiring of the Main Circuit/ Wiring Diagram	2-44
Specifications of Motor connector	2-48
Wiring method to connector	2-50
3. Wiring to the connector, X1	
Connecting host computer	2-51
4. Wiring to the connector, X2	
Connecting communication connector	2-51
5. Wiring to the connector, X3	
Safety function connector	2-53
6. Wiring to the connector, X4	
Connection to Host Controller	2-54
7. Wiring to the connector, X5	
Connect on to External Scale	2-55
8. Wiring to the connector, X6	
Connection to Encoder	2-57
9. Wiring to the connector, X7	
Monitor output	2-60
10. Timing Chart	
Timing on power-up	2-61
Alarm	2-62
Servo-Lock	2-63
Servo-ON/OFF	2-64
11. Built-in Holding Brake	
Outline	2-65
Specifications	2-66
12. Dynamic Brake	
Outline	2-67
Connections of external dynamic brake resistor (Example)	2-68
Condition setting chart	2-70
13. Setup of Parameter and Mode	
Outline / Setup / Connection	2-72
Composition and List of Parameters	2-73
List of Parameters	2-74
Setup of Torque Limit	2-82
14. Setup of command division and multiplication ratio (electronic gear ratio)	
Relation between Electronic Gear and Position Resolution or Traveling Speed	2-84
15. How to Use the Front Panel	
Setup	2-86
Structure of Each Mode	2-88
Setup of front panel lock	2-90
Monitor Mode (SELECTION display)	2-91
Monitor Mode (EXECUTION display)	2-92
Parameter Setup Mode	2-106
EEPROM Writing Mode	2-107
Auxiliary Function Mode (SELECTION display)	2-108
Auxiliary Function Mode (EXECUTION display)	2-109

EC Directives

The EC Directives apply to all such electronic products as those having specific functions and have been exported to EU and directly sold to general consumers. Those products are required to conform to the EU unified standards and to furnish the CE marking on the products.


However, our AC servos meet the relevant EC Directives for Low Voltage Equipment so that the machine or equipment comprising our AC servos can meet EC Directives.

EMC Directives

MINAS Servo System conforms to relevant standard under EMC Directives setting up certain model (condition) with certain locating distance and wiring of the servo motor and the driver. And actual working condition often differs from this model condition especially in wiring and grounding. Therefore, in order for the machine to conform to the EMC Directives, especially for noise emission and noise terminal voltage, it is necessary to examine the machine incorporating our servos.

Conformity to UL Standards

Observe the following conditions of (1) and (2) to make the system conform to UL508C (E164620).

- (1) Use the driver in an environment of Pollution Degree 2 or 1 prescribed in IEC60664-1. (e.g. Install in the control box with IP54 enclosure.)
- (2) Make sure to install a circuit breaker or fuse which are UL recognized (Listed ) marked) between the power supply and the noise filter.

Remarks

Use a copper cable with temperature rating of 75°C or higher.

Note

For rated current of circuit breaker and fuse, refer to P.2-10 "Driver and List of Applicable Peripheral Equipments".

- (3) Over-load protection level

Over-load protective function will be activated when the effective current exceeds 115% or more than the rated current based on the time characteristics (see the next page). Confirm that the effective current of the driver does not exceed the rated current. Set up the peak permissible current with Pr0.13 (Setup of 1st torque limit) and Pr5.22 (Setup 2nd torque limit).

SEMI F47

- Includes a function in compliance with the SEMI F47 standard for voltage sag immunity under no load or light load.
- Ideal for the semiconductor and LCD industries.

Caution

- (1) Excluding the single-phase 100-V type.
- (2) Please verify the actual compliance of your machine with the F47 standard for voltage sag immunity.

Note

For Overload protection time characteristics, refer to P.6-14.

1. Conformance to international standards

EC Directives

Conformed Standards

		Driver	Motor
EC Direc- tives	EMC Directives	EN55011 EN61000-6-2 EN61800-3	—
	Low-Voltage Directives	EN61800-5-1	EN60034-1 EN60034-5
	Machinery Directives Functional safety (*1)	EN954-1 (Cat. 3) ISO13849-1 (PL c,d)(Cat. 3) EN61508 (SIL 2) EN62061 (SIL 2) EN61800-5-2 (STO) IEC61326-3-1	—
UL Standards		UL508C (E164620)	UL1004-1 (E327868: to 750W (200V) from 6.0kW) UL1004 (E327868: 400W (400V) 600W (400V), 750W (400V) 0.9kW to 5.0kW)
CSA Standards		C22.2 No.14	C22.2 No.100

IEC : International Electrotechnical Commission

EN : Europaischen Normen

EMC : Electromagnetic Compatibility

UL : Underwriters Laboratories

CSA : Canadian Standards Association

Pursuant to the directive 2004/108/EC, article 9(2)

Panasonic Testing Centre

Panasonic Service Europe, a division of

Panasonic Marketing Europe GmbH

Winsbergring 15, 22525 Hamburg, F.R. Germany

* Only for position control type does not support functional safety^(*1) standards.

Caution

Use options correctly after reading Operating Instructions of the options to better understand the precautions.


Take care not to apply excessive stress to each optional part.

1. Conformance to international standards

EC Directives

Installation Environment


Use the servo driver in the environment of Pollution Degree 1 or 2 prescribed in IEC-60664-1 (e.g. Install the driver in control panel with IP54 protection structure.)



*1 A to D-frame: Noise filter for signal lines, E to H-frame: Noise filter for signal lines <Power supply cable>

*2 A to F-frame: Noise filter for signal lines, G, H-frame: Noise filter for signal lines <Motor cable>

*3 Only for position control type is not provided with X3 terminal.



*1 D to F-frame: Noise filter for signal lines, G, H-frame: Noise filter for signal lines <Power supply cable>

*2 D to F-frame: Noise filter for signal lines, G, H-frame: Noise filter for signal lines <Motor cable>

*3 Only for position control type is not provided with X3 terminal.

• Mandatory requirements to conform to EMC directive

- Install the servo driver on the metallic casing (control board).
- Install noise filter and lightning surge absorber in the power supply line.
- Use braided shield cable (tin plated annealed copper wire) for I/O signal cable and encoder cable.
- Provide the noise filter, as shown in the figure, for each cable, I/O line and power source line to be connected to the servo driver.
- Shield of cables not shown on the figure should be directly grounded through PE.

Because these conditions for EMC directive are affected by status of connected devices, wiring, connection and location, compliance should be checked after completing installation.

1. Conformance to international standards

EC Directives

• Details of cable (left-hand figure)

Symbol	From	To	Cable function	Length	Remarks	Shield	Noise filter for signal lines
①	Breaker	Noise filter	Power line	2m	Single phase or 3-phase	none	none
②	Noise filter	Servo driver	Power line	2m	—	none	with
③	Servo driver	Servo motor	Junction cable for motor	20m	—	*1	with
④	Servo driver	Servo motor	Junction cable for encoder	20m	—	with	with
⑤	Switch box	Servo driver	I/O cable	3m	—	with	with
⑥	Frame ground	Noise filter	FG line	1m	—	none	none
⑦	Frame ground	Noise filter	FG line	1m	—	none	none
⑧	AC power supply	Switch box	Power line	1m	—	none	none

*1 Frame A to F: none, Frame G and H: with.

• Refer to P.2-6 for a left-hand figure and the list of the Peripheral Equipments after .

Caution

Use options correctly after reading Operating Instructions of the options to better understand the precautions.

Take care not to apply excessive stress to each optional part.

Power Supply



100V type : (A to C-frame)	Single phase, 100V	+10% -15%	to	120V	+10% -15%	50/60Hz
200V type : (A to D-frame)	Single/3-phase, 200V	+10% -15%	to	240V	+10% -15%	50/60Hz
200V type : (E to H-frame)	3-phase, 200V	+10% -15%	to	230V	+10% -15%	50/60Hz
400V type : Main power supply (D to H-frame)	3-phase, 380V	+10% -15%	to	480V	+10% -15%	50/60Hz
: Control power supply		DC 24V \pm 15%				

(1) This product is designed to be used in over-voltage category (installation category) III of EN 61800-5-1:2007.

(2) Use an insulated power supply of DC12 to 24V which has CE marking or complies with EN60950.

Remarks

- Use sheathed (jacketed) cable, twisted cable or closely bundled cable for power cable.
- Power cable and signal wires must be sufficiently isolated from each other.



Circuit Breaker

Install a circuit breaker which complies with IEC Standards and UL recognized (Listed and UL marked) between power supply and noise filter.

The short-circuit protection circuit on the product is not for protection of branch circuit. The branch circuit should be protected in accordance with NEC and the applicable local regulations in your area.

Note

For driver and applicable peripheral equipments, refer to P.2-10 "Driver and List of Applicable Peripheral Equipments".

1. Conformance to international standards

Composition of Peripheral Equipments

Noise Filter


Option part No.	Voltage specifications for driver	Manufacturer's part No.	Applicable driver (frame)	Manufacturer
DV0P4170	Single phase 100V/200V	SUP-EK5-ER-6	A, B-frame	Okaya Electric Ind.
DV0PM20042	3-phase 200V	3SUP-HU10-ER-6	A, B-frame	
	Single phase 100V/200V 3-phase 200V		C-frame	
DV0P4220	Single/ 3-phase 200V	3SUP-HU30-ER-6	D-frame	
DV0PM20043	3-phase 200V	3SUP-HU50-ER-6	E-frame	
DV0P3410	3-phase 200V	3SUP-HL50-ER-6B	F-frame	

• Recommended components


Model No.	Voltage specifications for driver	Rated current	Applicable driver (frame)	Manufacturer
RTHN-5010	3-phase 200V	10	A, B, C-frame	TDK-Lambda Corp.
RTHN-5030		30	D-frame	
RTHN-5050		50	E, F-frame	
FS5559-60-34		60	G-frame	Schaffner
FS5559-80-34		80	H-frame	
FN258L-16-07	3-phase 400V	16	D, E-frame	
FN258L-30-07		30	F-frame	
FN258-42-07		42	G, H-frame	
FN258-42-33		42		

Remarks

- Select a noise filter whose capacity is commensurate with the power source capacity (in consideration of the load condition).
- For the detailed specifications of each noise filter, contact the manufacturer.
- When two or more servo drivers are used with a single noise filter at the common power source, consult with the noise filter manufacturer.
- Do not run the input and output wiring on the same passage: noise resistance will drop. (Figure at lower right)
- Isolate the input and output line from each other. (Figure at lower left)



The effect of the noise filter is a little.



Do not place the input and output lines in the same duct or do not tie both in a bundle.

Surge Absorber

Option part No.	Voltage specifications for driver	Manufacturer's part No.	Manufacturer
DV0P1450	3-phase 200V	R·A·V-781BXZ-4	Okaya Electric Ind.
DV0P4190	Single phase 100V/200V	R·A·V-781BWZ-4	
DV0PM20050	3-phase 400V	R·A·V-801BXZ-4	

Remarks

When performing withstand voltage test of machine and equipment, be sure to remove the surge absorber; otherwise, it will be damaged.

Related page

• P.2-10 "Driver and List of Applicable Peripheral Equipments" • P.7-94 "Option"

1. Conformance to international standards

Composition of Peripheral Equipments

Noise Filter for Signal Lines

Signal line, Encoder line, Control power line, Power line (A to D-frame: 100V/ 200V and D to F-frame: 400V) and Motor line (A to F-frame).




Option part No.	Manufacturer's part No.	Manufacturer
DV0P1460	ZCAT3035-1330	TDK Corp.

• Recommended components

Option part No.	Manufacturer's part No.	Applicable driver (frame)	Manufacturer
Power cable	RJ8035	E-frame 200 V, F-frame 200 V	KK-CORP.CO.JP
	RJ8095	G, H-frame	
Motor cable	T400-61D	G, H-frame	MICROMETALS

<Attaching signal noise filter>

- Signal wire Wind cables the number of turns required to form the signal noise filter.
- Power wire If sheathed (jacketed): remove the sheath (jacket) to the length so that wires (L1, L2, L3) can be wound on the signal noise filter (including power line dedicated filter). For effective noise reduction capability, L1, L2 and L3 should be wound together.
If not effective, increase the number of signal noise filters (including power line dedicated filters). (See figure below.)
- Motor line When installing the signal noise filter (including motor line dedicated filter) to our optional cable, remove the sheath (jacket) to the length so that wires can be wound on the signal noise filter (including power line dedicated filter). For effective noise reduction capability, U, V and W should be wound together.
If not effective, increase the number of signal noise filters (including power line dedicated filters). (See figure below.)
- Encoder line Wind cables the number of turns required to form the signal noise filter.



1. Conformance to international standards

Composition of Peripheral Equipments

Residual current device

Install a type B Residual current device (RCD) at primary side of the power supply.

Grounding

- (1) To prevent electric shock, be sure to connect the ground terminal (⊕) of the driver, and the ground terminal (PE) of the control panel.
- (2) The ground terminal (⊕) must not be shared with other equipment. Two ground terminals are provided.

Structure of control board

If there is a gap at cable inlet/outlet, mounting hole of operation panel or a door, radio waves will penetrate into or radiate out through the gap. To prevent unfavorable conditions due to radio frequency activities, observe the following control board design and selection instruction.

- The control board should be made of metal which provides electrical continuity.
- The control board should not have electrically-isolated conductor.
- All units installed in the casing should be grounded to the case.

Increasing noise resistance of control I/O signal

When noise is applied to the control input/output, it causes displacement and malfunctioning of I/O signal.

- X1 to X7 are secondary side circuit which should be isolated from the primary power source (24 VDC control power source, 24 VDC braking power source and 24 VDC for regenerative resistor). Do not connect the secondary side circuit to the primary power source and ground wire. Otherwise, I/O signal will cause error operation.
- Control power source (particularly 24 VDC) should be completely isolated from external operating power source. Never connect the ground of the control power source to that of external power source.
- The signal line should have shield, the both end of which should be connected to the ground.

Note

For driver and applicable peripheral equipments, refer to P.2-10 "Driver and List of Applicable Peripheral Equipments".

Caution

Use options correctly after reading Operating Instructions of the options to better understand the precautions.

Take care not to apply excessive stress to each optional part.

2

Preparation

2. System Configuration and Wiring

Driver and List of Applicable Peripheral Equipments

Driver	Applicable motor	Voltage *1	Rated output	Required Power at the (rated load)	Circuit breaker (rated current)	Noise filter (Single phase 3-phase)	Surge absorber (Single phase 3-phase)	Noise filter for signal	Rated operating current of magnetic contactor Contact configuration *2	Diameter and withstand voltage of main circuit cable	Crimp terminal for main circuit terminal block	Diameter and withstand voltage of control power supply cable	Crimp terminal for control power supply terminal block	Diameter and withstand voltage of motor cable *4	Diameter and withstand voltage of brake cable
MADH	MSME	Single phase, 100V	50W to 100W	approx. 0.4kVA	10A	DV0P4170	DV0P4190	20A (3P+1a)	0.75mm ² / AWG18 600 VAC or more	0.75mm ² / AWG18 600 VAC or more	Connection to exclusive connector	Connection to exclusive connector	2.0mm ² / AWG14 600 VAC or more	0.75mm ² / AWG18 100 VAC or more	0.75mm ² / AWG18 100 VAC or more
		Single/ 3-phase, 200V	50W to 200W	approx. 0.5kVA		DV0P4170 DV0PM20042	DV0P4190 DV0P1450								
MBDH	MSME	Single 100V	200W	approx. 0.5kVA		DV0P4170	DV0P4190								
		Single/ 3-phase, 200V	400W	approx. 0.9kVA		DV0P4170 DV0PM20042	DV0P4190 DV0P1450								
MCDH	MSME	Single 100V	400W	approx. 0.9kVA	15A	DV0PM20042	DV0P4190	30A (3P+1a)	2.0mm ² / AWG14 600V VAC or more	0.52mm ² / AWG20 100 VAC or more	Connection to exclusive connector	Connection to exclusive connector	0.75mm ² / AWG18 600 VAC or more	0.75mm ² / AWG18 100 VAC or more	0.75mm ² / AWG18 100 VAC or more
		Single/ 3-phase, 200V	750W	approx. 1.3kVA											
MDDH	MDME	3-phase, 200V	1.0kW	approx. 1.8kVA	20A	DV0P4220	DV0P4190 DV0P1450	20A (3P+1a)	2.0mm ² / AWG14 600V VAC or more	0.52mm ² / AWG20 100 VAC or more	Connection to exclusive connector	Connection to exclusive connector	0.75mm ² / AWG18 600 VAC or more	0.75mm ² / AWG18 100 VAC or more	0.75mm ² / AWG18 100 VAC or more
	MHME		0.9kW	approx. 1.8kVA											
	MSME		1.0kW	approx. 1.8kVA											
	MHME		1.5kW	approx. 2.3kVA											
	MDME	3-phase, 400V	1.0kW	approx. 1.8kVA	10A	FN258L-16-07 (Recommended component)	DV0PM20050	20A (3P+1a)	2.0mm ² / AWG14 600V VAC or more	0.52mm ² / AWG20 100 VAC or more	Connection to exclusive connector	Connection to exclusive connector	0.75mm ² / AWG18 600 VAC or more	0.75mm ² / AWG18 100 VAC or more	0.75mm ² / AWG18 100 VAC or more
	MHME		0.9kW	approx. 1.8kVA											
	MGME		1.5kW	approx. 2.3kVA											
	MDME		2.0kW	approx. 3.3kVA											
	MHME		2.5kW	approx. 3.8kVA											
	MFME		2.0kW	approx. 3.3kVA											
MEDH	MDME	3-phase, 200V	2.0kW	approx. 3.3kVA	30A	DV0PM20043	DV0P1450	60A (3P+1a)	2.0mm ² / AWG14 600V VAC or more	0.52mm ² / AWG20 100 VAC or more	Connection to exclusive connector	Connection to exclusive connector	0.75mm ² / AWG18 600 VAC or more	0.75mm ² / AWG18 100 VAC or more	0.75mm ² / AWG18 100 VAC or more
	MHME		2.5kW	approx. 3.8kVA											
	MSME		2.0kW	approx. 3.3kVA											
	MHME		2.5kW	approx. 3.8kVA											
	MDME	3-phase, 400V	2.0kW	approx. 3.3kVA	15A	FN258L-16-07 (Recommended component)	DV0PM20050	30A (3P+1a)	2.0mm ² / AWG14 600V VAC or more	0.52mm ² / AWG20 100 VAC or more	Connection to exclusive connector	Connection to exclusive connector	0.75mm ² / AWG18 600 VAC or more	0.75mm ² / AWG18 100 VAC or more	0.75mm ² / AWG18 100 VAC or more
	MHME		2.5kW	approx. 3.8kVA											
	MFME		2.0kW	approx. 3.3kVA											
	MDME		2.5kW	approx. 3.8kVA											
	MHME		2.0kW	approx. 3.3kVA											
	MFME		2.5kW	approx. 3.8kVA											
MFDH	MGME	3-phase, 200V	2.0kW	approx. 3.8kVA	50A	DV0P3410	DV0P1450	60A (3P+1a)	2.0mm ² / AWG14 600V VAC or more	0.52mm ² / AWG20 100 VAC or more	Connection to exclusive connector	Connection to exclusive connector	0.75mm ² / AWG18 600 VAC or more	0.75mm ² / AWG18 100 VAC or more	0.75mm ² / AWG18 100 VAC or more
	MDME		3.0kW	approx. 4.5kVA											
	MHME		4.0kW	approx. 6.0kVA											
	MSME		4.5kW	approx. 6.8kVA											
	MGME		5.0kW	approx. 7.5kVA											
	MDME		5.0kW	approx. 7.5kVA											
	MHME	3-phase, 400V	2.0kW	approx. 3.8kVA	30A	FN258L-30-07 (Recommended component)	DV0PM20050	60A (3P+1a)	2.0mm ² / AWG14 600V VAC or more	0.52mm ² / AWG20 100 VAC or more	Connection to exclusive connector	Connection to exclusive connector	0.75mm ² / AWG18 600 VAC or more	0.75mm ² / AWG18 100 VAC or more	0.75mm ² / AWG18 100 VAC or more
	MDME		3.0kW	approx. 4.5kVA											
	MGME		4.0kW	approx. 6.0kVA											
	MHME		4.5kW	approx. 6.8kVA											
	MSME		5.0kW	approx. 7.5kVA											
	MDME		5.0kW	approx. 7.5kVA											
	MHME	3-phase, 400V	2.0kW	approx. 3.8kVA	30A	FN258L-30-07 (Recommended component)	DV0PM20050	60A (3P+1a)	2.0mm ² / AWG14 600V VAC or more	0.52mm ² / AWG20 100 VAC or more	Connection to exclusive connector	Connection to exclusive connector	0.75mm ² / AWG18 600 VAC or more	0.75mm ² / AWG18 100 VAC or more	0.75mm ² / AWG18 100 VAC or more
	MDME		3.0kW	approx. 4.5kVA											
	MGME		4.0kW	approx. 6.0kVA											
	MHME		4.5kW	approx. 6.8kVA											
	MSME		5.0kW	approx. 7.5kVA											
	MDME		5.0kW	approx. 7.5kVA											


*1 Select peripheral equipments for single/3phase common specification according to the power source.

*2 For the external dynamic brake resistor, use the magnetic contactor with the same rating as that for the main circuit.

*3 When use the external regenerative resistor of the option (DV0PM20058, DV0PM20059), use the cable with the same diameter as the main circuit cable.

*4 The diameter of the ground cable and the external dynamic brake resistor cable must be equal to, or larger than that of the motor cable. The motor cable is a shield cable, which conforms to the EC Directives and UL Standards. (G, H-frame only)

*5 Use these products to suit an international standard.







Related page

Noise filter...P.7-94 Surge absorber...P.7-98


Noise filter for signal...P.7-99 Motor/brake connector...P.2-48

2. System Configuration and Wiring


Driver and List of Applicable Peripheral Equipments

Driver	Applicable motor	Voltage *1	Rated output	Required Power at the (rated load)	Circuit breaker (rated current)	Noise filter	Surge absorber	Noise filter for signal	Rated operating current of magnetic (contactor Contact) configuration *2	Diameter and withstand voltage of main circuit cable	Crimp terminal for main circuit terminal block	Diameter and withstand voltage of control power supply cable	Crimp terminal for control power supply terminal block	Diameter and withstand voltage of motor cable *4	Diameter and withstand voltage of brake cable						
MGDH	MDME	3-phase, 200V	7.5kW	approx. 11kVA	60A	FS5559-35-33 (Recommended component)	DV0P1450	DV0P1460 RJ8095 (Recommended component) T400-61D (Recommended component) *5	100A (3P+1a)	5.3mm ² / AWG10 600 VAC or more	 11mm or smaller Terminal block M5	0.75mm ² / AWG18 600 VAC or more	 10mm or smaller Terminal block M5	13.3 mm ² / AWG6 600 VAC or more	0.75mm ² / AWG18 100 VAC or more						
	MGME		6.0kW	approx. 9.0kVA					60A (3P+1a)												
	MHME		7.5kW	approx. 11kVA																	
	MDME	3-phase, 400V	7.5kW	approx. 11kVA	30A	FN258-42-07 or FN258-42-33 (Recommended component)	DV0PM20050		60A (3P+1a)	0.75mm ² / AWG18 100 VAC or more	Terminal block M5	0.75mm ² / AWG18 100 VAC or more	Terminal block M5	0.75mm ² / AWG18 100 VAC or more							
	MGME		6.0kW	approx. 9.0kVA																	
	MHME		7.5kW	approx. 11kVA																	
MHDH	MDME	3-phase, 200V	11kW	approx. 17kVA	100A	FS5559-80-34 (Recommended component)	DV0P1450		150A (3P+1a)	13.3mm ² / AWG6 600 VAC or more *3	 16mm or smaller Terminal block M6	0.75mm ² / AWG18 600 VAC or more	 10mm or smaller Terminal block M4	21.1 mm ² / AWG4 600 VAC or more							
			15kW	approx. 22kVA	125A									13.3 mm ² / AWG6 600 VAC or more							
		3-phase, 400V	11kW	approx. 17kVA	50A	FN258-42-07 or FN258-42-33 (Recommended component)	DV0PM20050		100A (3P+1a)						21.1 mm ² / AWG4 600 VAC or more						

• About circuit breaker and magnetic contactor

To comply to EC Directives, install a circuit breaker between the power and the noise filter without fail, and the circuit breaker should conform to IEC Standards and UL recognized (Listed and  marked).

Suitable for use on a circuit capable of delivering not more than 5,000Arms symmetrical amperes, below the maximum input voltage of the product.

Remarks  Select a circuit breaker and noise filter which match to the capacity of power supply (including a load condition).

• Terminal block and protective ground terminals

- Use a copper conductor cables with temperature rating of 75°C or higher.
- Use the attached exclusive connector for A to E-frame, and maintain the peeled off length of 8 to 9mm. (Refer to P.2-50)

• Fastening torque list (Terminal block screw/Terminal cover fastening screw)

Driver		Terminal block screw		Terminal cover fastening screw	
Frame	Terminal name	Nominal size	Fastening torque (N·m) (Note 1)	Nominal size	Fastening torque (N·m) (Note 1)
F200V	L1, L2, L3, L1C, L2C, B1, B2, B3, NC, U, V, W	M5	1.0 to 1.7	M3	0.19 to 0.21
F400V	24V, 0V	M3	0.4 to 0.6		
	L1, L2, L3, B1, B2, B3, NC, U, V, W	M4	0.7 to 1.0		
G	L1C, L2C, 24V, 0V, DB1, DB2, DB3, DB4, NC	M5	1.0 to 1.7	M3	0.3 to 0.5
	L1, L2, L3, B1, B2, NC, U, V, W	M5	2.0 to 2.4		
H	L1C, L2C, 24V, 0V, DB1, DB2	M4	0.7 to 1.0	M5	2.0 to 2.5
	L1, L2, L3, B1, B2, NC, U, V, W	M6	2.2 to 2.5		

• Fastening torque list (Ground terminal screw/Connector to host controller (X4))

Driver frame	Terminal block screw		Connector to host controller (X4)	
	Nominal size	Fastening torque (N·m) (Note 1)	Nominal size	Fastening torque (N·m) (Note 1)
A to E	M4	0.7 to 0.8	M2.6	0.3 to 0.35
F, G	M5	1.4 to 1.6		
H	M6	2.4 to 2.6		

Caution

(Note 1)

- Applying fastening torque larger than the maximum value may result in damage to the product.
- Do not turn on power without tightening all terminal block screws properly.
- Do not turn on power without tightening all terminal block screws properly, otherwise, loose contacts may generate heat (smoking, firing).
- To check for looseness, conduct periodic inspection of fastening torque once a year.

Remarks

Be sure to conduct wiring properly and securely. Insecure or improper wiring may cause the motor running out of control or being damaged from overheating. In addition, pay attention not to allow conductive materials, such as wire chips, entering the driver during the installation and wiring.

Connecting Example of A to D-frame

- Apply the voltage designated on the nameplate from the power source.

Symmetric current should be 5000 Arms or below. If the short-circuit current on the power source exceeds this value, use a current-limiting device (e.g. current-limiting fuse, current-limiting circuit breaker or transformer).

- **Wiring of Main Connector (XA)**

Circuit Breaker (MCCB)

To protect power supply line from overloading, install a wiring circuit breaker rated to the capacity of the power supply.

Noise Filter (NF)

Removes external noise from the power lines. And reduces an effect of the noise generated by the servo driver.

Magnetic Contactor (MC)

Turns on/off the main power of the servo driver.

Use coil surge suppression units together with this.

- **Never start nor stop the servo motor with this Magnetic Contactor.**

Reactor (L) (to be supplied by customer)

Reduces harmonic current of the main power.

- **Wiring of Motor Connector (XB)**

Pin B1 (6-pin), B2 (4-pin), and B3 (5-pin)

- **B2 and B3 to be kept shorted for normal operation (For C-frame and D-frame).**
- When you connect an external regenerative resistor, disconnect a short circuit wire between B2 and B3 (For C-frame and D-frame), then connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Note

Note that no regenerative resistor is equipped in Frame A and B type.

Mains
Residual
current device

Wiring to Connector, XA ⚡ P.2-14

- Connection to input power

L1 (Pin-5)

L2 (Pin-4)

L3 (Pin-3)

L1C (Pin-2)

L2C (Pin-1)

Wiring to Connector, XB ⚡ P.2-14

- Connection to external components

B1 (Pin-6)

B2 (Pin-4)

Regenerative resistor (optional)

Remarks ⚡

- When you use an external regenerative resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Thermal fuse and thermostat are built in to the regenerative resistor (Option). **If the thermal fuse is activated, it will not resume.**
- Mount the regenerative resistor on **incombustible material such as metal.**

Note ⚡

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page ⚡

• P.7-94... "Options"

2. System Configuration and Wiring

Overall Wiring (A to D-frame, 100/200 V type)


 : High voltage

Handle lever
Use this for connector connection. Store this after connection for other occasions.
(Refer to P.2-50 for connection.)

Wiring to Connector, X7 P.2-60

- Monitor output

PC (to be supplied by customer)



Setup support software "PANATERM"
Please download from our web site.

Wiring to Connector, X1 P.2-51

- Connection to PC (PANATERM)

Wiring to Connector, X2 P.2-51

- Connection to RS232, RS485 or host controller

Wiring to Connector, X3 P.2-53

- Connection to Safety by-pass plug

Wiring to Connector, X4 P.2-54

- Connection to host controller

Wiring to Connector, X5 P.2-55

- Connection to feedback scale

Wiring to Connector, X6 P.2-57

- Connection to encoder

Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, 24 VDC power supply for brake), insulation is required.
- Do not connect these terminals to the same power supply.

Wiring to Connector, XB P.2-14

- Connection to motor driving phase and ground

Ground terminal

Ground (earth)

Junction cable for encoder

Junction cable for motor

Junction cable for brake

DC Power supply for brake DC24V
(to be supplied by customer)

*1 Do not make displacement, wiring or inspection while the LED is lit - cause of electric shock.

Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver.

Related page


- Only for position control type is not provided with X2, X3 and X5.
- P.2-14 "Wiring of the Main Circuit (A to G-frame, 100/200 V type)"
- P.2-48 "Specifications of Motor connector"

A to D-frame, 100 V / 200 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the power connector (XA and XB) to which high voltage is applied.
There is a risk of electric shock.

• Tips on Wiring

- 1) Wire connector (XA and XB).
- 2) Connect the wired connector to the driver.
Fully insert the connector to the bottom until it clicks.



Note

The wiring indicated with the broken line shall be provided only when required.

Related page

- P.2-48 "Specifications of Motor connector" • P.2-50 "Wiring method to connector"
- P.7-111, 112 "Connector kit for XA" • P.7-113 "Connector kit for XB"


Compose the circuit so that the main circuit power will be shut off when an error occurs.

In Case of Single Phase, A to D-frame, 100 V / 200 V type

Power supply Single phase, 100V -15% to $120V +10\%$ Single phase, 200V -15% to $240V +10\%$


Remarks

When you use single phase, connect the main power between L1 and L3 terminals.



In Case of 3-Phase, A to D-frame, 200 V type

Power supply 3-phase, 200V -15% to $240V +10\%$



Note

The wiring indicated with the broken line shall be provided only when required.

Related page

• P.2-48 "Specifications of Motor connector" • P.2-50 "Wiring method to connector"

Connecting Example of E-frame

- Apply the voltage designated on the nameplate from the power source.
Symmetric current should be 5000 Arms or below.
If the short-circuit current on the power source exceeds this value, use a current-limiting device (e.g. current-limiting fuse, current-limiting circuit breaker or transformer).

- **Wiring of Main Connector (XA)**

- **Circuit Breaker (MCCB)**

- To protect power supply line from overloading, install a wiring circuit breaker rated to the capacity of the power supply.

- **Noise Filter (NF)**

- Removes external noise from the power lines. And reduces an effect of the noise generated by the servo driver.

- **Magnetic Contactor (MC)**

- Turns on/off the main power of the servo driver.

- Use coil surge suppression units together with this.

- **Never start nor stop the servo motor with this Magnetic Contactor.**

- **Reactor (L)** (to be supplied by customer)

- Reduces harmonic current of the main power.

- **Wiring of Motor Connector (XC)**

- **Pin B1 (4-pin), B2 (2-pin), and B3 3-pin)**

- **B2 and B3 to be kept shorted for normal operation.**

- When you connect an external regenerative resistor, disconnect a short circuit wire between B2 and B3, then connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Mains
Residual
current device

Wiring to Connector, XA ❖ P.2-18

- Connection to input power

L1 (Pin-5)

L2 (Pin-4)

L3 (Pin-3)

L1C (Pin-2)

L2C (Pin-1)

Wiring to Connector, XC ❖ P.2-18

- Connection to external components

B1 (Pin-6)

B2 (Pin-4)

Regenerative resistor (optional)
Remarks ❖

- When you use an external regenerative resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Thermal fuse and thermostat are built in to the regenerative resistor (Option). **If the thermal fuse is activated, it will not resume.**
- Mount the regenerative resistor **on incombustible material such as metal.**

Note ❖

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page ❖

• P.7-94... "Options"

2. System Configuration and Wiring

Overall Wiring (E-frame, 200 V type)


 : High voltage

Handle lever
Use this for connector connection. Store this after connection for other occasions. (Refer to P.2-50 for connection.)

Wiring to Connector, X7 P.2-60

- Monitor output

PC (to be supplied by customer)



Setup support software "PANATERM"
Please download from our web site.

Wiring to Connector, X1 P.2-51

- Connection to PC (PANATERM)

Wiring to Connector, X2 P.2-51

- Connection to RS232, RS485 or host controller

Wiring to Connector, X3 P.2-53

- Connection to Safety by-pass plug

Wiring to Connector, X4 P.2-54

- Connection to host controller

Wiring to Connector, X5 P.2-55

- Connection to feedback scale

Wiring to Connector, X6 P.2-57

- Connection to encoder

Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, 24 VDC power supply for brake), insulation is required.

Do not connect these terminals to the same power supply.

Short circuit wire(B2-B3)

U-phase(red)
V-phase(white)
W-phase(black)

* These colors are used for optional cable.

Ground terminal

Ground (earth)

Charge lamp (Red LED)^{*1}

Junction cable for encoder

Junction cable for motor

Wiring to Connector, XB P.2-18

- Connection to motor driving phase and ground


Junction cable for brake

DC Power supply for brake DC24V
(to be supplied by customer)

^{*1} Do not make displacement, wiring or inspection while the LED is lit - cause of electric shock.

Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver.
- Only for position control type is not provided with X2, X3 and X5.
- P.2-18 "Wiring of the Main Circuit (E-frame, 200 V type)"
- P.2-48 "Specifications of Motor connector"


Related page 

E-frame, 200 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the power connector (XA, XB and XC) to which high voltage is applied.
There is a risk of electric shock.

• **Tips on Wiring**

- 1) Wire connector (XA, XB and XC).
- 2) Connect the wired connector to the driver.
Fully insert the connector to the bottom until it clicks.

**Note**

The wiring indicated with the broken line shall be provided only when required.


Related page

- P.2-48 "Specifications of Motor connector" • P.2-50 "Wiring method to connector"
- P.7-112 "Connector kit for XA" • P.7-113 "Connector kit for XB, XC"

Compose the circuit so that the main circuit power will be shut off when an error occurs.


In Case of 3-Phase, E-frame, 200 V type

Power supply 3-phase, 200V -15% to 230V +10%



Note

Note The wiring indicated with the broken line shall be provided only when required.

Related page 

Related page • P.2-48 “Specifications of Motor connector” • P.2-50 “Wiring method to connector”

Connecting Example of F-frame

- Apply the voltage designated on the nameplate from the power source.
Symmetric current should be 5000 Arms or below.
If the short-circuit current on the power source exceeds this value, use a current-limiting device (e.g. current-limiting fuse, current-limiting circuit breaker or transformer).

• Wiring of Main Circuit

Circuit Breaker (MCCB)

To protect power supply line from overloading, install a wiring circuit breaker rated to the capacity of the power supply.

Noise Filter (NF)

Removes external noise from the power lines. And reduces an effect of the noise generated by the servo driver.

Magnetic Contactor (MC)

Turns on/off the main power of the servo driver.

Use coil surge suppression units together with this.

- **Never start nor stop the servo motor with this Magnetic Contactor.**

Reactor (L) (to be supplied by customer)


Reduces harmonic current of the main power.

Pin B1, B2 and B3

- **B2 and B3 to be kept shorted for normal operation.**
- When you connect an external regenerative resistor, disconnect a short bar between B2 and B3, then connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Pin NC

- Do not connect anything.



Regenerative resistor (optional)

Remarks

- When you use an external regenerative resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Thermal fuse and thermostat are built in to the regenerative resistor (Option). **If the thermal fuse is activated, it will not resume.**
- Mount the regenerative resistor **on incombustible material such as metal.**

Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page


• P.7-94... "Options"

2. System Configuration and Wiring

Overall Wiring (F-frame, 200 V type)

 : High voltage

PC (to be supplied by customer)
Setup support software
"PANATERM"
Please download
from our web site.



Wiring to Connector, X7 ❖ P.2-60

- Monitor output

Wiring to Connector, X1 ❖ P.2-51

- Connection to PC (PANATERM)

Wiring to Connector, X2 ❖ P.2-51

- Connection to RS232, RS485 or host controller

Wiring to Connector, X3 ❖ P.2-53

- Connection to Safety by-pass plug

Wiring to Connector, X4 ❖ P.2-54

- Connection to host controller

Wiring to Connector, X5 ❖ P.2-55


- Connection to feedback scale

Wiring to Connector, X6 ❖ P.2-57

- Connection to encoder

Remarks ❖

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, 24 VDC power supply for brake), insulation is required. Do not connect these terminals to the same power supply.



*1 Do not make displacement, wiring or inspection while the LED is lit - cause of electric shock.

Note ❖

- The figure above shows connections on velocity, position, torque and full-closed mode driver.
- Only for position control type is not provided with X2, X3 and X5.
- P.2-22 "Wiring of the Main Circuit (F-frame, 200 V type)"
- P.2-48 "Specifications of Motor connector"

Related page ❖

F-frame, 200 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

• **Tips on Wiring**


- 1) Take off the cover fixing screws, and detach the terminal cover.
- 2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, refer to "Driver and List of Applicable Peripheral Equipments" (P.2-10).

Tighten the terminal block screw with a torque between 1.0 and 1.7 N·m.

- 3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with a torque written on P.2-11.

**Note**

The wiring indicated with the broken line shall be provided only when required.


Related page

• P.2-48 "Specifications of Motor connector"

Compose the circuit so that the main circuit power will be shut off when an error occurs.

In Case of 3-Phase, F-frame, 200 V type

Power supply 3-phase, 200V –15% to 230V +10%



Note

Note The wiring indicated with the broken line shall be provided only when required.

Related page

- P.2-48 “Specifications of Motor connector”

Connecting Example of G-frame

- Apply the voltage designated on the nameplate from the power source.

Symmetric current should be 5000 Arms or below.
If the short-circuit current on the power source exceeds this value, use a current-limiting device (e.g. current-limiting fuse, current-limiting circuit breaker or transformer).

- **Wiring of Main Circuit**

- **Circuit Breaker (MCCB)**

To protect power supply line from overloading, install a wiring circuit breaker rated to the capacity of the power supply.

- **Noise Filter (NF)**

Removes external noise from the power lines. And reduces an effect of the noise generated by the servo driver.


- **Magnetic Contactor (MC)**

Turns on/off the main power of the servo driver.
Use coil surge suppression units together with this.

- **Never start nor stop the servo motor with this Magnetic Contactor.**

- **Reactor (L)** (to be supplied by customer)

Reduces harmonic current of the main power.



Regenerative resistor (optional)

Remarks

- When you use an external regenerative resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Thermal fuse and thermostat are built in to the regenerative resistor (Option). **If the thermal fuse is activated, it will not resume.**
- Mount the regenerative resistor **on incombustible material such as metal.**

Note

The wiring indicated with the broken line shall be provided only when required.

Pin B1 and B2

- When you connect an external regenerative resistor, connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Pin DB1, DB2, DB3 and DB4

- **Normally, leave DB3 and DB4 short-circuited.**
- To connect the external dynamic brake resistor, refer to “Dynamic Brake” on P.2-67 **Do not use the external dynamic brake resistor together with the built-in resistor.**

Pin NC

- Do not connect anything.

Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page


• P.7-94... “Options”

2. System Configuration and Wiring

Overall Wiring (G-frame, 200 V type)

 : High voltage

PC (to be supplied by customer)



Wiring to Connector, X7 ❖ P.2-60

- Monitor output

Setup support software "PANATERM"
Please download from our web site.

Wiring to Connector, X1 ❖ P.2-51

- Connection to PC (PANATERM)

Wiring to Connector, X2 ❖ P.2-51

- Connection to RS232, RS485 or host controller

Wiring to Connector, X3 ❖ P.2-53

- Connection to Safety by-pass plug

Wiring to Connector, X4 ❖ P.2-54

- Connection to host controller

Wiring to Connector, X5 ❖ P.2-55

- Connection to feedback scale

Wiring to Connector, X6 ❖ P.2-57

- Connection to encoder

Junction cable for encoder


Short bar (DB3-DB4)

Charge lamp (LED)

Do not make displacement, wiring or inspection while the LED is lit - cause of electric shock.

Remarks ❖

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, 24 VDC power supply for brake), insulation is required. Do not connect these terminals to the same power supply.



Ground terminal

Ground (earth)

Motor cable (Shield wire)

Connection to motor driving phase and ground ❖ P.2-26

Brake cable

DC Power supply for brake DC24V (to be supplied by customer)

Note ❖

- The figure above shows connections on velocity, position, torque and full-closed mode driver.

Related page ❖

- Only for position control type is not provided.
- P.2-26 "Wiring of the Main Circuit (G-frame, 200 V type)"
- P.2-48 "Specifications of Motor connector"

G-frame, 200 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

• **Tips on Wiring**

1) Take off the cover fixing screws, and detach the terminal cover.


2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, refer to "Driver and List of Applicable Peripheral Equipments" (P.2-11).

Tighten the terminal block screw with a torque between 2.0 and 2.4 N·m (left side) and 1.0 and 1.7 N·m (right side).

3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with the torque written on P.2-11.

**Note**

The wiring indicated with the broken line shall be provided only when required.

Related page

• P.2-48 "Specifications of Motor connector"

Connecting Example of H-frame

- Apply the voltage designated on the name-plate from the power source.
Symmetric current should be 5000 Arms or below.
If the short-circuit current on the power source exceeds this value, use a current-limiting device (e.g. current-limiting fuse, current-limiting circuit breaker or transformer).

• Wiring of Main Circuit

Circuit Breaker (MCCB)

To protect power supply line from overloading, install a wiring circuit breaker rated to the capacity of the power supply.

Noise Filter (NF)

Removes external noise from the power lines. And reduces an effect of the noise generated by the servo driver.

Magnetic Contactor (MC)

Turns on/off the main power of the servo driver. Use coil surge suppression units together with this.

- **Never start nor stop the servo motor with this Magnetic Contactor.**

Reactor (L) (to be supplied by customer)

Reduces harmonic current of the main power.

24 VDC

power supply for regenerative resistor
(to be supplied by customer)

* Use a power supply with 5 A or larger capacity.

Connection to external components P.2-30

Regenerative resistor
(optional)

Remarks


- When you use an external regenerative resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Thermal fuse and thermostat are built in to the regenerative resistor (Option). **If the thermal fuse is activated, it will not resume.**
- Mount the regenerative resistor **on incombustible material such as metal.**
- For wiring of the circuit, refer to "Wiring Diagram" on P.2-31.

Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page

• P.7-94... "Options"

**Charge lamp (LED)**

Do not make displacement, wiring or inspection while the LED is lit - cause of electric shock.

Connection with input power supply P.2-30

Dynamic Brake resistor
(to be supplied by customer)

Remarks

- When you use an external dynamic brake resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Mount the dynamic brake resistor **on incombustible material such as metal.**
- For wiring of the circuit, refer to "Wiring Diagram" on P.2-31.
- For an example of the recommended protective circuit, refer to "Dynamic Brake" on P.2-67.

Magnetic Contactor (MC)

Turns on/off the dynamic brake resistor. Use coil surge suppression units together with this.

2. System Configuration and Wiring


Overall Wiring (H-frame, 200 V type)

 : High voltage

Wiring to Connector, X7 P.2-60

- Monitor output

PC (to be supplied by customer)
Setup support software
“PANATERM”
Please download
from our web site.



Wiring to Connector, X1 P.2-51

- Connection to PC (PANATERM)

Wiring to Connector, X2 P.2-51

- Connection to RS232, RS485
or host controller

Wiring to Connector, X3 P.2-53

- Connection to Safety by-pass plug

Wiring to Connector, X4 P.2-54

- Connection to host controller

Wiring to Connector, X5 P.2-55

- Connection to feedback scale

Wiring to Connector, X6 P.2-57

- Connection to encoder

Remarks

- X1 to X7 are used for the secondary circuit.
To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for brake and the 24 VDC power supply for regenerative resistor), insulation is required.
Do not connect these terminals to the same power supply.

Pin B1 and B2

- When you connect an external regenerative resistor, connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Pin DB1 and DB2

- When installing an external dynamic brake resistor, connect the magnetic contactor (for controlling) for external dynamic brake to between LIC and DB1.

Remarks


- The voltage applied across DB1 and DB2 must be 300 VAC or below or 100 VDC or below.

Pin NC

- Do not connect anything.

Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver.
- Only for position control type is not provided.
- P.2-30 "Wiring of the Main Circuit (H-frame, 200 V type)"
- P.2-48 "Specifications of Motor connector"

Related page 

H-frame, 200 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

• Tips on Wiring

- 1) Take off the cover fixing screws, and detach the terminal cover.


- ## 2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, refer to "Driver and List of Applicable Peripheral Equipments" (P.2-11).

Tighten the terminal block screw with a torque between 0.7 and 0.8 N•m (upper side) and 2.2 and 2.5 N•m (lower side).

- 3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with the torque written on P.2-11.



Note

Note The wiring indicated with the broken line shall be provided only when required.


Related page 

- P.2-48 “Specifications of Motor connector”

Compose the circuit so that the main circuit power will be shut off when an error occurs.

In Case of 3-Phase, H-frame, 200 V type

Power supply 3-phase, 200V -15% to 230V +10%



Note 1)

Magnetic contactor MC2 must be the same as the contactor MC1 in the main circuit.

Note 2)

Servo may be turned on in the external sequence if the dynamic brake resistor deposits: to protect the system, provide the auxiliary contact.

Note 3)

Use 1.2 Ω, 400 W resistor (to be supplied by customer).

Note 4)

To use the external dynamic brake resistor:

Connect the R1 and R2 terminals to B1 and B2.

Connect the T1 and T2 terminals as shown in the left diagram.

Connect the 24 V and 0 V terminals to a 24 VDC power supply.

Connect the E terminal to the ground.

Refer to P.7-122 "Options" for the specifications of the external regenerative resistor.

Note 5)

Provide an external protective device (e.g. thermal fuse) to monitor the temperature of the external dynamic brake resistor.

Note

The wiring indicated with the broken line shall be provided only when required.

Related page

• P.2-48 "Specifications of Motor connector"

Connecting Example of D, E-frame

- Apply the voltage designated on the nameplate from the power source.

Symmetric current should be 5000 Arms or below. If the short-circuit current on the power source exceeds this value, use a current-limiting device (e.g. current-limiting fuse, current-limiting circuit breaker or transformer).

- **Wiring of Main Connector (XA)**

- **Circuit Breaker (MCCB)**

To protect power supply line from overloading, install a wiring circuit breaker rated to the capacity of the power supply.

- **Noise Filter (NF)**

Removes external noise from the power lines. And reduces an effect of the noise generated by the servo driver.

- **Magnetic Contactor (MC)**

Turns on/off the main power of the servo driver.

Use coil surge suppression units together with this.

- **Never start nor stop the servo motor with this Magnetic Contactor.**

- **Reactor (L)** (to be supplied by customer)

Reduces harmonic current of the main power.

- **Wiring of Motor Connector (XC)**

Pin B1 (4-pin), B2 (2-pin), and B3 (3-pin)

- **B2 and B3 to be kept shorted for normal operation.**
 - When you connect an external regenerative resistor, disconnect a short circuit wire between B2 and B3, then connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Mains
Residual
current device

* Use a power
supply with
2 A or larger
capacity.

**24 VDC power supply
for control**
(to be supplied by customer)

24V
0V

Wiring to Connector, XD ❖ P.2-34

- Connection to control power

Wiring to Connector, XA ❖ P.2-34

- Connection to input power

L1 (Pin-3)

L2 (Pin-2)

L3 (Pin-1)

Wiring to Connector, XC ❖ P.2-34

- Connection to external components

B1 (Pin-4)

B2 (Pin-2)

Regenerative resistor (optional)

Remarks ❖

- When you use an external regenerative resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Thermal fuse and thermostat are built in to the regenerative resistor (Option). **If the thermal fuse is activated, it will not resume.**
- Mount the regenerative resistor **on incombustible material such as metal.**

Note ❖

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page ❖

• P.7-94... "Options"

2. System Configuration and Wiring


Overall Wiring (D, E-frame, 400 V type)

 : High voltage

Wiring to Connector, X7 ❖ P.2-60

- Monitor output

PC (to be supplied by customer)
Setup support software
"PANATERM"
Please download
from our web site.



Handle lever
Use this for connector
connection. Store this
after connection for
other occasions.
(Refer to P.2-50 for
connection.)

Wiring to Connector, X1 ❖ P.2-51

- Connection to PC (PANATERM)

Wiring to Connector, X2 ❖ P.2-51

- Connection to RS232, RS485
or host controller

Wiring to Connector, X3 ❖ P.2-53

- Connection to Safety by-pass plug

Wiring to Connector, X4 ❖ P.2-54

- Connection to host controller

Wiring to Connector, X5 ❖ P.2-55

- Connection to feedback scale

Wiring to Connector, X6 ❖ P.2-57

- Connection to encoder

Remarks ❖

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control and the 24 VDC power supply for brake), insulation is required. Do not connect these terminals to the same power supply.

Short circuit wire (B2-B3)

Wiring to Connector, XB ❖ P.2-34

- Connection to motor

U-phase(red)
V-phase(white)
W-phase(black)

Ground
terminal

Ground
(earth)

Charge lamp
(Red LED)*1

Junction cable
for encoder

Brake cable

Motor cable (Shield wire)

Connection to motor driving phase and ground ❖ P.2-34

DC Power supply for brake
DC24V
(to be supplied by customer)

*1 Do not make displacement, wiring or inspection while the LED is lit - cause of electric shock.

Note ❖

- The figure above shows connections on velocity, position, torque and full-closed mode driver.

Related page ❖

- Only for position control type is not provided with X2, X3 and X5.

- P.2-34 "Wiring of the Main Circuit (D, E-frame, 400 V type)"


- P.2-48 "Specifications of Motor connector"

D, E-frame, 400 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the power connector (XA, XB, XC and XD) to which high voltage is applied. There is a risk of electric shock.

• Tips on Wiring

- 1) Wire connector (XA, XB, XC and XD).
 - 2) Connect the wired connector to the driver.
- Fully insert the connector to the bottom until it clicks.



Note

The wiring indicated with the broken line shall be provided only when required.


Related page

• P.2-48 "Specifications of Motor connector" • P.2-50 "Wiring method to connector"
• P.7-111, 112 "Connector kit for XA" • P.7-113 "Connector kit for XB, XC" • P.7-112 "Connector kit for XD"

Compose the circuit so that the main circuit power will be shut off when an error occurs.

In Case of 3-Phase, D, E-frame, 400 V type

Power supply 3-phase, 380V -15% to 480V +10%



Note 1)

Shielding the circuit is recommended for the purpose of noise reduction.

Note

The wiring indicated with the broken line shall be provided only when required.

Related page

• P.2-48 "Specifications of Motor connector" • P.2-50 "Wiring method to connector"

Connecting Example of F-frame

- Apply the voltage designated on the nameplate from the power source.

Symmetric current should be 5000 Arms or below. If the short-circuit current on the power source exceeds this value, use a current-limiting device (e.g. current-limiting fuse, current-limiting circuit breaker or transformer).

- **Wiring of Main Circuit**

Circuit Breaker (MCCB)

To protect power supply line from overloading, install a wiring circuit breaker rated to the capacity of the power supply.

Noise Filter (NF)

Removes external noise from the power lines. And reduces an effect of the noise generated by the servo driver.

Magnetic Contactor (MC)

Turns on/off the main power of the servo driver.

Use coil surge suppression units together with this.

- **Never start nor stop the servo motor with this Magnetic Contactor.**

Reactor (L) (to be supplied by customer)

Reduces harmonic current of the main power.

Pin B1, B2 and B3

- B2 and B3 to be kept shorted for normal operation.
- When you connect an external regenerative resistor, disconnect a short bar between B2 and B3, then connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Pin NC

- Do not connect anything.

Mains
Residual
current device

* Use a power supply with 2 A or larger capacity.

24 VDC power supply for control

(to be supplied by customer)

24V
0V

Connection with control power supply

❖ P.2-38

Connection with input power supply

❖ P.2-38

L1
L2
L3

Connection to external components

❖ P.2-38

B1
B2

Regenerative resistor (optional)**Remarks** ❖

- When you use an external regenerative resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Thermal fuse and thermostat are built in to the regenerative resistor (Option). **If the thermal fuse is activated, it will not resume.**
- Mount the regenerative resistor **on incombustible material such as metal.**

Note ❖

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page ❖


• P.7-94... "Options"

2. System Configuration and Wiring

Overall Wiring (F-frame, 400 V type)

 : High voltage

PC (to be supplied by customer)



Wiring to Connector, X7 ❖ P.2-60

- Monitor output

Setup support software "PANATERM"
Please download from our web site.

Wiring to Connector, X1 ❖ P.2-51

- Connection to PC (PANATERM)

Wiring to Connector, X2 ❖ P.2-51

- Connection to RS232, RS485 or host controller

Wiring to Connector, X3 ❖ P.2-53

- Connection to Safety by-pass plug

Wiring to Connector, X4 ❖ P.2-54

- Connection to host controller

Wiring to Connector, X5 ❖ P.2-55


- Connection to feedback scale

Wiring to Connector, X6 ❖ P.2-57

- Connection to encoder

Remarks ❖

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control and the 24 VDC power supply for brake), insulation is required. Do not connect these terminals to the same power supply.



*1 Do not make displacement, wiring or inspection while the LED is lit - cause of electric shock.

Note ❖

- The figure above shows connections on velocity, position, torque and full-closed mode driver.
- Only for position control type is not provided with X2, X3 and X5.
- P.2-38 "Wiring of the Main Circuit (F-frame, 400 V type)"
- P.2-48 "Specifications of Motor connector"

Related page ❖

F-frame, 400 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

• **Tips on Wiring**

1) Take off the cover fixing screws, and detach the terminal cover.


2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, refer to "Driver and List of Applicable Peripheral Equipments" (P.2-10).

Tighten the terminal block screw with a torque written on P.2-11.

3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with a torque written on P.2-11.

**Note**

The wiring indicated with the broken line shall be provided only when required.


Related page

• P.2-48 "Specifications of Motor connector"

Compose the circuit so that the main circuit power will be shut off when an error occurs.

In Case of 3-Phase, F-frame, 400 V type

Power supply 3-phase, 380V -15% to 480V $+10\%$



Note 1)

Shielding the circuit is recommended for the purpose of noise reduction.

Note

The wiring indicated with the broken line shall be provided only when required.

Related page

• P.2-48 "Specifications of Motor connector"

Connecting Example of G-frame

- Apply the voltage designated on the name-plate from the power source.
Symmetric current should be 5000 Arms or below.
If the short-circuit current on the power source exceeds this value, use a current-limiting device (e.g. current-limiting fuse, current-limiting circuit breaker or transformer).

• Wiring of Main Circuit

Circuit Breaker (MCCB)

To protect power supply line from overloading, install a wiring circuit breaker rated to the capacity of the power supply.

Noise Filter (NF)

Removes external noise from the power lines. And reduces an effect of the noise generated by the servo driver.


Magnetic Contactor (MC)

Turns on/off the main power of the servo driver. Use coil surge suppression units together with this.

- **Never start nor stop the servo motor with this Magnetic Contactor.**

Reactor (L) (to be supplied by customer)

Reduces harmonic current of the main power.



Connection to external components P.2-42

Regenerative resistor (optional)

Remarks

- When you use an external regenerative resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Thermal fuse and thermostat are built in to the regenerative resistor (Option). **If the thermal fuse is activated, it will not resume.**
- Mount the regenerative resistor **on incombustible material such as metal.**

Note

The wiring indicated with the broken line shall be provided only when required.

Pin B1 and B2

- When you connect an external regenerative resistor, connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Pin DB1, DB2, DB3 and DB4

- **Normally, leave DB3 and DB4 short-circuited.**
- To connect the external dynamic brake resistor, refer to "Dynamic Brake" on P.2-67.
Do not use the external dynamic brake resistor together with the built-in resistor.

Pin NC

- Do not connect anything.

Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page

• P.7-94... "Options"

2. System Configuration and Wiring


Overall Wiring (G-frame, 400 V type)

 : High voltage

Wiring to Connector, X7 ❖ P.2-60

- Monitor output

PC (to be supplied by customer)



Setup support software "PANATERM"
Please download from our web site.

Wiring to Connector, X1 ❖ P.2-51

- Connection to PC (PANATERM)

Wiring to Connector, X2 ❖ P.2-51

- Connection to RS232, RS485 or host controller

Wiring to Connector, X3 ❖ P.2-53

- Connection to Safety by-pass plug

Wiring to Connector, X4 ❖ P.2-54

- Connection to host controller

Wiring to Connector, X5 ❖ P.2-55

- Connection to feedback scale

Wiring to Connector, X6 ❖ P.2-57

- Connection to encoder

Junction cable for encoder


Short bar (DB3-DB4)

Charge lamp (LED)

Do not make displacement, wiring or inspection while the LED is lit - cause of electric shock.

Remarks ❖

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, 24 VDC power supply for brake), insulation is required.
- Do not connect these terminals to the same power supply.



Connection to motor driving phase and ground ❖ P.2-42

DC Power supply for brake DC24V (to be supplied by customer)

Note ❖

- The figure above shows connections on velocity, position, torque and full-closed mode driver.

Related page ❖

- Only for position control type is not provided.
- P.2-42 "Wiring of the Main Circuit (G-frame, 400 V type)"
- P.2-48 "Specifications of Motor connector"

G-frame, 400 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

• Tips on Wiring

- 1) Take off the cover fixing screws, and detach the terminal cover.


- ## 2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, refer to "Driver and List of Applicable Peripheral Equipments" (P.2-11).

Tighten the terminal block screw with a torque between 2.0 and 2.4 N·m (left side) and 1.0 and 1.7 N·m (right side).

- 3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with the torque written on P.2-11.



Note

Note The wiring indicated with the broken line shall be provided only when required.


Related page

- P.2-48 “Specifications of Motor connector”

Compose the circuit so that the main circuit power will be shut off when an error occurs.

In Case of 3-Phase, G-frame, 400 V type

Power supply 3-phase, 380V -15% to 480V +10%



Note 1)

Shielding the circuit is recommended for the purpose of noise reduction.

Note 2)

Normally, do not disconnect the shorting bar.

Note

The wiring indicated with the broken line shall be provided only when required.

Related page

• P.2-48 "Specifications of Motor connector"

Connecting Example of H-frame

- Apply the voltage designated on the nameplate from the power source.
Symmetric current should be 5000 Arms or below.
If the short-circuit current on the power source exceeds this value, use a current-limiting device (e.g. current-limiting fuse, current-limiting circuit breaker or transformer).

- **Wiring of Main Circuit**

Circuit Breaker (MCCB)

To protect power supply line from overloading, install a wiring circuit breaker rated to the capacity of the power supply.

Noise Filter (NF)

Removes external noise from the power lines. And reduces an effect of the noise generated by the servo driver.

Magnetic Contactor (MC)

Turns on/off the main power of the servo driver. Use coil surge suppression units together with this.

- **Never start nor stop the servo motor with this Magnetic Contactor.**

Reactor (L) (to be supplied by customer)

Reduces harmonic current of the main power.

24 VDC power supply for regenerative resistor (to be supplied by customer)


* Use a power supply with 5 A or larger capacity.

Connection to external components P.2-46

Regenerative resistor (optional)

Remarks

- When you use an external regenerative resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Thermal fuse and thermostat are built in to the regenerative resistor (Option). **If the thermal fuse is activated, it will not resume.**
- Mount the regenerative resistor **on incombustible material such as metal.**
- For wiring of the circuit, refer to "Wiring Diagram" on P.2-47.



Dynamic Brake resistor
(to be supplied by customer)

Remarks

- When you use an external dynamic brake resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Mount the dynamic brake resistor **on incombustible material such as metal.**
- For wiring of the circuit, refer to "Wiring Diagram" on P.2-47.
- For an example of the recommended protective circuit, refer to "Dynamic Brake" on P.2-67.

Magnetic Contactor (MC)

Turns on/off the dynamic brake resistor. Use coil surge suppression units together with this.

Note

This overall wiring diagram is a typical one. The pages that follow show wiring for specific application. The wiring indicated with the broken line shall be provided only when required.

Related page

• P.7-94... "Options"

2. System Configuration and Wiring


Overall Wiring (H-frame, 400 V type)

 : High voltage

Wiring to Connector, X7 P.2-60

- Monitor output

PC (to be supplied by customer)
Setup support software
"PANATERM"
Please download
from our web site.



Wiring to Connector, X1 P.2-51

- Connection to PC (PANATERM)

Wiring to Connector, X2 P.2-51

- Connection to RS232, RS485
or host controller

Wiring to Connector, X3 P.2-53

- Connection to Safety by-pass plug

Wiring to Connector, X4 P.2-54

- Connection to host controller

Wiring to Connector, X5 P.2-55

- Connection to feedback scale

Wiring to Connector, X6 P.2-57

- Connection to encoder

Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor), insulation is required. Do not connect these terminals to the same power supply.

Pin B1 and B2

- When you connect an external regenerative resistor, connect the external regenerative resistor between B1 and B2, set up Pr0.16 to 1 or 2.

Pin DB1 and DB2

- When installing an external dynamic brake resistor, connect the magnetic contactor (for controlling) for external dynamic brake to between LIC and DB1.

Remarks


- The voltage applied across DB1 and DB2 must be 300 VAC or below or 100 VDC or below.

Note

- L1C is connected after the R-phase of the noise filter.
- L1C is not indicated on the driver body.

Pin NC

- Do not connect anything.



Connection to motor driving phase and ground P.2-46

Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver.

Related page

- Only for position control type is not provided.
- P.2-46 "Wiring of the Main Circuit (H-frame, 400 V type)"
- P.2-48 "Specifications of Motor connector"

H-frame, 400 V type

- Wiring should be performed by a specialist or an authorized personnel.
- Do not turn on the power until the wiring is completed.
- Never touch the terminal to which high voltage is applied. There is a risk of electric shock.

• Tips on Wiring

- 1) Take off the cover fixing screws, and detach the terminal cover.


- ## 2) Make wiring

Use clamp type terminals of round shape with insulation cover for wiring to the terminal block. For cable diameter and size, refer to "Driver and List of Applicable Peripheral Equipments" (P.2-11).

Tighten the terminal block screw with a torque between 0.7 and 1.0 N•m (upper side) and 2.2 and 2.5 N•m (lower side).

- 3) Attach the terminal cover, and fix with screws.

Tighten the screw securing the cover with the torque written on P.2-11.



Note

Note The wiring indicated with the broken line shall be provided only when required.


Related page 

- P.2-48 “Specifications of Motor connector”

Compose the circuit so that the main circuit power will be shut off when an error occurs.

In Case of 3-Phase, H-frame, 400 V type

Power supply 3-phase, 380V -15% to 480V $+10\%$



Note 1)

Shielding the circuit is recommended for the purpose of noise reduction.

Note 2)

Magnetic contactor MC2 must be the same as the contactor MC1 in the main circuit.

Note 3)

Servo may be turned on in the external sequence if the dynamic brake resistor deposits: to protect the system, provide the auxiliary contact.

Note 4)

Use 4.8 Ω , 400 W resistor (to be supplied by customer).

Note 5)

To use the external dynamic brake resistor:

Connect the R1 and R2 terminals to B1 and B2.

Connect the T1 and T2 terminals as shown in the left diagram.

Connect the 24 V and 0 V terminals to a 24 VDC power supply.

Connect the E terminal to the ground.

Refer to P.7-122 "Options" for the specifications of the external regenerative resistor.

Note 6)

Provide an external protective device (e.g. thermal fuse) to monitor the temperature of the external dynamic brake resistor.

Note

The wiring indicated with the broken line shall be provided only when required.

Related page

• P.2-48 "Specifications of Motor connector"



2. System Configuration and Wiring

Specifications of Motor connector

- When the motors of <MSMD, MHMD> are used, they are connected as shown below.

Connector: Made by Tyco Electronics k.k, (The figures below show connectors for the motor.)


Connector for encoder



172168-1
20-bit Incremental


PIN No.	Application
1	NC
2	PS
3	PS
4	E5V
5	E0V
6	FG(SHIELD)

Connector for brake



Connector for motor

<Connector for motor>



172167-1

PIN No.	Application
1	U-phase
2	V-phase
3	W-phase
4	Ground

<Connector for brake>



172165-1



PIN No.	Application
1	Brake
2	Brake

- When the motors of <MSME (50 W to 750 W)> are used, they are connected as shown below.

Connector: Made by Japan Aviation Electronics Industry, Ltd. (The figures below show connectors for the motor.)

* Do not remove the gasket supplied with the junction cable connector. Securely install the gasket in place. Otherwise, the degree of protection of IP67 will not be guaranteed.

Connector for encoder



JN6CR07PM2

20-bit Incremental

PIN No.	Application
1	FG(SHIELD)
2	—
3	E0V
4	PS
5	—
6	E5V
7	PS



17-bit Absolute

PIN No.	Application
1	FG(SHIELD)
2	BAT-
3	E0V
4	PS
5	BAT+
6	E5V
7	PS

Tightening torque of the screw (M2) 0.19 to 0.21 N·m

* Be sure to use only the screw supplied with the connector, to avoid damage.

Connector for motor



JN8AT04NJ1


PIN No.	Application
1	U-phase
2	V-phase
3	W-phase
PE	Ground

Tightening torque of the screw (M2) 0.085 to 0.095 N·m (screwed to plastic)

* Be sure to use only the screw supplied with the connector, to avoid damage.

[Motor with brake]

Connector for brake



JN4AT02PJM-R

PIN No.	Application
1	Brake
2	Brake

* Electromagnetic brake is a nonpolar device.

Tightening torque of the screw (M2) 0.19 to 0.21 N·m

* Be sure to use only the screw supplied with the connector, to avoid damage.

Remarks Do not connect anything to NC.



2. System Configuration and Wiring

Specifications of Motor connector

- When the motors of <MSME (750W (400V), 1.0 kW to 5.0 kW), MDME, MGME, MHME> are used, they are connected as shown below.

Connector: Made by Japan Aviation Electronics Industry, Ltd. (The figures below show connectors for the motor.)

Connector for encoder



JN2AS10ML3-R


20-bit Incremental

PIN No.	Application
1	E0V
2	NC
3	PS
4	E5V
5	NC
6	NC
7	PS
8	NC
9	FG(SHIELD)
10	NC


17-bit Absolute

PIN No.	Application
1	E0V
2	NC
3	PS
4	E5V
5	BAT-
6	BAT+
7	PS
8	NC
9	FG(SHIELD)
10	NC

Connector for motor




<without Brake>




JL04V-2E20-4PE-B-R

MSME	750W (400V) 1.0kW to 2.0kW
MDME	400W to 2.0kW
MGME	0.9kW
MHME	1.0kW to 1.5kW



JL04V-2E20-18PE-B-R

MFME	1.5kW (200V)
------	--------------



JL04V-2E24-11PE-B-R

MFME	1.5kW (400V) 2.5kW, 4.5kW
------	------------------------------

JL04HV-2E22-22PE-B-R

MSME	3.0kW to 5.0kW
MDME	3.0kW to 5.0kW
MGME	2.0kW to 4.5kW
MHME	2.0kW to 5.0kW


PIN No.	Application
A	U-phase
B	V-phase
C	W-phase
D	Ground

PIN No.	Application
G	NC
H	NC
A	NC
F	U-phase
I	V-phase
B	W-phase
E	Ground
D	Ground
C	NC


PIN No.	Application
A	NC
B	NC
C	NC
D	U-phase
E	V-phase
F	W-phase
G	Ground
H	Ground
I	NC

Connector for motor

Connector for brake



<Motor>




JL04V-2E32-17PE-B-R

MDME	7.5kW to 15.0kW
MGME	6.0kW
MHME	7.5kW

PIN No.	Application
A	U-phase
B	V-phase
C	W-phase
D	Ground

<Brake>




N/MS3102A 14S-2P

MDME	7.5kW to 15.0kW
MGME	6.0kW
MHME	7.5kW

PIN No.	Application
A	Brake
B	Brake
C	NC
D	NC


<with Brake> (200 V)



JL04V-2E20-18PE-B-R

MSME	1.0kW to 2.0kW
MDME	1.0kW to 2.0kW
MFME	1.5kW
MGME	0.9kW
MHME	1.0kW to 1.5kW

PIN No.	Application
G	Brake
H	Brake
A	NC
F	U-phase
I	V-phase
B	W-phase
E	Ground
D	Ground
C	NC




JL04V-2E24-11PE-B-R

MSME	3.0kW to 5.0kW
MDME	3.0kW to 5.0kW
MFME	2.5kW, 4.5kW
MGME	2.0kW to 4.5kW
MHME	2.0kW to 5.0kW

PIN No.	Application
A	Brake
B	Brake
C	NC
D	U-phase
E	V-phase
F	W-phase
G	Ground
H	Ground
I	NC

<with Brake> (400 V)



JL04V-2E24-11PE-B-R

MSME	750W to 5.0kW
MDME	400W to 5.0kW
MFME	1.5kW to 4.5kW
MGME	0.9kW to 4.5kW
MHME	1.0kW to 5.0kW

PIN No.	Application
A	Brake
B	Brake
C	NC
D	U-phase
E	V-phase
F	W-phase
G	Ground
H	Ground
I	NC


Remarks ⚠ Do not connect anything to NC.

- Follow the procedures below for the wiring connection to the Connector [XA], [XB] and [XC].

How to connect


1. Peel off the insulation cover of the cable.

- For single wire (Please obey the length in figure.)
- For stranded wires (ferrules must be used as illustrated below).




Example: Ferrules with plastic insulating sleeve (AI series, Phoenix Contact, Ltd.)

- Peel off the sheath so that the conductor portion of the cable will protrude from the tip of the ferrule. (It should protrude 1 mm or more from the ferrule.)
 - Insert the cable into the ferrule and crimp it with an appropriate crimping tool.
 - After crimping, cut off the cable conductor portion protruding from the ferrule. (The allowable protruding length after cutting should be 0 to 0.5 mm.)
- Part No. of the crimping tool: CRIMPFOX U-D66 (1204436)
Available from Phoenix Contact, Ltd.



Examples: Nylon-insulated ferrule (NTUB series, J.S.T. Mfg. Co., Ltd.) Vinyl-insulated ferrule (VTUB series, J.S.T. Mfg. Co., Ltd.)

- Peel off the sheath of the cable conductor portion to the length equal to that of sheath on the ferrule.
 - Insert the cable into the ferrule and crimp it with an appropriate crimping tool.
- Part No. of the crimping tool: YNT-1614
Available from J.S.T. Mfg. Co., Ltd



- When peeling off the sheath of the cable, take care not to damage other portions.
- When crimping the ferrule, sufficiently check the status of the ferrule and cable. If the conductors of the cable stick out from the insulation cover or protrude excessively from the tip of the ferrule, accidents such as an electric shock and fire from a short circuit may result.

2. Insert the cable to the connector in the following 2 methods.

- Insert the cable using the supplied handle lever.
- Insert the cable using a flat-blade screwdriver (Edge width: 3.0 to 3.5 mm).

(a) Using handle lever	(b) Using screw driver
<div data-bbox="225 1473 456 1648"> <p>1 Attach the handle lever to the handling slot on the upper portion. Press down the lever to push down the spring.</p> </div> <div data-bbox="225 1648 456 1823"> <p>2 Insert the peeled cable while pressing down the lever, until it hits the insertion slot (round hole).</p> </div> <div data-bbox="225 1823 456 1998"> <p>3 Release the lever.</p> <p>* You can pull out the cable by pushing down the spring as the above.</p> </div>	<div data-bbox="847 1473 1078 1648"> <p>1 Press the screw driver to the handling slot on the upper portion to push down the spring.</p> </div> <div data-bbox="847 1648 1078 1823"> <p>2 Insert the peeled cable while pressing down the screw driver, until it hits the insertion slot (round hole).</p> </div> <div data-bbox="847 1823 1078 1998"> <p>3 Release the screw driver.</p> </div>

- Take off the connector from the Servo Driver before making connection.
- Insert only one cable into each one of cable insertion slot.
- Pay attention to injury by screw driver.

3. Wiring to the connector, X1

Connecting host computer

This is used for USB connection to a personal computer. It is possible to change the parameter setting and perform monitoring.

Application	Symbol	Connector Pin No.	Contents
USB signal terminal	VBUS	1	Use for communication with personal computer.
	D–	2	
	D+	3	
	—	4	Do not connect.
	GND	5	Connected to ground of control circuit.



Caution Use commercially available USB mini-B connector for the driver.

4. Wiring to the connector, X2

Connecting communication connector

This is used for connection to the host controller when two or more units are used. RS232 and RS485 interfaces are supplied.

Application	Symbol	Connector Pin No.	Contents
Signal ground	GND	1	Connected to ground of control circuit.
NC	—	2	Do not connect.
RS232 signal	TXD	3	RS232 The transmission / reception method.
	RXD	4	
RS485 signal	485–	5	RS485 The transmission / reception method.
	485+	6	
	485–	7	
	485+	8	
Frame ground	FG	Shell	Connected with protective earth terminal in the servo driver.

Connector (plug): 2040008-1 (optional, available from Tyco Electronics)
[Connector pin assignment]

8	6	4	2
7	5	3	1

(Viewed from cable)



Remarks • X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.



Note • Only for position control type is not provided with X2.



Related page • P.7-110 "Connector Kit for Communication Cable (for RS485, RS232)"

4. Wiring to the connector, X2


Connecting host computer

- This servo driver features 2 kinds of communication function, RS232 and RS485, and you can use in 3 connecting methods.

To communicate with a single driver through RS232


Connect the host (PC or controller) to an driver through RS232.

[How to connect]



To communicate with multiple drivers through RS232 and RS485

By connecting the host (PC and host controller) and one driver via RS232 and connecting other drivers via RS485 each other, you can connect multiple drivers.




Note

- You can connect up to 32 drivers with the host.
- For details, refer to P.7-27, "Communication" of Supplement.

To communicate with multiple drivers only through RS485

Communications between the host (PC or controller) and multiple drivers can be made through RS485.



Note

- You can connect up to 31 drivers with the host.
- For details, refer to P.7-27, "Communication" of Supplement.

Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

Note

- Only for position control type is not provided with X2.

A safety by-pass plug is supplied as standard equipment. Do not disconnect it in normal times.

When controlling the safety function from the connected host controller, accessory connector cannot be used. Prepare and wire the connector (option) as specified below.

Since the standard connector cannot be used when controlling the safety function from the host controller, purchase the optional connector and make connection as shown below.

Application	Symbol	Connector Pin No.	Contents
NC	—	1	Do not connect.
	—	2	
Safety input 1	SF1—	3	These are two independent circuits that turn off the operation signal to the power module to shut off the motor current.
	SF1+	4	
Safety input 2	SF2—	5	
	SF2+	6	
EDM output	EDM—	7	This is an output for monitoring the failure of the safety function.
	EDM+	8	
Frame ground	FG	Shell	Connected with protective earth terminal in the servo driver.

Connector (plug): 2013595-1 (optional, available from Tyco Electronics)

[Connector pin assignment]

8	6	4	2
7	5	3	1

(Viewed from cable)

Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

Caution

- Disconnecting this connector during operation results in immediate stop.



Note

- Only for position control type is not provided with X2.

Related page

- P.7-110 "Connector Kit for Safety"

Tips on wiring



◦ Peripheral apparatus such as host controller should be located within 3m.

◦ Separate the main circuit at least 30cm away.
Don't pass them in the same duct, nor bind them together.

◦ Power supply for control signals (V_{CC}) between COM+ and COM- (V_{DC}) should be prepared by customer.

◦ Use shield twisted pair for the wiring of command pulse input and encoder signal output.

◦ Don't apply more than 24V to the control signal output terminals, nor run 50mA or more to them.

◦ When the relay is directly driven by the control output signals, install a diode in parallel with a relay, and in the direction as the Fig. shows. The driver might be damaged without a diode installment, or by reverse direction.

◦ Frame ground (FG) and the shell of connector is connected to the earth terminal inside of the driver.

Related page

• For details, refer to P.3-18, "Wiring Diagram to the connector, X4" and P.3-30, "Inputs and outputs on connector X4".

• Specifications of the Connector, X4

Connector at driver side	Connector to be prepared by customer		Manufacturer
	Part name	Part No.	
52986-5079 equivalent	Connector (soldering type)	54306-5019 equivalent	Molex Inc.
	Connector cover	54331-0501 equivalent	
or			
10250-52A2** equivalent	Connector (soldering type)	10150-3000PE equivalent	Sumitomo 3M
	Connector cover	10350-52A0-008 equivalent	

Note

• For details, refer to P.7-109, "Options" of Supplement.

Remarks

• Tightening torque of the screws for connector (X4) for the connection to the host to be 0.3 to 0.35N·m. Larger tightening torque than these may damage the connector at the driver side.

Remarks

• X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

Provide a power supply for the external scale on your part or use the following power output (250mA or less).

Application	Symbol	Connector Pin No.	Contents
Power supply output	EX5V	1	Supply the power of external scale or A, B, Z phase encoder.
	EX0V	2	Connected to ground of control circuit.
I/F of external scale signals	EXPS	3	Serial signal
	/EXPS	4	The transmission / reception method.
A, B, Z phase Encoder signal input	EXA	5	Parallel signal reception Correspondence speed : 4Mpps (after quadruple)
	/EXA	6	
	EXB	7	
	/EXB	8	
	EXZ	9	
	/EXZ	10	
Frame ground	FG	Shell	Connected with protective earth terminal in the servo driver.

Connector (plug) serial external signal: MUF-PK10K-X (by J.S.T. Mfg. Co., Ltd.)

• Caution

1) The manufacturers applicable external scales for this product are as follows.

- Mitutoyo Corp.
- Magnescale Co., Ltd.

For the details of the external scale product, contact each company.

2) **Recommended external scale ratio is $1/40 \leq \text{External scale ratio} \leq 160$**

If you set up the external scale ratio to smaller value than 50/position loop gain (Pr1.00 and Pr1.05), you may not be able to control per 1 pulse unit, even if within the range as described above. Setup of larger scale ratio may result in larger noise.

Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.
- Only for position control type is not provided with X5.

Note


Related page

- P.4-30, 4-31 "Details of Parameter" • P.7-110 "Connector Kit for External Scale"

7. Wiring to the connector, X5

Connect on to Feedback Scale

Wiring Diagram of X5




How to Wiring

Wire the signals from the external scale to the external scale connector, X5.

- 1) Cable for the external scale to be the twisted pair with bundle shielding and to having the twisted core wire with diameter of 0.18mm².
- 2) Cable length to be max. 20m. Double wiring for 5V power supply is recommended when the wiring length is long to reduce the voltage drop effect.
- 3) Connect the outer film of the shield wire of the external scale to the shield of the junction cable. Also connect the outer film of the shield wire to the shell (FG) of connector X5 of the driver without fail.
- 4) Separate the wiring to X7 from the power line (L1, L2, L3, B1, B2, B3, U, V, W, \oplus) as much as possible (30cm or more). Do not pass these wires in the same duct, nor bundle together.
- 5) Do not connect anything to the vacant pins of X5.
- 6) The maximum power available from the connector X5 is 250 mA at 5 V \pm 5%. If you use an external scale requiring more power, you should provide the suitable power source by yourself. Some external scales need longer initialization period after power up. Your design should meet this operation timing after power up.
- 7) When driving the external scale from an external power supply, keep the EX5V pin open circuit so that it does not receive any external voltage. Connect the GND circuit (0 V) to EX0V (connector X5, pin 2) of the driver to eliminate potential difference.

Input circuit

• EXA, EXB, EXZ input circuit




Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

Note

- Only for position control type is not provided with X5.

Tips on Wiring



- Maximum cable length between the driver and the motor to be 20m. Consult with a dealer or distributor if you want to use the longer cable than 20m. (Refer to the back cover.)
- Keep this wiring away from the main circuit by 30 cm or more. Don't guide this wiring through the same duct with the main, nor bind them together.
- The voltage of input power to encoder side connector should be in the range 4.90–5.25 VDC.
- When you make your own encoder junction cable (for connectors, refer to P.7-111, "Options (Connector Kit for Motor and Encoder connection)" of Supplement.

1) Refer to the Wiring Diagram below.

2) Cable to be : Shielded twisted pair cable with core diameter of 0.18mm² or larger (AWG24), and with higher bending resistance.

3) Use twisted pair cable for corresponding signal/power wiring.

4) Shielding treatment

- Shield wall of the driver side : It solders the shell of Connector X6.


- Shield wall of the motor side :

manufactured by JAE

Small type motor (50W to 750W): connect to 6-pins

Large type motor (0.9W to 15.0kW): connect to 9-pins

5) Connect nothing to the empty terminals of each connector.



Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

Related page




- P.7-111 "Connector Kit for Encoder"

8. Wiring to the connector, X6

Connection to Encoder

Wiring Diagram

• In case of 20-bit incremental encoder



Remarks


- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

8. Wiring to the connector, X6

Connection to Encoder

• In case of 17-bit absolute encoder

MSME 50W to 750W



Caution

- Tighten the motor connector mounting screw (M2) with a torque between 0.19 and 0.21 N·m. To avoid damage, be sure to use only the screw supplied with the connector.
- Do not remove the gasket supplied with the junction cable connector. Securely install the gasket in place. Otherwise, the degree of protection of IP67 will not be guaranteed.

Remarks

- Connect the battery for absolute encoder across 5P and 2P of the junction connector (the figure above).
- A battery holder and a battery connection cable should be the option cable or prepared by the user.


MSME 750W (400V), 1.0kW to 5.0kW

MFME 1.5kW to 4.5kW

MGME 0.9kW to 6.0kW

MDME 400W to 15.0kW

MHME 1.0kW to 7.5kW



Remarks

- Connect the battery for absolute encoder across 6P and 5P of the junction connector (the figure above).
- A battery holder and a battery connection cable should be the option cable or prepared by the user.

Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

9. Wiring to the connector, X7


Monitor output

The connector X7 of the front panel is for monitor output.

Analogue output : 2 systems

Digital output : 1 systems


In both cases, it is possible to switch the output signal by setting parameters.



Connector X7

Manufacturer's part No.: 530140610

Manufacturer: Japan Molex Inc.



Application	Symbol	Connector Pin No.	Contents
Analogue monitor output 1	AM1	1	<ul style="list-style-type: none"> Output the analogue signal for monitor. The amplitude of the output signal is ± 10 V. Output impedance is 1 kW. When connecting a measuring instrument, check its input circuit for impedance matching.
Analogue monitor output 2	AM2	2	
Signal ground	GND	3	
Digital monitor output *1	DM	4	<ul style="list-style-type: none"> Output the digital signal for monitor. Output voltage is CMOS level compatible. Output impedance is 2.2 kW. When connecting a measuring instrument, check its input circuit for impedance matching.
NC	—	5	Do not connect.
NC	—	6	Do not connect.

*1 Position, Velocity, torque, Full closed type.

NC on Only for position control type. Leave this pin unconnected.

• Parameter rerated to monitor output.

Parametr No.		Title	Function
Class	No.		
4	16	Type of analog monitor 1	Select the type of monitor for analog monitor 1.
4	17	Analog monitor 1 output gain	Set up the output gain of analog monitor 1.
4	18	Type of analog monitor 2	Select the type of monitor for analog monitor 2.
4	19	Analog monitor 2 output gain	Set up the output gain of analog monitor 2.
4	20	Type of digital monitor	Select type of the digital monitor.
4	21	Analog monitor output setup	Select output format of the analog monitor.

*1 Position, Velocity, torque, Full closed type.

Only for position control type is not provided with this function.


Remarks

- X1 to X7 are used for the secondary circuit. To connect these terminals to the primary power supply (particularly, the 24 VDC power supply for control, the 24 VDC power supply for brake, and the 24 VDC power supply for regenerative resistor [H-frame only]), insulation is required. Do not connect these terminals to the same power supply.

Related page

- P.4-36... "Details of parameter" • P.7-111 "Connector Kit for Analog Monitor Signal"

Servo-on signal accept timing on power-up



- The above chart shows the timing from AC power-ON to command input.
- Activate the external command input according to the above timing chart.


Caution

- *1. In this term Servo-ON input (SRV-ON) turns ON as a hard ware, but operation command can not be received.
 - *2. S-RDY output will turn on when both conditions are met, initialization of micro computer has been completed and the main power has been turned on.
 - *3. After Internal control power supply, protective functions are active from approx. 1.5 sec after the start of initializing microcomputer. Please set the signals, especially for protective function, for example over-travel inhibit input (POT, NOT) or external scale input, so as to decide their logic until this term.
- The lapse time can be changed with Pr6.18 Wait time after power-up.

Related page

• P.4-54... "Details of parameter"

When an Error (Alarm) Has Occurred (at Servo-ON Command)


**Caution**

*1. t1 will be a shorter time of either the setup value of Pr4.38[Mechanical brake action at running setup] or elapsing time for the motor speed to fall below Pr4.39[Brake release speed setup].

t1 will be 0 when the motor is in stall regardless of the setup pf Pr4.37.

*2. When an alarm is generated, the dynamic brake operates according to Pr5.10 Sequence at alarm.


When an Alarm Has Been Cleared (at Servo-ON Command)

**Caution**

*1. The alarm clear input recognition time can be changed in Pr5.16 Alarm clear input setup.

Servo-ON/OFF Action While the Motor Is at Stall (Servo-Lock)


Remarks ✨ To turn on/off the servo during normal operation, first stop the motor.



- Caution** ✨
- *1 t1 depends on the setup value of Pr4.37 Setup of mechanical brake action at stalling.
 - *2 The operation of dynamic brake during servo off depends on the setup value of Pr5.06 Sequence at servo off.
 - *3. Servo-ON will not be activated until the motor speed falls below approx. 30r/min.

Servo-ON/OFF Action While the Motor Is in Motion

Remarks ⚙️ Timing at emergency stop or trip. Do not repeat this sequence.



- Caution** ⚙️
- *1. t1 will be a shorter time of either the setup value of Pr4.38 "Mechanical brake action at running setup" or elapsing time for the motor speed to fall below Pr4.39 "Brake release speed setup".
 - *2. Even though the SRV-ON signal is turned on again during the motor deceleration, Servo-ON will not be activated until the motor stops.
 - *3. For the action of dynamic brake at alarm occurrence, refer to an explanation of Pr5.06, "Sequence at Servo-OFF" as well.
 - *4. Servo-ON will not be activated until the motor speed falls below approx. 30r/min.
 - *5. For the motor energization during deceleration at Servo-OFF depends on the setup value of Pr5.08, "Sequence at Servo-OFF".


In the applications where the motor drives the vertical axis, this brake would be used to hold and prevent the work (moving load) from falling by gravity while the power to the servo is shut off.

Caution

Use this built-in brake for "Holding" purpose only, that is to hold the stalling status. Never use this for "Brake" purpose to stop the load in motion.

Connecting Example

The following shows the example when the brake is controlled by using the brake release output signal (BRK-OFF) of the driver.

**Note**

1. The brake coil has no polarity.

Caution

2. Power supply for the brake to be provided by customer. Do not co-use the power supply for the brake and for the control signals (VDC).
3. Install a surge absorber as the above Fig. shows to suppress surge voltage generated by ON/OFF action of the relay (RY). When you use a diode, note that the time from the brake release to brake engagement is slower than that of the case of using a surge absorber.
4. For a surge absorber, refer to P.7-124, "Recommended Components" of Supplement.
5. Recommended components are specified to measure the brake releasing time. Reactance of the cable varies depending on the cable length, and it might generate surge voltage. Select a surge absorber so that relay coil voltage (max. rating : 30V, 50mA) and terminal voltage may not exceed the rating.

Output Timing of BRK-OFF Signal

- For the brake release timing at power-on, or braking timing at Servo-OFF/Servo-Alarm while the motor is in motion, refer to P.2-61, "Timing Chart".
- With the parameter, Pr4.38 (Setup of mechanical brake action while the motor is in motion), you can set up a time between when the motor enters to a free-run from energized status and when BRK-OFF signal turns off (brake will be engaged), when the Servo-OFF or alarm occurs while the motor is in motion.

Note

1. The lining sound of the brake (chattering and etc.) might be generated while running the motor with built-in brake, however this does not affect any functionality.
2. Magnetic flux might be generated through the motor shaft while the brake coil is energized (brake is open). Pay an extra attention when magnetic sensors are used nearby the motor.

11. Built-in Holding Brake

Specifications

Motor series	Motor output	Static friction torque N·m	Rotor inertia x 10 ⁻⁴ kg·m ²	Engaging time ms	Releasing time ms	Exciting current DC A (at cool-off)	Releasing voltage	Permissible work (J) per one braking	Permissible total work x 10 ³ J	Permissible angular acceleration rad/s ²
MSMD	50W, 100W	0.29 or less	0.002	35 or less	20 or less	0.3	DC1V or more	39.2	4.9	30000
	200W, 400W	1.27 or less	0.018	50 or less	15 or less	0.36		137	44.1	
	750W	2.45 or less	0.075	70 or less	20 or less	0.42		196	147	
MSME	50W, 100W	0.29 or less	0.002	35 or less	20 or less	0.3	DC1V or more	39.2	4.9	30000
	200W, 400W	1.27 or less	0.018	50 or less	15 or less	0.36		137	44.1	
	750W(200V)	2.45 or less	0.075	70 or less	20 or less	0.42		196	147	
	750W(400V)	2.5 or less	0.33	50 or less	15 or less	0.7	DC2V or more	392	490	10000
	1.0kW, 1.5kW, 2.0kW	7.8 or less		15 or less (100)	0.81					
	3.0kW	11.8 or less		80 or less						
	4.0kW, 5.0kW	16.2 or less	1.35	110 or less	50 or less (130)	0.9		1470	2200	
MDME	400W, 600W	2.5 or less	1.35	50 or less	15 or less	0.70	DC2V or more	392	490	10000
	1.0kW	4.9 or less		80 or less	70 or less (200)	0.59		588	780	
	1.5kW, 2.0kW	13.7 or less		100 or less	50 or less (130)	0.79		1176	1500	
	3.0kW	16.2 or less		110 or less	0.9	1470		2200		
	4.0kW, 5.0kW	24.5 or less	4.7	80 or less	25 or less (200)	1.3		1372	2900	5440
	7.5kW	58.8 or less		150 or less	50 or less	1.4				5000
	11kW, 15kW	100 or less	7.1	300 or less	140 or less	1.08		2000	4000	3000
MFME	1.5kW	7.8 or less	4.7	80 or less	35 or less	0.83	DC2V or more	1372	2900	10000
	2.5kW	21.6 or less	8.75	150 or less	100 or less	0.75		1470	1500	
	4.5kW	31.4 or less							2200	
MGME	0.9kW	13.7 or less	1.35	100 or less	50 or less (130)	0.79	DC2V or more	1176	1500	10000
	2.0kW	24.5 or less	4.7	80 or less	25 or less (200)	1.3		1372	2900	5440
	3.0kW	58.8 or less		150 or less	50 or less (130)	1.4				
	4.5kW, 6.0kW				50 or less					
MHMD	200W, 400W	1.27 or less	0.018	50 or less	15 or less	0.36	DC1V or more	137	44.1	30000
	750W	2.45 or less	0.075	70 or less	20 or less	0.42		196	147	
MHME	1.0kW	4.9 or less	1.35	80 or less	70 or less (200)	0.59	DC2V or more	588	780	10000
	1.5kW	13.7 or less		100 or less	50 or less (130)	0.79		1176	1500	
	2.0kW to 5.0kW	24.5 or less	4.7	80 or less	25 or less (200)	1.3		1372	2900	5440
	7.5kW	58.8 or less		150 or less	50 or less	1.4				5000

- Excitation voltage is DC24V±10%.
- Releasing time values represent the ones with DC-cutoff using a varistor.
Values in () represent those measured by using a diode (V03C by Hitachi, Ltd.)
- Above values (except static friction torque, releasing voltage and excitation current) represent typical values.
- Backlash of the built-in holding brake is kept ±1° or smaller at ex-factory point.
- Service life of the number of acceleration/deceleration with the above permissible angular acceleration is more than 10 million times. (Life end is defined as when the brake backlash drastically changes.)

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

This driver (A to G-frame) is equipped with a dynamic brake for emergency stop.
Pay a special attention to the followings.
The H-frame driver does not incorporate the dynamic brake.

Caution

1. Dynamic brake is only for emergency stop.

Do not start/stop the motor by turning on/off the Servo-ON signal (SRV-ON). Otherwise it may damage the dynamic brake circuit of the driver.

The Motor becomes a dynamo when driven externally and short circuit current occurred while dynamic brake is activated may cause smoking or fire.

2. Dynamic brake is a short-duration rating, and designed for only emergency stop. Allow approx. 10 minutes pause when the dynamic brake is activated during high-speed running. (F-frame(200V), G-frame(200V/400V) built-in dynamic brake resistor is capable of handling up to 3 continuous halts at the rated revolutions with max. permissible inertia. When overheated under more critical operating conditions, the brake will blow out and should be replaced with a new one.)

• **You can activate the dynamic brake in the following cases.**


- 1) When the main power is turned off
- 2) At Servo-OFF
- 3) When one of the protective function is activated.
- 4) When over-travel inhibit input (NOT, POT) of connector X4 is activated

In the above cases from 1) to 4), you can select either activation of the dynamic brake or making the motor free-run during deceleration or after the stop, with parameter.

Note that when the control power is off, for A to F-frame driver, the dynamic brake will be kept activated, and for G and H-frame driver, the dynamic brake will be kept released.


- If the built-in dynamic brake resistor of the G-frame driver is insufficient, external dynamic brake resistors can be connected.
- For the H-frame driver, external dynamic brake resistors can be connected. Connections of the external dynamic brake resistors are the same as those of the G-frame driver. (The DB3 and DB4 terminals are not provided.)
- Use the following resistors as the external dynamic brake resistors. (To be prepared by user)

Driver		Resistance specifications per piece		Quantity of use
Frame	Voltage	Resistance	Electric power	
G, H	200V	1.2Ω	400W	3 pcs.
G, H	400V	4.8Ω	400W	3 pcs.

**Related page**

- P.3-38 "Inputs and outputs on connector X4"
- P.4-44... "Details of Parameter"
- P.6-5 "Protective Function"

G-frame, 200 V

**Magnetic Contactor (MC)**

Turns on/off the dynamic brake resistor.
Use coil surge suppression units together with this.

Remarks

- Use the same magnetic contactor as that of the main circuit.
- Provide an auxiliary contact for protection, **so that the servo does not turn on with an external sequence when the dynamic brake resistor is fused.**

Dynamic Brake Resistor (to be supplied by customer)

Remarks

- When you use an external dynamic brake resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Mount the dynamic brake resistor **on incombustible material such as metal.**
- **Do not use an external dynamic brake resistor together with the built-in resistor.**
- **Provide one dynamic brake resistor for each phase.**
- When using an external dynamic brake, be sure to use the resistor.
Do not make short circuit.

Terminals DB1, DB2, DB3 and DB4

- To connect an external dynamic brake resistor, disconnect the shorting bar between DB3 and DB4.
- Connect a magnetic contactor (for control) for the external dynamic brake between L1C and DB1.
- Provide an external protective device (e.g. thermal fuse) between DB2 and LC2.

Remarks

- **The voltage applied across DB1 and DB2 must be 300 VAC or below or 100 VDC or below.**


Pin NC

- Do not connect anything.

12. Dynamic Brake

Connections of external dynamic brake resistor (Example)

G-frame, 400 V



Magnetic Contactor (MC)

Turns on/off the dynamic brake resistor.
Use coil surge suppression units together with this.

Remarks

- Use the same magnetic contactor as that of the main circuit.
- Provide an auxiliary contact for protection, **so that the servo does not turn on with an external sequence when the dynamic brake resistor is fused.**

Dynamic Brake Resistor (to be supplied by customer)

Remarks

- When you use an external dynamic brake resistor, **install an external protective apparatus, such as thermal fuse without fail.**
- Mount the dynamic brake resistor **on incombustible material such as metal.**
- **Do not use an external dynamic brake resistor together with the built-in resistor.**
- **Provide one dynamic brake resistor for each phase.**
- When using an external dynamic brake, be sure to use the resistor.
Do not make short circuit.

Terminals DB1, DB2, DB3 and DB4

- To connect an external dynamic brake resistor, disconnect the shorting bar between DB3 and DB4.
- Connect a magnetic contactor (for control) for the external dynamic brake between L1C and DB1.
- Provide an external protective device (e.g. thermal fuse) between DB2 and the neutral point.

Remarks

- **The voltage applied across DB1 and DB2 must be 300 VAC or below or 100 VDC or below.**

Note

- L1C is connected after the R-phase of the noise filter.
- L1C is not indicated on the driver body.

Pin NC

- Do not connect anything.

12. Dynamic Brake

Condition setting chart

1) Setup of driving condition from deceleration to after stop by main power-off (Pr5.07)

Sequence at main power-off (Pr5.07)	Driving condition		Contents of deviation counter
	During deceleration	After stalling	
Setup value of Pr5.07 ↓			
0	D B	D B	Clear
1	Free-run	D B	Clear
2	D B	Free-run	Clear
3	Free-run	Free-run	Clear
4	D B	D B	Hold
5	Free-run	D B	Hold
6	D B	Free-run	Hold
7	Free-run	Free-run	Hold
8	Emergency stop	D B	Clear
9	Emergency stop	Free-run	Clear

Torque limit value at emergency stop will be that of Pr5.11 (Setup of torque at emergency stop) when the setup value is 8 or 9.

2) Setup of driving condition from deceleration to after stop by Servo-OFF (Pr5.06)

Sequence at main Servo-OFF (Pr5.06)	Driving condition		Contents of deviation counter
	During deceleration	After stalling	
Setup value of Pr5.06 ↓			
0	D B	D B	Clear
1	Free-run	D B	Clear
2	D B	Free-run	Clear
3	Free-run	Free-run	Clear
4	D B	D B	Hold
5	Free-run	D B	Hold
6	D B	Free-run	Hold
7	Free-run	Free-run	Hold
8	Emergency stop	D B	Clear
9	Emergency stop	Free-run	Clear

Torque limit value at emergency stop will be that of Pr5.11 (Setup of torque at emergency stop) when the setup value is 8 or 9.

12. Dynamic Brake

Condition setting chart

3) Setup of driving condition from deceleration to after stop by activation of protective function (Pr5.10)

Sequence at over-travel inhibit input (Pr5.10)	Driving condition		Contents of deviation counter
	During deceleration	After stalling	
Setup value of Pr5.10 ↓			
0	D B	D B	Hold
1	Free-run	D B	Hold
2	D B	Free-run	Hold
3	Free-run	Free-run	Hold
4	Engaged A: Emergency stop Engaged B: DB	D B	Hold
5	Engaged A: Emergency stop Engaged B: Free-run	D B	Hold
6	Engaged A: Emergency stop Engaged B: DB	Free-run	Hold
7	Engaged A: Emergency stop Engaged B: Free-run	Free-run	Hold

When setup value is within the range 4 and 7, the protection function that supports immediate stop acts according to operation A and the function that does not support acts according to operation B.

During deceleration to stop, the main power supply must be maintained.

When the protection function acts, content of deviation counter is cleared as the alarm is cleared.

4) Setup of driving condition from deceleration to after stop by validation of over-travel inhibit input (Pr5.05)

Sequence at over-travel inhibit input (Pr5.05)	Driving condition		Contents of deviation counter
	During deceleration	After stalling	
Setup value of Pr5.05 ↓			
0	DB	Torque command to inhibited direction is 0	Hold
1	Torque command to inhibited direction is 0	Torque command to inhibited direction is 0	Hold
2	Emergency stop	Torque command to inhibited direction is 0	clear

Torque limit value during deceleration will be that of Pr5.11 (Setup of torque at emergency stop) when the setup value is 2.

Changes will be validated after the control power is turned on.

Outline of Parameter

This driver is equipped with various parameters to set up its characteristics and functions. This section describes the function and purpose of each parameter. Read and comprehend very well so that you can adjust this driver in optimum condition for your running requirements.

Setup of Parameter

- You can refer and set up the parameter with either one of the following.
 - 1) front panel of the driver
 - 2) combination of the setup support software, "PANATERM" and PC.

Note

How to control the front panel, refer to P.2-86.

Setup with the PC

It is possible to connect your personal computer to connector X1 of MINAS A5 using a USB cable for personal computer connection. Downloading the setup support software "PANATERM" from our web site and installing it on your personal computer will allow you to perform the following easily.


• **With the PANATERM, you can execute the followings.**

- 1) Setup and storage of parameters, and writing to the memory (EEPROM).
- 2) Monitoring of I/O, pulse input and load factor.
- 3) Display of the present alarm and reference of the error history.
- 4) Data measurement of the wave-form graphic and bringing of the stored data.
- 5) Normal auto-gain tuning
- 6) Frequency characteristic measurement of the machine system.

Note

Because no production software such as CD-ROM is available, download the setup support software from our web site and install it on your personal computer.

• **How to Connect**



• **USB cable**

On the driver, use commercially available USB mini-B connector.

The connector on the personal computer side should be in accordance with the specifications of the PC.

When the cable does not have noise filter, attach a signal line noise filter (DV0P1460) to both ends of the cable.

Related page

- P.4-2 "Details of Parameter"
- P.7-26 "Setup support software [PANATERM]"

- The parameter No. is displayed in the form of PrX.YY (X: Classification, YY: No.).
- For the details on the parameters, refer to P.4-4 “Details of parameter”.

Parametr No.		Class name	Group	page
Class	No.*			
0	00 to 17	Basic setting	Parameter for Basic setting	P.2-74
1	00 to 27	Gain adjustment	Parameter for Gain adjustment	P.2-75
2	00 to 23	Damping control	Parameter for Damping control	P.2-76
3	00 to 29	Verocity/ Torque/ Full-closed control	Parameter for Verocity/ Torque/ Full-closed control	P.2-77
4	00 to 44	I/F monitor setting	Parameter for I/F monitor setting	P.2-78
5	00 to 35	Enhancing setting	Parameter for Enhancing setting	P.2-79
6	00 to 39	Special setting	Parameter for Special setting	P.2-81

* The Parameter No. consists of 2 digits.

- In this document, following symbols represent each mode.

Symbol	Control mode	Setup value of Pr0.01
P	Position control	0
S	Velocity control	1
T	Torque control	2
F	Full-Closed control	6
P/S	Position (1st)/Velocity (2nd) control	3 *
P/T	Position (1st)/Torque (2nd) control	4 *
S/T	Velocity (1st)/Torque (2nd) control	5 *

* When you select the combination mode of 3, 4 or 5, you can select either 1st or 2nd with control mode switching input (C-MODE).

When C-MODE is ON : 1st mode selection

When C-MODE is OFF : 2nd mode selection

Do not enter the command 10ms before/after the switching.

13. Setup of Parameter and Mode

List of Parameters

[Class 0] Basic setting

Parametr No.	Class	No.	Title	Range	Default				Unit	Turning on of power supply	Related Control Mode				Detail page
					A,B -frame	C -frame	D,E,F -frame	G,H -frame			P	S	T	F	
0	00		Rotational direction setup	0 to 1	1				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-4
0	01		Control mode setup	0 to 6	0				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
0	02		Real-time auto-gain tuning setup	0 to 6	1				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-5
0	03		Selection of machine stiffness at real-time auto-gain tuning	0 to 31	13		11		–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
0	04		Inertia ratio	0 to 10000	250				%	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-6
0	05		Selection of command pulse input	0 to 1	0				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
0	06		Command pulse rotational direction setup	0 to 1	0				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-7
0	07		Command pulse input mode setup	0 to 3	1				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
0	08		Command pulse counts per one motor revolution	0 to 2 ²⁰	10000				pulse	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-8
0	09		1st numerator of electronic gear	0 to 2 ³⁰	0				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
0	10		Denominator of electronic gear	0 to 2 ³⁰	10000				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
0	11		Output pulse counts per one motor revolution	1 to 262144	2500				P/r	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-9
0	12		Reversal of pulse output logic	0 to 3	0				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-11
0	13		1st torque limit	0 to 500	500 ^{*1}				%	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
0	14		Position deviation excess setup	0 to 2 ²⁷	100000				Command unit	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
0	15		Absolute encoder setup	0 to 2	1				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-12
0	16		External regenerative resistor setup	0 to 3	3	0	3		–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
0	17		Load factor of external regenerative resistor selection	0 to 4	0				–	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

* Definition of symbols under “Power Off/On” - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

* Definition of symbols under “Related mode” - P: position control, S: velocity control, T: torque control, F: full closed control

*1 Default settings depend on the combination of driver and motor. Refer to P. 2-82 “Torque limit setting”.

Note



Parameter describes of this page is P.4-4 to P.4-12.

13. Setup of Parameter and Mode

List of Parameters

[Class 1] Gain adjustment

Parametr No.	Class	No.	Title	Range	Default				Unit	Turning on of power supply	Related Control Mode				Detail page
					A,B -frame	C -frame	D,E,F -frame	G,H -frame			P	S	T	F	
1	00		1st gain of position loop	0 to 30000	480		320		0.1/s*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-13
1	01		1st gain of velocity loop	1 to 32767	270		180		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	02		1st time constant of velocity loop integration	1 to 10000	210		310		0.1ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	03		1st filter of speed detection	0 to 5	0				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	04		1st time constant of torque filter	0 to 2500	84		126		0.01ms		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-14
1	05		2nd gain of position loop	0 to 30000	570		380		0.1/s*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	06		2nd gain of velocity loop	1 to 32767	270		180		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	07		2nd time constant of velocity loop integration	1 to 10000	10000				0.1ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	08		2nd filter of speed detection	0 to 5	0				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	09		2nd time constant of torque filter	0 to 2500	84		126		0.01ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	10		Velocity feed forward gain	0 to 1000	300				0.10%*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-15
1	11		Velocity feed forward filter	0 to 6400	50				0.01ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	12		Torque feed forward gain	0 to 1000	0				0.10%*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	13		Torque feed forward filter	0 to 6400	0				0.01ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	14		2nd gain setup	0 to 1	1				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-16
1	15		Mode of position control switching	0 to 10	0				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	16		Delay time of position control switching	0 to 10000	50				0.1ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-17
1	17		Level of position control switching	0 to 20000	50				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	18		Hysteresis at position control switching	0 to 20000	33				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	19		Position gain switching time	0 to 10000	33				0.1ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-18
1	20		Mode of velocity control switching	0 to 5	0				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	21		Delay time of velocity control switching	0 to 10000	0				0.1ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	22		Level of velocity control switching	0 to 20000	0				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	23		Hysteresis at velocity control switching	0 to 20000	0				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-19
1	24		Mode of torque control switching	0 to 3	0				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	25		Delay time of torque control switching	0 to 10000	0				0.1ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	26		Level of torque control switching	0 to 20000	0				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
1	27		Hysteresis at torque control switching	0 to 20000	0				–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

* Definition of symbols under “Power Off/On” - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

* Definition of symbols under “Related mode” - P: position control, S: velocity control, T: torque control, F: full closed control

Caution

The symbol “*” attached to “Unit”. indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note

Parameter describes of this page is P.4-13 to P.4-19.

13. Setup of Parameter and Mode

List of Parameters

[Class 2] Damping control

Parametr No.	Class	No.	Title	Range	Default				Unit	Turning on of power supply	Related Control Mode				Detail page
					A,B -frame	C -frame	D,E,F -frame	G,H -frame			P	S	T	F	
2	00		Adaptive filter mode setup	0 to 4			0		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-20
2	01		1st notch frequency	50 to 5000			5000		Hz		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	02		1st notch width selection	0 to 20			2		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	03		1st notch depth selection	0 to 99			0		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	04		2nd notch frequency	50 to 5000			5000		Hz		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	05		2nd notch width selection	0 to 20			2		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	06		2nd notch depth selection	0 to 99			0		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-21
2	07		3rd notch frequency	50 to 5000			5000		Hz		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	08		3rd notch width selection	0 to 20			2		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	09		3rd notch depth selection	0 to 99			0		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	10		4th notch frequency	50 to 5000			5000		Hz		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	11		4th notch width selection	0 to 20			2		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	12		4th notch depth selection	0 to 99			0		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-22
2	13		Selection of damping filter switching	0 to 3			0		–		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	14		1st damping frequency	0 to 2000			0		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
2	15		1st damping filter setup	0 to 1000			0		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-23
2	16		2nd damping frequency	0 to 2000			0		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-22
2	17		2nd damping filter setup	0 to 1000			0		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-23
2	18		3rd damping frequency	0 to 2000			0		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-22
2	19		3rd damping filter setup	0 to 1000			0		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-23
2	20		4th damping frequency	0 to 2000			0		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-22
2	21		4th damping filter setup	0 to 1000			0		0.1Hz*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-23
2	22		Positional command smoothing filter	0 to 10000			0		0.1ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-24
2	23		Positional command FIR filter	0 to 10000			0		0.1ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

* Definition of symbols under “Power Off/On” - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

* Definition of symbols under “Related mode” - P: position control, S: velocity control, T: torque control, F: full closed control

Caution

The symbol “*” attached to “Unit”. indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note

Parameter describes of this page is P.4-20 to P.4-24.

13. Setup of Parameter and Mode

List of Parameters

[Class 3] Velocity/ Torque/ Full-closed control

Parametr No.	Class	No.	Title	Range	Default				Unit	Turning on of power supply	Related Control Mode				Detail page
					A,B -frame	C -frame	D,E,F -frame	G,H -frame			P	S	T	F	
3	00		Speed setup, Internal/External switching	0 to 3			0		–			<input type="radio"/>			4-25
3	01		Speed command rotational direction selection	0 to 1			0		–			<input type="radio"/>			
3	02		Input gain of speed command	10 to 2000			500		(r/min)/ V			<input type="radio"/>	<input type="radio"/>		4-26
3	03		Reversal of speed command input	0 to 1			1		–			<input type="radio"/>			
3	04		1st speed of speed setup	–20000 to 20000			0		r/min			<input type="radio"/>			4-27
3	05		2nd speed of speed setup	–20000 to 20000			0		r/min			<input type="radio"/>			
3	06		3rd speed of speed setup	–20000 to 20000			0		r/min			<input type="radio"/>			
3	07		4th speed of speed setup	–20000 to 20000			0		r/min			<input type="radio"/>			
3	08		5th speed of speed setup	–20000 to 20000			0		r/min			<input type="radio"/>			
3	09		6th speed of speed setup	–20000 to 20000			0		r/min			<input type="radio"/>			
3	10		7th speed of speed setup	–20000 to 20000			0		r/min			<input type="radio"/>			
3	11		8th speed of speed setup	–20000 to 20000			0		r/min			<input type="radio"/>			
3	12		Acceleration time setup	0 to 10000			0		ms/ (1000r/min)			<input type="radio"/>			4-28
3	13		Deceleration time setup	0 to 10000			0		ms/ (1000r/min)			<input type="radio"/>			
3	14		Sigmoid acceleration/ deceleration time setup	0 to 1000			0		ms			<input type="radio"/>			
3	15		Speed zero-clamp function selection	0 to 3			0		–			<input type="radio"/>	<input type="radio"/>		
3	16		Speed zero clamp level	10 to 20000			30		r/min			<input type="radio"/>	<input type="radio"/>		4-29
3	17		Selection of torque command	0 to 2			0		–				<input type="radio"/>		
3	18		Torque command direction selection	0 to 1			0		–				<input type="radio"/>		
3	19		Input gain of torque command	10 to 100			30		0.1V/100%*				<input type="radio"/>		
3	20		Input reversal of torque command	0 to 1			0		–				<input type="radio"/>		4-30
3	21		Speed limit value 1	0 to 20000			0		r/min				<input type="radio"/>		
3	22		Speed limit value 2	0 to 20000			0		r/min				<input type="radio"/>		
3	23		External scale selection	0 to 2			0		–	<input type="radio"/>				<input type="radio"/>	4-31
3	24		Numerator of external scale division	0 to 2 ²⁰			0		–	<input type="radio"/>				<input type="radio"/>	
3	25		Denominator of external scale division	1 to 2 ²⁰			10000		–	<input type="radio"/>				<input type="radio"/>	
3	26		Reversal of direction of external scale	0 to 1			0		–	<input type="radio"/>				<input type="radio"/>	
3	27		External scale Z phase disconnection detection disable	0 to 1			0		–	<input type="radio"/>				<input type="radio"/>	4-32
3	28		Hybrid deviation excess setup	1 to 2 ²⁷			16000		Command unit	<input type="radio"/>				<input type="radio"/>	
3	29		Hybrid deviation clear setup	0 to 100			0		Revolution	<input type="radio"/>				<input type="radio"/>	

* Definition of symbols under “Power Off/On” - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

* Definition of symbols under “Related mode” - P: position control, S: velocity control, T: torque control, F: full closed control

Caution

The symbol “*” attached to “Unit”. indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note

Parameter describes of this page is P.4-25 to P.4-32.

13. Setup of Parameter and Mode

List of Parameters

[Class 4] I/F monitor setting

Parametr No.	Class	No.	Title	Range	Default				Unit	Turning on of power supply	Related Control Mode				Detail page
					A,B -frame	C -frame	D,E,F -frame	G,H -frame			P	S	T	F	
4	00		SI1 input selection (Pin No.8)	0 to 00FFFFFFh	8553090				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-33
4	01		SI2 input selection (Pin No.9)	0 to 00FFFFFFh	8487297				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-34
4	02		SI3 input selection (Pin No.26)	0 to 00FFFFFFh	9539850				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	03		SI4 input selection (Pin No.27)	0 to 00FFFFFFh	394758				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	04		SI5 input selection (Pin No.28)	0 to 00FFFFFFh	4108				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	05		SI6 input selection (Pin No.29)	0 to 00FFFFFFh	197379				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	06		SI7 input selection (Pin No.30)	0 to 00FFFFFFh	3847				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	07		SI8 input selection (Pin No.31)	0 to 00FFFFFFh	263172				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	08		SI9 input selection (Pin No.32)	0 to 00FFFFFFh	328965				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	09		SI10 input selection (Pin No.33)	0 to 00FFFFFFh	3720				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	10		SO1 output selection (Pin No.10, 11 Line driver output)	0 to 00FFFFFFh	197379				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-35
4	11		SO2 output selection (Pin No.34, 35 Line driver output)	0 to 00FFFFFFh	131586				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	12		SO3 output selection (Pin No.36, 37 Line driver output)	0 to 00FFFFFFh	65793				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	13		SO4 output selection (Pin No.38, 39 Line driver output)	0 to 00FFFFFFh	328964				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	14		SO5 output selection (Pin No.12 Open collector output)	0 to 00FFFFFFh	460551				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	15		SO6 output selection (Pin No.40 Open collector output)	0 to 00FFFFFFh	394758				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	16		Type of analog monitor 1	0 to 21	0				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-36
4	17		Analog monitor 1 output gain	0 to 214748364	0				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	18		Type of analog monitor 2	0 to 21	4				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	19		Analog monitor 2 output gain	0 to 214748364	0				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	20		Type of digital monitor	0 to 3	0				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	21		Analog monitor output setup	0 to 2	0				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-38
4	22		Analog input 1 (AI1) offset setup	−5578 to 5578	0				0.366mV	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	23		Analog input 1 (AI1) filter	0 to 6400	0				0.01ms*	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	24		Analog input 1 (AI1) overvoltage setup	0 to 100	0				0.1V*	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	25		Analog input 2 (AI2) offset setup	−342 to 342	0				5.86mV	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	26		Analog input 2 (AI2) filter	0 to 6400	0				0.01ms*	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	27		Analog input 2(AI2) overvoltage setup	0 to 100	0				0.1V*	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	28		Analog input 3 (AI3) offset setup	−342 to 342	0				5.86mV	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	29		Analog input 3 (AI3) filter	0 to 6400	0				0.01ms*	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-39

* Definition of symbols under “Power Off/On” - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

* Definition of symbols under “Related mode” - P: position control, S: velocity control, T: torque control, F: full closed control

Caution

The symbol “*” attached to “Unit”. indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note

Parameter describes of this page is P.4-33 to P.4-39.

13. Setup of Parameter and Mode

List of Parameters

Parametr No.	Class	No.	Title	Range	Default				Unit	Turning on of power supply	Related Control Mode				Detail page
					A,B -frame	C -frame	D,E,F -frame	G,H -frame			P	S	T	F	
4	30		Analog input 3 (AI3) overvoltage setup	0 to 100	0				0.1V*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-39
4	31		Positioning complete (In-position) range	0 to 262144	10				Command unit		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	32		Positioning complete (In-position) output setup	0 to 3	0				—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	33		INP hold time	0 to 30000	0				1ms		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	34		Zero-speed	10 to 20000	50				r/min		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-40
4	35		Speed coincidence range	10 to 20000	50				r/min		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	36		At-speed (Speed arrival)	10 to 20000	1000				r/min		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-41
4	37		Mechanical brake action at stalling setup	0 to 10000	0				1ms		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	38		Mechanical brake action at running setup	0 to 10000	0				1ms		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	39		Brake release speed setup	30 to 3000	30				r/min	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-42
4	40		Selection of alarm output 1	0 to 10	0				—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	41		Selection of alarm output 2	0 to 10	0				—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
4	42		2nd Positioning complete (In-position) range	0 to 262144	10				Command unit		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

* Definition of symbols under “Power Off/On” - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

* Definition of symbols under “Related mode” - P: position control, S: velocity control, T: torque control, F: full closed control

[Class 5] Enhancing setting

Parametr No.	Class	No.	Title	Range	Default				Unit	Turning on of power supply	Related Control Mode				Detail page
					A,B -frame	C -frame	D,E,F -frame	G,H -frame			P	S	T	F	
5	00		2nd numerator of electronic gear	0 to 2 ³⁰	0				—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-43
5	01		3rd numerator of electronic gear	0 to 2 ³⁰	0				—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	02		4th numerator of electronic gear	0 to 2 ³⁰	0				—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	03		Denominator of pulse output division	0 to 262144	0				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	04		Over-travel inhibit input setup	0 to 2	1				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	05		Sequence at over-travel inhibit	0 to 2	0				—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-44
5	06		Sequence at Servo-Off	0 to 9	0				—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	07		Sequence at main power OFF	0 to 9	0				—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	08		LV trip selection at main power OFF	0 to 1	1				—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-45
5	09		Detection time of main power off	70 to 2000	70				1ms	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

* Definition of symbols under “Power Off/On” - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

* Definition of symbols under “Related mode” - P: position control, S: velocity control, T: torque control, F: full closed control

Note Parameter describes of this page is P.4-39 to P.4-45.

13. Setup of Parameter and Mode

List of Parameters

Parametr No.	Class	No.	Title	Range	Default				Unit	Turning on of power supply	Related Control Mode				Detail page
					A,B -frame	C -frame	D,E,F -frame	G,H -frame			P	S	T	F	
5	10		Sequence at alarm	0 to 7			0		—		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-45
5	11		Torque setup for emergency stop	0 to 500			0		%		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-46
5	12		Over-load level setup	0 to 500			0		%		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	13		Over-speed level setup	0 to 20000			0		r/min		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	14		Motor working range setup	0 to 1000			10		0.1 revolution*		<input type="radio"/>			<input type="radio"/>	
5	15		I/F reading filter	0 to 3			0		—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	16		Alarm clear input setup	0 to 1			0		—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-47
5	17		Counter clear input mode	0 to 4			3		—		<input type="radio"/>			<input type="radio"/>	
5	18		Invalidation of command pulse inhibit input	0 to 1			1		—		<input type="radio"/>			<input type="radio"/>	
5	19		Command pulse inhibit input reading setup	0 to 4			0		—	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>	
5	20		Position setup unit select	0 to 1			0		—	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>	4-48
5	21		Selection of torque limit	0 to 6			1		—		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	
5	22		2nd torque limit	0 to 500			500*1		%		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	
5	23		Torque limit switching setup 1	0 to 4000			0		ms/100%		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	4-49
5	24		Torque limit switching setup 2	0 to 4000			0		ms/100%		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	
5	25		External input positive direction torque limit	0 to 500			500*1		%		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	
5	26		External input negative direction torque limit	0 to 500			500*1		%		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	
5	27		Input gain of analog torque limit	10 to 100			30		0.1V/100%*		<input type="radio"/>	<input type="radio"/>		<input type="radio"/>	
5	28		LED initial status	0 to 35			1		—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-50
5	29		RS232 baud rate setup	0 to 6			2		—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	30		RS485 baud rate setup	0 to 6			2		—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	31		Axis address	0 to 127			1		—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-51
5	32		Command pulse input maximum setup	250 to 4000			4000		kpulse/s	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>	
5	33		Pulse regenerative output limit setup	0 to 1			0		—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
5	34		For manufactuer's use	—			4		—						
5	35		Front panel lock setup	0 to 1			0		—	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

* Definition of symbols under “Power Off/On” - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

* Definition of symbols under “Related mode” - P: position control, S: velocity control, T: torque control, F: full closed control

*1 Default settings depend on the combination of driver and motor. Refer to P. 2-82 “Torque limit setting”.

Caution

The symbol “*” attached to “Unit”. indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note

Parameter describes of this page is P.4-45 to P.4-51.

13. Setup of Parameter and Mode

List of Parameters

[Class 6] Special setting

Parametr No.	Class	No.	Title	Range	Default				Unit	Turning on of power supply	Related Control Mode				Detail page
					A,B -frame	C -frame	D,E,F -frame	G,H -frame			P	S	T	F	
6	00		Analog torque feed forward conversion gain	0 to 100			0		0.1V/100%*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-51
6	02		Velocity deviation excess setup	0 to 20000			0		r/min		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	04		JOG trial run command speed	0 to 500			300		r/min		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	05		Position 3rd gain valid time	0 to 10000			0		0.1ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	06		Position 3rd gain scale factor	50 to 1000			100		%		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	07		Torque command additional value	-100 to 100			0		%		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-52
6	08		Positive direction torque compensation value	-100 to 100			0		%		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	09		Negative direction torque compensation value	-100 to 100			0		%		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	10		Function expansion setup	0 to 63			0		-		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	11		Current response setup	50 to 100			100		%		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	13		Current response setup	0 to 10000			250		%		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-53
6	14		Emergency stop time at alarm	0 to 1000			200		1ms		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	15		2nd over-speed level setup	0 to 20000			0		r/min		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	16		For manufacturer's use	-			0		-	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	17		Front panel parameter writing selection	0 to 1			0		-	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	18		Power-up wait time	0 to 100			0		0.1s*	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-54
6	19		Encoder Z phase setup	0 to 32767			0		pulse	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	20		Z-phase setup of external scale	0 to 400			0		μs	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	21		Serial absolute external scale Z phase setup	0 to 2 ²⁸			0		pulse	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	22		A, B phase external scale pulse output method selection	0 to 1			0		-	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	23		Disturbance torque compensating gain	-100 to 100			0		%		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-55
6	24		Disturbance observer filter	0 to 2500			53		0.01ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	27		Alarm latch time selection	0 to 10			5		s	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	31		Real time auto tuning estimation speed	0 to 3			1		-		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-56
6	32		Real time auto tuning custom setup	-32768 to 32767			0		-		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	33		For manufacturer's use	-			1000		-		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	4-57
6	34		Hybrid vibration suppression gain	0 to 30000			0		0.1/s*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	35		Hybrid vibration suppression filter	0 to 6400			10		0.01ms*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	37		Oscillation detecting level	0 to 1000			0		0.1%*		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	38		Alarm mask setup	-32768 to 32767			4		-	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	
6	39		For manufactuer's use	-			0		-		<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	

* Definition of symbols under "Power Off/On" - : if a change is made, it will be reflected upon the parameter when the power to the driver is turned off and then on again.

* Definition of symbols under "Related mode" - P: position control, S: velocity control, T: torque control, F: full closed control

Caution

The symbol " *" attached to "Unit". indicates that the digits of setting unit will change if the parameter is set by using the setup support software PANATERM.

Note

Parameter describes of this page is P.4-51 to P.4-57.

13. Setup of Parameter and Mode

Setup of Torque Limit

Torque limit setup range is 0 to 300 and default is 300 except the combinations of the motor and the driver listed in the table below.

Frame	Model No.	Applicable motor	Max. value of torque limit	Frame	Model No.	Applicable motor	Max. value of torque limit
D	MDDHT5540	MGME092G**	225	G	MGDHTC3B4	MGME602G**	272
		MGME092S**	225			MGME602S**	272
	MDDHT3420	MGME094G**	225			MDME752G**	265
		MGME094S**	225			MDME752S**	265
F	MFDHTA390	MGME202G**	250			MHME752G**	265
		MGME202S**	250			MHME752S**	265
	MFDHTB3A2	MGME302G**	250		MGDHTB4A2	MGME604G**	272
		MGME302S**	250			MGME604S**	272
		MGME452G**	262			MDME754G**	267
		MGME452S**	262			MDME754S**	267
	MFDHT5440	MGME204G**	250			MHME754G**	267
		MGME204S**	250			MHME754S**	267
	MFDHTA464	MGME304G**	250	H	MHDHTC3B4	MDMEC12G**	265
		MGME304S**	250			MDMEC12S**	265
		MGME454G**	263			MDMEC52G**	253
		MGME454S**	263			MDMEC52S**	253
					MHDHTB4A2	MDMEC14G**	265
						MDMEC14S**	265
						MDMEC54G**	253
						MDMEC54S**	253

- The above limit applies to Pr0.13 (1st torque limit), Pr5.22 (2nd torque limit), Pr5.11 (Torque setup for emergency stop), Pr5.25 (External input positive direction torque limit) and Pr5.26(External input negative direction torque limit).

Caution

When you change the motor model, above max. value may change as well. Check and reset the setup values of Pr0.13, Pr5.22, Pr5.11, Pr5.25 and Pr5.26.

13. Setup of Parameter and Mode


Setup of Torque Limit

Cautions on Replacing the Motor

As stated previously, torque limit setup range might change when you replace the combination of the motor and the driver. Pay attention to the followings.


1. When the motor torque is limited,

When you replace the motor series or to the different wattage motor, you need to reset the torque limit setup because the rated torque of the motor is different from the previous motor. (see e.g.1)




2. When you want to obtain the max. motor torque,

You need to reset the torque limiting setup to the upper limit, because the upper limit value might be different from the previous motor. (see e.g.2)



14. Setup of command division and multiplication ratio (electronic gear ratio)

Relation between Electronic Gear and Position Resolution or Traveling Speed



Example of ball screw drive by servo motor

Here we take a ball screw drive as an example of machine.

A travel distance of a ball screw M [mm] corresponding to travel command P1 [P], can be described by the following formula (1) by making the lead of ball screw as L [mm]

$$M = P1 \times (D/E) \times (1/R) \times L \dots\dots\dots (1)$$

therefore, position resolution (travel distance ΔM per one command pulse) will be described by the formula (2)

$$\Delta M = (D/E) \times (1/R) \times L \dots\dots\dots (2)$$

modifying the above formula (2), electronic gear ratio can be found in the formula (3).

$$D = (\Delta M \times E \times R) \times L \dots\dots\dots (3)$$

Actual traveling velocity of ball screw, V[mm/s] can be described by the formula (4) and the motor rotational speed, N at that time can be described by the formula (5).

$$V = F \times (D/E) \times (1/R) \times L \dots\dots\dots (4)$$

$$N = F \times (D/E) \times 60 \dots\dots\dots (5)$$

modifying the above formula (5), electronic gear ratio can be found in the formula (6).

$$D = (N \times E) / (F \times 60) \dots\dots\dots (6)$$

Note

- 1) Make a position resolution, ΔM as approx. 1/5 to 1/10 of the machine positioning accuracy, $\Delta \varepsilon$, considering a mechanical error.
- 2) Set up Pr0.09 and Pr0.10 to any values between 1 to 2^{30} .
- 3) The desired setting can be determined by selecting value of numerator and denominator of electronic gear. However, an excessively high division or multiplication ratio cannot guarantee the operation. The ratio should be in a range between 1/1000 and 1000. Excessively high multiplication ratio will cause Err27.2 (command pulse multiplication error protection) due to varying command pulse input or noises, even if the other settings are within the specified range.


4)	2^n	Decimal	2^n	Decimal
	2^0	1	2^{11}	2048
	2^1	2	2^{12}	4096
	2^2	4	2^{13}	8192
	2^3	8	2^{14}	16384
	2^4	16	2^{15}	32768
	2^5	32	2^{16}	65536
	2^6	64	2^{17}	131072
	2^7	128	2^{18}	262144
	2^8	256	2^{19}	524288
	2^9	512	2^{20}	1048576
	2^{10}	1024		

14. Setup of command division and multiplication ratio (electronic gear ratio)


Relation between Electronic Gear and Position Resolution or Traveling Speed

	Electronic gear ratio $D = \frac{\Delta M \times E \times R}{L}$	$D = \frac{\text{Pr0.09}}{\text{Pr0.10}}$
Lead of ball screw, L = 10mm Gear reduction ratio, R = 1 Position resolution, $\Delta M = 0.005\text{mm}$ Encoder, 17-bit (E = 2^{17}P/r)	$\frac{0.0005 \times 2^{17} \times 1}{10} = \frac{5 \times 2^{17}}{10 \times 10^4} = \frac{655360}{100000}$	Pr0.09 = 655360 Pr0.10 = 100000
Lead of ball screw, L = 20mm Gear reduction ratio, R = 1 Position resolution, $\Delta M = 0.0005\text{mm}$ Encoder, 17-bit (E = 2^{17}P/r)	$\frac{0.00005 \times 2^{17} \times 1}{20} = 0.32768$ D < 1, hence use 120-bit.	"D = 1" is the condition for minimum resolution.
Encoder : 20-bit (E = 2^{20}P/r)	$\frac{0.00005 \times 2^{20} \times 1}{20} = \frac{5 \times 2^{20}}{20 \times 10^5} = \frac{5242880}{2000000}$	Pr0.09 = 5242880 Pr0.10 = 2000000

	Motor rotational speed (r/min), $N = F \times \frac{D}{E} \times 60$	
Lead of ball screw, L = 20mm Gear reduction ratio, R = 1 Position resolution, $\Delta M = 0.0005\text{mm}$ Line driver pulse input, 500kpps Encoder, 17-bit	$500000 \times \frac{1 \times 2^{15}}{10000} \times \frac{1}{2^{17}} \times 60$ $= 50 \times 60 \times \frac{1}{2^2} = 750$	
Ditto To make it to 2000r/min.	Electronic gear ratio $D = \frac{N \times E}{F \times 60}$	$D = \frac{\text{Pr0.09}}{\text{Pr0.10}}$
	$D = \frac{2000 \times 2^{17}}{500000 \times 60} = \frac{2000 \times 2^{17}}{30000000} = \frac{262144000}{30000000}$	Pr0.09 = 262144000 Pr0.10 = 30000000
	Travel distance per command pulse (mm) (Position resolution) $\Delta M = \frac{D}{E} \times \frac{1}{R} \times L$	
	$\frac{2^{15}}{3750} \times \frac{1}{2^{17}} \times \frac{1}{1} \times 20 = \frac{1}{3750} \times \frac{20}{2^2} = \frac{20}{3750 \times 4} = 0.00133\text{mm}$	

Related page  • P.4-8 "Details of Parameter"

Setup with the Front Panel

**Display LED (6-digit)**

Switch to error display screen when error occurs, and LED will flash (about 2Hz).

LED will flash slowly (about 1Hz) when warning occurs.

Mode switching button

(valid at SELECTION display)

Press this to switch 4 kinds of mode.

- 1) Monitor Mode
- 2) Parameter Set up Mode
- 3) EEPROM Writing Mode
- 4) Auxiliary Function Mode

SET Button (valid at any time)

Press this to switch SELECTION and EXECUTION display.

Press these to change display and data, select parameters and execute actions.

(Change/Selection/Execution is valid to the digit which decimal point flashes.)

Numerical value increases by pressing, ▲, decreases by pressing ▼.

Shifting of the digit for data changing to higher digit.

X7

Output connector for monitor

Note

For connector X7, refer to P.2-60 "Wiring to the connector, X7".


15. How to Use the Front Panel

Setup

Initial Status of the Front Panel Display (7 Segment LED)


Status

Front panel display shows the following after turning on the power of the driver.



Upon Occurrence of an Alarm

If a driver alarm is generated, the front panel display shows the following repeatedly.




Below shows possible cause of an alarm.


alarm No.	Alarm	Content
A0	Overload protection	Load factor is 85% or more the protection level.
A1	Over-regeneration alarm	Regenerative load factor is 85% or more the protection level.
A2	Battery alarm	Battery voltage is 3.2 V or lower.
A3	Fan alarm	Fan has stopped for 1 sec.
A4	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.
A5	Encoder overheat alarm	The encoder detects overheat alarm.
A6	Oscillation detection alarm	Oscillation or vibration is detected.
A7	Lifetime detection alarm	The life expectancy of capacity or fan becomes shorter than the specified time.
A8	External scale error alarm	The external scale detects the alarm.
A9	External scale communication alarm	The number of successive external scale communication errors exceeds the specified value.

15. How to Use the Front Panel

Structure of Each Mode

Use each button on the touch panel to select the structure and switch the mode.


Note


You can change the flashing decimal point with , then shift the digit for data change "."

Caution

On power-up, the monitor mode executed is displayed according to the setup of Pr5.28 LED initial status.

15. How to Use the Front Panel

Structure of Each Mode



1 Before Using the Products

2 Preparation

3 Connection

4 Setup

5 Adjustment

6 When in Trouble

7 Supplement

15. How to Use the Front Panel

Setup of front panel lock

Outline

To prevent operational error e.g. unintentional parameter modification, the front panel may be locked.

Once locked, operations on the panel are limited as follows:

Mode	Locked panel conditions
Monitor Mode	No limitation: all monitored data can be checked.
Parameter Set up Mode	No parameter can be changed but setting can be checked.
EEPROM Writing Mode	Cannot be run. (No display)
Auxiliary Function Mode	Cannot be run except for "Release of front panel lock". (No display)

How to operate

• Related parameters

Parameter No.		Title	Function
Class	No.		
5	35	Setup of front panel lock	Locks the operation attempted from the front panel.

Lock and unlock can be made in one of two ways.

Procedure	Front panel	Setup support software PANATERM
Lock	(1) Set Pr5.35 "Front panel lock" to 1, and writ the setting to EEPROM. (2) Turn on power to the driver. (3) The front panel is locked.	
Unlock	(1) Execute the auxiliary function mode, front panel lock release function. (2) Turn on power to the driver. (3) The front panel is unlocked.	(1) Set Pr5.35 "Front panel lock" to 0, and writ the setting to EEPROM. (2) Turn on power to the driver. (3) The front panel is unlocked.


Note

For details of front panel lock release, refer to P.2-113.

Related page

• P.4-51 "Details of Parameter"


To change the monitor display setting, select the display option to be changed from “**SELECTION** display”, and press **(S_{SET})** to change to “**EXECUTION** display”. After completion of changing, press **(S_{SET})** to return to the selection display,

**Note**

When you turn on the Product for the first time, display shows **r** **0**. (at motor stall)
 To change this display, change the setup of Pr5.28 (Initial status of LED).

(1) Display of positional command deviation [command unit]


Displays positional deviation of the command unit in High order or Low order.



- To switch between Low order (L) and High order (H), press

(2) Display of motor speed, positional command speed, velocity control command and torque command

- Motor speed (r/min)




- Positional command speed (r/min)



- Velocity control command (r/min)



- Torque command (%)



15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

(3) Display of Feedback Pulse Sum, Command Pulse Sum and External Scale Feedback Pulse Sum

• Feedback Pulse Sum [Encoder feedback pulse]

L 3 9 0 2 5

↑ ↑ Feedback Pulse Sum

LLow order

HHigh order

- To switch between Low order (L) and High order (H), press ◀.

L 3 9 0 2 5 ↔ H 1 0 3

• Command Pulse Sum [Command Pulse]

L 3 9 0 2 5

↑ ↑ Command Pulse Sum

LLow order

HHigh order

- To switch between Low order (L) and High order (H), press ◀.

L 3 9 0 2 5 ↔ H 1 0 3

• External Scale Feedback Pulse Sum

L 3 9 0 2 5

↑ ↑ External Scale Feedback Pulse Sum

LLow order

HHigh order

- To switch between Low order (L) and High order (H), press ◀.

L 3 9 0 2 5 ↔ H 1 0 3

(4) Display of Control Mode

P o S c n tPosition control mode

S P d c n tVelocity control mode

t r q c n tTorque control mode


F c l c n tFull-closed control mode

15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

(5) Display of I/O Signal Status

Displays the control input and output signal to be connected to connector X4.
Use this function to check if the wiring is correct or not.




- Shift the flashing decimal point with (◀).


(Right side of decimal point : Pin No. selection)

(Left side of decimal point : Input/Output Pin No. selection)

- Select In or Out by pressing (▲) or (▼) button.



- Select the Pin No. to be monitored by pressing (▲) (▼).



- *1 When input signal Active : Input signal photocoupler is ON.
 Inactive: Input signal photocoupler is OFF.
- When output signal Active : Output signal transistor is ON.
 Inactive: Output signal transistor is OFF.


Note

For detail of input/output signal, refer to P.3-30 "Inputs and outputs on connector X4"
For detail of Error Code, refer to P.6-2 "Protective Function".


15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

(6) Display of Analog Input Value



•Select the signal No. to be monitored by pressings ▲ ▼.



Caution ⚠ Voltage exceeding $\pm 10\text{V}$ can not be displayed correctly.

15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

(7) Display of Error Factor and Reference of History

Err.---

Error code No. (- - - appears if no error occurs)

Err.Present error

E - 0History 0 (latest error)

E 1 3History 13 (oldest error)

• You can refer the last 14 error factors (including present one)

Press   to select the factor to be referred.

<List of error code No.>

Error code		Protective function	Attribute		
Main	Sub		History	Can be cleared	Immediate stop
11	0	Control power supply under- voltage protection		<input type="radio"/>	
12	0	Over-voltage protection	<input type="radio"/>	<input type="radio"/>	
13	0	Main power supply under-voltage protection (between P to N)		<input type="radio"/>	
	1	Main power supply under-voltage protection (AC interception detection)		<input type="radio"/>	
14	0	Over-current protection	<input type="radio"/>		
	1	IPM error protection	<input type="radio"/>		
15	0	Over-heat protection	<input type="radio"/>		<input type="radio"/>
16	0	Over-load protection	<input type="radio"/>	<input type="radio"/> *1	
18	0	Over-regeneration load protection	<input type="radio"/>		<input type="radio"/>
	1	Over-regeneration Tr error protection	<input type="radio"/>		
21	0	Encoder communication disconnect error protection	<input type="radio"/>		
	1	Encoder communication error protection	<input type="radio"/>		
23	0	Encoder communication data error protection	<input type="radio"/>		
24	0	Position deviation excess protection	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	1	Velocity deviation excess protection	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
25	0	Hybrid deviation excess error protection	<input type="radio"/>		<input type="radio"/>
26	0	Over-speed protection	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	1	2nd over-speed protection	<input type="radio"/>	<input type="radio"/>	
27	0	Command pulse input frequency error protection	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
	2	Command pulse multiplier error protection	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
28	0	Limit of pulse replay error protection	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
29	0	Deviation counter overflow protection	<input type="radio"/>	<input type="radio"/>	
30	0	Safety detection		<input type="radio"/>	
33	0	IF overlaps allocation error 1 protection	<input type="radio"/>		
	1	IF overlaps allocation error 2 protection	<input type="radio"/>		
	2	IF input function number error 1 protection	<input type="radio"/>		
	3	IF input function number error 2 protection	<input type="radio"/>		
	4	IF output function number error 1 protection	<input type="radio"/>		
	5	IF output function number error 2 protection	<input type="radio"/>		
	6	CL fitting error protection	<input type="radio"/>		
	7	INH fitting error protection	<input type="radio"/>		

15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

Error code		Protective function	Attribute		
Main	Sub		History	Can be cleared	Immediate stop
34	0	Software limit protection	○	○	
36	0 to 2	EEPROM parameter error protection			
37	0 to 2	EEPROM check code error protection			
38	0	Over-travel inhibit input protection		○	
39	0	Analog input1 excess protection	○	○	○
	1	Analog input2 excess protection	○	○	○
	2	Analog input3 excess protection	○	○	○
40	0	Absolute system down error protection	○	○	
41	0	Absolute counter over error protection	○		
42	0	Absolute over-speed error protection	○	○	
43	0	Initialization failure	○		
44	0	Absolute single turn counter error protection	○		
45	0	Absolute multi-turn counter error protection	○		
47	0	Absolute status error protection	○		
48	0	Encoder Z-phase error protection	○		
49	0	Encoder CS signal error protection	○		
50	0	External scale connection error protection	○		
	1	External scale communication error protection	○		
51	0	External scale status 0 error protection	○		
	1	External scale status 1 error protection	○		
	2	External scale status 2 error protection	○		
	3	External scale status 3 error protection	○		
	4	External scale status 4 error protection	○		
	5	External scale status 5 error protection	○		
55	0	A-phase connection error protection	○		
	1	B-phase connection error protection	○		
	2	Z-phase connection error protection	○		
87	0	Compulsory alarm input protection		○	
95	0 to 4	Motor automatic recognition error protection			
Other number		Other error	○		

Note

History...The error will be stored in the error history.

Can be cleared...To cancel the error, use the alarm clear input (A-CLR).

If the alarm clear input is not effective, turn off power, remove the cause of the error and then turn on power again.

Immediate stop...Instantaneous controlled stop upon occurrence of an error.

(Setting of "Pr.5.10 Sequence at alarm" is also required.)

Caution

- 1) Certain alarms are not included in the history. For detailed information on alarms e.g. alarm numbers, refer to P.6-2.
- 2) When one of the errors which are listed in error history occurs, this error and history o shows the same error No.

15. How to Use the Front Panel


Monitor Mode (EXECUTION display)

(8) Alarm Display

.....No alarm occurred

.....High priority alarm
 ↑
 Alarm number

- To display the alarm occurrence condition, press or button.



alarm No.	Alarm	Content	Latched time ^{*1}
A0	Overload protection	Load factor is 85% or more the protection level.	1 to 10s or ∞
A1	Over-regeneration alarm	Regenerative load factor is 85% or more the protection level.	10s or ∞
A2	Battery alarm	Battery voltage is 3.2 V or lower.	Fixed at ∞
A3	Fan alarm	Fan has stopped for 1 sec.	1 to 10s or ∞
A4	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.	1 to 10s or ∞
A5	Encoder overheat alarm	The encoder detects overheat alarm.	1 to 10s or ∞
A6	Oscillation detection alarm	Oscillation or vibration is detected.	1 to 10s or ∞
A7	Lifetime detection alarm	Life expectancy of capacitor or fan is short.	Fixed at ∞
A8	External scale error alarm	The external scale detects the alarm.	1 to 10s or ∞
A9	External scale communication alarm	The number of successive external scale communication errors exceeds the specified value.	1 to 10s or ∞

^{*1} Alarms can be cleared by using the alarm clear. Because the all existing alarms are kept cleared while the alarm clear input (A-CLR) is kept ON, be sure to turn it OFF during normal operation. Either 1-10s or ∞ can be selected by using user parameter.

Exception: Battery alarm is fixed at ∞ because it is latched by the encoder.

Because the end of life alarm means that the life expectancy cannot be extended, the alarm is set at ∞.

15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

(9) Display of Regenerative Load Factor, Over-load Factor and Inertia Ratio

• Regenerative Load Factor

rL 30



Display the ratio (%) against the alarm trigger level of regenerative protection.

This is valid when Pr0.16 (External regenerative resistor setup) is 0 or 1.

• Over-load Factor

oL 28



Displays the ratio (%) against the rated load.

Refer to P.6-14, "Overload Protection Time Characteristics" of When in Trouble.

• Inertia Ratio

J 100



Displays the inertia ratio (%).

Value of Pr0.04 (Inertia Ratio) will be displayed as it is.

Note




For alarm function, refer to P.4-42 "Pr4.40, Pr4.41".

15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

10) Display of the Factor of No-Motor Running

Displays the factor of no-motor running in number.



Control mode

Factor No.

PPosition control

tTorque control

S Velocity control

F Full-closed control

• Explanation of factor No.

Factor No.	Factor	Related Control Mode				Content
		P	S	T	F	
flashing	Occurrence of error/alarm	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	An error is occurring, and an alarm is triggered.
00	No particular factor	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	No factor is detected for No-motor run. The motor runs in normal case.
01	Main power shutoff	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	The main power of the driver is not turned on.
02	No entry of SRV-ON input	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	The Servo-ON input (SRV-ON) is not connected to COM-.
03	Over-travel inhibition input is valid	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	While Pr5.04 is 0 (Run-inhibition input is valid), • Positive direction over-travel inhibition input (POT) is open and speed command is Positive direction. • Negative direction over-travel inhibition input (NOT) is open and speed command is Negative direction.
04	Torque limit setup is small	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Either one of the valid torque limit setup value of Pr0.13 (1st) or Pr5.22 (2nd) is set to 5% or lower than the rating.
05	Analog torque limit input is valid.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	While Pr5.21 is 0 (analog torque limit input accepted), • Positive direction analog torque limit input (P-ATL) is negative voltage and speed command is Positive direction. • Negative direction analog torque limit input (N-ATL) is positive voltage and speed command is Negative direction.
06	INH input is valid.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	Pr5.18 is 0 (Command pulse inhibition input is valid.), and INH is open.
07	Command pulse input frequency is low.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	The position command per each control cycle is 1 pulse or smaller due to, • No correct entry of command pulse • No correct connection to the input selected with Pr0.05. • No matching to input status selected with Pr0.06 pr Pr0.07.
08	CL input is valid.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	While Pr5.17 is 0 (Deviation counter clear at level), the deviation counter clear input (CL) is connected to COM-.
09	ZEROSPD input is valid.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	While Pr3.15 is 1 (Speed zero clamp is valid.), the speed zero clamp input (ZEROSPD) is open.
10	External speed command is small.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	While the analog speed command is selected, the analog speed command is smaller than 0.06[V].
11	Internal speed command is 0.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	While the internal speed command is selected, the internal speed command is set to lower than 30 [r/min]
12	Torque command is small.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	The analog torque command input (SPR or P-ATL) is smaller than 5 [%] of the rating.
13	Speed limit is small.	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	• While Pr3.17 is 0 (speed is limited by 4th speed of internal speed), Pr3.07, (4th speed of speed setup) is set to lower than 30 [r/min]. • While Pr3.17 is 1 (speed is limited by SPR input), the analog speed limit input (SPR) is smaller than 0.06 [V].
14	Other factor	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	The motor runs at 20 [r/min] or lower even though the factors from 1 to 13 are cleared, (the command is small, the load is heavy, the motor lock or hitting, driver/motor fault etc.)

Note


* Motor might run even though the other number than 0 is displayed.

Refer to "6.In trouble".

15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

(11) Display of No. of changes in I/O signals




- Shift the flashing decimal point with \leftarrow .


(Left side of decimal point : Pin No. selection)

(Right side of decimal point : Input/Output Pin No. selection)


- The switch of input/output, by pressing \uparrow or \downarrow button.




- Select the No. of pin, the number of changes on that pin should be displayed, by pressing \uparrow or \downarrow button.



(12) Display of absolute encoder data



- Select the data to be displayed by pressing \uparrow or \downarrow button.




15. How to Use the Front Panel


Monitor Mode (EXECUTION display)

(13) Display of absolute external scale position


- Displays the absolute position of serial absolute scale.
- If a serial incremental scale, displays the scale position relative to the power on position which is defined as 0.




- Select encoder or external scale by pressing ▲ or ▼ button.




(14) Display of No. of encoder/ external scale communication errors monitor




- Select encoder or external scale by pressing ▲ or ▼ button.




(15) Display of communication axis address



(16) Display of encoder positional deviation [Encoder unit]



- To switch between Low order (L) and High order (H), press ◀▶.



15. How to Use the Front Panel

Monitor Mode (EXECUTION display)

(17) Display of External Scale Deviation [External Scale Unit]

L 3 9 0 2 5

External Scale Deviation [External scale unit]
LLow order
HHigh order

- To switch between Low order (L) and High order (H), press ◀.

L 3 9 0 2 5 ↔ H 1 0 3

(18) Display of hybrid deviation [Command unit]

L 3 9 0 2 5

Hybrid deviation [Command unit]
LLow order
HHigh order

- To switch between Low order (L) and High order (H), press ◀.

L 3 9 0 2 5 ↔ H 1 0 3

(19) Display of voltage across PN [V]

P n 2 8 0

Displays the voltage across PN [V]
(only for reference not an instrument)

(20) Display of Software Version

A - 1 . 0 0

Displays the software version of the driver.
(Example of display: Ver 1.00)

(21) Display of driver serial number

A L 0 0 0 1

Driver serial number
A LDriver serial number- Low order
A HDriver serial number- High order


- To switch between Low order (L) and High order (H), press ▲ or ▼.
(Example of display: Serial number 09010001)

A L 0 0 0 1
▲ ▼
A H 0 9 0 1


15. How to Use the Front Panel

Monitor Mode (EXECUTION display)


(22) Display of motor serial number




- To switch between Low order (L) and High order (H), press ▲ or ▼.
(Example of display: Serial number 09040001)



(23) Display of accumulated operation time



- To switch between Low order (L) and High order (H), press ◀.




(24) Automatic Motor Recognizing Function

Aud onAutomatic recognition is valid.

Aud offAutomatic recognition is invalid.


(25) Display of temperature




15. How to Use the Front Panel

Monitor Mode (EXECUTION display)


(26) Display of safety condition monitor



• Select desired monitor option by pressing or button.



Related page P.7-2 "safety".

Monitor Mode **SELECTION display**
 (Mode switch button)
Parameter Setup Mode **SELECTION display**



Pr _ 000.

Parameter No.
(Hexadecimal No.)

Class

Note

For parameters which place is displayed with "r", the content changed and written to EEPROM becomes valid after turning off the power once.

- Press  or  to select parameter No. to be set.

Pr _ 000.

Pr0.00

Pr _ 001.

Pr0.01

...

Pr _ 632.


Pr6.32

Pr _ 633.

Pr6.33

Pr _ 000.

Pr0.00

- Press  and the flashing decimal separator shifts to the high order position, allowing the figure at this digit to any other figure.

Pr _ 001.


Pr0.01

Pr _ 011.


Pr0.11

Pr _ 111.

Pr1.11

- Display the No. of parameter to be changed and press  to change to EXECUTION display.















(SET button)

 (Mode switch button)
EEPROM Writing Mode **SELECTION display****EXECUTION display**


1000.

Parameter value

← You can change the value which digit has a flashing decimal point.


- Press  or  to set up the value of parameter. (Value increases with , decreases with .)
- Press  and the flashing decimal separator shifts to the high order position, allowing the figure at this digit to any other figure.
- Prolonged depression of  updates the parameter in the driver. Note that the parameter value selected by  or  is not reflected until  is pressed in this way.
- To cancel the value selected by  or , press  instead of , and the driver internal parameter value is kept unchanged and the display returns to the parameter number display screen.

Remarks

After changing the parameter value and pressing , the content will be reflected in the control. Do not extremely change the parameter value which change might affect the motor movement very much (especially velocity loop or position loop gains).

Note


- After setting up parameters, return to SELECT mode, referring to structure of each mode (P.2-88).
- Each parameter has a limit in number of places for upper-shifting.



**Caution**

1. When writing error occurs, make writing again. If the writing error repeats many times, this might be a failure.
2. Don't turn off the power during EEPROM writing. Incorrect data might be written. If this happens, set up all of parameters again, and re-write after checking the data.
3. When the error defined by Err11.0 "Under voltage protection of control power supply" occurs, Error is displayed indicating that no writing is made to EEPROM.

15. How to Use the Front Panel

Auxiliary Function Mode (SELECTION display)

EEPROM Writing Mode **SELECTION display**
 (Mode switch button)
Auxiliary Function Mode **SELECTION display**

- To select the desired auxiliary function, press  or .

AF - A c L.

Alarm Clear



AF - o F 1.

A1 Automatic
Offset Adjustment

AF - o F 2.

A2 Automatic
Offset Adjustment

AF - o F 3.

A3 Automatic
Offset Adjustment

AF - J o G.

Trial Run

AF - E n c.

Clearing of
Absolute Encoder

AF - i n i.

Initialization of
parameter


AF - u n L.


Release of
front panel lock

AF - A c L.

Alarm Clear

- TDisplay the auxiliary function to be changed and press  to change to EXECUTION display.

 (Mode switch button)
Monitor Mode **SELECTION display****EXECUTION display**

Display example	Description	Pages to refer
<div>AcL -</div> <div>Pressing .</div> <div>StArt -</div> <div>Fin,sh -</div>	(Alarm Clear) Alarm clear starts. Alarm clear completes	P.2-109 (1)
<div>o F 1 -</div>	(A1 Automatic Offset Adjustment)	P.2-110 (2)
<div>o F 2 -</div>	(A2 Automatic Offset Adjustment)	P.2-110 (2)
<div>o F 3 -</div>	(A3 Automatic Offset Adjustment)	P.2-110 (2)
<div>J o G -</div>	(Motor Trial Run)	P.2-111 (3)
<div>E n c -</div>	(Clearing of Absolute Encoder)	P.2-113 (4)
<div>i n i -</div>	(Initialization of parameter)	P.2-114 (5)
<div>u n L -</div>	(Release of front panel lock)	P.2-115 (6)

 (SET button)


15. How to Use the Front Panel

Auxiliary Function Mode (EXECUTION display)

1) Alarm Clear Screen

This function releases the current alarm status.

Certain alarms will persist. If this is the case, refer to P.6-2 "When in Trouble - Protective Function".



Note

• After alarm cleaning, return to SELECTION display, referring to structure of each mode (P.2-88).

15. How to Use the Front Panel

Auxiliary Function Mode (EXECUTION display)


(2) Analog inputs 1 to 3 automatic offset adjustment

This function automatically adjusts offset setting of analog input.

Analog input 1 (AI1).....Pr4.22 (Analog input 1 (AI1) offset setup)

Analog input 2 (AI2).....Pr4.25 (Analog input 2 (AI2) offset setup)

Analog input 3 (AI3).....Pr4.28 (Analog input 1 (AI3) offset setup)



Remarks

- You cannot write the data only by executing automatic offset adjustment. Execute a writing to EEPROM when you need to reflect the result afterward.

Note

- After completion of the automatic offset adjustment, return to SELECTION display by referring to P.2-88 “Structure of Each Mode”.

15. How to Use the Front Panel

Auxiliary Function Mode (EXECUTION display)

(3) Motor trial run

You can make a trial run (JOG run) without connecting the Connector, Connector X4 to the host controller such as PLC.

Remarks

- Separate the motor from the load, detach the Connector, Connector X4 before the trial run.
- Bring the user parameter setups (especially Pr0.04 and Pr1.01 to 1.04) to defaults, to avoid oscillation or other failure.

• Inspection Before Trial Run

(1) Inspection on wiring

- Miswiring ? (Especially power input and motor output)
- Short or grounded ?
- Loose connection ?

(2) Confirmation of power supply and voltage


- Rated voltage ?

(3) Fixing of the servo motor

- Unstable mounting ?

(4) Separation from the mechanical system

(5) Release of the brake



(6) Turn to Servo-OFF after finishing the trial run by pressing .


Related page

- For wiring details, refer to P2-12 "Overall Wiring".
- P.4-6 "Pr0.04"
- P.4-13 "Pr1.01 to 1.04"

15. How to Use the Front Panel

Auxiliary Function Mode (EXECUTION display)

• Procedure for Trial Run



Caution

- Before starting the trial run, set the gain-related parameters to appropriate values to avoid problems such as oscillation. If the load is removed, be sure to set Pr0.04 “Inertia Ratio” to 0.
- During the trial run, use the velocity control mode. Various settings including parameters should assure safe and positive operation under appropriate velocity control.
- If SRV-ON becomes valid during trial run, the display changes to E r r o r . which is normal run through external command.

Note


- After finished trial running, return to SELECTION display, referring to structure of each mode (P.2-88).

15. How to Use the Front Panel

Auxiliary Function Mode (EXECUTION display)

4) Clearing of Absolute Encoder

You can clear the multi-turn data of the absolute encoder.



Note


- After clearing of absolute encoder finishes, return to SELECTION display, referring to structure of each mode (P.2-88).

15. How to Use the Front Panel

Auxiliary Function Mode (EXECUTION display)

(5) Initialization of parameter

Initialize the parameter.



- Caution** ❖ • Parameter cannot be initialized when one of the following error occurs: Err11.0 "Under voltage protection of control power supply", EEPROM related errors (Err36.0, Err36.1, Err36.2, Err37.0, Err37.1 and Err37.2) - initialization will result in "Error" display.

Note


- After initialization of parameter finishes, return to SELECTION display, referring to structure of each mode (P.2-88).

15. How to Use the Front Panel

Auxiliary Function Mode (EXECUTION display)

(6) Release of front panel lock

Release the front panel lock setting.



Note

- After release of front panel lock finishes, return to SELECTION display, referring to structure of each mode (P.2-88).

[illegible]

3. Connection

1. Outline of mode

Position Control Mode	3-2
Velocity Control Mode	3-6
Torque Control Mode	3-9
Full-closed Control Mode	3-12

2. Control Block Diagram

Position Control Mode	3-14
Velocity Control Mode	3-15
Torque Control Mode	3-16
Full-closed Control Mode	3-17

3. Wiring Diagram to the connector, X4

Example of control mode specific wiring	3-18
Connecting Example to Host Controller	3-20

4. Inputs and outputs on connector X4

Interface Circuit (Input)	3-30
Interface Circuit (Output)	3-32
Input Signal and Pin No.	3-34
Output Signal and Pin No.	3-45


5. IF Monitor Settings

How to Assign Various I/O Functions to the I/F	3-50
--	------

Outline

You can perform position control based on the positional command (pulse train) from the host controller.

This section describes the fundamental setup to be used for the position control.



Function

(1) Process of command pulse input

The positional commands of the following 3 types (pulse train) are available.

- 2-phase pulse
- Positive direction pulse/negative direction pulse
- Pulse train + sign

Set the pulse configuration and pulse counting method based on the specification and configuration of installation of the host controller.

The input terminals can accommodate the following 2 systems.

- Input 1 "PULSH1, PULSH2, SIGNH1, SIGNH2" line receiver input (4 Mpps)
- Input 2 "PULS1, PULS2, SIGN1, SIGN2" photocoupler input (500 kpps)

Caution

For line driver output, "Input 2" can also be used without changing the allowable input frequency.

• Relevant parameters

Parameter No.	Title	Range	Function
Pr0.05	Selection of command pulse input	0 to 1	You can select either the photo-coupler input or the exclusive input for line driver as the command pulse input.
Pr0.06	Command pulse rotational direction setup	0 to 1	Sets the counting direction when command pulse is input.
Pr0.07	Command pulse input mode setup	0 to 3	Sets the counting method when command pulse is input.

Note

For details of these parameters, refer to P.4-6 and 7 "Details of parameter".

Related page

- P.3-14 "Control Block Diagram"
- P.3-18 "Wiring Diagram to the connector, X4"

1. Outline of mode

Position Control Mode

(2) Electronic gear function

This function multiplies the input pulse command from the host controller by the pre-determined dividing or multiplying factor and applies the result to the position control section as the positional command. By using this function, desired motor rotations or movement distance per unit input command pulse can be set; or the command pulse frequency can be increased if the desired motor speed cannot be obtained due to limited pulse output capacity of the host controller.

• Relevant parameters

Parameter No.	Title	Range	Function
Pr0.08	Command pulse counts per one motor revolution	0 to 1048576	Set the command pulses that causes single turn of the motor shaft.
Pr0.09	1st numerator of electronic gear	0 to 1073741824	Set the numerator of division/multiplication operation made according to the command pulse input.
Pr0.10	Denominator of electronic gear	1 to 1073741824	Set the Denominator of division/multiplication operation made according to the command pulse input.

Note

For details of these parameters, refer to P.4-8 “Details of parameter”.

(3) Positional command filtering function

To make the positional command divided or multiplied by the electronic gear smooth, set the command filter.

• Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr2.22	Positional command smoothing filter	0 to 10000	0.1ms	Set up the time constant of the 1st delay filter in response to the positional command.
Pr2.23	Positional command FIR filter	0 to 10000	0.1ms	Set up the time constant of the 1st delay filter in response to the positional command.

Note

For details of these parameters, refer to P.4-23 and 24 “Details of parameter”.

1. Outline of mode

Position Control Mode

(4) Pulse regeneration function

The information on the amount of movement can be sent to the host controller in the form of A- and B-phase pulses from the servo driver. When the output source is the encoder, Z-phase signal is output once per motor revolution; or if the feedback scale, the signal is output at absolute zero position. The output resolution, B-phase logic and output source (encoder or external scale) can be set with parameters.

• Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr0.11	Output pulse counts per one motor revolution	1 to 262144	P/r	You can set up the output pulse counts per one motor revolution for each OA and OB with the Pr0.11 setup.
Pr0.12	Reversal of pulse output logic	0 to 3	—	You can set up the B-phase logic and the output source of the pulse output. With this parameter, you can reverse the phase relation between the A-phase pulse and the B-phase pulse by reversing the B-phase logic.
Pr5.03	Denominator of pulse output division	0 to 262144	—	For application where the number of pulses per revolution is not an integer, this parameter can be set to a value other than 0, and the dividing ratio can be set by setting numerator of division to Pr0.11 and denominator of division to Pr5.03.
Pr5.33	Pulse regenerative output limit setup	0 to 1	—	Enable/disable detection of Err28.0 Pulse regenerative limit protection.
Pr6.20	Z-phase setup of external scale	0 to 400	μs	Set up the Z phase regenerative width of feedback scale in unit of time.
Pr6.21	Serial absolute external scale Z phase setup	0 to 268435456	pulse	Full-closed control using serial absolute feedback scale. When outputting pulses by using the feedback scale as the source of the output, set the Z phase output interval in units of A phase output pulses of the feedback scale (before multiplied by 4).
Pr6.22	A, B phase external scale pulse output method selection	0 to 1	—	Select the pulse regeneration method of A, B and Z parallel feedback scale.

Note

For details of these parameters, refer to P.4-9, 10, 11, 43, 51 and 55 “Details of parameter”.

(5) Deviation counter clear function

The deviation counter clear input (CL) clears the counts of positional deviation counter at the position control to 0.

• Relevant parameters

Parameter No.	Title	Range	Function
Pr5.17	Counter clear input mode	0 to 4	You can set up the clearing conditions of the counter clear input signal.

Note

For details of these parameters, refer to P.4-47 “Details of parameter”.

1. Outline of mode

Position Control Mode

(6) Positioning complete output (INP) function

The completion of positioning can be verified by the positioning complete output (INP). When the absolute value of the positional deviation counter at the position control is equal to or below the positioning complete range by the parameter, the output is ON. Presence and absence of positional command can be specified as one of judgment conditions.

• Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr4.31	Positioning complete (In-position) range	0 to 262144	Command unit	Set up the timing of positional deviation at which the positioning complete signal (INP1) is output.
Pr4.32	Positioning complete (In-position) output setup	0 to 3	—	Select the condition to output the positioning complete signal (INP1).
Pr4.33	INP hold time	0 to 30000	1ms	Set up the hold time when Pr4.32 Positioning complete output setup = 3.
Pr4.42	2nd Positioning complete (In-position) range	0 to 262144	Command unit	Set up the timing of positional deviation at which the positioning complete signal (INP2) is output.

Note

For details of these parameters, refer to P.4-39 and 42 “Details of parameter”.

(7) Command pulse inhibition (INH) function

The command pulse input counting process can be forcibly terminated by using the command pulse inhibit input signal (INH). When INH input is ON, the servo driver ignores the command pulse, disabling pulse counting function.

The default setting of this inhibition function is disable. To use INH function, change the setting of Pr5.18 “Invalidation of command pulse prohibition input”.

• Relevant parameters


Parameter No.	Title	Range	Function
Pr5.18	Invalidation of command pulse inhibit input	0 to 1	Select command pulse inhibit input enable/disable.
Pr5.19	Command pulse inhibit input reading setup	0 to 4	Select command pulse inhibit input enable/disable signal reading period. When the status of several signals read during the predetermined reading period are same, update the signal status.

Note

For details of these parameters, refer to P.4-47 “Details of parameter”.

Outline

You can control the speed according to the analog speed command from the host controller or the speed command set in the servo driver.



Note

Only for position control type is not provided with analog input.

Function

(1) Velocity control by analog speed command

The analog speed command input voltage is converted to equivalent digital speed command. You can set the filter to eliminate noise or adjust the offset.

• Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr3.00	Speed setup, Internal/ External switching	0 to 3	—	This driver is equipped with internal speed setup function so that you can control the speed with contact inputs only.
Pr3.01	Speed command rotational direction selection	0 to 1	—	Select the Positive/Negative direction specifying method.
Pr3.02	Input gain of speed command	10 to 2000	(r/min)/V	Based on the voltage applied to the analog speed command (SPR), set up the conversion gain to motor command speed.
Pr3.03	Reversal of speed command input	0 to 1	—	Specify the polarity of the voltage applied to the analog speed command (SPR).
Pr4.22	Analog input 1 (AI1) offset setup	–5578 to 5578	0.359mV	Set up the offset correction value applied to the voltage fed to the analog input 1.
Pr4.23	Analog input 1 (AI1) filter	0 to 6400	0.01ms	Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 1.

Note

For details of these parameters, refer to P.4-25, 26 and 38 “Details of parameter”. Only for position control type is not provided with analog input.

Related page

- P.3-15 “Control Block Diagram”
- P.3-18 “Wiring Diagram to the connector, X4”

1. Outline of mode

Velocity Control Mode

(2) Velocity control by internal speed command

You can control the speed by using the internal speed command set to the parameter. By using the internal speed command selections 1, 2, 3 (INTSPD1, 2, 3), you can select best appropriate one among up to 8 internal speed command settings. Default setting uses the analog speed command. To use the internal speed command, select it through Pr3.00 "Internal/external speed setup".

• Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr3.00	Speed setup, Internal/External switching	0 to 3	—	This driver is equipped with internal speed setup function so that you can control the speed with contact inputs only.
Pr3.01	Speed command rotational direction selection	0 to 1	—	Select the Positive/Negative direction specifying method.
Pr3.04	1st speed of speed setup	-20000 to 20000	r/min	Set up internal command speeds, 1st to 1st.
Pr3.05	2nd speed of speed setup			Set up internal command speeds, 1st to 2nd.
Pr3.06	3rd speed of speed setup			Set up internal command speeds, 1st to 3rd.
Pr3.07	4th speed of speed setup			Set up internal command speeds, 1st to 4th.
Pr3.08	5th speed of speed setup			Set up internal command speeds, 1st to 5th.
Pr3.09	6th speed of speed setup			Set up internal command speeds, 1st to 6th.
Pr3.10	7th speed of speed setup			Set up internal command speeds, 1st to 7th.
Pr3.11	8th speed of speed setup			Set up internal command speeds, 1st to 8th.

Note

For details of these parameters, refer to P.4-25, 26 and 27 "Details of parameter".

(3) Speed zero clamp (ZEROSPD) function

You can forcibly set the speed command to 0 by using the speed zero clamp input.

• Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr3.15	Speed zero-clamp function selection	0 to 3	—	You can set up the function of the speed zero clamp input.
Pr3.16	Speed zero clamp level	0 to 1	r/min	elect the timing at which the position control is activated as the Pr3.15 Speed zero-clamp function selection is set to 2 or 3.

Note

For details of these parameters, refer to P.4-28 "Details of parameter".

(4) Attained speed output (AT-SPEED)

The signal AT-SPEED is output as the motor reaches the speed set to Pr4.36 "Attained speed".

• Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr4.36	At-speed (Speed arrival)	10 to 20000	r/min	Set the detection timing of the speed arrival output (AT-SPEED).

Note

For details of these parameters, refer to P.4-41 "Details of parameter".

1. Outline of mode

Velocity Control Mode

(5) Speed coincidence output (V-COIN)

This signal is output when the motor speed is equal to the speed specified by the speed command. The motor speed is judged to be coincident with the specified speed when the difference from the speed command before/after acceleration/deceleration is within the range specified by Pr4.35 "Speed coincident range".

• Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr4.35	Speed coincidence range	10 to 20000	r/min	Set the speed coincidence (V-COIN) output detection timing.

Note

For details of these parameters, refer to P.4-40 "Details of parameter".

(6) Speed command acceleration/deceleration setting function

This function controls the speed by adding acceleration or deceleration instruction in the driver to the input speed command.

Using this function, you can use the soft start when inputting stepwise speed command or when using internal speed setup. You can also use S shaped acceleration/deceleration function to minimize shock due to change in speed.

• Relevant parameters

Parameter No.	Title	Range	Unit	Function
Pr3.12	Acceleration time setup	0 to 10000	ms/ (1000r/min)	Set up acceleration processing time in response to the speed command input.
Pr3.13	Deceleration time setup	0 to 10000	ms/ (1000r/min)	Set up deceleration processing time in response to the speed command input.
Pr3.14	Sigmoid acceleration/ deceleration time setup	0 to 1000	ms	Set S-curve time for acceleration/ deceleration process when the speed command is applied.

Caution

When the position loop is external to the driver, do not use the acceleration/deceleration time setting. Set these values to 0.

Note

For details of these parameters, refer to P.4-27 and 28 "Details of parameter".

Outline

The torque control is performed according to the torque command specified in the form of analog voltage. For controlling the torque, the speed limit input is required in addition to the torque command to maintain the motor speed within the speed limit.

With the A5 series, 3 torque control modes are available, each requires different torque command and speed limit as shown in the table below.

• Pr3.17 (Selection of torque command)


Setup value		Torque command input	Velocity limit input
0	Selection of torque command 1	Analog input 1 *1 (AI1, 16-bit resolution)	Parameter value (Pr3.21)
1	Selection of torque command 2	Analog input 2 (AI2, 12-bit resolution)	Analog input 1 (AI1, 16-bit resolution)
2	Selection of torque command 3	Analog input 1 *1 (AI1, 16-bit resolution)	Parameter value (Pr3.21, Pr3.22)

*1 For Pr0.01 Control mode setup = 5 (velocity/torque control), the torque command input is the analog input 2 (AI2, 12-bit resolution).


Note

For details of these parameters, refer to P.4-29 "Details of parameter".

<Selection of torque command 1, 3>



<Selection of torque command2>



Note

Only for position control type is not provided with analog input.

Related page

• P.3-16 "Control Block Diagram" • P.3-19 "Wiring Diagram to the connector, X4"

1. Outline of mode

Torque Control Mode

Function

(1) Process of analog torque command input

This process converts the analog torque command input (voltage) to the equivalent digital torque command having the same effect. You can set the filter or adjust the offset to eliminate noise.

• Relevant parameters <Selection of torque command 1, 3>

Parameter No.	Title	Range	Unit	Function
Pr3.18	Torque command direction selection	0 to 1	—	Select the direction positive/negative direction of torque command.
Pr3.19	Input gain of torque command	10 to 100	0.1V /100%	Based on the voltage (V) applied to the analog torque command (TRQ R), set up the conversion gain to torque command (%).
Pr3.20	Input reversal of torque command	0 to 1	—	Set up the polarity of the voltage applied to the analog torque command (TRQR).
Pr4.22	Analog input 1 (AI1) offset setup	–5578 to 5578	0.359mV	Set up the offset correction value applied to the voltage fed to the analog input 1.
Pr4.23	Analog input 1 (AI1) filter	0 to 6400	0.01ms	Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 1.

• Relevant parameters <Selection of torque command 2>

Parameter No.	Title	Range	Unit	Function
Pr3.18	Torque command direction selection	0 to 1	—	Select the direction positive/negative direction of torque command.
Pr3.19	Input gain of torque command	10 to 100	0.1V /100%	Based on the voltage (V) applied to the analog torque command (TRQ R), set up the conversion gain to torque command (%).
Pr3.20	Input reversal of torque command	0 to 1	—	Set up the polarity of the voltage applied to the analog torque command (TRQR).
Pr4.25	Analog input 2 (AI2) offset setup	–342 to 342	5.86mV	Set up the offset correction value applied to the voltage fed to the analog input 2.
Pr4.26	Analog input 2 (AI2) filter	0 to 6400	0.01ms	Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 2.

Note

For details of these parameters, refer to P.4-29 and 38 “Details of parameter”.

1. Outline of mode

Torque Control Mode

(2) Speed limit function

The speed limit is one of protective functions used during torque control.

This function regulates the motor speed so that it does not exceed the speed limit while the torque is controlled.

Caution

While the speed limit is used to control the motor, the torque command applied to the motor is not directly proportional to the analog torque command. Torque command should have the following result: the motor speed is equal to the speed limit.

• Relevant parameters <Selection of torque command 1, 3>

Parameter No.	Title	Range	Unit	Function
Pr3.21	Speed limit value 1	0 to 20000	r/min	Set up the speed limit used for torque controlling.
Pr3.22	Speed limit value 2	0 to 20000	r/min	
Pr3.15	Speed zero-clamp function selection	0 to 3	—	You can set up the function of the speed zero clamp input.

• Relevant parameters <Selection of torque command 2>


Parameter No.	Title	Range	Unit	Function
Pr3.02	Input gain of speed command	10 to 2000	(r/min)/V	Based on the voltage applied to the analog speed command (SPR), set up the conversion gain to motor command speed.
Pr4.22	Analog input 1 (AI1) offset setup	–5578 to 5578	0.359mV	Set up the offset correction value applied to the voltage fed to the analog input 1.
Pr4.23	Analog input 1 (AI1) filter	0 to 6400	0.01ms	Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 1.
Pr3.15	Speed zero-clamp function selection	0 to 3	—	You can set up the function of the speed zero clamp input.

Note

For details of these parameters, refer to P.4-26, 28, 30 and 38 “Details of parameter”.

Outline


In this full-closed control, you can make a position control by using an external scale mounted externally which detects the position directly and feeds it back. With this control, you can control without being affected by the positional variation due to the ball screw error or temperature and you can expect to achieve a very high precision positioning in sub-micron order.



We recommend the external scale division ratio of $\frac{1}{40} \leq \text{External scale division ratio} \leq 160$

Cautions on Full-Closed Control

- (1) Enter the command pulses making the external scale as a reference.
If the command pulses do not match to the external scale pulses, use the command division/multiplication function (Pr0.09 to Pr0.10) and setup so that the command pulses after division/multiplication is based on the external scale reference.
- (2) The A5 series supports the external scale of A- and B-phase output type and serial communication type. Initialize the parameters according to the following procedures and write to EEPROM and turn on power.
- (3) When using a scale of A- and B-phase output type, correctly connect it so that the rotating direction of the motor (CW/CCW) and A-phase and B-phase of the external scale have the following relationship.



<How to make an initial setup of parameters related to external scale >

- 1) Turn on the power after checking the wiring.
- 2) Check the values (initial) feedback pulse sum and external scale feedback pulse sum with the front panel.
- 3) Move the work and check the travel from the initial values of the above 2).
- 4) If the travel of the feedback pulse sum and the external scale feedback pulse sum are reversed in positive and negative, set up the reversal of external scale direction (Pr3.26) to 1.
- 5) Set up the external scale division ratio (Pr3.24, Pr3.25) using the formula below,

$$\text{External scale division ratio} = \frac{\text{Total variation of feedback pulse sum}}{\text{Total variation of external scale feedback pulse sum}} = \frac{\text{Pr3.24}}{\text{Pr3.25}}$$

* If the design value of the external scale division ratio is obtained, set up this value.

Note

Only for position control type is not provided with connector X5.

Related page

- P.3-17 "Control Block Diagram" • P.3-19 "Wiring Diagram to the connector, X4"
- P.3-30 "Inputs and outputs on connector X4" • P.4-31 "Details of parameter"

1. Outline of mode

Full-closed Control Mode

6) Set up appropriate value of hybrid deviation excess (Pr3.28) in command unit, in order to avoid the damage to the machine.

* A5-series driver calculates the difference between the encoder position and the external scale position as hybrid deviation, and is used to prevent the machine runaway or damage in case of the external scale breakdown or when the motor and the load is disconnected.

If the hybrid deviation excess range is too wide, detection of the breakdown or the disconnection will be delayed and error detection effect will be lost. If this is too narrow, it may detect the normal distortion between the motor and the machine under normal operation as an error.

* When the external scale division ratio is not correct, hybrid deviation excess error (Err25.0) may occur especially when the work travels long distance, even though the external scale and the motor position matches.

In this case, widen the hybrid deviation excess range by matching the external scale division ratio to the closest value.

Function

(1) Selection of external scale type

Select the type of external scale to be used.

• Relevant parameters

Parameter No.	Title	Range	Function
Pr3.23	External scale selection	0 to 2	Select the type of external scale.
Pr3.26	Reversal of direction of external scale	0 to 1	Reverse the direction of external scale, feedback counter.

Note

For details of these parameters, refer to P.4-30 and 31 "Details of parameter".

(2) Setup of external scale division ratio

Set up the division ratio of encoder resolution and external scale resolution.

• Relevant parameters

Parameter No.	Title	Range	Function
Pr3.24	Numerator of external scale division	0 to 2^{20}	Set up the numerator of the external scale dividing setup.
Pr3.25	Denominator of external scale division	1 to 2^{20}	Set up the Denominator of the external scale dividing setup.

Note

For details of these parameters, refer to P.4-31 "Details of parameter".

(3) Setup of hybrid excessive deviation

This function detects the positional difference between the motor (encoder) and load (external scale) and enables the hybrid excessive deviation protection if the difference exceeds Pr3.28 "Hybrid excessive deviation setup".


Hybrid excessive deviation is mainly caused by feedback scale error, wrong connection and loose connection between the motor and load.

• Relevant parameters

Parameter No.	Title	Range	Function
Pr3.28	Hybrid deviation excess setup	1 to 2^{27}	You can setup the permissible gap (hybrid deviation) between the present motor position and the present external scale position.
Pr3.29	Hybrid deviation clear setup	0 to 100	As the motor turns the number of revolutions set by this parameter, the hybrid deviation is cleared to 0.


Note

For details of these parameters, refer to P.4-32 "Details of parameter".



Related page

- P.3-18 "Wiring example of position control mode"
- P.3-20 "Connecting example to host controller"
- P.3-30 "Inputs and outputs on connector X4"
- P.4-2 "List of Parameters"

**Note**

Only for position control type is not provided with analog input.

Related page


• P.3-18 "Wiring example of velocity control mode"

3

Connection

2. Control Block Diagram

Torque Control Mode




Note

Only for position control type is not provided with analog input.

Related page

• P.3-19 "Wiring example of torque control mode"

**Note**

Only for position control type is not provided with analog input.

Related page

• P.3-19 "Wiring example of full-close control mode"


3

Connection


3. Wiring Diagram to the connector, X4

Example of control mode specific wiring

Wiring Example of Position Control Mode



Wiring Example of Velocity Control Mode




Note

- The functions of the following pin can be changed using parameters. (Refer to P.4-33)
 Input(Position): 8, 9, 26, 27, 28, 29, 31, 32 Output: 10-11, 12, 34-35, 36-37, 38-39, 40
 Input(Velocity): 8, 9, 26, 27, 28, 29, 30, 31, 32, 33 Output: 10-11, 12, 34-35, 36-37, 38-39, 40
 * Pins in the figure above represent default parameter values.
- Only for position control type is not provided with analog input.


3. Wiring Diagram to the connector, X4

Example of control mode specific wiring

Wiring Example of Torque Control Mode



Wiring Example of Full-closed Control Mode



Note

- The functions of the following pin can be changed using parameters. (Refer to P.4-33)
Input(Torque): 8, 9, 26, 27, 28, 29, 30, 31, 32, 33 Output: 10-11, 12, 34-35, 36-37, 38-39, 40
Input(Full-closed): 8, 9, 26, 27, 28, 29, 31, 32 Output: 10-11, 12, 34-35, 36-37, 38-39, 40
* Pins in the figure above represent default parameter values.
- Only for position control type is not provided with analog input.
- Only for position control type is not provided with connector X5.


3

Connection

3. Wiring Diagram to the connector, X4

Connecting Example to Host Controller

Connection between MINAS A5 and FP2-PP22 AFP2434 (Panasonic Electric Works)



Note

represents twisted pair wire.


Related page

• P.3-30 "Inputs and outputs on connector X4"

3. Wiring Diagram to the connector, X4

Connecting Example to Host Controller

Connection between MINAS A5 and FP2-PP22 AFP2434 (Panasonic Electric Works)



Note

represents twisted pair wire.


Related page

• P.3-30 "Inputs and outputs on connector X4"

3. Wiring Diagram to the connector, X4

Connecting Example to Host Controller

Connection between MINAS A5 and FPG-C32T (Panasonic Electric Works)



Note

represents twisted pair wire.


Related page

• P.3-30 "Inputs and outputs on connector X4"

3. Wiring Diagram to the connector, X4

Connecting Example to Host Controller

Connection between MINAS A5 and F3YP14-ON/F3YP18-ON (Yokogawa Electric Corp.)



Note

represents twisted pair wire.


Related page

• P.3-30 "Inputs and outputs on connector X4"

3. Wiring Diagram to the connector, X4

Connecting Example to Host Controller

Connection between MINAS A5 and F3NC32-ON/F3NC34-ON (Yokogawa Electric Corp.)



Note

represents twisted pair wire.

Related page

• P.3-30 "Inputs and outputs on connector X4"

Connecting Example to Host Controller

PLC
CJ1W-NC113
(Omron Corp.)

Terminal Assignment Table:

Terminal	Function
50	FG
3	PULS1
4	PULS2
5	SIGN1
6	SIGN2
23	OZ+
24	OZ-
13,25	GND
7	COM+
30	CL
29	SRV-ON
27	GAIN
31	A-CLR
9	POT
8	NOT
35	S-RDY+
34	S-RDY-
37	ALM+
36	ALM-
39	INP+
38	INP-
41	COM-

Wiring Schematic Details:

- Power Supply:** +24V DC is connected to terminals 13, 25 (GND) and 7 (COM+).
- Inputs:**
 - Command pulse input 2:** PULS1 (3) and PULS2 (4) are connected to the PLC I/O output.
 - Command sign input 2:** SIGN1 (5) and SIGN2 (6) are connected to the PLC I/O output.
 - Z-phase output:** OZ+ (23) and OZ- (24) are connected to the PLC I/O output.
 - Counter clear input:** CL (30) is connected to the PLC I/O output.
 - Servo-ON input:** SRV-ON (29) is connected to the PLC I/O output.
 - Gain switching input:** GAIN (27) is connected to the PLC I/O output.
 - Alarm clear input:** A-CLR (31) is connected to the PLC I/O output.
 - Inhibit positive direction travel input:** POT (9) is connected to the PLC I/O output.
 - Inhibit negative direction travel input:** NOT (8) is connected to the PLC I/O output.
- Outputs:**
 - Servo-Ready output:** S-RDY+ (35) and S-RDY- (34) are connected to the PLC I/O input.
 - Servo-Alarm output:** ALM+ (37) and ALM- (36) are connected to the PLC I/O input.
 - Positioning complete output:** INP+ (39) and INP- (38) are connected to the PLC I/O input.
- Other Connections:**
 - Origin line driver input:** A16 and A14 are connected to the PLC I/O output.
 - Deviation counter reset output:** A10 is connected to the PLC I/O output.
 - Emergency stop input:** A24 and A20 are connected to the PLC I/O output.
 - Origin proximity input:** A21 is connected to the PLC I/O output.
 - CCW limit excess input:** A23 is connected to the PLC I/O output.
 - CW limit excess input:** A22 is connected to the PLC I/O output.


 represents twisted pair wire.

3-26

3. Wiring Diagram to the connector, X4

Connecting Example to Host Controller

Connection between MINAS A5 and CJ1W-NC133 (Omron Corp.)



Note

represents twisted pair wire.


Related page

• P.3-30 "Inputs and outputs on connector X4"

3. Wiring Diagram to the connector, X4

Connecting Example to Host Controller

Connection between MINAS A5 and QD75D1 (Mitsubishi Electric Corp.)



Note

represents twisted pair wire.


Related page

• P.3-30 "Inputs and outputs on connector X4"

3. Wiring Diagram to the connector, X4

Connecting Example to Host Controller

Connection between MINAS A5 and KV-5000/3000 (keyence Corp.)



Note

represents twisted pair wire.

Related page

• P.3-30 "Inputs and outputs on connector X4"

Input Circuit

SI

Connection to sequence input signals

Related control mode



P

S

T

F

- Connect to contacts of switches and relays, or open collector output transistors.
- When you use contact inputs, use the switches and relays for micro current to avoid contact failure.
- Make the lower limit voltage of the power supply (12 to 24V) as 11.4V or more in order to secure the primary current for photo-couplers.



- 10 systems: SI1 to SI10. For assign and function, refer to P.3-37 to P.3-42.

Note



Related page P.3-50

PI1

Connection to sequence input signals (Pulse train interface)

Related control mode

P

S




T

F

- (1) Line driver I/F (Permissible max. input frequency of command pulse input signal.: 500kpps)
 - This signal transmission method has better noise immunity.
 - We recommend this to secure the signal transmission.
- (2) Open collector I/F (Permissible max. input frequency of command pulse input signal.: 200kpps)
 - The method which uses an external control signal power supply (V_{DC})
 - Current regulating resistor (R) corresponding to V_{DC} is required in this case.
 - Connect the specified resistor as below.
 - (R) should be placed close to the driver for effective noise reduction.
- (3) Open collector I/F (Permissible max. input frequency of command pulse input signal.: 200kpps)
 - Connecting diagram when a current regulating resistor is not used with 24V power supply.

V _{DC}	Specifications
12V	1kΩ/2W
24V	2kΩ/2W

$$\frac{V_{DC} - 1.5}{R + 220} \approx 10\text{mA}$$



* Keep the length of wiring short (1 m or less).

Max.input voltage :

DC24V, Rated current : 10mA

⌘ represents twisted pair.

- 1 system: PI1. For function, refer to P.3-35, P.3-36.

4. Inputs and outputs on connector X4

Interface Circuit (Input)

PI2	Connection to sequence input signals (Pulse train interface exclusive to line driver)	Related control mode	P	S	T	F

Line driver I/F (Permissible max. input frequency of command pulse input signal.: 4Mpps)

- This signal transmission method has better noise immunity.
- We recommend this to secure the signal transmission when line driver I/F is used.

• 1 system: PI2. For function, refer to P.3-35, P.3-36.

AI	Analog command input	Related control mode	P	S	T	F

- It goes through 3 systems, AI1 to AI3.
- Max. permissible input voltage to each input is $\pm 10V$.
For input impedance of each input, refer to the right Fig.
- When you compose a simple command circuit using variable resistor (VR) and register R, connect as the right Fig. shows. When the variable range of each input is made as $-10V$ to $+10V$, use VR with 2kW, B-characteristics, 1/2W or larger, R with 200W, 1/2W or larger.
- A/D converter resolution of each command input is as follows.
 - (1) ADC1 : 16 bit (AI1)
 - (2) ADC2 : 12 bit (AI2, AI3)

• For function, refer to P.3-43, P.3-44.

Note Only for position control type is not provided with analog input.

Output Circuit

SO

Sequence output circuit

Related
control mode

P


S

T

F

- The output circuit is composed of open collector transistor outputs in the Darlington connection, and connect to relays or photo-couplers.
- There exists collector to emitter voltage, V_{CE} (SAT) of approx. 1V at transistor-ON, due to the Darlington connection of the output or. Note that normal TTL IC cannot be directly connected since it does not meet VIL.
- There are two types of output, one (2 systems of SO5, SO6) which emitter side of the output transistor is independent and is connectable individually, and the one (4 systems of SI1 to SI4) which is common to – side of the control power supply (COM–).
- If a recommended primary current value of the photo-coupler is 10mA, decide the resistor value using the formula of the below figure.
- When accepting the output signal through a logic circuit, e.g. gate, influence from noises should be prevented.

For the recommended primary current value, refer to the data sheet of the equipment and photo-coupler to be used.



Note

- For function, refer to P.3-45 to P.3-48.

Related page P.3-52

PO1

Line driver (Differential output) output

Related
control mode


P

S

T

F

- Feeds out the divided encoder outputs (A, B and Z-phase) in differential through each line driver.
- At the host side, receive these in line receiver. Install a terminal resistor (approx. 330Ω) (right figure (1)) between line receiver inputs without fail.
- These outputs are not insulated.



- For function, refer to P.3-48.

represents twisted pair.

4. Inputs and outputs on connector X4

Interface Circuit (Output)

PO2

Open collector output

Related control mode


P

S

T

F

- Feeds out the Z-phase signal among the encoder signals in open collector. This output is not insulated.
- Receive this output with high-speed photo couplers at the host side, since the pulse width of the Z-phase signal is narrow.



- For function, refer to P.3-48.

AO

Analog monitor output

Related control mode

P

S

T

F

- There are two outputs, the speed monitor signal output (SP) and the torque monitor signal output (IM)
- Output signal width is $\pm 10V$.
- The output impedance is $1k\Omega$. Pay an attention to the input impedance of the measuring instrument or the external circuit to be connected.


<Resolution>

(1) Speed monitor output (SP)

With a setup of 6V/3000r/min, the resolution converted to speed is 8r/min/16mV.

(2) Torque monitor output (IM)

With a relation of 3V/rated torque (100%), the resolution converted to torque is 0.4%/12mV.



- For function, refer to P.3-49.

3

Connection

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Input Signals (common) and Their Functions

Pin No.	7	Title of signal	Power supply for control signal (+)	Related control mode	P	S	T	F
		Symbol	COM+	I/F circuit	—			
<ul style="list-style-type: none">• Connect + of the external DC power supply (12 to 24V).• Use the power supply voltage of 12V ± 5% – 24V ± 5%								

Pin No.	41	Title of signal	Power supply for control signal (-)	Related control mode	P	S	T	F
		Symbol	COM–	I/F circuit	—			
<ul style="list-style-type: none">• Connect – of the external DC power supply (12 to 24V).• The power capacity varies depending on a composition of I/O circuit. 0.5A or more is recommended.								

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Input Signals (Pulse Train) and Their Functions

You can select appropriate interface out of two kinds, depending on the command pulse specifications.

• Pulse train interface exclusive for line driver

Pin No.	44	Title of signal	Command pulse input 1	Related control mode	P	S	T	F
	45	Symbol	Pin No.44: PULSH1 Pin No.45: PULSH2	I/F circuit	PI2 3-31 page			
Pin No.	46	Title of signal	Command pulse sign input 1	Related control mode	P	S	T	F
	47	Symbol	Pin No.46: SIGNH1 Pin No.47: SIGNH2	I/F circuit	PI2 3-31 page			
<ul style="list-style-type: none">• Input terminal for position command pulse. You can select by setting up Pr0.05 (Selection of command pulse input) to 1.• This input becomes invalid at such control mode as velocity control or torque control, where no position command is required.• Permissible max. input frequency is 4Mpps.• You can select up to 6 command pulse input formats with Pr0.06 (Setup of command pulse rotational direction) and Pr0.07 (Setup of command pulse input mode). For details, refer to the table next page, "Command pulse input format".								

• Pulse train interface (supports both line driver and open collector)

Pin No.	1	Title of signal	Command pulse input 2	Related control mode	P	S	T	F
	3 4	Symbol	Pin No.1: OPC1 Pin No.3: PULS1 Pin No.4: PULS2	I/F circuit	PI1 3-30 page			
Pin No.	2	Title of signal	Command pulse sign input 2	Related control mode	P	S	T	F
	5 6	Symbol	Pin No.2: OPC2 Pin No.5: SIGN1 Pin No.6: SIGN2	I/F circuit	PI1 3-30 page			
<ul style="list-style-type: none">• Input terminal for the position command. You can select by setting up Pr0.05 (Selection of command pulse input) to 0.• This input becomes invalid at such control mode as the velocity control or torque control, where no position command is required.• Permissible max. input frequency is 500kpps at line driver input and 200kpps at open collector input.• You can select up to 6 command pulse input formats with Pr0.06 (Setup of command pulse rotational direction) and Pr0.07 (Setup of command pulse input mode). For details, refer to the table next page, "Command pulse input format".								













Related page

- P.3-30 "Inputs and outputs on connector X4"
- P.4-4 "Details of parameter"

4. Inputs and outputs on connector X4

Input Signal and Pin No.

• Input format command pulse

Pr0.06 setup value (Command pulse rotational direction setup)	Pr0.07 setup value (Command pulse input mode setup)	Command pulse format	Signal title	Positive direction command	Negative direction command
0	0 or 2	90° phase difference 2-phase pulse (A + B-phase)	PULS SIGN	 <p>B-phase advances to A by 90°.</p>	 <p>B-phase delays from A by 90°.</p>
	1	Positive direction pulse train + Negative direction pulse train	PULS SIGN		
	3	pulse train + Signal	PULS SIGN	 <p>"H"</p>	 <p>"L"</p>
1	0 or 2	90° phase difference 2-phase pulse (A + B-phase)	PULS SIGN	 <p>B-phase delays from A by 90°.</p>	 <p>B-phase advances to A by 90°.</p>
	1	Positive direction pulse train + Negative direction pulse train	PULS SIGN		
	3	pulse train + Signal	PULS SIGN	 <p>"L"</p>	 <p>"H"</p>

- PULS and SIGN represents the outputs of pulse train in put circuit. Refer to the fig. of P.3-30, "Input Circuit".
- In case of negative direction pulse train + positive direction pulse train and pulse train + sign, pulse train will be cap tured at the rising edge.
- In case of 2-phase pulse, pulse train will be captured at each edge.

• Permissible max. input frequency, and min. necessary time width of command pulse input signal.

Input I/F of PULS/SIGN signal		Permissible max. input frequency	Min. necessary time width (μs)					
			t1	t2	t3	t4	t5	t6
Pulse train interface exclusive to line driver		4Mpps	0.25	0.125	0.125	0.125	0.125	0.125
Pulse train interface	Line driver interface	500kpps	2	1	1	1	1	1
	Open collector interface	200kpps	5	2.5	2.5	2.5	2.5	2.5

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Control Input

Control signal having the desired function can be applied to any input pin of I/F connector.
The logic can be changed.

• Default assignment

Pin No.		Title of signal	Symbol	Applicable parameter	Default parameter setting (): decimal notation	Default Setup					
						Position/ Full-closed control		Verocity control		Torque control	
						Signal	Logic *1	Signal	Logic *1	Signal	Logic *1
8		SI1 input	SI1	Pr4.00	00828282h (8553090)	NOT	b-contact	NOT	b-contact	NOT	b-contact
		Symbol									
9		SI2 input	SI2	Pr4.01	00818181h (8487297)	POT	b-contact	POT	b-contact	POT	b-contact
		Symbol									
26		SI3 input	SI3	Pr4.02	0091918Ah (9539850)	VS-SEL1	b-contact	ZEROSPD	b-contact	ZEROSPD	b-contact
		Symbol									
27		SI4 input	SI4	Pr4.03	00060606h (394758)	GAIN	a-contact	GAIN	a-contact	GAIN	a-contact
		Symbol									
28		SI5 input	SI5	Pr4.04	0000100Ch (4108)	DIV1	b-contact	INTSPD3	b-contact	—	—
		Symbol									
29		SI6 input	SI6	Pr4.05	00030303h (197379)	SRV-ON	a-contact	SRV-ON	a-contact	SRV-ON	a-contact
		Symbol									
30		SI7 input	SI7	Pr4.06	00000f07h (3847)	CL	a-contact	INTSPD2	a-contact	—	—
		Symbol									
31		SI8 input	SI8	Pr4.07	00040404h (263172)	A-CLR	a-contact	A-CLR	a-contact	A-CLR	a-contact
		Symbol									
32		SI9 input	SI9	Pr4.08	00050505h (328965)	C-MODE	a-contact	C-MODE	a-contact	C-MODE	a-contact
		Symbol									
33		SI10 input	SI10	Pr4.09	00000E88h (3720)	INH	b-contact	INTSPD1	b-contact	—	—
		Symbol									

• The function depends on parameter setup. Refer to P.4-33, 4-34.

Refer to the next section “Function assignable to general purpose input”.

Note

*1 Operation of a-contact and b-contact:

a-contact: Input signal disconnected from COM— function disabled (OFF state)

Input signal connected to COM— function enabled (ON state)

b-contact: Input signal disconnected from COM— function enabled (ON state)

Input signal connected to COM function disabled (OFF state)

[—]: No function assigned

Related page P.3-50

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Function allocatable to control input

Title of signal	Servo-ON input		Related control mode	P	S	T	F
Symbol	SRV-ON	Default assignment	29 (SI6)	I/F circuit	SI	3-30	page
<ul style="list-style-type: none"> This signal turns on/off the servo (motor). 							

Title of signal	Positive direction over-travel inhibition input		Related control mode	P	S	T	F
Symbol	POT	Default assignment	9 (SI2)	I/F circuit	SI	3-30	page
<ul style="list-style-type: none"> Positive direction over-travel inhibit input. The operation with this input turned ON is set up in Pr5.04 "Setup of over-travel inhibit input". When using this input, set Pr5.04 "Setup of over-travel inhibit input" to a value other than 1 so that the input is ON when the moving portion of the machine exceeds this signal range toward positive direction. 							

Title of signal	Negative direction over-travel inhibition input		Related control mode	P	S	T	F
Symbol	NOT	Default assignment	8 (SI1)	I/F circuit	SI	3-30	page
<ul style="list-style-type: none"> Negative direction over-travel inhibit input. The operation with this input turned ON is set up in Pr5.04 "Setup of over-travel inhibit input". When using this function, set Pr5.04 "Setup of over-travel inhibit input" to a value other than 1 so that the input is ON when the moving portion of the machine exceeds this signal range toward negative direction. 							

Title of signal	Deviation counter clear input			Related control mode	P	S	T	F
Symbol	CL	Default assignment	30 (SI7)	I/F circuit	SI	3-30 page		

- Clears the positional deviation counter.
- Default setup clears the counter at the rising edge of the clear input, To change the setup, modify it in the Pr5.17 “Counter clear input mode”.

<Signal width and clear timing>

Pr5.17	CL signal width	Deviation clear timing
1	500 μs or more	Continually clear the counter while the deviation counter clear input is ON. *1
2	1 ms or more	
3	100 μs or more	Only once clear the counter at OFF to ON edge of the deviation counter clear input signal. *1
4	1 ms or more	

*1 Deviation counter clear input ON/OFF = input photocoupler ON/OFF

Caution

This function can be assigned to only SI7. Allocation of this function to any other pin will cause an error.

Related page ⚡ • P.4-43, 47 "Details of Parameter"

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Title of signal	Alarm clear input			Related control mode	P	S	T	F
Symbol	A-CLR	Default assignment	31 (SI8)	I/F circuit	SI	3-30	page	
<ul style="list-style-type: none"> Clears the alarm condition. This input cannot clear some alarms. For details, refer to P.6-2 When in Trouble "Protective function", P.2-98 "(8) Alarm Display" and P.7-25 "Display of Battery Alarm". 								

Title of signal	Command pulse inhibition input			Related control mode	P	S	T	F
Symbol	INH	Default assignment	33 (SI10)	I/F circuit	SI	3-30	page	
<ul style="list-style-type: none"> Ignores the positional command pulse. When using this feature, set Pr5.18 "Invalidation of command pulse inhibition input" to 0. 								
Caution ⚡ This function can be assigned to only SI10. Allocation of this function to any other pin will cause an error.								

Title of signal	Control mode switching input			Related control mode	P	S	T	F
Symbol	C-MODE	Default assignment	32 (SI9)	I/F circuit	SI	3-30	page	
<ul style="list-style-type: none"> Selects a control mode. 								
Caution ⚡ This signal is required in all control modes. No setting will cause an error.								
<ul style="list-style-type: none"> Do not input any command 10 ms before and after changing the control mode. 								

Title of signal	Electronic gear (division/multiplication) switching input 1			Related control mode	P	S	T	F																						
Symbol	DIV1	Default assignment	28 (SI5)	I/F circuit	SI	3-30 page																								
Title of signal	Electronic gear (division/multiplication) switching input 2			Related control mode	P	S	T	F																						
Symbol	DIV2	Default assignment	—	I/F circuit	SI	3-30 page																								
<div>• Up to 4 numerators can be used for command dividing/multiplying by using DIV1 and DIV2.</div> <div><DIV1 and DIV2 vs numerator/denominator of selected command dividing/multiplying process></div> <table><tr><th rowspan="2">DIV1</th><th rowspan="2">DIV2</th><th colspan="2">Selected command dividing/multiplying process</th></tr><tr><th>Numerator</th><th>Denominator</th></tr><tr><td>OFF</td><td>OFF</td><td>Pr0.09</td><td>Pr0.10</td></tr><tr><td>ON</td><td>OFF</td><td>Pr5.00</td><td>Pr0.10</td></tr><tr><td>OFF</td><td>ON</td><td>Pr5.01</td><td>Pr0.10</td></tr><tr><td>ON</td><td>ON</td><td>Pr5.02</td><td>Pr0.10</td></tr></table>									DIV1	DIV2	Selected command dividing/multiplying process		Numerator	Denominator	OFF	OFF	Pr0.09	Pr0.10	ON	OFF	Pr5.00	Pr0.10	OFF	ON	Pr5.01	Pr0.10	ON	ON	Pr5.02	Pr0.10
DIV1	DIV2	Selected command dividing/multiplying process																												
		Numerator	Denominator																											
OFF	OFF	Pr0.09	Pr0.10																											
ON	OFF	Pr5.00	Pr0.10																											
OFF	ON	Pr5.01	Pr0.10																											
ON	ON	Pr5.02	Pr0.10																											

Title of signal	Damping control switching input 1			Related control mode	P	S	T	F
Symbol	VS-SEL1	Default assignment	26 (SI3)	I/F circuit	SI	3-30	page	
Title of signal	Damping control switching input 2			Related control mode	P	S	T	F
Symbol	VS-SEL2	Default assignment	—	I/F circuit	SI	3-30	page	
<ul style="list-style-type: none"> Selects applicable frequency for damping control. Combination of damping control input changeover 1 and 2 (VS-SEL1, VS-SEL2) enables select of max. 4 options. 								
Note ⚡ Also refer to P.4-22 "Pr2.13 [Damping filter switching selection]".								

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Title of signal	Gain switching input			Related control mode	P	S	T	F
Symbol	GAIN	Default assignment	27 (SI4)	I/F circuit	SI	3-30 page		
• Select 1st or 2nd gain.								

Title of signal	Torque limit switching input			Related control mode	P	S	T	F
Symbol	TL-SEL	Default assignment	—	I/F circuit	SI	3-30 page		

- Select 1st or 2nd torque limit.

Pr5.21	Torque limit switching input (TL-SEL)	Torque limit switching setup (Pr5.23, Pr5.24)	Positive direction Torque limit	Negative direction Torque limit
0	Analog input *1		Pr0.13	
1			Pr0.13	
2	—	—	Pr0.13	Pr5.22
3	OFF ON	Valid	Pr0.13	Pr5.22
4	Analog input *1		Pr0.13	
5			Pr5.22	
6	OFF ON	—	Pr0.13 Pr5.25	Pr5.22 Pr5.26


*1 To specify the torque limit value by an analog input, refer to Pr5.21 “Analog torque limit function”.

• Setup of rate of change after torque limit switchover

When applying Pr5.21 “Torque limit selection” = 3, changing rate of torque (slope) after selecting new torque limit can be changed.

When changing from the 1st torque limit to 2nd torque limit, the changing rate (slope) set at Pr5.23 “Torque limit selection setup 1” is applied; after changing from the 2nd torque limit to 1st torque limit, the changing rate (slope) set at Pr5.24 “Torque limit selection setup 2” is applied. The sign of the changing rate is automatically selected by the driver according to the difference in value between the 1st and 2nd torque limit.

If Pr5.23 “Torque limit selection setup 1” and Pr5.24 “Torque limit selection setup 2” are set to 0, switchover is instantaneous.



Caution

When the 1st torque limit (Pr0.13) and 2nd torque limit (Pr5.22) are changed from the front panel or through communication, the changing rate setup is ignored and the new torque limit value is immediately and directly applied. That is, changing rate setting is effective only when the selection is made by using the torque limit select input (TL-SEL).

Related page • P.4-48 “Details of Parameter”

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Title of signal	Selection 1 input of internal command speed			Related control mode	P	S	T	F
Symbol	INTSPD1	Default assignment	33 (SI10)	I/F circuit	SI	3-30 page		
Title of signal	Selection 2 input of internal command speed			Related control mode	P	S	T	F
Symbol	INTSPD2	Default assignment	30 (SI7)	I/F circuit	SI	3-30 page		
Title of signal	Selection 3 input of internal command speed			Related control mode	P	S	T	F
Symbol	INTSPD3	Default assignment	28 (SI5)	I/F circuit	SI	3-30 page		


- Select one of 8 internal command speeds.

<Relationship between Pr3.00 “Switching between internal and external speed setup” and internal command speed selection 1-3 and the speed command selected>.


Pr3.00	Selection 1 of internal command speed (INTSPD1)	Selection 2 of internal command speed (INTSPD2)	Selection 3 of internal command speed (INTSPD3)	Selection of speed command
1	OFF	OFF	No effect	1st speed
	ON	OFF		2nd speed
	OFF	ON		3rd speed
	ON	ON		4th speed
2	OFF	OFF	No effect	1st speed
	ON	OFF		2nd speed
	OFF	ON		3rd speed
	ON	ON		Analog speed command
3	The same as Pr3.00=1		OFF	1st to 4th speed
	OFF	OFF	ON	5th speed
	ON	OFF	ON	6th speed
	OFF	ON	ON	7th speed
	ON	ON	ON	8th speed

Caution

Internal command speed switching pattern should be so arranged as shown below that single input signals are selected alternately. If 2 or more input signals are selected simultaneously, unspecified internal command speed may be advertently selected, whose setting value and acceleration/deceleration setting will cause unexpected operation.



Example 1) When Pr3.00=1 or 2



Example 2) When Pr3.00=3

Title of signal	Speed zero clamp input			Related control mode	P	S	T	F
Symbol	ZEROSPD	Default assignment	26 (SI3)	I/F circuit	SI	3-30 page		
<div><div></div><div><ul style="list-style-type: none">• Set the speed command to 0.• When using, set Pr3.15 “Speed zero clamp function selection” to a value other than 0.</div></div>								

Title of signal	Speed command sign input				Related control mode	P	S	T	F
Symbol	VC-SIGN	Default assignment	—	I/F circuit	SI	3-30 page			
<div>• Specify the sign of speed command input at velocity control. Refer to P.4-25 “Pr3.01 Speed command rotational direction selection”</div>									

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Title of signal	Torque command sign input			Related control mode	P	S	T	F				
Symbol	TC-SIGN	Default assignment	—	I/F circuit	SI	3-30 page						
<ul style="list-style-type: none">Specify the sign of torque command input at torque control. <table><tr><td>ON</td><td>Negative direction</td></tr><tr><td>OFF</td><td>Positive direction</td></tr></table> <p>Refer to P.4-29 “Pr3.18 Torque command direction selection”</p>									ON	Negative direction	OFF	Positive direction
ON	Negative direction											
OFF	Positive direction											

Title of signal	Forced alarm input			Related control mode	P	S	T	F
Symbol	E-STOP	Default assignment	—	I/F circuit	SI	3-30 page		
• Generates Err87.0 “Forced alarm input error”.								

Title of signal	Inertia ratio switching input			Related control mode	P	S	T	F						
Symbol	J-SEL	Default assignment	—	I/F circuit	SI	3-30 page								
<ul style="list-style-type: none">Selects 1st inertia ratio or 2nd inertia ratio according to the inertia ratio select input (J-SEL).														
<table><tr><th>Inertia ratio switching input (J-SEL)</th><th>Applicable inertia ratio</th></tr><tr><td>OFF</td><td>1st Inertia ratio (Pr0.04)</td></tr><tr><td>ON</td><td>2nd Inertia ratio (Pr6.12)</td></tr></table>									Inertia ratio switching input (J-SEL)	Applicable inertia ratio	OFF	1st Inertia ratio (Pr0.04)	ON	2nd Inertia ratio (Pr6.12)
Inertia ratio switching input (J-SEL)	Applicable inertia ratio													
OFF	1st Inertia ratio (Pr0.04)													
ON	2nd Inertia ratio (Pr6.12)													
Refer to P.4-53 “Pr6.10 Function expansion setup”														

Note Only for position control type is not provided with analog input.

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Input Signals (Analog Command)

Pin No.	14	Title of signal	AI1 input	Correspondence function
		Symbol	AI1	SPR, TRQR, SPL
Pin No.	16	Title of signal	AI2 input	Correspondence function
		Symbol	AI2	TRQR, P-ATL
Pin No.	18	Title of signal	AI3 input	Correspondence function
		Symbol	AI3	N-ATL

Function allocatable to Input Signals (Analog Command)

Title of signal	Positive direction Torque limit input	Related control mode	P	S	T	F
Symbol	P-ATL	I/F circuit	AI	3-31 page		
Title of signal	Negative direction Torque limit input	Related control mode	P	S	T	F
Symbol	N-ATL	I/F circuit	AI	3-31 page		
<div>• Specify the torque limit for each direction value by the analog voltage.</div>						
Pr5.21	Positive direction Torque limit input (P-ATL)	Negative direction Torque limit input (N-ATL)	Positive direction Torque limit	Negative direction Torque limit		
0	0 to 10V	-10 to 0V	P-ATL	N-ATL		
1	—		Set up through parameter. *1			
2						
3						
4	0 to 10V	0 to 10V	P-ATL	N-ATL		
5	0 to 10V	No effect	P-ATL			
6	—		Setup by parameter *1			
<div>*1 When specifying the torque limit value through the parameter, refer to P.4-48 “Torque limit select function”</div>						

Note Only for position control type is not provided with analog input.

4. Inputs and outputs on connector X4

Input Signal and Pin No.

Title of signal	Speed command input	Related control mode	P	S	T	F
Symbol	SPR	I/F circuit	AI	3-31	page	
<ul style="list-style-type: none"> Input the speed command in the form of analog voltage. The table below shows relationship between the combination of Pr3.00 "Switching between internal and external speed setup", Pr3.01 "Speed command direction selection", Pr3.03 "Speed command input inversion", analog speed command (SPR) of I/F connector and speed command sign selection (VC-SIGN) and the motor rotational direction; and the conversion graph of analog speed command input voltage to the speed command. 						
Pr3.00	Pr3.01	Pr3.03	Speed command input (SPR)	Speed command sign selection (VC-SIGN)	Motor rotational direction	
0	0	0	+Voltage (0 to 10V)	No effect	Positive direction	
			–Voltage (–10 to 0V)	No effect	Negative direction	
		1	+Voltage (0 to 10V)	No effect	Negative direction	
			–Voltage (–10 to 0V)	No effect	Positive direction	
	1	No effect	+Voltage (0 to 10V)	OFF	Positive direction	
			–Voltage (–10 to 0V)		Positive direction	
			+Voltage (0 to 10V)	ON	Negative direction	
			–Voltage (–10 to 0V)		Negative direction	

Title of signal	Torque command input	Related control mode	P	S	T	F
Symbol	TRQR	I/F circuit	AI	3-31	page	
<ul style="list-style-type: none"> Input the torque command in the form of analog voltage. When Pr3.19 "Torque command selection" = 0, pin No.14 When Pr3.19 "Torque command selection" = 1, pin No.16 						
Pr3.17	Pr3.18	Pr3.20	Torque command input (TRQR)	Torque command sign selection (TC-SIGN)	Motor rotational direction	
0	0	0	+Voltage (0 to 10V)	No effect	Positive direction	
			–Voltage (–10 to 0V)	No effect	Negative direction	
		1	+Voltage (0 to 10V)	No effect	Negative direction	
			–Voltage (–10 to 0V)	No effect	Positive direction	
	1	No effect	+Voltage (0 to 10V)	OFF	Positive direction	
			–Voltage (–10 to 0V)		Positive direction	
			+Voltage (0 to 10V)	ON	Negative direction	
			–Voltage (–10 to 0V)		Negative direction	

Title of signal	Speed limit input	Related control mode	P	S	T	F
Symbol	SPL	I/F circuit	AI	3-31	page	
<ul style="list-style-type: none"> When setting Pr3.17 "Torque command selection" to 1, input the speed limit value in the form of analog voltage. 						

Note Only for position control type is not provided with analog input.

Output Signals (Common) and Their Functions

Control output signal of desired function can be assigned to I/F connector. Logic of the output pin cannot be changed.

Pin No.		Title of signal		Applicable parameter	Default parameter setting (): decimal notation	Default Setup		
						Position/ Full-closed control Signal	Verocity control Signal	Torque control Signal
Pin No. 10 11		Title of signal	SO1 output	Pr4.10	00030303h (197379)	BRK-OFF	BRK-OFF	BRK-OFF
		Symbol	Pin No.10: SO1- Pin No.11: SO1+					
Pin No. 34 35		Title of signal	SO2 output	Pr4.11	00020202h (131586)	S-RDY	S-RDY	S-RDY
		Symbol	Pin No.34: SO2- Pin No.35: SO2+					
Pin No. 36 37		Title of signal	SO3 output *1	Pr4.12	00010101h (65793)	ALM	ALM	ALM
		Symbol	Pin No.36: SO3- Pin No.37: SO3+					
Pin No. 38 39		Title of signal	SO4 output	Pr4.13	00050504h (328964)	INP	AT-SPEED	AT-SPEED
		Symbol	Pin No.38: SO4- Pin No.39: SO4+					
Pin No. 12		Title of signal	SO5 output	Pr4.14	00070707h (460551)	ZSP	ZSP	ZSP
		Symbol	SO5					
Pin No. 40		Title of signal	SO6 output	Pr4.15	00060606h (394758)	TLC	TLC	TLC
		Symbol	SO6					

- The function is changed by the setting of parameter. For details, refer to P.4-35.
See "Functions assignable to control output" as shown below.

Note

*1 Fixed ALM output.

[—]: No function assigned

Related page P.3-52

Function allocatable to control input

Title of signal	Servo-Alarm output		Related control mode	P	S	T	F
Symbol	ALM	Default assignment	36, 37 (SO3)	I/F circuit	SO	3-32 page	
<ul style="list-style-type: none"> • This signal shows that the driver is in alarm status.. • Output transistor turns ON when the driver is at normal status, and turns OFF at alarm status. 							

Title of signal	Servo-Ready output		Related control mode	P	S	T	F
Symbol	S-RDY	Default assignment	34, 35 (SO2)	I/F circuit	SO	3-32 page	
<ul style="list-style-type: none"> • This signal shows that the driver is ready to be activated. • Output transistor turns ON when both control and main power are ON but not at alarm status. When in the absolute mode and absolute I/F function is enabled, turns on the output transistor upon completion of the absolute data transfer provided that the conditions shown above are met. 							

4. Inputs and outputs on connector X4

Output Signal and Pin No.

Title of signal	External brake release signal			Related control mode	P	S	T	F
Symbol	BRK-OFF	Default assignment	10, 11 (SO1)	I/F circuit	SO	3-32 page		
<ul style="list-style-type: none">• Feeds out the timing signal which activates the holding brake of the motor.• Turns the output transistor ON at the release timing of the holding brake.								

Title of signal	Positioning complete			Related control mode	P	S	T	F
Symbol	INP	Default assignment	38, 39 (SO4)	I/F circuit	SO	3-32 page		
Title of signal	Positioning complete 2			Related control mode	P	S	T	F
Symbol	INP2	Default assignment	—	I/F circuit	SO	3-32 page		
<div>• Outputs the positioning complete signal/positioning complete signal 2.</div> <div>• Turns ON the output transistor upon completion of positioning.</div>								

Title of signal	Speed arrival output			Related control mode	P	S	T	F
Symbol	AT-SPPED	Default assignment	38, 39 (SO4)	I/F circuit	SO	3-32 page		
<ul style="list-style-type: none">• Outputs the speed arrival signal.• Turns ON the output transistor upon arrive of speed.								

Title of signal	Torque in-limit signal output			Related control mode	P	S	T	F
Symbol	TLC	Default assignment	40 (SO6)	I/F circuit	SO	3-32 page		
<div>• Outputs thetorque in-limit signal.</div> <div>• Turns ON the output transistor upon limit of torque.</div>								

Title of signal	Zero-speed detection output signal			Related control mode	P	S	T	F
Symbol	ZSP	Default assignment	12 (SO5)	I/F circuit	SO	3-32 page		
<div><ul style="list-style-type: none">• Outputs the zero-speed detection signal.• Turns ON the output transistor upon detection of Zero-speed.</div>								

Title of signal	Speed coincidence output			Related control mode	P	S	T	F
Symbol	V-COIN	Default assignment	—	I/F circuit	SO	3-32 page		
<div>• Outputs the speed coincidence signal.</div> <div>• Turns ON the output transistor upon coincidence of speed.</div>								

Title of signal	Alarm output 1				Related control mode	P	S	T	F
Symbol	WARN1	Default assignment	—	I/F circuit	SO	3-32 page			
<ul style="list-style-type: none">• Outputs the warning output signal set to Pr4.40 “Warning output select 1”.• Turns ON the output transistor upon occurrence of warning condition.									

4. Inputs and outputs on connector X4

Output Signal and Pin No.

Title of signal	Alarm output 2			Related control mode	P	S	T	F
Symbol	WARN2	Default assignment	—	I/F circuit	SO	3-32 page		
<div><ul style="list-style-type: none">• Outputs the warning output signal set to Pr4.41 “Warning output select 2”.• Turns ON the output transistor upon occurrence of warning condition.</div>								

• Selection of alarm 1 output and 2 output

Alarm No.	Alarm	Content	Pr6.27 *1	Pr4.40/ Pr4.41 *2	Pr6.38 Corresponding bit *3
A0	Overload protection	Load factor is 85% or more the protection level.	○	1	bit7
A1	Over-regeneration alarm	Regenerative load factor is 85% or more the protection level.	○	2	bit5
A2	Battery alarm	Battery voltage is 3.2 V or lower.	Fixed at no time limit.	3	bit0
A3	Fan alarm	Fan has stopped for 1 sec.	○	4	bit6
A4	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.	○	5	bit4
A5	Encoder overheat alarm	The encoder detects overheat alarm.	○	6	bit3
A6	Oscillation detection alarm	Oscillation or vibration is detected.	○	7	bit9
A7	Lifetime detection alarm	The life expectancy of capacity or fan becomes shorter than the specified time.	Fixed at no time limit.	8	bit2
A8	External scale error alarm	The feedback scale detects the alarm.	○	9	bit8
A9	External scale communication alarm	The number of successive feedback scale communication errors exceeds the specified value.	○	10	bit10

- *1 The "circle" means that a time in the range 1 to 10s or no time limit can be selected through Pr6.27 "Warning latching time". Note that the battery warning and the end of life warning have no time limit.
- *2 Select the warning output signal 1 (WARN1) or warning output signal 2 (WARN2) through Pr4.40 "Warning output select 1" or Pr4.41 "Warning output select 2". When the set value is 0, all warnings are ORed before being output. Do not set to any value other than those specified in the table above.
- *3 A warning detection can be masked by Pr6.38 "Warning mask setup" Corresponding bits are shown in the table. Warning is masked with bit = 1.
- *4 The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal and no fan alarm is displayed.

Title of signal	Positional command ON/OFF output				Related control mode	P	S	T	F
Symbol	P-CMD	Default assignment	—	I/F circuit	SO	3-32 page			
• Turns on output transistor with positional command applied.									

Title of signal	Speed in-limit output			Related control mode	P	S	T	F
Symbol	V-LIMIT	Default assignment	—	I/F circuit	SO	3-32 page		
• Turns on output transistor when the speed is limited by torque controlling function.								

Title of signal	Alarm attribute output			Related control mode	P	S	T	F
Symbol	ALM-ATB	Default assignment	—	I/F circuit	SO	3-32 page		
• Turns on output transistor when an alarm that can be cleared generates.								

4. Inputs and outputs on connector X4

Output Signal and Pin No.

Title of signal	Speed command ON/OFF output				Related control mode	P	S	T	F
Symbol	V-CMD	Default assignment	—	I/F circuit	SO	3-32 page			
<ul style="list-style-type: none">• Turns on output transistor when the speed command is applied while the speed is controlled.									

Output Signals (Pulse Train) and Their Functions



Pin No.	21	Title of signal	A-phase output	Related control mode	P	S	T	F
	22	Symbol	Pin No.21: OA+ Pin No.22: OA-	I/F circuit	PO1 3-32 page			
Pin No.	48	Title of signal	B-phase output	Related control mode	P	S	T	F
	49	Symbol	Pin No.48: OB+ Pin No.49: OB-	I/F circuit	PO1 3-32 page			
Pin No.	23	Title of signal	Z-phase output	Related control mode	P	S	T	F
	24	Symbol	Pin No.23: OZ+ Pin No.24: OZ-	I/F circuit	PO1 3-32 page			
<ul style="list-style-type: none">• Feeds out the divided encoder signal or feedback scale signal (A, B, Z-phase) in differential. (equivalent to RS422)• Ground for line driver of output circuit is connected to signal ground (GND) and is not insulated.• Max. output frequency is 4Mpps (after quadrupled)								

Pin No.	19	Title of signal	Z-phase output	Related control mode	P	S	T	F
		Symbol	CZ	I/F circuit	PO2	3-33 page		
<ul style="list-style-type: none">• Open collector output of Z-phase signal• The emitter side of the transistor of the output circuit is connected to the signal ground (GND) and is not insulated.• When using the CZ signal, isolate it from external noise.• Note that the logic of Z phase open collector output (CZ) is a reversal of the line driver output (OZ) logic.								

Note

When the output source is the encoder

- If the encoder resolution $\times \frac{\text{Pr0.11}}{\text{Pr5.03}}$ is multiple of 4, Z-phase will be fed out synchronizing with A-phase. In other case, the Z-phase width will be equal to the encoder resolution, and will not synchronize with A-phase because of narrower width than that of A-phase.



- In case of the 5-wire, 20-bit incremental encoder, the signal sequence might not follow the above fig. until the first Z-phase is fed out. When you use the pulse output as the control signal, rotate the motor one revolution or more to make sure that the Z-phase is fed out at least once before using.

4. Inputs and outputs on connector X4

Output Signal and Pin No.

Output Signals (Analog) and Their Functions

Pin No.	42	Title of signal	Torque monitor output	Related control mode	P	S	T	F
		Symbol	IM	I/F circuit	AO	3-33 page		
<ul style="list-style-type: none">• Definition of the output signal varies with the output of Pr4.18 (analog monitor 2 type).• The output signal is identical to the analog monitor 2 on the front monitor.• For output setting, refer to P.4-36 “Details of parameter”								

Pin No.	43	Title of signal	Speed monitor output	Related control mode	P	S	T	F
		Symbol	SP	I/F circuit	AO	3-33 page		
<ul style="list-style-type: none">• Definition of the output signal varies with the output of Pr4.16 (analog monitor 1 type).• The output signal is identical to the analog monitor 1 on the front monitor.• For output setting, refer to P.4-36 “Details of parameter”								

Output Signals (Others) and Their Functions

Pin No.	13, 15	Title of signal	Signal ground	Related control mode	P	S	T	F
	17, 25	Symbol	GND	I/F circuit	—			
<div>• Signal ground</div> <div>• This output is insulated from the control signal power (COM–) inside of the driver.</div>								

Pin No.	50	Title of signal	Frame ground	Related control mode	P	S	T	F
		Symbol	FG	I/F circuit	—			
• This output is connected to the earth terminal inside of the driver.								

Control Input Settings

Title of signal	Connector X4 Pin No.	Parameter No.
SI1 input selection	8	Pr4.00
SI2 input selection	9	Pr4.01
SI3 input selection	26	Pr4.02
SI4 input selection	27	Pr4.03
SI5 input selection	28	Pr4.04
SI6 input selection	29	Pr4.05
SI7 input selection	30	Pr4.06
SI8 input selection	31	Pr4.07
SI9 input selection	32	Pr4.08
SI10 input selection	33	Pr4.09

These parameters shall be set by using hexadecimal numbers. Setting shall be made for each control mode as shown in examples below.

00 ———▲▲ h: Position/Full-closed control

00 — * * — h: Speed control

00 ■■ ——— h: Torque control

Set an appropriate function number in place of “■■”, “* *” and “▲▲”. For the function number, see the table on the below.

Title	Symbol	Setup value	
		a-contact	b-contact
Invalid	—	00h	Do not setup.
Positive direction over-travel inhibition input	POT	01h	81h
Negative direction over-travel inhibition input	NOT	02h	82h
Servo-ON input *1	SRV-ON	03h	83h
Alarm clear input	A-CLR	04h	Do not setup.
Control mode switching input *2	C-MODE	05h	85h
Gain switching input	GAIN	06h	86h
Deviation counter clear input *3	CL	07h	Do not setup.
Command pulse inhibition input *4	INH	08h	88h
Torque limit switching input	TL-SEL	09h	89h
Damping control switching input 1	VS-SEL1	0Ah	8Ah
Damping control switching input 2	VS-SEL2	0Bh	8Bh
Electronic gear switching input 1	DIV1	0Ch	8Ch
Electronic gear switching input 2	DIV2	0Dh	8Dh
Selection 1 input of internal command speed	INTSPD1	0Eh	8Eh
Selection 2 input of internal command speed	INTSPD2	0Fh	8Fh
Selection 3 input of internal command speed	INTSPD3	10h	90h
Speed zero clamp input	ZEROSPD	11h	91h
Speed command sign input	VC-SIGN	12h	92h
Torque command sign input	TC-SIGN	13h	93h
Forced alarm input	E-STOP	14h	94h
Inertia ratio switching input	J-SEL	15h	95h

(e.g. 1) Parameter setting

00 82 82 82 h (Hexadecimal numbers)

↑ Position/ Full-closed Control (Negative direction over-travel inhibition input; b-contact)
 ↑ Velocity Control (Negative direction over-travel inhibition input; b-contact)
 ↑ Torque Control (Negative direction over-travel inhibition input; b-contact)

↓ Convert to a decimal number

8553090 ← Enter this value to the relevant parameter.

(e.g. 2) Parameter setting

00 ■■ ** ▲▲ h (Hexadecimal numbers)


↑ Position/ Full-closed Control (Damping control switching input 1; a-contact)
 ↑ Velocity Control (Speed zero clamp input; b-contact)
 ↑ Torque Control (Speed zero clamp input; b-contact)

↓ Convert to a decimal number

← Enter this value to the relevant parameter.

5. IF Monitor Settings

How to Assign Various I/O Functions to the I/F



The front panel display is in decimal (six digits). For setting functions and parameters, hexadecimal and decimal numbers should be used respectively.

The expression of “00 ■■ ** ▲▲ h” indicates that the number is hexadecimal.

The SI1 input (connector X4, pin No. 8) means that the negative direction over-travel inhibition input is set to b-contact as a factory default.

For using the device in the position or full-closed control mode, the negative direction over-travel inhibition input is set to b-contact by setting “8” and “2” in the seventh and eighth digits from the left respectively. The settings in the first to sixth digits from the left do not matter.

For the hexadecimal value “00000082h” or simply “82h”, enter “130” (decimal) to the parameter Pr4.00.

To make multiple settings, enter the function number in the first eight digits from the left and then enter a parameter in a decimal number after converting it from a hexadecimal number.

An example of this is shown in example 1 (the case on the left side).

Similarly, the SI3 input (connector X4, pin No. 26) has a function of damping control switching input 1 as a default when used in the position control mode.

Also, if the speed control is used, it is set to the function of speed zero clamp input.

Therefore, in order to set it to the damping control switching input in the position control mode, enter the value of “10” (decimal) in the parameter Pr4.02 meaning the hexadecimal number “0Ah”, or “Ah”.

To change the speed zero clamp of pin No. 26 from b-contact to a-contact in the speed control mode, enter the decimal number of “4352” in the parameter Pr4.02 meaning the hexadecimal number of “00001100h”, or “1100h”.

Caution

- Do not setup to a value other than that specified in the table.
- Do not assign specific function to 2 or more signals. Duplicated assignment will cause Err33.0 I/F input multiple assignment error 1 or Err33.1 I/F input multiple assignment error 2.
- *1 Servo-on input signal (SRV-ON) must be used to enable servo-on.
- *2 When using control mode switching input (C-MODE), set the signal to all control modes. If the signal is set to only 1 or 2 control modes, Err33.2 I/F input function number error 1 or Err33.3 I/F input function number error 2 will be generated.
 - The control input pin set to invalid state does not affect any operation.
 - Function (servo-on input, alarm clear, etc.) to be used in multiple control modes must be assigned to the same pin with correct logical arrangement. Incorrect setting will cause Err33.0 I/F input multiple assignment error 1 or Err33.1 I/F input multiple assignment error 2.
- *3 Deviation counter clear input (CL) can be assigned only to SI7 input. Wrong assignment will cause Err33.6 Counter clear assignment error.
- *4 Command pulse inhibit input (INH) can be assigned only to SI10 input. Wrong assignment will cause Err33.7 Command pulse input inhibit input.

Note

- Input circuit, refer to P.3-30 and function, refer to P.3-37 to P.3-42.

Related page P.4-33, P.4-34

5. IF Monitor Settings

How to Assign Various I/O Functions to the I/F

Control Output Settings

Title of signal	Connector X4 Pin No.	Parameter No.
SO1 input	10, 11	Pr4.10
SO2 input	34, 35	Pr4.11
SO3 input	36, 37	Pr4.12
SO4 input	38, 39	Pr4.13
SO5 input	12	Pr4.14
SO6 input	40	Pr4.15

These parameters shall be set by using hexadecimal numbers. Setting shall be made for each control mode as shown in examples below.

00 ———▲▲ h: Position/Full-closed control

00 — * * — h: Speed control

00 ■■ ——— h: Torque control

Set an appropriate function number in place of “■■”, “* *” and “▲▲”. For the function number, see the table on the right.

Setup value	Title	Symbol
00h	Invalid	—
02h	Servo-Ready output	S-RDY
03h	External brake release signal	BRK-OFF
04h	Positioning complete output	INP
05h	At-speed output	AT-SPPED
06h	Torque in-limit signal output	TLC
07h	Zero-speed detection output signal	ZSP
08h	Speed coincidence output	V-COIN
09h	Alarm output 1	WARN1
0Ah	Alarm output 2	WARN2
0Bh	Positional command ON/OFF output	P-CMD
0Ch	Positioning complete 2	INP2
0Dh	Speed in-limit output	V-LIMIT
0Eh	Alarm attribute output	ALM-ATB
0Fh	Speed command ON/OFF output	V-CMD

(e.g. 1) Parameter setting

00 03 03 03 h (Hexadecimal numbers)

↑ ↑ ↑
Position/ Full-closed Control (External brake release signal)
Velocity Control (External brake release signal)
Torque Control (External brake release signal)

↓ Convert to a decimal number

197379 ← Enter this value to the relevant parameter.

(e.g. 2) Parameter setting

00 05 05 04 h (Hexadecimal numbers)

↑ ↑ ↑
Position/ Full-closed Control (Positioning complete)
Velocity Control (Speed arrival output)
Torque Control (Speed zero clamp input; b-contact)

↓ Convert to a decimal number

328964 ← Enter this value to the relevant parameter.

- Same function can be assigned to 2 or more output signals.
- Control output pin set to invalid always has the output transistor turned OFF.
- Do not change the setup value shown in the table.

Caution

*1 Note that the setup values are displayed in decimal on the front panel.

Note

• Input circuit, refer to P.3-32 and function, refer to P.3-45 to P.3-48.

Related page P.4-35

4. Setup

5. Details of parameter

List of Parameters	4-2
[Class 0] Basic setting	4-4
[Class 1] Gain adjustment	4-13
[Class 2] Damping control	4-20
[Class 3] Velocity/ Torque/ Full-closed control	4-25
[Class 4] I/F monitor setting	4-33
[Class 5] Enhancing setting	4-43
[Class 6] Special setting	4-52

2.Trial Run (JOG run)

Inspection Before Trial Run	4-59
Trial Run by Connecting the Connector X4	4-60
Setup of Motor Rotational Speed and Input Pulse Frequency	4-63

1. Details of parameter

List of Parameters

- A parameter is designated as follows:

Class Pr0.00 Parameter No.

- Definition of symbols under “Related mode” -

P: position control, S: velocity control,
T: torque control, F: full closed control

Parametr No.	Title		Related Control Mode				Detail page
Class No.			P	S	T	F	
[Class 0] Basic setting	00	Rotational direction setup	○	○	○	○	4-4
	01	Control mode setup	○	○	○	○	
	02	Real-time setup	○	○	○	○	4-5
	03	auto-gain tuning Selection of machine stiffness	○	○	○	○	
	04	Inertia ratio	○	○	○	○	4-6
	05	Command pulse input selection	○	—	—	○	4-7
	06		○	—	—	○	
	07		○	—	—	○	
	08	Command pulse counts per one motor revolution	○	—	—	—	4-8
	09	1st numerator of electronic gear	○	—	—	○	
	10	Denominator of electronic gear	○	—	—	○	
	11	Output pulse counts per one motor revolution	○	○	○	○	4-9
	12	Reversal of pulse output logic	○	○	○	○	4-11
	13	1st torque limit	○	○	○	○	
	14	Position deviation excess setup	○	—	—	○	
	15	Absolute encoder setup	○	—	—	○	4-12
	16	External regenerative resistor setup	○	○	○	○	
	17	Load factor of external regenerative resistor selection	○	○	○	○	

[Class 1] Gain adjustment	00	gain of position loop	○	—	—	○	4-13
	01	gain of velocity loop	○	○	○	○	
	02	1st time constant of velocity loop integration	○	○	○	○	
	03	filter of speed detection	○	○	○	○	
	04	time constant of torque filter	○	○	○	○	4-14
	05	gain of position loop	○	—	—	○	
	06	gain of velocity loop	○	○	○	○	
	07	2nd time constant of velocity loop integration	○	○	○	○	
	08	filter of speed detection	○	○	○	○	
	09	time constant of torque filter	○	○	○	○	4-15
	10	Velocity feed forward gain	○	—	—	○	
	11		○	—	—	○	
	12	Torque feed forward gain	○	○	—	○	
	13		○	○	—	○	4-16
	14	2nd gain setup	○	○	○	○	
	15	Position control switching mode	○	—	—	○	4-17
	16		○	—	—	○	
	17		○	—	—	○	4-18
	18	hysteresis	○	—	—	○	
	19	Position gain switching time	○	—	—	○	4-19
	20	Velocity control switching mode	—	○	—	—	
	21		—	○	—	—	
	22		—	○	—	—	
	23	hysteresis	—	○	—	—	4-30
	24	Torque control switching mode	—	—	○	—	
	25		—	—	○	—	
	26		—	—	○	—	
	27	hysteresis	—	—	○	—	

Parametr No.	Title		Related Control Mode				Detail page
Class No.			P	S	T	F	
[Class 2] Damping control	00	Adaptive filter mode setup	○	○	—	○	4-20
	01	frequency	○	○	○	○	
	02	1st notch width selection	○	○	○	○	
	03	depth selection	○	○	○	○	
	04	frequency	○	○	○	○	4-21
	05	2nd notch width selection	○	○	○	○	
	06	depth selection	○	○	○	○	
	07	frequency	○	○	○	○	
	08	3rd notch width selection	○	○	○	○	4-22
	09	depth selection	○	○	○	○	
	10	frequency	○	○	○	○	
	11	4th notch width selection	○	○	○	○	
	12	depth selection	○	○	○	○	4-23
	13	Selection of damping filter switching	○	—	—	○	
	14	1st damping frequency	○	—	—	○	
	15	filter setup	○	—	—	○	
	16	2nd damping frequency	○	—	—	○	4-22
	17	filter setup	○	—	—	○	4-23
	18	3rd damping frequency	○	—	—	○	4-22
	19	filter setup	○	—	—	○	4-23
	20	4th damping frequency	○	—	—	○	4-22
	21	filter setup	○	—	—	○	4-23
	22	Positional smoothing filter	○	—	—	○	4-23
	23	FIR filter	○	—	—	○	4-24

[Class 3] Velocity/ Torque/ Full-closed control	00	Speed setup, Internal/External switching	—	○	—	—	4-25
	01	Speed command rotational direction selection	—	○	—	—	
	02		—	○	○	—	4-26
	03	input gain	—	○	—	—	
	04	Speed setup reversal input	—	○	—	—	4-27
	05		—	○	—	—	
	06		—	○	—	—	
	07		—	○	—	—	
	08		—	○	—	—	
	09		—	○	—	—	
	10		—	○	—	—	
	11		—	○	—	—	
	12	Time setup acceleration	—	○	—	—	4-28
	13		—	○	—	—	
	14	Sigmoid acceleration/ deceleration time setup	—	○	—	—	4-29
	15	Speed function selection	—	○	○	—	
	16	zero-clamp level	—	○	○	—	4-30
	17	selection	—	—	○	—	
	18	Torque command direction selection	—	—	○	—	
	19		—	—	○	—	
	20		—	—	○	—	4-31
	21	Speed limit value 1	—	—	○	—	
	22		—	—	○	—	
	23	External scale selection	—	—	—	○	
	24		—	—	—	○	
	25		—	—	—	○	
	26		—	—	—	○	4-32
	27	Z phase disconnection detection disable	—	—	—	○	
	28	Hybrid excess setup	—	—	—	○	
	29	deviation clear setup	—	—	—	○	

Note

- Only for position control type is not provided with X2 (Communication connector), X3 (Safety function connector), X5 (External scale connector) and analog input.

1. Details of parameter

List of Parameters

Parameter No.		Title		Related Control Mode				Detail page	
Class	No.			P	S	T	F		
[Class 4] I/F monitor setting	00	Input selection	SI1 (Pin No.8)	○	○	○	○	4-33	
	01		SI2 (Pin No.9)	○	○	○	○	4-34	
	02		SI3 (Pin No.26)	○	○	○	○		
	03		SI4 (Pin No.27)	○	○	○	○		
	04		SI5 (Pin No.28)	○	○	○	○		
	05		SI6 (Pin No.29)	○	○	○	○		
	06		SI7 (Pin No.30)	○	○	○	○		
	07		SI8 (Pin No.31)	○	○	○	○		
	08		SI9 (Pin No.32)	○	○	○	○		
	09		SI10 (Pin No.33)	○	○	○	○		
	10	Output selection	SO1 (Pin No.10, 11 Line driver output)	○	○	○	○	4-35	
	11		SO2 (Pin No.34, 35 Line driver output)	○	○	○	○		
	12		SO3 (Pin No.36, 37 Line driver output)	○	○	○	○		
	13		SO4 (Pin No.38, 39 Line driver output)	○	○	○	○		
	14		SO5 (Pin No.12 Open collector output)	○	○	○	○		
	15		SO6 (Pin No.40 Open collector output)	○	○	○	○		
	16	Analog monitor 1	type	○	○	○	○	4-36	
	17		output gain	○	○	○	○		
	18	Analog monitor 2	type	○	○	○	○		
	19		output gain	○	○	○	○		
	20	Type of digital monitor			○	○	○	○	4-38
	21	Analog monitor output setup			○	○	○	○	
	22	Analog input 1 (AI1)	offset setup	○	○	○	○		
	23		filter	○	○	○	○		
	24		overvoltage setup	○	○	○	○		
	25	Analog input 2 (AI2)	offset setup	○	○	○	○		
	26		filter	○	○	○	○		
	27		overvoltage setup	○	○	○	○		
	28	Analog input 3 (AI3)	offset setup	○	○	○	○		
	29		filter	○	○	○	○		
	30		overvoltage setup	○	○	○	○		
	31	Positioning complete (In-position)	range	○	—	—	○	4-39	
	32		output setup	○	—	—	○		
	33	INP hold time			○	—	—	○	4-40
	34	Zero-speed			○	○	○	○	
	35	Speed coincidence range			—	○	○	—	
	36	At-speed (Speed arrival)			—	○	○	—	
	37	Mechanical brake action	at stalling setup	○	○	○	○	4-41	
	38		at running setup	○	○	○	○		
	39	Mechanical brake action at running setup			○	○	○	○	4-42
	40	Selection of alarm output	1	○	○	○	○		
	41		2	○	○	○	○		
42	2nd Positioning complete (In-position) range			○	—	—	○		
[Class 5] Enhancing setting	00	2nd	numerator of electronic gear	○	—	—	○	4-43	
	01	3rd		○	—	—	○		
	02	4th		○	—	—	○		
	03	Denominator of pulse output division			○	○	○	○	4-44
	04	Over-travel inhibit input setup			○	○	○	○	
	05	Sequence at over-travel inhibit			○	○	○	○	
	06	Sequence at Servo-Off			○	○	○	○	
	07	main power OFF	sequence	○	○	○	○	4-45	
	08		LV trip selection	○	○	○	○		
	09		detection time	○	○	○	○		
	10	Sequence at alarm			○	○	○	○	4-46
	11	Torque setup for emergency stop			○	○	○	○	
	12	Over-load level setup			○	○	○	○	
13	Over-speed level setup			○	○	○	○		

Parametr No.		Title		Related Control Mode				Detail page
Class	No.			P	S	T	F	
[Class 5] Enhancing setting	14	Motor working range setup		○	—	—	○	4-46
	15	I/F reading filter		○	○	○	○	
	16	Alarm clear input setup		○	○	○	○	4-47
	17	Counter clear input mode		○	—	—	○	
	18	Command pulse	Invalidation	○	—	—	○	
	19	inhibit input	reading setup	○	—	—	○	
	20	Position setup unit select		○	—	—	○	4-48
	21	Selection of torque limit		○	○	—	○	
	22	2nd torque limit		○	○	—	○	
	23	Torque limit switching	1	○	○	—	○	
	24	setup	2	○	○	—	○	4-49
	25	External input	positive direction torque limit	○	○	—	○	
	26		negative direction torque limit	○	○	—	○	
	27	Input gain of analog torque limit		○	○	—	○	
	28	LED initial status		○	○	○	○	
	29	RS232	baud rate setup	○	○	○	○	
	30	RS485		○	○	○	○	
	31	Axis address		○	○	○	○	4-51
	32	Command pulse input maximum setup		○	—	—	○	
	33	Pulse regenerative output limit setup		○	○	○	○	
	34	For manufacturer's use						
	35	Front panel lock setup		○	○	○	○	

[Class 6] Special setting	00	Analog torque feed forward conversion gain		○	○	—	○	4-52
	02	Velocity deviation excess setup		○	—	—	—	
	04	JOG trial run command speed		○	○	○	○	
	05	Position 3rd gain	valid time	○	—	—	○	
	06		scale factor	○	—	—	○	
	07	Torque command additional value		○	○	—	○	4-53
	08	Positive direction	torque compensation value	○	—	—	○	
	09	Negative direction		○	—	—	○	
	10	Function expansion setup		○	○	○	○	
	11	Current response setup		○	○	○	○	
	13	2nd Inertia ratio		○	○	○	○	
	14	Emergency stop time at alarm		○	○	○	○	
	15	2nd over-speed level setup		○	○	○	○	4-55
	17	Front panel parameter writing selection		○	○	○	○	
	18	Power-up wait time		○	○	○	○	
	19	Encoder Z phase setup		—	—	—	○	
	20	Z-phase setup of external scale		—	—	—	○	4-56
	21	Serial absolute external scale Z phase setup		—	—	—	○	
	22	A, B phase external scale pulse output method selection		—	—	—	○	
	23	Disturbance torque compensating gain		○	○	—	—	
	24	Disturbance observer filter		○	○	—	—	4-57
	27	Alarm latch time selection		○	○	○	○	
	31	Real time auto tuning	estimation speed	○	○	○	○	
	32		custom setup	○	○	○	○	
	34	Hybrid vibration suppression	gain	—	—	—	○	4-58
	35		filter	—	—	—	○	
	37	Oscillation detection level		○	○	○	○	
	38	Alarm mask setup		○	○	○	○	
	39	For manufacturer's use						

1. Details of parameter

[Class 0] Basic setting

Default: []

Pr0.00 *

Rotational direction setup

Range

0 to 1

Unit

—

Default

1


Related control mode

P S T F

Setup the relationship between the direction of command and direction of motor rotation.

0: Motor turns CW in response to positive direction command (CW when viewed from load side shaft end)

1: Motor turns CCW in response to positive direction command (CCW when viewed from load side shaft end)



Setup value	Command direction	Motor rotational direction	Positive direction drive inhibit input	Negative direction drive inhibit input
0	Positive direction	CW	Valid	—
	Negative direction	CCW	—	Valid
[1]	Positive direction	CCW	Valid	—
	Negative direction	CW	—	Valid

Pr0.01 *

Control mode setup

Range

0 to 6

Unit

—

Default

0


Related control mode

P S T F

You can set up the control mode to be used.

Setup value	Content	
	1st mode	2nd mode
[0]	Position	—
1	Velocity	—
2	Torque	—
3 *1	Position	Velocity
4 *1	Position	Torque
5 *1	Velocity	Torque
6	Full-closed	—

*1) When you set up the combination mode of 3, 4 or 5, you can select either the 1st or the 2nd with control mode switching input (C-MODE). When C-MODE is open, the 1st mode will be selected. When C-MODE is shorted, the 2nd mode will be selected. Don't enter commands 10ms before/after switching.



The waveform above shows when logical setting of C-MODE input is a-c-contact. When b-contact is used, open and short is reversed.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.
- Only for position control type is not provided with X2 (Communication connector), X3 (Safety function connector), X5 (External scale connector) and analog input.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 0] Basic setting

Default: []

Pr0.02	Real-time auto-gain tuning setup	Range	Unit	Default	Related control mode			
		0 to 6	—	1	P	S	T	F

You can set up the action mode of the real-time auto-gain tuning.

Setup value	Mode	Varying degree of load inertia in motion
0	Invalid	Real-time auto-gain tuning function is disabled.
[1]	Standard	Basic mode. Do not use unbalanced load, friction compensation or gain switching.
2	Positioning ^{*1}	Main application is positioning. It is recommended to use this mode on equipment without unbalanced horizontal axis, ball screw driving equipment with low friction, etc.
3	Vertical axis ^{*2}	With additional features to the positioning mode - use this mode to positively and effectively compensate for unbalanced load to the vertical axis or minimize variations in setting time.
4	Friction compensation ^{*3}	With additional features to the vertical axis mode - use this mode to positively and effectively reduce positioning setting time when the belt driving axis has high friction.
5	Load characteristic measurement	Estimate the load characteristics without changing current parameter setting. This mode requires use of the setup support software.
6	Customize ^{*4}	Functions of real-time auto-gain tuning can be customized to meet the requirements of the specific application by combining desired functions according to the Pr6.32 "Real-time auto-gain tuning custom setting".

*1 Velocity and torque controls are the same as in the standard mode.
 *2 Torque control is the same as in the standard mode.
 *3 Velocity control is the same as in the vertical axis mode. Torque control is the same as in the standard mode.
 *4 Certain function(s) is not available in a specific control mode. Refer to description in Pr6.32.

Pr0.03	Selection of machine stiffness at real-time auto-gain tuning	Range	Unit	Default	Related control mode			
		0 to 31	—	A,B,C-frame: 13 D to H-frame: 11	P	S	T	F

You can set up the response while the real-time auto-gain tuning is valid.

low ← machine stiffness → high

low ← servo gain → high

0, 1 ----- 11 -- 13 ----- 30, 31

low ← response → high

Caution

Higher the setup value, higher the velocity response and servo stiffness will be obtained. However, when increasing the value, check the resulting operation to avoid oscillation or vibration.

Control gain is updated while the motor is stopped. If the motor cannot be stopped due to excessively low gain or continuous application of one-way direction command, any change made to Pr0.03 “Selection of machine stiffness at real-time auto-gain tuning” is not used for update. If the changed stiffness setting is made valid after the motor stopped, abnormal sound or oscillation will be generated. To prevent this problem, stop the motor after changing the stiffness setting and check that the changed setting is enabled.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of " * ",** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... "Inputs and outputs on connector X4"

1. Details of parameter

[Class 0] Basic setting

Default: []

Pr0.04	Inertia ratio	Range	Unit	Default	Related control mode			
		0 to 10000	%	250 *	P	S	T	F

Set 1st inertia ratio.

You can set up the ratio of the load inertia against the rotor (of the motor) inertia.

$$\text{Pr0.04} = (\text{load inertia} / \text{rotor inertia}) \times 100 [\%]$$

The inertia ratio will be estimated at all time while the real-time auto-gain tuning is valid, and its result will be saved to EEPROM every 30 min.

Caution

If the inertia ratio is correctly set, the setup unit of Pr1.01 and Pr1.06 becomes (Hz). When the inertia ratio of Pr0.04 is larger than the actual, the setup unit of the velocity loop gain becomes larger, and when the inertia ratio of Pr0.04 is smaller than the actual, the setup unit of the velocity loop gain becomes smaller.

Pr0.05 *	Selection of command pulse input	Range	Unit	Default	Related control mode		
		0 to 1	—	0	P		F
You can select either the photo-coupler input or the exclusive input for line driver as the command pulse input.							
Setup value		Content					
[0]		Photo-coupler input (PULS1, PULS2, SIGN1, SIGN2)					
1		Exclusive input for line driver (PULSH1, PULSH2, SIGNH1, SIGNH2)					

Note

- Parameters which **default values have a suffix of " * "** will be automatically set up during real time auto-gain tuning. When you change manually, invalidate the real-time auto-gain tuning first then set, referring to P.5-8, "Release of Automatic Gain Adjusting Function" of Adjustment.

1. Details of parameter

[Class 0] Basic setting

Default: []

Pr0.06 *	Command pulse rotational direction setup	Range	Unit	Default	Related control mode		
		0 to 1	—	0	P		F
Pr0.07 *	Command pulse input mode setup	Range	Unit	Default	Related control mode		
		0 to 3	—	1	P		F

You can set up the rotational direction against the command pulse input, and the command pulse input format.

The table below shows combinations of Pr0.06 Command pulse rotational direction setup and Pr0.07 Command pulse input mode setup.

Pulses are counted at edges indicated by the arrows as shown in the table.

• Input format command pulse

Pr0.06 setup value (Command pulse rotational direction setup)	Pr0.07 setup value (Command pulse input mode setup)	Command pulse format	Signal title	Positive direction command	Negative direction command
[0]	0 or 2	90° phase difference 2-phase pulse (A + B-phase)	PULS SIGN	<p>B-phase advances to A by 90°.</p>	<p>B-phase delays from A by 90°.</p>
	[1]	Positive direction pulse train + Negative direction pulse train	PULS SIGN		
	3	pulse train + Signal	PULS SIGN	<p>"H"</p>	<p>"L"</p>
1	0 or 2	90° phase difference 2-phase pulse (A + B-phase)	PULS SIGN	<p>B-phase delays from A by 90°.</p>	<p>B-phase advances to A by 90°.</p>
	1	Positive direction pulse train + Negative direction pulse train	PULS SIGN		
	3	pulse train + Signal	PULS SIGN	<p>"L"</p>	<p>"H"</p>

• Permissible max. input frequency, and min. necessary time width of command pulse input signal.

Input I/F of PULS/SIGN signal		Permissible max. input frequency	Min. necessary time width (μs)					
			t1	t2	t3	t4	t5	t6
Pulse train interface exclusive to line driver		4Mpps	0.25	0.125	0.125	0.125	0.125	0.125
Pulse train interface	Line driver interface	500kpps	2	1	1	1	1	1
	Open collector interface	200kpps	5	2.5	2.5	2.5	2.5	2.5

Make the rising/falling time of the command pulse input signal to 0.1μs or smaller.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of " * ", changed contents will be validated when you turn on the control power.

Related page

- P.3-30... "Inputs and outputs on connector X4"

1. Details of parameter

[Class 0] Basic setting

Default: []

Pr0.08 *	Command pulse counts per one motor revolution	Range	Unit	Default	Related control mode		
		0 to 1048576	pulse	10000	P		
Set the command pulses that causes single turn of the motor shaft. When this setting is 0, Pr0.09 1st numerator of electronic gear and Pr0.10 Denominator of electronic gear become valid.							

Pr0.09	1st numerator of electronic gear	Range	Unit	Default	Related control mode		
		0 to 2 ³⁰	—	0	P		F
Set the numerator of division/multiplication operation made according to the command pulse input. This setup is enabled when Pr0.08 command pulse counts per one motor revolution = 0.							

Pr0.10	Denominator of electronic gear	Range	Unit	Default	Related control mode		
		1 to 2 ³⁰	—	10000	P		F
Set the Denominator of division/multiplication operation made according to the command pulse input. This setup is enabled when Pr0.08 command pulse counts per one motor revolution = 0.							

<Interrelationship between Pr0.08, Pr0.09 and Pr0.10 during Position control>

Pr0.08	Pr0.09	Pr0.10	Command division/multiplication operation
1 to 1048576	— (Not effect)	— (Not effect)	<p>Command pulse input → $\frac{\text{Encoder resolution}}{[\text{Pr0.08 setup value}]}$ → Positional command</p> <p>* Regardless of setup of Pr0.09 and Pr0.10, this operation is processed according to setup value of Pr0.08.</p>
0	0	0 to 1073741824	<p>Command pulse input → $\frac{\text{Encoder resolution}}{[\text{Pr0.10 setup value}]}$ → Positional command</p> <p>* When both Pr0.08 and Pr0.09 are set to 0, this operation is processed according to setup value of Pr0.10.</p>
	1 to 1073741824	1 to 1073741824	<p>Command pulse input → $\frac{[\text{Pr0.09 setting}]}{[\text{Pr0.10 setting}]}$ → Positional command</p> <p>* When setup value of Pr0.08 is 0, and Pr0.09 ≠ 0, this operation is processed according to setup value of Pr0.09 and Pr0.10.</p>

<Interrelationship between Pr0.08, Pr0.09 and Pr0.10 during full closed control>

Related page • P.4-63... "Setup of Motor Rotational Speed and Input Pulse Frequency"
• P.6-7, P.6-8... "Protective function (Detail of error code)"

1. Details of parameter

[Class 0] Basic setting

Default: []

Pr0.08	Pr0.09	Pr0.10	Command division/multiplication operation
(Invalid)	0	1 to 1073741824	<p>Command pulse input → $\frac{1}{1}$ → Positional command</p> <p>* If Pr0.09 is 0 during full closed controlling, the process as shown above is performed with both numerator and denominator set to 1.</p>
	1 to 1073741824	1 to 1073741824	<p>Command pulse input → $\frac{[\text{Pr0.09 setting}]}{[\text{Pr0.10 setting}]}$ → Positional command</p> <p>* When setup value of Pr0.09≠0, this operation is processed according to setup value of Pr0.09 and Pr0.10.</p>

Caution ⚠ The desired setting can be determined by selecting value of numerator and denominator of electronic gear. However, an excessively high division or multiplication ratio cannot guarantee the operation. The ratio should be in a range between 1/1000 and 1000.

Excessively high multiplication ratio will cause Err27.2 (command pulse multiplication error protection) due to varying command pulse input or noises, even if the other settings are within the specified range.

During full closed controlling, do not change command division and multiplication ratio. Otherwise, Err25.0 (Hybrid over deviation alarm) will be generated.

Pr0.11 *	Output pulse counts per one motor revolution	Range	Unit	Default	Related control mode			
		0 to 262144	P/r	2500	P	S	T	F
<p>You can set up the output pulse counts per one motor revolution for each OA and OB with the Pr0.11 setup.</p> <p>Caution ⚠ For details of setup, refer to description in Pr5.03.</p>								

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page ⚠

- P.4-63... “Setup of Motor Rotational Speed and Input Pulse Frequency”
- P.6-7, P.6-8... “Protective function (Detail of error code)”

1. Details of parameter

[Class 0] Basic setting

Default: []

Pr5.03 *	Denominator of pulse output division	Range	Unit	Default	Related control mode			
		0 to 262144	—	0	P	S	T	F

For an application where the number of output pulses per one motor revolution is not an integer, set this parameter to a value other than 0; and the dividing ratio can be set by using Pr0.11 as the numerator and Pr5.03 as the denominator.

Output pulse counts per one revolution

$$= (\text{Pr0.11 setup value} / \text{Pr5.03 setup value}) \times \text{Encoder resolution} \times \frac{1}{4}$$

<Combination of Pr0.11 Output pulse counts per one motor revolution and Pr5.03 Denominator of pulse output division>

Pr0.11	Pr5.03	Pulse reproducing process
1 to 262144	[0]	<p>When the output source is encoder</p> <p>* When Pr5.03 = 0, the above process is made according to Pr0.11 setup value. The number of pulses of reproduced pulse output OA and OB are the number of pulses set in Pr0.11. The resolution of pulse output per one revolution is equal to or less the encoder resolution.</p> <p>When the output source is external scale</p> <p>* Division ratio is 1:1.</p>
	1 to 262144	<p>Encoder feedback pulse or external scale pulse [pulse] → [Pr0.11 setup value] [Pr5.03 setup value] → Output pulse [pulse]</p> <p>* If Pr5.03 is not equal to 0, then the above process is performed based on setup value of Pr0.11 and Pr5.03.</p> <p>When the output source is encoder The number of reproduced pulses (OA, OB) per one motor revolution is not an integer. Note that when the number of pulses per one motor revolution is not an integer, Z-phase output is not synchronized with that of A-phase, reducing pulse width. The pulse output resolution per one revolution cannot become higher than the encoder resolution.</p>

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.
- P.2-82... “Setup of Torque Limit” • P.3-30... “Inputs and outputs on connector X4”
- P.6-3... “Protective Function”

Related page

1. Details of parameter

[Class 0] Basic setting

Default: []

Pr0.12 *	Reversal of pulse output logic	Range	Unit	Default	Related control mode			
		0 to 3	—	0	P	S	T	F

You can set up the B-phase logic and the output source of the pulse output. With this parameter, you can reverse the phase relation between the A-phase pulse and the B-phase pulse by reversing the B-phase logic. Encoder or external scale can be selected as the output source for full-closed control. The encoder is selected as the source if not for full-closed control.

<Reversal of pulse output logic>

Pr0.12	B-phase logic	Output source	CCW direction rotation	CW direction rotation
[0]	Non-reversal	Encoder	A-phase	A-phase
2		External scale	B-phase	B-phase
1	Reversal	Encoder	A-phase	A-phase
3		External scale	B-phase	B-phase

Caution

Setup value 2 and 3 are valid only for full-closed control. Setting must be 0 or 1 if not for full-closed control.

The selection of the output source of Z-phase is held concurrently.

Setup value 0 and 1 are Z-phase output of encoder.

Setup value 2 and 3 are Z-phase output of external scale.

Pr0.13	1st torque limit	Range	Unit	Default	Related control mode			
		0 to 500	%	500	P	S	T	F
<p>You can set up the limit value of the motor output torque.</p> <div><div>Note</div><div>For details of torque limit value, refer to P.2-82.</div></div>								

Pr0.14	Position deviation excess setup	Range	Unit	Default	Related control mode			
		0 to 134,217,728	Command unit	100000	P			F
<ul style="list-style-type: none">• Set excess range of positional deviation by the command unit (default).• Setup unit can be changed to encoder unit through Pr5.20 (position setup unit selection). If the unit is changed, set up with the encoder pulse counts at the position control and with the external scale pulse counts at the full-closed control.• Err24.0 (Error detection of position deviation excess) becomes invalid when you set up this to 0.								
<div>Note</div> <p>For description of “command unit” and “encoder unit”, refer to P.4-48 “Pr5.20”.</p>								

Pr0.15 *	Absolute encoder setup	Range	Unit	Default	Related control mode		
		0 to 2	—	1	P		F
You can set up the using method of 17-bit absolute encoder.							
Setup value		Function					
0		Use as an absolute encoder.					
[1]		Use as an incremental encoder.					
2		Use as an absolute encoder, but ignore the multi-turn counter over.					

Caution

This parameter will be invalidated when 5-wire, 20-bit incremental encoder is used.

1. Details of parameter

[Class 0] Basic setting

Default: []

Pr0.16 *	External regenerative resistor setup	Range	Unit	Default	Related control mode			
		0 to 3	—	A,B,G,H-frame: 3 C,D,E,F-frame: 0	P	S	T	F

With this parameter, you can select either to use the built-in regenerative resistor of the driver, or to separate this built-in regenerative resistor and externally install the regenerative resistor (between B1 and B2 of Connector XB in case of A to D-frame, between B1 and B2 of Connector XC in case of D-frame(400V) and E-frame, between B1 and B2 of terminal block in case of F to H-frame).

A, B, G and H-frame driver is not provided with built-in resistor.

Setup value	Regenerative resistor to be used	Function
[0] (C to F-frame)	Built-in resistor	Regenerative processing circuit will be activated and regenerative resistor overload protection will be triggered according to the built-in resistor (approx. 1% duty).
1	External resistor	The driver trips due to regenerative overload protection (Err18.0), when regenerative processing circuit is activated and its active ratio exceeds 10%.
2	External resistor	Regenerative processing circuit is activated, but no regenerative over-load protection is triggered.
[3] (A, B, G, H-frame)	No resistor	Both regenerative processing circuit and regenerative protection are not activated, and built-in capacitor handles all regenerative power.

Remarks ❖

Install an external protection such as thermal fuse when you use the external regenerative resistor.

Otherwise, the regenerative resistor might be heated up abnormally and result in burnout, regardless of validation or invalidation of regenerative over-load protection.

Caution ❖

When you use the built-in regenerative resistor, never to set up other value than 0. Don't touch the external regenerative resistor.

External regenerative resistor gets very hot, and might cause burning.

Pr0.17 *	Load factor of external regenerative resistor selection	Range	Unit	Default	Related control mode			
		0 to 4	—	0	P	S	T	F
When selecting the external regenerative resistor (Pr0.16 = 1, 2), select the computing method of load factor of regenerative resistor.								
Setup value		Function						
[0]		Regenerative load factor is 100% when duty factor of external regenerative resistor is 10%.						
1 to 4		For manufacturer's use (do not setup)						

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.

Related page

- P.2-12... “System Configuration and Wiring”
- P.3-30... “Inputs and outputs on connector X4”

Pr1.00	1st gain of position loop	Range	Unit	Default	Related control mode			
		0 to 30000	0.1/s	A,B,C-frame: 480 D to H-frame: 320	P			F

You can determine the response of the positional control system.
Higher the gain of position loop you set, faster the positioning time you can obtain.
Note that too high setup may cause oscillation.

Pr1.01	1st gain of velocity loop	Range	Unit	Default	Related control mode			
		1 to 32767	0.1Hz	A,B,C-frame: 270 D to H-frame: 180	P	S	T	F

You can determine the response of the velocity loop.
In order to increase the response of overall servo system by setting high position loop gain, you need higher setup of this velocity loop gain as well. However, too high setup may cause oscillation.

Caution When the inertia ratio of Pr0.04 is set correctly, the setup unit of Pr1.01 becomes (Hz).

Pr1.02	1st time constant of velocity loop integration	Range	Unit	Default	Related control mode			
		1 to 10000	0.1ms	A,B,C-frame: 210 D to H-frame: 310	P	S	T	F

You can set up the integration time constant of velocity loop.
Smaller the setup, faster you can dog-in deviation at stall to 0.
The integration will be maintained by setting to "9999".
The integration effect will be lost by setting to "10000".

Pr1.03	1st filter of speed detection	Range	Unit	Default	Related control mode			
		0 to 5	—	0	P	S	T	F

You can set up the time constant of the low pass filter (LPF) after the speed detection, in 6 steps.
Higher the setup, larger the time constant you can obtain so that you can decrease the motor noise, however, response becomes slow. Use with a default value of 0 in normal operation.

Pr1.04	1st time constant of torque filter	Range	Unit	Default	Related control mode			
		0 to 2500	0.01ms	A,B,C-frame: 84 D to H-frame: 126	P	S	T	F

You can set up the time constant of the 1st delay filter inserted in the torque command portion. You might expect suppression of oscillation caused by distortion resonance.

Caution

• To Panasonic MINAS users: A4 and higher series
CAUTION: Parameter settings shown in this manual may differ from those applied to your product (s).

Note

• **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

• P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 1] Gain adjustment

Default: []


Pr1.05	2nd gain of position loop	Range	Unit	Default	Related control mode			
		0 to 30000	0.1/s	A,B,C-frame: 570 D to H-frame: 380	P			F
Pr1.06	2nd gain of velocity loop	Range	Unit	Default	Related control mode			
		1 to 32767	0.1Hz	A,B,C-frame: 270 D to H-frame: 180	P	S	T	F
Pr1.07	2nd time constant of velocity loop integration	Range	Unit	Default	Related control mode			
		1 to 10000	0.1ms	10000	P	S	T	F
Pr1.08	2nd filter of speed detection	Range	Unit	Default	Related control mode			
		0 to 5	—	0	P	S	T	F
Pr1.09	2nd time constant of torque filter	Range	Unit	Default	Related control mode			
		0 to 2500	0.01ms	A,B,C-frame: 84 D to H-frame: 126	P	S	T	F
<p>Position loop, velocity loop, speed detection filter and torque command filter have their 2 pairs of gain or time constant (1st and 2nd).</p> <div>Related page</div> <p>For details of switching the 1st and the 2nd gain or the time constant, refer to P.5-17 "Gain Switching Function" of Adjustment.</p> <p>The function and the content of each parameter is as same as that of the 1st gain and time constant.</p>								

Pr1.10	Velocity feed forward gain	Range	Unit	Default	Related control mode		
		0 to 1000	0.10%	300	P		F
Multiply the velocity control command calculated according to the internal positional command by the ratio of this parameter and add the result to the speed command resulting from the positional control process.							

Pr1.11	Velocity feed forward filter	Range	Unit	Default	Related control mode		
		0 to 6400	0.01ms	50	P		F
<p>Set the time constant of 1st delay filter which affects the input of velocity feed forward.</p> <p><Usage example of velocity feed forward></p> <p>The velocity feed forward will become effective as the velocity feed forward gain is gradually increased with the velocity feed forward filter set at approx. 50 (0.5 ms). The positional deviation during operation at a constant velocity is reduced as shown in the equation below in proportion to the value of velocity feed forward gain.</p> <div><p>Positional deviation [unit of command] = command speed [unit of command/s] / positional loop gain [1/s] × (100 - velocity feed forward gain [%]) / 100</p></div>							

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.
- P.3-30... “Inputs and outputs on connector X4”

 Related page

1. Details of parameter

[Class 1] Gain adjustment

Default: []

Pr1.12	Torque feed forward gain	Range	Unit	Default	Related control mode		
		0 to 1000	0.1%	0	P	S	F

- Multiply the torque command calculated according to the velocity control command by the ratio of this parameter and add the result to the torque command resulting from the velocity control process.
- Positional deviation at a constant acceleration/deceleration can be minimized close to 0 by increasing the torque forward gain. This means that positional deviation can be maintained at near 0 over entire operation range while driving in trapezoidal speed pattern under ideal condition where disturbance torque is not active.

Pr1.13	Torque feed forward filter	Range	Unit	Default	Related control mode		
		0 to 6400	0.01ms	0	P	S	F

- Set up the time constant of 1st delay filter which affects the input of torque feed forward.
- The torque feed forward will become effective as the torque feed forward gain is gradually increased with the torque feed forward filter is set at approx. 50 (0.5 ms).

<Usage example of torque feed forward>

- To use the torque feed forward, correctly set the inertia ratio.
Use the value that was determined at the start of the real time auto tuning, or set the inertia ratio that can be calculated from the machine specification to Pr0.04 Inertia ratio.
- The torque feed forward will become effective as the torque feed forward gain is gradually increased with the torque feed forward filter is set at approx. 50 (0.5 ms).
- Positional deviation at a constant acceleration/deceleration can be minimized close to 0 by increasing the torque forward gain. This means that positional deviation can be maintained at near 0 over entire operation range while driving in trapezoidal speed pattern under ideal condition where disturbance torque is not active .

Caution ❗ Zero positional deviation is impossible in actual situation because of disturbance torque. As with the velocity feed forward, large torque feed forward filter time constant decreases the operating noise but increases positional deviation at acceleration change point.

Pr1.14	2nd gain setup	Range	Unit	Default	Related control mode			
		0 to 1	—	1	P	S	T	F

Arrange this parameter when performing optimum adjustment by using the gain switching function.

Setup value	Gain selection/switching
0	1st gain is fixed at a value. By using the gain switching input (GAIN), change the velocity loop operation from PI to P. GAIN input photo-coupler OFF → PI operation GAIN input photo-coupler ON → P operation * The above description applies when the logical setting of GAIN input is a-contact. ON/OFF of photo-coupler is reversed when b-contact.
[1]	Enable gain switching of 1st gain (Pr1.00-Pr1.04) and 2nd gain (Pr1.05-Pr1.09).

Related page ❗ For switching condition of the 1st and the 2nd, refer to P.5-17 "Gain Switching Function" of Adjustment.

1. Details of parameter

[Class 1] Gain adjustment

Pr1.15	Mode of position control switching	Range	Unit	Default	Related control mode		
		0 to 10	—	0	P		F

Set up the triggering condition of gain switching for position control.

Setup value	Switching condition	Gain switching condition
[0]	Fixed to 1st gain	Fixed to the 1st gain (Pr1.00 to Pr1.04).
1	Fixed to 2nd gain	Fixed to the 2nd gain (Pr1.05 to Pr1.09).
2	With gain switching input	<ul style="list-style-type: none"> 1st gain when the gain switching input (GAIN) is open. 2nd gain when the gain switching input (GAIN) is connected to COM-. * If no input signal is allocated to the gain switching input (GAIN), the 1st gain is fixed.
3	Torque command is large	<ul style="list-style-type: none"> Shift to the 2nd gain when the absolute value of the torque command exceeded (level + hysteresis) (%) previously with the 1st gain. Return to the 1st gain when the absolute value of the torque command was kept below (level - hysteresis) (%) previously during delay time with the 2nd gain.
5	Speed command is large	<ul style="list-style-type: none"> Valid for position and full-closed controls. Shift to the 2nd gain when the absolute value of the speed command exceeded (level + hysteresis) (r/min) previously with the 1st gain. Return to the 1st gain when the absolute value of the speed command was kept below (level - hysteresis) (r/min) previously during delay time with the 2nd gain.
6	Position deviation is large	<ul style="list-style-type: none"> Valid for position and full-closed controls. Shift to the 2nd gain when the absolute value of the positional deviation exceeded (level + hysteresis) (pulse) previously with the 1st gain. Return to the 1st gain when the absolute value of the positional deviation was kept below (level - hysteresis) (pulse) previously over delay time with the 2nd gain. * Unit of level and hysteresis (pulse) is set as the encoder resolution for positional control and external scale resolution for full-closed control.
7	Position command exists	<ul style="list-style-type: none"> Valid for position and full-closed controls. Shift to the 2nd gain when the positional command was not 0 previously with the 1st gain. Return to the 1st gain when the positional command was kept 0 previously during delay time with the 2nd gain.
8	Not in positioning complete	<ul style="list-style-type: none"> Valid for position and full-closed controls. Shift to the 2nd gain when the positioning was not completed previously with the 1st gain. Return to the 1st gain when the positioning was kept in completed condition previously during delay time with the 2nd gain.
9	Actual speed is large	<ul style="list-style-type: none"> Valid for position and full-closed controls. Shift to the 2nd gain when the absolute value of the actual speed exceeded (level + hysteresis) (r/min) previously with the 1st gain. Return to the 1st gain when the absolute value of the actual speed was kept below (level - hysteresis) (r/min) previously during delay time with the 2nd gain.
10	Position command exists + Actual speed	<ul style="list-style-type: none"> Valid for position and full-closed controls. Shift to the 2nd gain when the positional command was not 0 previously with the 1st gain. Return to the 1st gain when the positional command was kept at 0 during the delay time and the absolute value of actual speed was kept below (level - hysteresis) (r/min) previously with the 2nd gain.

Pr1.16	Delay time of position control switching	Range	Unit	Default	Related control mode		
		0 to 10000	0.1ms	50	P		F

For position controlling : When shifting from the 2nd gain to the 1st gain with Pr1.15 Position control switching mode set at 3, 5, 6, 7, 8, 9 or 10, set up the delay time from trigger detection to the switching operation.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 1] Gain adjustment

Default: []

Pr1.17	Level of position control switching	Range	Unit	Default	Related control mode		
		0 to 20000	Mode-dependent	50	P		F

For position controlling: Set up triggering level when Pr1.15 Position control gain switching mode is set at 3, 5, 6, 9 or 10.
Unit of setting varies with switching mode.

Caution ⚠ Set the level equal to or higher than the hysteresis.

Pr1.18	Hysteresis at position control switching	Range	Unit	Default	Related control mode		
		0 to 20000	Mode-dependent	33	P		F

For position controlling: Set up triggering hysteresis when Pr1.15 Position control gain switching mode is set at 3, 5, 6, 9 or 10.
Unit of setting varies with switching mode.

Caution ⚠ When level < hysteresis, the hysteresis is internally adjusted so that it is equal to level.

Pr1.19	Position gain switching time	Range	Unit	Default	Related control mode		
		0 to 10000	0.1ms	33	P		F

For position controlling: If the difference between Pr1.00 1st gain of position loop and Pr1.05 2nd gain of position loop is large, the increasing rate of position loop gain can be limited by this parameter.
The position loop gain will increase over the time set.

<Position gain switching time>
When using position control and full-closed control, gain of position loop rapidly changes, causing torque change and vibration. By adjusting Pr1.19 Position gain switching time, increasing rate of the position loop gain can be decreased and vibration level can be reduced.

Caution ⚠ Setting of this parameter does not affect the gain switching time when the gain of position loop is switched to lower level (gain is switched immediately).
Example: 1st (Pr1.00) > 2nd (Pr1.05)

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 1] Gain adjustment

Default: []

Pr1.20	Mode of velocity control switching	Range	Unit	Default	Related control mode	
		0 to 5	—	0	S	

For velocity controlling: Set the condition to trigger gain switching.

Setup value	Switching condition	Gain switching condition
[0]	Fixed to the 1st gain.	Fixed to the 1st gain (Pr1.00 to Pr1.04).
1	Fixed to the 2nd gain.	Fixed to the 2nd gain (Pr1.05 to Pr1.09).
2	Gain switching input	<ul style="list-style-type: none"> 1st gain when the gain switching input (GAIN) is open. 2nd gain when the gain switching input (GAIN) is connected to COM—. * If no input signal is allocated to the gain switching input (GAIN), the 1st gain is fixed.
3	Torque command	<ul style="list-style-type: none"> Shift to the 2nd gain when the absolute value of the torque command exceeded (level + hysteresis) (%) previously with the 1st gain. Return to the 1st gain when the absolute value of the torque command was kept below (level - hysteresis) (%) previously during delay time with the 2nd gain.
4	Speed command variation is larger.	<ul style="list-style-type: none"> Valid only during velocity control. Shift to the 2nd gain when the absolute value of the speed command variations exceeded (level + hysteresis) (10r/min/s) previously with the 1st gain. Return to the 1st gain when the absolute value of the speed command variations was kept below (level - hysteresis) (10r/min/s) during delay time previously with the 2nd gain. * The 1st gain is fixed while the velocity control is not applied.

Related page For the switching level and timing, refer to P.5-18, "Setup of Gain Switching Condition" of Adjustment.

Pr1.21	Delay time of velocity control switching	Range	Unit	Default	Related control mode	
		0 to 10000	0.1ms	0	S	

For velocity controlling: When shifting from the 2nd gain to the 1st gain with Pr1.20 Velocity control switching mode set at 3, 4 or 5, set the delay time from trigger detection to the switching operation.

Pr1.22	Level of velocity control switching	Range	Unit	Default	Related control mode	
		0 to 20000	Mode-dependent	0	S	

For velocity controlling: Set up triggering level when Pr1.20 Velocity control gain switching mode is set at 3, 4 or 5.

Caution Unit of setting varies with switching mode.
Set the level equal to or higher than the hysteresis.

Pr1.23	Hysteresis at velocity control switching	Range	Unit	Default	Related control mode	
		0 to 20000	Mode-dependent	0	S	

For velocity controlling: Set up triggering hysteresis when Pr1.20 Velocity control gain switching mode is set at 3, 4 or 5.

Caution Unit of setting varies with switching mode.
When level < hysteresis, the hysteresis is internally adjusted so that it is equal to level.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.

Related page P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 1] Gain adjustment

Default: []

Pr1.24	Mode of torque control switching	Range	Unit	Default	Related control mode	
		0 to 3	—	0		T
For torque controlling: Set the condition to trigger gain switching.						
Setup value	Switching condition	Gain switching condition				
[0]	Fixed to the 1st gain.	Fixed to the 1st gain (Pr1.00 to Pr1.04).				
1	Fixed to the 2nd gain.	Fixed to the 2nd gain (Pr1.05 to Pr1.09).				
2	Gain switching input	<ul style="list-style-type: none">• 1st gain when the gain switching input (GAIN) is open.• 2nd gain when the gain switching input (GAIN) is connected to COM—.* If no input signal is allocated to the gain switching input (GAIN), the 1st gain is fixed.				
3	Torque command	<ul style="list-style-type: none">• Shift to the 2nd gain when the absolute value of the torque command exceeded (level + hysteresis) (%) previously with the 1st gain.• Return to the 1st gain when the absolute value of the torque command was kept below (level - hysteresis) (%) previously during delay time with the 2nd gain.				

Pr1.25	Delay time of torque control switching	Range	Unit	Default	Related control mode	
		0 to 10000	0.1ms	0		T
For torque controlling : When shifting from the 2nd gain to the 1st gain with Pr1.24 Torque control switching mode set at 3, set up the delay time from trigger detection to the switching operation.						

Pr1.26	Level of torque control switching	Range	Unit	Default	Related control mode	
		0 to 20000	Mode-dependent	0		T
For torque controlling: Set up triggering level when Pr1.24 Torque control gain switching mode is set at 3.						
Unit varies depending on the setup of mode of control switching.						
<div>Caution</div> Set the level equal to or higher than the hysteresis.						

Pr1.27	Hysteresis at torque control switching	Range	Unit	Default	Related control mode	
		0 to 20000	Mode-dependent	0		T
For torque controlling: Set up triggering hysteresis when Pr1.24 Torque control gain switching mode is set at 3.						
Unit of setting varies with switching mode.						
<div>Caution</div> When level < hysteresis, the hysteresis is internally adjusted so that it is equal to level.						

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 2] Damping control

Pr2.00	Adaptive filter mode setup	Range	Unit	Default	Related control mode		
		0 to 4	—	0	P	S	F

Set up the resonance frequency to be estimated by the adaptive filter and specify the operation after estimation.

Setup value	Content	
[0]	Adaptive filter: invalid	Parameters related to the 3rd and 4th notch filter hold the current value.
1	Adaptive filter: 1 filter is valid	One adaptive filter is enabled. Parameters related to the 3rd notch filter will be updated based on adaptive performance.
2	Adaptive filter: 2 filters are valid	Two adaptive filters are enabled. Parameters related to the 3rd and 4th notch filters will be updated based on adaptive performance.
3	Resonance frequency measurement mode	Measure the resonance frequency. Result of measurement can be checked with PANATERM. Parameters related to the 3rd and 4th notch filter hold the current value.
4	Clear result of adaptation	Parameters related to the 3rd and 4th notch filter are disabled and results of adaptive operation are cleared.

Pr2.01	1st notch frequency	Range	Unit	Default	Related control mode			
		50 to 5000	Hz	5000	P	S	T	F

Set the center frequency of the 1st notch filter.

Caution The notch filter function will be invalidated by setting up this parameter to "5000".

Pr2.02	1st notch width selection	Range	Unit	Default	Related control mode			
		0 to 20	—	2	P	S	T	F

Set the width of notch at the center frequency of the 1st notch filter.

Caution Higher the setup, larger the notch width you can obtain. Use with default setup in normal operation.

Pr2.03	1st notch depth selection	Range	Unit	Default	Related control mode			
		0 to 99	—	0	P	S	T	F

Set the depth of notch at the center frequency of the 1st notch filter.

Caution Higher the setup, shallower the notch depth and smaller the phase delay you can obtain.

Pr2.04	2nd notch frequency	Range	Unit	Default	Related control mode			
		50 to 5000	Hz	5000	P	S	T	F

Set the center frequency of the 2nd notch filter.

Caution The notch filter function will be invalidated by setting up this parameter to "5000".

Pr2.05	2nd notch width selection	Range	Unit	Default	Related control mode			
		0 to 20	—	2	P	S	T	F

Set the width of notch at the center frequency of the 2nd notch filter.

Caution Higher the setup, larger the notch width you can obtain. Use with default setup in normal operation.

1. Details of parameter

[Class 2] Damping control

Default: []

Pr2.06	2nd notch depth selection	Range	Unit	Default	Related control mode			
		0 to 99	—	0	P	S	T	F
Set the depth of notch at the center frequency of the 2nd notch filter.								
Caution ⚠ Higher the setup, shallower the notch depth and smaller the phase delay you can obtain.								

Pr2.07	3rd notch frequency	Range	Unit	Default	Related control mode			
		50 to 5000	Hz	5000	P	S	T	F
Notch frequency is automatically set to the 1st resonance frequency estimated by the adaptive filter.								
Caution ⚠ In no resonance point is found, the frequency is set to 5000.								

Pr2.08	3rd notch width selection	Range	Unit	Default	Related control mode			
		0 to 20	—	2	P	S	T	F
Set the width of notch at the center frequency of the 3rd notch filter.								
Caution ⚠ Higher the setup, larger the notch width you can obtain. Use with default setup in normal operation. When the applicable filter function is used, parameter value is automatically set.								

Pr2.09	3rd notch depth selection	Range	Unit	Default	Related control mode			
		0 to 99	—	0	P	S	T	F
Set the depth of notch at the center frequency of the 3rd notch filter.								
Caution ⚠ Higher the setup, shallower the notch depth and smaller the phase delay you can obtain. When the applicable filter function is used, parameter value is automatically set.								

Pr2.10	4th notch frequency	Range	Unit	Default	Related control mode			
		50 to 5000	Hz	5000	P	S	T	F
Notch frequency is automatically set to the 2nd resonance frequency estimated by the adaptive filter.								
Caution ⚠ The notch filter function will be invalidated by setting up this parameter to "5000".								

Pr2.11	4th notch width selection	Range	Unit	Default	Related control mode			
		0 to 20	—	2	P	S	T	F
Set the width of notch at the center frequency of the 4th notch filter.								
Caution ⚠ Higher the setup, larger the notch width you can obtain. Use with default setup in normal operation. When the applicable filter function is used, parameter value is automatically set.								

Pr2.12	4th notch depth selection	Range	Unit	Default	Related control mode			
		0 to 99	—	0	P	S	T	F
Set the depth of notch at the center frequency of the 4th notch filter.								
Caution ⚠ Higher the setup, shallower the notch depth and smaller the phase delay you can obtain. When the applicable filter function is used, parameter value is automatically set.								

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 2] Damping control

Default: []

Pr2.13 Selection of damping filter switching

Range	Unit	Default	Related control mode		
0 to 3	—	0	P		F

Among 4 filters select the filters to be used for damping control.

- When setup value is 0: Up to 2 filters can be used simultaneously.
- When setup value is 1 or 2: Select the filter with external input(s) (VS-SEL1 and/or VS-SEL2).

Setup value	VS-SEL2	VS-SEL1	1st damping	2nd damping	3rd damping	4th damping
[0]	—	—	<input type="radio"/>	<input type="radio"/>		
1	—		<input type="radio"/>		<input type="radio"/>	
	—	<input type="radio"/>		<input type="radio"/>		<input type="radio"/>
2			<input type="radio"/>			
		<input type="radio"/>		<input type="radio"/>		
	<input type="radio"/>				<input type="radio"/>	
	<input type="radio"/>	<input type="radio"/>				<input type="radio"/>

- With setup value 3: Select the filter with command direction.

Setup value	Position command direction	1st damping	2nd damping	3rd damping	4th damping
3	Positive direction	<input type="radio"/>		<input type="radio"/>	
	Negative direction		<input type="radio"/>		<input type="radio"/>

Caution

- Switching of damping controls will be done on the rising edge of the command whose number of pulses/0.166 ms has been changed from 0 while the positioning complete signal is being output.

When the damping frequency is increased or disabled, and positioning complete range is large, and pulses are stored in the filter at that time (the area represented by the value of position command before filter subtracted by the value of position command after filter and integrated with the time). Note that since these pulses will be discharged at a higher rate upon switching to return back to the original position, the motor may run at a speed higher than the command speed for a short time.

Pr2.14 1st damping frequency

Range	Unit	Default	Related control mode		
0 to 2000	0.1Hz	0	P		F

Pr2.16 2nd damping frequency

Range	Unit	Default	Related control mode		
0 to 2000	0.1Hz	0	P		F

Pr2.18 3rd damping frequency

Range	Unit	Default	Related control mode		
0 to 2000	0.1Hz	0	P		F

Pr2.20 4th damping frequency

Range	Unit	Default	Related control mode		
0 to 2000	0.1Hz	0	P		F

You can set up the 1st to 4th damping frequency of the damping control which suppress vibration at the load edge.

The driver measures vibration at load edge. Setup unit is 0.1[Hz].

Related page

The setup frequency is 1.0 to 200.0[Hz]. Setup of 0 to 9 becomes invalid. Refer to P.5-20, "Damping control" as well before using this parameter.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 2] Damping control

Pr2.15	1st damping filter setup	Range	Unit	Default	Related control mode		
		0 to 1000	0.1Hz	0	P		F
Pr2.17	2nd damping filter setup	Range	Unit	Default	Related control mode		
		0 to 1000	0.1Hz	0	P		F
Pr2.19	3rd damping filter setup	Range	Unit	Default	Related control mode		
		0 to 1000	0.1Hz	0	P		F
Pr2.21	4th damping filter setup	Range	Unit	Default	Related control mode		
		0 to 1000	0.1Hz	0	P		F

If torque saturation occurs with damping frequency (1st- 4th) enabled, decrease the setup value, or if the operation is slow, increase it. Usually set it to 0.

Caution The maximum setup value is internally limited to the corresponding damping frequency or 2000 - damping frequency, whichever is smaller.

Related page Refer to P.5-24, "Damping control" as well before using this parameter.

Pr2.22	Positional command smoothing filter	Range	Unit	Default	Related control mode		
		0 to 10000	0.1ms	0	P		F

• Set up the time constant of the 1st delay filter in response to the positional command.

• When a square wave command for the target speed V_c is applied, set up the time constant of the 1st delay filter as shown in the figure below.

*1 Actual filter time constant (setup value \times 0.1 ms) has the maximum absolute error of 0.2 ms for a time constant below 100 ms and the maximum relative error of 0.1% for a time constant 20 ms or more.

*2 Switching of Pr2.22 Positional command smoothing filter is performed on the rising edge of the command with the number of command pulses/0.166 ms is changed from 0 to a value other than 0 while the positioning complete is being output. If the filter time constant is decreased and positioning complete range is increased, and a many number of plusses are accumulated in the filter (the area equivalent of "value of positional command filter - value of positional command after filter" integrated over the time), at the time of switching, these pulses are discharged at a higher rate, causing the motor to return to the previous position - the motor runs at a speed higher than the command speed for a short time.

*3 Even if Pr2.22 Positional command smoothing filter is changed, it is not applied immediately. If the switching as described in *2 occurs during this delay time, the change of Pr2.22 will be suspended.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of " * ",** changed contents will be validated when you turn on the control power.

Related page P.3-30... "Inputs and outputs on connector X4"


1. Details of parameter

[Class 2] Damping control

Default: []

Pr2.23	Positional command FIR filter	Range	Unit	Default	Related control mode		
		0 to 10000	0.1ms	0	P		F

- Set up the time constant of the 1st delay filter in response to the positional command.
- When a square wave command of the target speed V_c is applied, set up the V_c arrival time as shown in the figure below.



- *1 The actual average travel time (setup value $\times 0.1 \text{ ms}$) has the maximum absolute error of 0.1 ms for a time constant below 10 ms and the maximum relative error of 1.6% for a time constant 10 ms or more.
- *2 When changing Pr2.23 Positional command FIR filter, stop the command pulse and wait until the filter switching wait time has elapsed. The filter switching wait time is the setup value $\times 0.1 \text{ ms} + 0.25 \text{ ms}$ when the setup time is 10 ms , and setup value $\times 0.1 \text{ ms} \times 1.05$ when the setup time is 10 ms or more. If Pr2.23 is changed while the command pulse is being input, the change is not reflected until the command pulse-less state has continued for the filter switching wait time.
- *3 Even if Pr2.23 Positional command FIR filter is changed, it is not applied immediately. If the switching as described in *2 occurs during this delay time, the change of Pr2.23 will be suspended.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.
- P.3-30... “Inputs and outputs on connector X4”

Related page

Default: []

Pr3.00	Speed setup, Internal/External switching	Range	Unit	Default	Related control mode	
		0 to 3	—	0	S	


This driver is equipped with internal speed setup function so that you can control the speed with contact inputs only.

Setup value	Speed setup method
[0]	Analog speed command (SPR)
1	Internal speed command 1st to 4th speed (Pr3.04 to Pr3.07)
2	Internal speed command 1st to 3rd speed (Pr3.04 to Pr3.06), Analog speed command (SPR)
3	Internal speed command 1st to 8th speed (Pr3.04 to Pr3.11)


<Relationship between Pr3.00 Internal/external switching speed setup and the internal command speed selection 1, 2 and 3, and speed command to be selected>

Setup value	Selection 1 of internal command speed (INTSPD1)	Selection 2 of internal command speed (INTSPD2)	Selection 3 of internal command speed (INTSPD3)	Selection of Speed command
1	OFF	OFF	No effect	1st speed
	ON	OFF		2nd speed
	OFF	ON		3rd speed
	ON	ON		4th speed
2	OFF	OFF	No effect	1st speed
	ON	OFF		2nd speed
	OFF	ON		3rd speed
	ON	ON		Analog speed command
3	The same as Pr3.00=1		OFF	1st to 4th speed
	OFF	OFF	ON	5th speed
	ON	OFF	ON	6th speed
	OFF	ON	ON	7th speed
	ON	ON	ON	8th speed

Internal command speed switching pattern should be so arranged as shown below that single input signals are selected alternately. If 2 or more input signals are selected simultaneously, unspecified internal command speed may be advertently selected, whose setting value and acceleration/deceleration setting will cause unexpected operation.



Example 1) When Pr3.00=1 or 2



Example 2) When Pr3.00=3

Pr3.01	Speed command rotational direction selection	Range	Unit	Default	Related control mode	
		0 to 1	—	0	S	

Select the Positive/Negative direction specifying method.

Setup value	Select speed command sign (1st to 8th speed)	Speed command direction (VC-SIGN)	Position command direction
[0]	+	No effect	Positive direction
	-	No effect	Negative direction
1	Sign has no effect.	OFF	Positive direction
	Sign has no effect.	ON	Negative direction

1. Details of parameter

[Class 3] Velocity/ Torque/ Full-closed control

Default: []

Pr3.02	Input gain of speed command	Range	Unit	Default	Related control mode		
		10 to 2000	(r/min)/V	500	S	T	

Based on the voltage applied to the analog speed command (SPR), set up the conversion gain to motor command speed.

- You can set up a "slope" of the relation between the command input voltage and the motor speed, with Pr3.02.
- Default is set to Pr3.02=500 [r/min], hence input of 6V becomes 3000r/min.

Caution ❖

- Do not apply more than $\pm 10\text{V}$ to the speed command input (SPR).
- When you compose a position loop outside of the driver while you use the driver in velocity control mode, the setup of Pr3.02 gives larger variance to the overall servo system. Pay an extra attention to oscillation caused by larger setup of Pr3.02.

Pr3.03	Reversal of speed command input	Range	Unit	Default	Related control mode		
		0 to 1	—	1	S		

Specify the polarity of the voltage applied to the analog speed command (SPR).

Setup value	Motor rotating direction	
0	Non-reversal	" +Voltage " → "Positive direction", " -Voltage " → "Negative direction"
[1]	Reversal	" +Voltage " → "Negative direction", " -Voltage " → "Positive direction"

Note ❖ Default of this parameter is 1, and the motor turns to CW with (+) signal, this has compatibility to existing MINAS series driver.

Caution ❖ When you compose the servo drive system with this driver set to velocity control mode and external positioning unit, the motor might perform an abnormal action if the polarity of the speed command signal from the unit and the polarity of this parameter setup does not match.

Note ❖

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of " * ",** changed contents will be validated when you turn on the control power.

Related page ❖ P.3-30... "Inputs and outputs on connector X4"

1. Details of parameter

[Class 3] Verocity/ Torque/ Full-closed control

Default: []

Pr3.04	1st speed of speed setup	Range	Unit	Default	Related control mode		
		-20000 to 20000	r/min	0		S	
Pr3.05	2nd speed of speed setup	Range	Unit	Default	Related control mode		
		-20000 to 20000	r/min	0		S	
Pr3.06	3rd speed of speed setup	Range	Unit	Default	Related control mode		
		-20000 to 20000	r/min	0		S	
Pr3.07	4th speed of speed setup	Range	Unit	Default	Related control mode		
		-20000 to 20000	r/min	0		S	
Pr3.08	5th speed of speed setup	Range	Unit	Default	Related control mode		
		-20000 to 20000	r/min	0		S	
Pr3.09	6th speed of speed setup	Range	Unit	Default	Related control mode		
		-20000 to 20000	r/min	0		S	
Pr3.10	7th speed of speed setup	Range	Unit	Default	Related control mode		
		-20000 to 20000	r/min	0		S	
Pr3.11	8th speed of speed setup	Range	Unit	Default	Related control mode		
		-20000 to 20000	r/min	0		S	
Set up internal command speeds, 1st to 8th.							


Pr3.12	Acceleration time setup	Range	Unit	Default	Related control mode
		0 to 10000	ms/ (1000r/min)	0	S
Pr3.13	Deceleration time setup	Range	Unit	Default	Related control mode
		0 to 10000	ms/ (1000r/min)	0	S

Set up acceleration/deceleration processing time in response to the speed command input. Set the time required for the speed command (stepwise input) to reach 1000 r/min to Pr3.12 Acceleration time setup. Also set the time required for the speed command to reach from 1000 r/min to 0 r/min, to Pr3.13 Deceleration time setup.

Assuming that the target value of the speed command is V_c (r/min), the time required for acceleration/deceleration can be computed from the formula shown below.

$$\text{Acceleration time (ms)} = V_c/1000 \times \text{Pr3.12} \times 1 \text{ ms}$$

$$\text{Deceleration time (ms)} = V_c/1000 \times \text{Pr3.13} \times 1 \text{ ms}$$



Caution

When the speed difference between the speed command being selected and the speed command after acceleration/deceleration indicates the same direction as that of the speed command applied after acceleration/deceleration, result is “acceleration” and if the reverse direction, the result is “deceleration”.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 3] Velocity/ Torque/ Full-closed control

Default: []

Pr3.14	Sigmoid acceleration/ deceleration time setup	Range	Unit	Default	Related control mode	
		0 to 1000	ms	0	S	

Set S-curve time for acceleration/deceleration process when the speed command is applied. According to Pr3.12 Acceleration time setup and Pr3.13 Deceleration time setup, set up sigmoid time with time width centering the inflection point of acceleration/deceleration.

Speed [r/min]

Target speed (Vc)

ts

ts

Speed command after acceleration/deceleration process

ts

ts

ta

td

Time

$t_a = V_c / 1000 \times \text{Pr3.12} \times 1\text{ms}$
 $t_d = V_c / 1000 \times \text{Pr3.13} \times 1\text{ms}$
 $t_s = \text{Pr3.14} \times 1\text{ms}$
 * Use with the setup of $t_a/2 > t_s$, $t_d/2 > t_s$

Pr3.15	Speed zero-clamp function selection	Range	Unit	Default	Related control mode	
		0 to 3	—	0	S	T

You can set up the function of the speed zero clamp input.

Setup value	Function of ZEROSPD (Pin-26)
[0]	Invalid: Speed zero-clamp input is ignored.
1	Speed command is forced to 0 when the speed zero clamp (ZEROSPD) input signal is turned ON ^{*1} .
2	Speed command is forced to 0 when the speed zero clamp (ZEROSPD) input signal is turned ON ^{*1} . And when the actual motor speed drops to Pr3.16 Speed zero clamp level or below, the position control is selected and servo lock is activated at this point. The fundamental operations except for this function (switching to the position control) are identical to those when setup value is 1.
3	When the speed zero clamp (ZEROSPD) input signal is ON ^{*1} and speed command is below Pr3.16 Speed zero clamp level -10 r/min, then the position control is selected and servo lock is activated at that point.

^{*1} The default logic is b-contact: the function is enabled while the terminal is open (input signal is ON). Refer to P.3-37 Control input.

Pr3.16	Speed zero clamp level	Range	Unit	Default	Related control mode	
		10 to 20000	r/min	30	S	T

Select the timing at which the position control is activated as the Pr3.15 Speed zero-clamp function selection is set to 2 or 3.

If Pr3.15 = 3, then hysteresis of 10 r/min is provided for detection.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.
- P.3-30... “Inputs and outputs on connector X4”

Related page

1. Details of parameter

[Class 3] Velocity/ Torque/ Full-closed control

Default: []

Pr3.17	Selection of torque command	Range	Unit	Default	Related control mode	
		0 to 2	—	0		T

You can select the input of the torque command and the speed limit.

Setup value	Torque command input	Velocity limit input
[0]	Analog input 1 *1 (AI1, 16-bit resolution)	Parameter value (Pr3.25)
1	Analog input 2 (AI2, 12-bit resolution)	Analog input 1 (AI1, 16-bit resolution)
2	Analog input 1 *1 (AI1, 16-bit resolution)	Parameter value (Pr3.21, Pr3.22)

*1 For Pr0.01 Control mode setup = 5 (velocity/torque control), the torque command input is the analog input 2 (AI2, 12-bit resolution).

Pr3.18	Torque command direction selection	Range	Unit	Default	Related control mode	
		0 to 1	—	0		T

Select the direction positive/negative direction of torque command.

Setup value	Designation
[0]	Specify the direction with the sign of torque command. Example: Torque command input (+) for positive direction, (–) for negative direction
1	Specify the direction with torque command sign (TC-SIGN). OFF: Positive direction, ON: Negative direction

Pr3.19	Input gain of torque command	Range	Unit	Default	Related control mode	
		10 to 100	0.1V/100%	30		T

Based on the voltage (V) applied to the analog torque command (TRQR), set up the conversion gain to torque command (%).

- Unit of the setup value is [0.1V/100%] and set up input voltage necessary to produce the rated torque.
- Default setup of 30 represents 3V/100%.

Pr3.20	Input reversal of torque command	Range	Unit	Default	Related control mode	
		0 to 1	—	0		T

Set up the polarity of the voltage applied to the analog torque command (TRQR).

Setup value	Direction of motor output torque	
[0]	Non-reversal	“+Voltage” → “Positive direction”, “–Voltage” → “Negative direction”
1	Reversal	“+Voltage” → “Negative direction”, “–Voltage” → “Positive direction”

1. Details of parameter

[Class 3] Verocity/ Torque/ Full-closed control

Default: []

Pr3.21	Speed limit value 1	Range	Unit	Default	Related control mode		
		0 to 20000	r/min	0		T	

Set up the speed limit used for torque controlling.
During the torque controlling, the speed set by the speed limit value cannot be exceeded.
When Pr3.17 = 2, the speed limit is applied upon receiving positive direction command.

Pr3.22	Speed limit value 2	Range	Unit	Default	Related control mode		
		0 to 20000	r/min	0		T	

Speed limit value of negative direction command when Pr3.17 = 2.

Pr3.17	Pr3.21	Pr3.22	Pr3.15	Speed zero clamp (ZEROSPD)	Analog torque command direction	Speed limit value
0	0 to 20000	No effect	0	No effect	No effect	Pr3.21 setup value
			1 to 3	OFF		Pr3.21 setup value
				ON		0
2	0 to 20000	0 to 20000	0	No effect	Positive direction	Pr3.21 setup value
					Negative direction	Pr3.22 setup value
	0 to 20000	0 to 20000	1 to 3	OFF	Positive direction	Pr3.21 setup value
					Negative direction	Pr3.22 setup value
	0 to 20000	0 to 20000	1 to 3	ON	No effect	0

Pr3.23 *	External scale selection	Range	Unit	Default	Related control mode		
		0 to 2	—	0			F

Select the type of external scale.

Setup value	External scale type	Compatible scale	Compatible speed
[0]	A,B phase output type *1	External scale of A, B phase output type	to 4Mpps (after quadrupled)
1	Serial communication type (incremental version) *1	Magnescale Co., Ltd. SR75, SR85, SL700, SL710	to 400Mpps
2	Serial communication type (absolute version) *1	Mitsutoyo Corp. AT573, ST771A, ST773A Magnescale Co., Ltd. SR77, SR87	to 400Mpps

*1 Connect the external scale so that it increments the count as the motor shaft turns positive direction, and decrements as the shaft turns negative direction. If this connection arrangement is impossible due to installation condition, etc., use the count reverse function of Pr3.26 Reversal of direction of external scale.

Caution When the setup value is 1 or 2 while the A, B phase output type is connected, Err50.0 External scale wiring error protection occurs, and if the setup value is 0 while the serial communication type is connected, Err55.0, 1 or 2 A phase, B phase or Z phase wiring error protection will occur.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”
- P.6-2 “Protective Function”

1. Details of parameter

[Class 3] Velocity/ Torque/ Full-closed control

Pr3.24 *	Numerator of external scale division	Range	Unit	Default	Related control mode		
		0 to 1,048,576	—	0			F

Set up the numerator of the external scale dividing setup.

When setup value = 0, encoder resolution is used as numerator of the division.

Pr3.25 *	Denominator of external scale division	Range	Unit	Default	Related control mode		
		1 to 1,048,576	—	10000			F

- Check the number of encoder feedback pluses per one motor revolution and the number of external scale pulses per one motor revolution, and then set up the numerator of external scale division (Pr3.24) and the denominator of external scale division (Pr3.25) to establish the expression shown below.

- With Pr3.24 set at 0, the encoder resolution is automatically used as numerator.

Example: When ball screw pitch is 10 mm, scale 0.1 _m/pulse, encoder resolution 20 bits (1048.576 pulses);

$$\frac{\text{Pr3.24 } 1048576}{\text{Pr3.25 } 100000} = \frac{\text{Encoder resolution per one motor revolution [pulse]}}{\text{External scale resolution per one motor revolution [pulse]}}$$

Caution

If this ratio is wrong, the difference between the position calculated based on the encoder pulses and the position calculated based on the external scale pulses becomes large over a long travel distance and will activate the excess hybrid deviation error protection.

Pr3.26 *	Reversal of direction of external scale	Range	Unit	Default	Related control mode		
		0 to 1	—	0			F

Reverse the direction of external scale, feedback counter.

Setup value	Content
[0]	Count value of external scale can be used as it is.
1	Sign (positive/negative) of count value of external scale should be inverted.

Note

For setting method of this parameter, refer to P.3-12 Full closed control mode.

Pr3.27 *	External scale Z phase disconnection detection disable	Range	Unit	Default	Related control mode		
		0 to 1	—	0			F

Enable/disable Z-phase disconnection detection when A, B phase output type external scale is used.

Setup value	Content
[0]	Valid
1	Invalid

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.

- **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 3] Verocity/ Torque/ Full-closed control

Default: []

Pr3.28 *	Hybrid deviation excess setup	Range	Unit	Default	Related control mode		
		1 to 134,217,728	Command unit	16000			F

You can setup the permissible gap (hybrid deviation) between the present motor position and the present external scale position.

Pr3.29 *	Hybrid deviation clear setup	Range	Unit	Default	Related control mode		
		0 to 100	Revolution	0			F

As the motor turns the number of revolutions set by this parameter, the hybrid deviation is cleared to 0. No clearing is made with setup value 0.

<Hybrid deviation clear feature>
As the motor reaches the number of revolutions set by Pr3.29 Hybrid deviation clear setup, clear the hybrid deviation to 0. This feature allows the motor to be used in an application where hybrid deviation accumulate due to slippage, etc.

Note: Revolution in the hybrid deviation clear setup is counted by using encoder feedback pulses.

Caution To use the hybrid deviation clear, be sure to set Pr3.29 Hybrid deviation clear setup to the appropriate value. If the setup value is too small with respect to the value of Pr3.28 Hybrid deviation excess setup, abnormal operation due to e.g. external scale connection error cannot be protected.
Limit sensor should be used to assure safety.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.
- P.3-30... “Inputs and outputs on connector X4”

Related page

Pr4.00 *

SI1 input selection

Range

0 to 00FFFFFFh

Unit

—

Default

00828282h
(8553090)Related
control mode

P S T F

Assign functions to SI1 inputs.

These parameters are presented in hexadecimal. *5

Hexadecimal presentation is followed by a specific control mode designation.

0 0 — — — * * h : position/full-closed control

0 0 — — * * — — h : velocity control

0 0 * * — — — — h : torque control

Replace * * with the function number.

For the function number see the table below. Logical setup is also a function number.

Title	Symbol	Setup value	
		a-contact	b-contact
Invalid	—	00h	Do not setup.
Positive direction over-travel inhibition input	POT	01h	81h
Negative direction over-travel inhibition input	NOT	02h	82h
Servo-ON input *1	SRV-ON	03h	83h
Alarm clear input	A-CLR	04h	Do not setup.
Control mode switching input *2	C-MODE	05h	85h
Gain switching input	GAIN	06h	86h
Deviation counter clear input *3	CL	07h	Do not setup.
Command pulse inhibition input *4	INH	08h	88h
Torque limit switching input	TL-SEL	09h	89h
Damping control switching input 1	VS-SEL1	0Ah	8Ah
Damping control switching input 2	VS-SEL2	0Bh	8Bh
Electronic gear switching input 1	DIV1	0Ch	8Ch
Electronic gear switching input 2	DIV2	0Dh	8Dh
Selection 1 input of internal command speed	INTSPD1	0Eh	8Eh
Selection 2 input of internal command speed	INTSPD2	0Fh	8Fh
Selection 3 input of internal command speed	INTSPD3	10h	90h
Speed zero clamp input	ZEROSPD	11h	91h
Speed command sign input	VC-SIGN	12h	92h
Torque command sign input	TC-SIGN	13h	93h
Forced alarm input	E-STOP	14h	94h
Inertia ratio switching input	J-SEL	15h	95h

Note

For input pin assignment with default setting, refer to P.3-37 Control input.

Related page P.3-50

<Example of change>

To change the default setting “Negative direction over-travel inhibition input” (in all modes) for b-contact to for a-contact, set the input to 00020202h.

* For easier setting, use the setup support software PANATERM.

Caution

- Do not setup to a value other than that specified in the table.
- Do not assign specific function to 2 or more signals. Duplicated assignment will cause Err33.0 I/F input multiple assignment error 1 or Err33.1 I/F input multiple assignment error 2.

*1 Servo-on input signal (SRV-ON) must be used to enable servo-on.

*2 When using control mode switching input (C-MODE), set the signal to all control modes. If the signal is set to only 1 or 2 control modes, Err33.2 I/F input function number error 1 or Err33.3 I/F input function number error 2 will be generated.

• The control input pin set to invalid state does not affect any operation.

• Function (servo-on input, alarm clear, etc.) to be used in multiple control modes must be assigned to the same pin with correct logical arrangement. Incorrect setting will cause Err33.0 I/F input multiple assignment error 1 or Err33.1 I/F input multiple assignment error 2.

*3 Deviation counter clear input (CL) can be assigned only to SI7 input. Wrong assignment will cause Err33.6 Counter clear assignment error.

*4 Command pulse inhibit input (INH) can be assigned only to SI10 input. Wrong assignment will cause Err33.7 Command pulse input inhibit input.

*5 Note that the front panel indicates parameter value in decimal number.

1. Details of parameter

[Class 4] I/F monitor setting

Pr4.01 *	SI2 input selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00818181h (8487297)	P	S	T	F
Pr4.02 *	SI3 input selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	0091910Ah (9539850)	P	S	T	F
Pr4.03 *	SI4 input selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00060606h (394758)	P	S	T	F
Pr4.04 *	SI5 input selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	0000100Ch (4108)	P	S	T	F
Pr4.05 *	SI6 input selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00030303h (197379)	P	S	T	F
Pr4.06 *	SI7 input selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00000f07h (3847)	P	S	T	F
<div>Caution</div> Deviation counter clear (CL) can be set up only with this parameter. If any other parameter is used for this purpose, Err33.6 Counter clear assignment error will be issued.								
Pr4.07 *	SI8 input selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00040404h (263172)	P	S	T	F
Pr4.08 *	SI9 input selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00050505h (328965)	P	S	T	F
Pr4.09 *	SI10 input selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00000E88h (3720)	P	S	T	F
<p>Assign functions to SI2 to SI10 inputs. These parameters are presented in hexadecimal. Setup procedure is the same as described for Pr4.00.</p> <div>Note</div> For input pin assignment with default setting, also refer to P.3-37 Control input.								
<div>Caution</div> Command pulse inhibition input (INH) can be setup only with this parameter. If any other parameter is used for this purpose, Err33.7 INH assignment error will be issued.								

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”
- P.6-2 “Protective Function”

1. Details of parameter

[Class 4] I/F monitor setting

Default: []

Pr4.10 *	SO1 output selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00030303h (197379)	P	S	T	F

Assign functions to SO1 outputs.
 These parameters are presented in hexadecimal. *1
 Hexadecimal presentation is followed by a specific control mode designation.
 0 0 — — — * * h : position/full-closed control
 0 0 — — * * — — h : velocity control
 0 0 * * — — — — h : torque control
 Replace * * with the function number.
 For the function number see the table below. Logical setup is also a function number.

Setup value	Title	Symbol
00h	Invalid	—
02h	Servo-Ready output	S-RDY
03h	External brake release signal	BRK-OFF
04h	Positioning complete output	INP
05h	At-speed output	AT-SPPED
06h	Torque in-limit signal output	TLC
07h	Zero-speed detection output signal	ZSP
08h	Speed coincidence output	V-COIN
09h	Alarm output 1	WARN1
0Ah	Alarm output 2	WARN2
0Bh	Positional command ON/OFF output	P-CMD
0Ch	Positioning complete 2	INP2
0Dh	Speed in-limit output	V-LIMIT
0Eh	Alarm attribute output	ALM-ATB
0Fh	Speed command ON/OFF output	V-CMD

Note For output pin assignment with default setting, also refer to P.3-45 Output signals (common) and their functions.
 Related page P.3-52

<Example of change>
 To change the default setting “External brake release signal” (in all modes) to “Alarm output 1”, set the input to 00090909h.
 * For easier setting, use the setup support software PANATERM.

Caution

- Same function can be assigned to 2 or more output signals.
- Control output pin set to invalid always has the output transistor turned OFF.
- Do not change the setup value shown in the table.

*1 Note that the setup values are displayed in decimal on the front panel.

Pr4.11 *	SO2 output selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00020202h (131586)	P	S	T	F

Pr4.12 *	SO3 output selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00010101h (65793)	P	S	T	F

Pr4.13 *	SO4 output selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00050504h (328964)	P	S	T	F

Pr4.14 *	SO5 output selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00070707h (460551)	P	S	T	F

Pr4.15 *	SO6 output selection	Range	Unit	Default	Related control mode			
		0 to 00FFFFFFh	—	00060606h (394758)	P	S	T	F

Assign functions to SO2 to SO6 outputs.
 These parameters are presented in hexadecimal.
 Setup procedure is the same as described for Pr4.10.

1. Details of parameter

[Class 4] I/F monitor setting

Default: []

Pr4.16	Type of analog monitor 1	Range	Unit	Default	Related control mode			
		0 to 21	—	0	P	S	T	F

Select the type of monitor for analog monitor 1. *See the table shown on the next page.

Pr4.17	Analog monitor 1 output gain	Range	Unit	Default	Related control mode			
		0 to 214748364	[Monitor unit in Pr4.16] / V	0	P	S	T	F

Set up the output gain of analog monitor 1.

For Pr4.16 = 0 Motor speed, 1 V is output at the motor speed [r/min] = Pr4.17 setup value.

Pr4.18	Type of analog monitor 2	Range	Unit	Default	Related control mode			
		0 to 21	—	4	P	S	T	F

Select the type of monitor for analog monitor 2. *See the table shown on the next page.

Pr4.19	Analog monitor 2 output gain	Range	Unit	Default	Related control mode			
		0 to 214748364	[Monitor unit in Pr4.16] / V	0	P	S	T	F

Set up the output gain of analog monitor 2.

For Pr4.18 = 3 Torque command, 1 V is output at the torque command [%] = Pr4.19 setup value.

Pr4.20	Type of digital monitor	Range	Unit	Default	Related control mode			
		0 to 3	—	0	P	S	T	F

Select type of the digital monitor.

Setup value	Type of monitor	Digital signal output	
		L output	H output
[0]	Positioning complete condition	Not completed	Completed
1	Positional command	Without command	With command
2	Alarm	Not generated	Generated
3	Gain selected	1st gain	2nd gain (including 3rd gain)

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.
- Only for position control type is not provided with analog input.
- Only for position control type is not provided with digital monitor output.
- P.3-30... “Inputs and outputs on connector X4”

Related page

1. Details of parameter

[Class 4] I/F monitor setting


Pr4.16/Pr4.18	Type of monitor	Unit	Output gain for setting Pr4.17/Pr4.19 = 0
0	Motor speed	r/min	500
1	Positional command speed *3	r/min	500
2	Internal positional command speed *3	r/min	500
3	Velocity control command	r/min	500
4	Torque command	%	33
5	Command positional deviation *4	pulse (Command unit)	3000
6	Encoder positional deviation *4	pulse (Encoder unit)	3000
7	Full-closed deviation *4	pulse (External scale unit)	3000
8	Hybrid deviation	pulse (Command unit)	3000
9	Voltage across PN	V	80
10	Regenerative load factor	%	33
11	Overload factor	%	33
12	Positive direction torque limit	%	33
13	Negative direction torque limit	%	33
14	Speed limit value	r/min	500
15	Inertia ratio	%	500
16	Analog input 1 *2	V	1
17	Analog input 2 *2	V	1
18	Analog input 3 *2	V	1
19	Encoder temperature *5	°C	10
20	Driver temperature	°C	10
21	Encoder single-turn data *1	pulse (Encoder unit)	110000

*1 The encoder rotation data CCW is always positive value regardless of Pr0.00 Rotational direction setup.


The direction of other monitor data basically follows Pr0.00 Rotational direction setup.

*2 Analog inputs 1, 2 and 3 always output terminal voltage regardless of usage of analog input function.
Only for position control type is not provided with analog inputs.

*3 For the command pulse input, the speed before the command filter (smoothing, FIR filter) is defined as positional command speed and speed after filter is defined as internal command speed.



*4 Command positional deviation is the deviation with respect to the command pulse input and the encoder positional deviation/ full-closed positional deviation is the deviation at the input section of the positional control, as described in the figure below.



*5 Temperature information from the encoder includes value only when it is a 20-bit incremental encoder. Otherwise, the value is always 0.

1. Details of parameter

[Class 4] I/F monitor setting

Default: []

Pr4.21	Analog monitor output setup	Range	Unit	Default	Related control mode			
		0 to 2	—	0	P	S	T	F
Select output format of the analog monitor.								
Setup value	Output format							
[0]	Signed data output		−10 V to 10 V					
1	Absolute value data output		0 V to 10 V					
2	Data output with offset		0 V to 10 V (5 V at center)					

Pr4.22	Analog input 1 (AI1) offset setup	Range	Unit	Default	Related control mode			
		–5578 to 5578	0.359mV	0	P	S	T	F
Set up the offset correction value applied to the voltage fed to the analog input 1.								

Pr4.23	Analog input 1 (AI1) filter	Range	Unit	Default	Related control mode			
		0 to 6400	0.01ms	0	P	S	T	F
Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 1.								

Pr4.24	Analog input 1 (AI1) overvoltage setup	Range	Unit	Default	Related control mode			
		0 to 100	0.1V	0	P	S	T	F
Set up the excessive level of the input voltage of analog input 1 by using the voltage associated with offset.								

Pr4.25	Analog input 2 (AI2) offset setup	Range	Unit	Default	Related control mode			
		−342 to 342	5.86mV	0	P	S	T	F
Set up the offset correction value applied to the voltage fed to the analog input 2.								

Pr4.26	Analog input 2 (AI2) filter	Range	Unit	Default	Related control mode			
		0 to 6400	0.01ms	0	P	S	T	F
Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 2.								

Pr4.27	Analog input 2 (AI2) overvoltage setup	Range	Unit	Default	Related control mode			
		0 to 100	0.1V	0	P	S	T	F
Set up the excessive level of the input voltage of analog input 2 by using the voltage associated with offset.								

Pr4.28	Analog input 3 (AI3) offset setup	Range	Unit	Default	Related control mode			
		−342 to 342	5.86mV	0	P	S	T	F
Set up the offset correction value applied to the voltage fed to the analog input 3.								

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.
- P.3-30... “Inputs and outputs on connector X4”

Related page

1. Details of parameter

[Class 4] I/F monitor setting

Pr4.29	Analog input 3 (AI3) filter	Range	Unit	Default	Related control mode			
		0 to 6400	0.01ms	0	P	S	T	F

Set up the time constant of 1st delay filter that determines the lag time behind the voltage applied to the analog input 3.

Pr4.30	Analog input 3 (AI3) overvoltage setup	Range	Unit	Default	Related control mode			
		0 to 100	0.1V	0	P	S	T	F

Set up the excessive level of the input voltage of analog input 3 by using the voltage associated with offset.

Pr4.31	Positioning complete (In-position) range	Range	Unit	Default	Related control mode			
		0 to 262144	Command unit	10	P			F

Set up the timing of positional deviation at which the positioning complete signal (INP1) is output.

Caution The command unit is used as the default unit but can be replaced by the encoder unit by using Pr5.20. Positioning unit selection. Note that when the encoder unit is used, unit of Pr0.14 Positional deviation excess setup is also changed.

Note For description of “command unit” and “encoder unit”, refer to P.4-48 “Pr5.20”.

Pr4.32	Positioning complete (In-position) output setup	Range	Unit	Default	Related control mode			
		0 to 3	—	0	P			F

Select the condition to output the positioning complete signal (INP1).

Setup value	Action of positioning complete signal
[0]	The signal will turn on when the positional deviation is smaller than Pr4.31 (Positioning complete range)
1	The signal will turn on when there is no position command and the positional deviation is smaller than Pr4.31 (Positioning complete range).
2	The signal will turn on when there is no position command, the zero-speed detection signal is ON and the positional deviation is smaller than Pr4.31 (Positioning complete range).
3	The signal will turn on when there is no position command and the positional deviation is smaller than Pr4.31 (Positioning complete range). Then holds "ON" status until the next position command is entered. Subsequently, ON state is maintained until Pr4.33 INP hold time has elapsed. After the hold time, INP output will be turned ON/OFF according to the coming positional command or condition of the positional deviation.

Pr4.33	INP hold time	Range	Unit	Default	Related control mode			
		0 to 30000	1ms	0	P			F

Set up the hold time when Pr4.32 Positioning complete output setup = 3.

Setup value	State of positioning complete signal
[0]	The hold time is maintained definitely, keeping ON state until the next positional command is received.
1 to 30000	ON state is maintained for setup time (ms) but switched to OFF state as the positional command is received during hold time.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 4] I/F monitor setting

Default: []


Pr4.34 Zero-speed

Range	Unit	Default	Related control mode			
10 to 20000	r/min	50	P	S	T	F

You can set up the timing to feed out the zero-speed detection output signal (ZSP or TCL) in rotational speed [r/min].

The zero-speed detection signal (ZSP) will be fed out when the motor speed falls below the setup of this parameter, Pr4.34.

- The setup of Pr4.34 is valid for both Positive and Negative direction regardless of the motor rotating direction.
- There is hysteresis of 10 [r/min].




Pr4.35 Speed coincidence range

Range	Unit	Default	Related control mode			
10 to 20000	r/min	50	S	T		

Set the speed coincidence (V-COIN) output detection timing.

Output the speed coincidence (V-COIN) when the difference between the speed command and the motor speed is equal to or smaller than the speed specified by this parameter.



*1 Because the speed coincidence detection is associated with 10 r/min hysteresis, actual detection range is as shown below.

Speed coincidence output OFF → ON timing $(Pr4.35 - 10) \text{ r/min}$

Speed coincidence output ON → OFF timing $(Pr4.35 + 10) \text{ r/min}$

Note

- A parameter is designated as follows: Class $\underline{Pr0.00}$ Parameter No.
- **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 4] I/F monitor setting

Default: []

Pr4.36	At-speed (Speed arrival)	Range	Unit	Default	Related control mode		
		10 to 20000	r/min	1000	S	T	

Set the detection timing of the speed arrival output (AT-SPEED).
When the motor speed exceeds this setup value, the speed arrival output (AT-SPEED) is output.
Detection is associated with 10 r/min hysteresis.

Pr4.37	Mechanical brake action at stalling setup	Range	Unit	Default	Related control mode				
		0 to 10000	1ms	0	P	S	T	F	

You can set up the time from when the brake release signal (BRK-OFF) turns off to when the motor is de-energized (Servo-free), when the motor turns to Servo-OFF while the motor is at stall.

- Set up to prevent a micro-travel/ drop of the motor (work) due to the action delay time (tb) of the brake
- After setting up $Pr4.37 \geq tb$, then compose the sequence so as the driver turns to Servo-OFF after the brake is actually activated.

Pr4.38	Mechanical brake action at running setup	Range	Unit	Default	Related control mode				
		0 to 10000	1ms	0	P	S	T	F	

You can set up time from when detecting the off of Servo-ON input signal (SRV-ON) is to when external brake release signal (BRK-OFF) turns off, while the motor turns to servo off during the motor in motion.

- Set up to prevent the brake deterioration due to the motor running.
- At Servo-OFF during the motor is running, tb of the right fig. will be a shorter one of either Pr4.38 setup time, or time lapse till the motor speed falls below Pr4.39 setup speed.

1. Details of parameter

[Class 4] I/F monitor setting

Default: []

Pr4.39	Brake release speed setup	Range	Unit	Default	Related control mode			
		30 to 3000	r/min	30	P	S	T	F

Set up the speed timing of brake output checking during operation.

Pr4.40	Selection of alarm output 1	Range	Unit	Default	Related control mode			
		0 to 10	—	0	P	S	T	F

Pr4.41	Selection of alarm output 2	Range	Unit	Default	Related control mode			
		0 to 10	—	0	P	S	T	F

Select the type of alarm issued as the alarm output 1 or 2.

Setup value	Alarm	Content
[0]	—	ORed output of all alarms.
1	Overload protection	Load factor is 85% or more the protection level.
2	Over-regeneration alarm	Regenerative load factor is 85% or more the protection level.
3	Battery alarm	Battery voltage is 3.2 V or lower.
4	Fan alarm	Fan has stopped for 1 sec. *1
5	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.
6	Encoder overheat alarm	The encoder detects overheat alarm.
7	Oscillation detection alarm	Oscillation or vibration is detected.
8	Lifetime detection alarm	Life expectancy of capacitor or fan becomes short.
9	External scale error alarm	The external scale detects the alarm.
10	External scale communication alarm	The number of successive external scale communication errors exceeds the specified value.

*1 The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal.

Related page

For detailed description of alarm types, refer to P.3-46, 47.

Pr4.42	2nd Positioning complete (In-position) range	Range	Unit	Default	Related control mode			
		0 to 262144	Command unit	10	P			F

The INP2 turns ON whenever the positional deviation is lower than the value set up in this parameter, without being affected by Pr4.32 Positioning complete output setup. (Presence/absence of positional command is not related to this judgment.)

Caution

The command unit is used as the default unit but can be replaced by the encoder unit by using Pr5.20. Positioning unit selection. Note that when the encoder unit is used, unit of Pr0.14 Positional deviation excess setup is also changed.

Note

For description of “command unit” and “encoder unit”, refer to P.4-48 “Pr5.20”.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

Default: []

Pr5.00	2nd numerator of electronic gear	Range	Unit	Default	Related control mode		
		0 to 2 ³⁰	—	0	P		F
Pr5.01	3rd numerator of electronic gear	Range	Unit	Default	Related control mode		
		0 to 2 ³⁰	—	0	P		F
Pr5.02	4th numerator of electronic gear	Range	Unit	Default	Related control mode		
		0 to 2 ³⁰	—	0	P		F

Set the 2nd to 4th numerator of division/multiplication operation made according to the command pulse input.

This setup is enabled when Pr0.08 command pulse counts per one motor revolution = 0 or full closed controlling.

When the setting value is 0 for positioning controlling, encoder resolution is set as a numerator.

When the setting value is 0 for full closed controlling, both numerator and denominator are set to 1.

Pr5.03 *	Denominator of pulse output division	Range	Unit	Default	Related control mode			
		0 to 262144	—	0	P	S	T	F

For details, refer to P.4-10.

Pr5.04 *	Over-travel inhibit input setup	Range	Unit	Default	Related control mode			
		0 to 2	—	1	P	S	T	F

Set up the operation of the run-inhibition (POT, NOT) inputs.

Setup value	Operation
0	POT → Inhibit positive direction travel NOT → Inhibit negative direction travel
[1]	Disable POT, NOT
2	POT or NOT input activates Err38.0 Run-inhibition input protection.

Pr5.05 *	Sequence at over-travel inhibit	Range	Unit	Default	Related control mode			
		0 to 2	—	0	P	S	T	F

When Pr5.04 Over-travel inhibition = 0, specify the status during deceleration and stop after application of the over-travel inhibition (POT, NOT).

<Details of Pr5.05 (Sequence at over-travel inhibit)>

Pr5.04	Pr5.05	During deceleration	After stalling	Deviation counter content
0	[0]	Dynamic brake action	Torque command=0 towards inhibited direction	Hold
	1	Torque command=0 towards inhibited direction	Torque command=0 towards inhibited direction	Hold
	2	Emergency stop	Command=0 towards inhibited direction	Clears before/ after deceleration

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”
- P.6-2 “Protective Function”

1. Details of parameter

[Class 5] Enhancing setting

Default: []

Pr5.06	Sequence at Servo-Off	Range	Unit	Default	Related control mode			
		0 to 9	—	0	P	S	T	F

Specify the status during deceleration and after stop, after servo-off.

Setup value	During deceleration ^{*3}	After stalling	Positional deviation/ external scale deviation
[0]	Dynamic Brake (DB) action	Dynamic Brake (DB) action	Clear ^{*4}
1	Free-run (DB OFF)	Dynamic Brake (DB) action	Clear ^{*4}
2	Dynamic Brake (DB) action	Free-run (DB OFF)	Clear ^{*4}
3	Free-run (DB OFF)	Free-run (DB OFF)	Clear ^{*4}
4	Dynamic Brake (DB) action	Dynamic Brake (DB) action	Hold ^{*2}
5	Free-run (DB OFF)	Dynamic Brake (DB) action	Hold ^{*2}
6	Dynamic Brake (DB) action	Free-run (DB OFF)	Hold ^{*2}
7	Free-run (DB OFF)	Free-run (DB OFF)	Hold ^{*2}
8	Emergency stop ^{*1}	Dynamic Brake (DB) action	Clear ^{*4}
9	Emergency stop ^{*1}	Free-run (DB OFF)	Clear ^{*4}

^{*1} Emergency stop refers to a controlled immediate stop with servo-on.
The torque command value is limited during this process by Pr5.11 Emergency stop torque setup.

^{*2} If the positional command is kept applied or the motor is kept running with servo-off condition, positional deviation is accumulated, causing Err24.0 Excess positional deviation protection to be issued. If the servo is turned ON while the position or external scale is significantly deviating, the motor may rapidly operate to reduce the deviation to 0. Remember these requirements if you want to maintain the positional deviation/external scale deviation.

^{*3} Deceleration period is the time required for the running motor to speed down to 30 r/min. Once the motor speed drops below 30 r/min, it is treated as in stop state regardless of its speed.

^{*4} Positional deviation/external scale deviation is always cleared to 0.

Caution ❗ If an error occurs during servo-off, follow Pr5.10 Sequence at alarm. If the main power is turned off during servo-off, follow Pr5.07 Sequence during main power interruption.

Related page ❖ Refer to P.2-63, "Timing Chart"-Servo-ON/OFF action while the motor is at stall" of Preparation as well.

Pr5.07	Sequence at main power OFF	Range	Unit	Default	Related control mode			
		0 to 9	—	0	P	S	T	F

Specify the status during deceleration after main power interrupt or after stoppage.
The relationship between the setup value of Pr5.06 and the operation and process at deviation counters is the same as that for Pr5.07 (sequence at main power OFF).

Caution ❗ If an error occurs with the main power supply turned off, Pr5.10 Sequence at alarm is applied to the operation.
When the main power supply is turned off with servo-on state, Err13.1 Main power undervoltage error occurs if Pr5.08 LV trip selection with main power off = 1, and the operation follows Pr5.10 Sequence at alarm.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.

Related page ❖ P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 5] Enhancing setting

Default: []

Pr5.08	LV trip selection at main power OFF	Range	Unit	Default	Related control mode			
		0 to 1	—	1	P	S	T	F

You can select whether or not to activate Err13.1 (Main power under-voltage protection) function while the main power shutoff continues for the setup of Pr5.09 (Main power-OFF detection time).

Setup value	Action of main power low voltage protection
0	When the main power is shut off during Servo-ON, Err13.1 will not be triggered and the driver turns to Servo-OFF. The driver returns to Servo-ON again after the main power resumption.
[1]	When the main power is shut off during Servo-ON, the driver will trip due to Err13.1 (Main power low voltage protection).

Caution

This parameter is invalid when Pr5.09 (Detection time of main power OFF)=2000. Err13.1 (Main power under-voltage protection) is triggered when setup of P5.09 is long and P-N voltage of the main converter falls below the specified value before detecting the main power shutoff, regardless of the Pr5.08 setup.

Pr5.09 *	Detection time of main power off	Range	Unit	Default	Related control mode			
		70 to 2000	1ms	70	P	S	T	F
You can set up the time to detect the shutoff while the main power is kept shut off continuously. The main power off detection is invalid when you set up this to 2000.								

Pr5.10	Sequence at alarm	Range	Unit	Default	Related control mode			
		0 to 7	—	0	P	S	T	F
Specify the status during deceleration and after stop, after occurrence of alarm.								
Setup value	During deceleration *3	After stalling	Positional deviation/ external scale deviation					
[0]	Dynamic Brake (DB) action	Dynamic Brake (DB) action	Hold *1					
1	Free-run (DB OFF)	Dynamic Brake (DB) action	Hold *1					
2	Dynamic Brake (DB) action	Free-run (DB OFF)	Hold *1					
3	Free-run (DB OFF)	Free-run (DB OFF)	Hold *1					
4	Action A: Emergency stop Action B: DB action *2	Dynamic Brake (DB) action	Hold *1					
5	Action A: Emergency stop Action B: DB OFF *2	Dynamic Brake (DB) action	Hold *1					
6	Action A: Emergency stop Action B: DB action *2	Free-run (DB OFF)	Hold *1					
7	Action A: Emergency stop Action B: DB OFF *2	Free-run (DB OFF)	Hold *1					
*1 Positional deviation/external scale deviation is maintained during alarm condition and will be cleared when the alarm is cancelled.								
*2 Action of A/B: When an alarm requiring emergency stop occurs, the action A is selected when the setup value in the table is set within the range 4 to 7, causing emergency stop of operation. When an alarm not requiring emergency stop occurs, it triggers dynamic braking (DB) specified by action B, or free-running.								
*3 Deceleration period is the time required for the running motor to speed down to 30 r/min.								

1. Details of parameter

[Class 5] Enhancing setting

Default: []

Pr5.11	Torque setup for emergency stop	Range	Unit	Default	Related control mode			
		0 to 500	%	0	P	S	T	F
Set up the torque limit at emergency stop.								
<div>Note</div> When setup value is 0, the torque limit for normal operation is applied.								

Pr5.12	Over-load level setup	Range	Unit	Default	Related control mode			
		0 to 500	%	0	P	S	T	F
<ul style="list-style-type: none">• You can set up the over-load level. The overload level becomes 115 [%] by setting up this to 0.• Use this with 0 setup in normal operation. Set up other value only when you need to lower the over-load level.• The setup value of this parameter is limited by 115[%] of the motor rating.								

Pr5.13	Over-speed level setup	Range	Unit	Default	Related control mode			
		0 to 20000	r/min	0	P	S	T	F
<div><div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><div></div><div></div></div><div><div></div><</div></div>								

Pr5.14	Motor working range setup	Range	Unit	Default	Related control mode			
		0 to 1000	0.1 revolution	10	P	S	T	F
<div><div></div><div><ul style="list-style-type: none">• You can set up the movable range of the motor against the position command input range.• When the motor movement exceeds the setup value, software limit protection of Err34.0 will be triggered.</div></div>								

Pr5.15 *	I/F reading filter	Range	Unit	Default	Related control mode			
		0 to 3	—	0	P	S	T	F
Select reading period of the control input signal.								
Setup value		Reading period of the signal.						
[0]		0.166ms						
1		0.333ms						
2		1ms						
3		1.666ms						
Exclude deviation counter clear input (CL) and command pulse inhibit input (INH).								

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”
- P.6-2 “Protective Function”

1. Details of parameter

[Class 5] Enhancing setting

Default: []

Pr5.16 *	Alarm clear input setup	Range	Unit	Default	Related control mode			
		0 to 1	—	0	P	S	T	F

Select alarm clear input (A-CLR) recognition time.

Setup value	Recognition time
[0]	120ms
1	To Pr5.15 IF reading filter

Pr5.17	Counter clear input mode	Range	Unit	Default	Related control mode			
		0 to 4	—	3	P			F

You can set up the clearing conditions of the counter clear input signal.

Setup value	Clear condition
0	Invalid
1	Clear at a level (no reading filter)
2	Clear at a level (with reading filter)
[3]	Clear at an edge (no reading filter)
4	Clear at an edge (with reading filter)

Note For signal width/timing requiring the deviation counter input, refer to P.3-38.

Pr5.18	Invalidation of command pulse inhibit input	Range	Unit	Default	Related control mode			
		0 to 1	—	1	P			F

Select command pulse inhibit input enable/disable.

Setup value	INH input
0	Valid
[1]	Invalid

Pr5.19 *	Command pulse inhibit input reading setup	Range	Unit	Default	Related control mode			
		0 to 4	—	0	P			F

Select command pulse inhibit input enable/disable signal reading period. When the status of several signals read during the predetermined reading period are same, update the signal status.

Setup value	Signal reading period
[0]	0.166ms
1	0.333ms
2	1ms
3	1.666ms
4	0.166 ms (no check for multiple coincidence)

Caution Longer reading period protects against operation error due to noise but decreases response to input signal.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”
- P.6-2 “Protective Function”

1. Details of parameter

[Class 5] Enhancing setting

Pr5.20 *	Position setup unit select	Range	Unit	Default	Related control mode		
		0 to 1	—	0	P		F

Specify the unit to determine the range of positioning complete and excessive positional deviation.

Setup value	Unit
[0]	Command unit
1	Encoder unit

Note The command unit defines 1 command pulse from the higher level device as setting value 1, while the encoder unit defines 1 encoder pulse as setting value 1.
When the electronic gear ratio set by using the command division and multiplication function (electronic gear) is R, the following relationship is obtained.

Command unit × R = encoder unit

For example, if 20-bit encoder is used with the default setting,

$$R = \frac{2^{20}}{10000}, \text{ then, command unit } \frac{2^{20}}{10000} = \text{encoder unit.}$$

Pr5.21	Selection of torque limit	Range	Unit	Default	Related control mode		
		0 to 6	—	1	P	S	F

You can set up the torque limiting method.

Setup value	Positive direction	Negative direction
0	P-ATL (0 to 10V)	N-ATL (−10 to 0V)
[1]	1st torque limit (Pr0.13)	
2	1st torque limit (Pr0.13)	2nd torque limit (Pr5.22)
3	TL-SEL OFF → 1st torque limit (Pr0.13) TL-SEL ON → 2nd torque limit (Pr5.22)	
4	P-ATL (0 to 10V)	N-ATL (0 to 10V)
5	P-ATL (0 to 10V)	
6	TL-SEL OFF	
	1st torque limit (Pr0.13)	2nd torque limit (Pr5.22)
	TL-SEL ON	
	External input positive direction torque limit (Pr5.25)	External input negative direction torque limit (Pr5.26)

Pr5.22	2nd torque limit	Range	Unit	Default	Related control mode		
		0 to 500	%	500	P	S	F

You can set up the 2nd limit value of the motor output torque.
The value of parameter is limited to the maximum torque of the applicable motor.

Note For details of torque limit value, refer to P.2-82.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

• P.2-82 “Setup of Torque Limit” • P.3-30... “Inputs and outputs on connector X4” • P.6-2 “Protective Function”

1. Details of parameter

[Class 5] Enhancing setting

Default: []

Pr5.23	Torque limit switching setup 1	Range	Unit	Default	Related control mode		
		0 to 4000	ms/100%	0	P	S	F

Specify the rate of change (slope) from 1st to 2nd during torque limit switching.

Pr5.24	Torque limit switching setup 2	Range	Unit	Default	Related control mode		
		0 to 4000	ms/100%	0	P	S	F

Specify the rate of change (slope) from 2nd to 1st during torque limit switching.

Pr5.25	External input positive direction torque limit	Range	Unit	Default	Related control mode		
		0 to 500	%	500	P	S	F

Set up positive direction torque limit upon receiving TL-SEL with Pr5.21 Selection of torque limit set at 6.

The value of parameter is limited to the maximum torque of the applicable motor.

Note

For details of torque limit value, refer to P.2-82.

Pr5.26	External input negative direction torque limit	Range	Unit	Default	Related control mode		
		0 to 500	%	500	P	S	F

Set up negative direction torque limit upon receiving TL-SEL with Pr5.21 Selection of torque limit set at 6.

The value of parameter is limited to the maximum torque of the applicable motor.

Note

For details of torque limit value, refer to P.2-82.

Pr5.27	Input gain of analog torque limit	Range	Unit	Default	Related control mode		
		10 to 100	0.1V/100%	30	P	S	F

From the voltage [V] applied to the analog torque limit input (P-ATL, N-ATL), set conversion gain to torque limit [%].

Note

• A parameter is designated as follows: Class Pr0.00 Parameter No.

• **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

• P.2-82 “Setup of Torque Limit” • P.3-30... “Inputs and outputs on connector X4” • P.6-2 “Protective Function”

1. Details of parameter

[Class 5] Enhancing setting

Default: []

Pr5.28 * LED initial status

Range

0 to 35

Unit

—


Default

1

Related control mode

P S T F

You can select the type of data to be displayed on the front panel LED (7 segment) at the initial status after power-on.



Setup value	Content	Setup value	Content	Setup value	Content
0	Positional command deviation	12	Error factor and reference of history	24	Encoder positional deviation [Encoder unit]
[1]	Motor speed	13	Alarm Display	25	External scale deviation [External scale unit]
2	Positional command speed	14	Regenerative load factor	26	Hybrid deviation [Command unit]
3	Velocity control command	15	Over-load factor	27	Voltage across PN [V]
4	Torque command	16	Inertia ratio	28	Software version
5	Feedback pulse sum	17	Factor of no-motor running	29	Driver serial number
6	Command pulse sum	18	No. of changes in I/O signals	30	Motor serial number
8	External scale feedback pulse sum	20	Absolute encoder data	31	Accumulated operation time
9	Control mode	21	Absolute external scale position	32	Automatic motor recognizing function
10	I/O signal status	22	No. of encoder/ external scale communication errors monitor	33	Temperature information
11	Analog input value	23	Communication axis address	35	Safety condition monitor

Related page

For details of display, refer to P.2-86 "How to Use the Front Panel" of Preparation.

Pr5.29 * Baud rate setup of RS232 communication

Range

0 to 6

Unit

—

Default

2

Related control mode

P S T F

You can set up the communication speed of RS232.

Note

For baud rate setup value, refer to RS485 setup.

Pr5.30 * Baud rate setup of RS485 communication

Range

0 to 6

Unit

—

Default

2

Related control mode

P S T F

You can set up the communication speed of RS485.

Setup value	Baud rate	Setup value	Baud rate
0	2400bps	4	38400bps
1	4800bps	5	57600bps
[2]	9600bps	6	115200bps
3	19200bps		

Baud rate error is $\pm 0.5\%$ for 2400 to 38400 bps, and $\pm 2\%$ for 57,600 to 115,200 bps.

Note

• Only for position control type is not provided with X2 (Communication connector).

1. Details of parameter

[Class 5] Enhancing setting

Pr5.31 *	Axis address	Range	Unit	Default	Related control mode			
		0 to 127	—	1	P	S	T	F

During communication with the host (e.g. PC) to control multiple shafts, the shaft being accessed by the host should be identified.

Note When using RS232/RS485, the maximum valid value is 31.

Pr5.32 *	Command pulse input maximum setup	Range	Unit	Default	Related control mode			
		250 to 4000	k pulse/s	4000	P			F

Set the maximum number of pulses to be used as command pulse input. If the number of input pulses exceeds the setup value × 1.2, Err27.0 Command pulse input frequency error protection occurs.

Caution The number of input pulses received by the driver is always checked. If the frequency of the received pulse is higher than the upper limit of the setting, input pulses are not accurately detected.

By selecting a value lower than 1000, a digital filter of the specification shown below is enabled against the command pulse input.

Pr5.32 setting range	Digital filter
250 to 499	200 ns 2-time reading
500 to 999	100 ns 2-time reading
1000 or more	No reading (thru)

Pr5.33 *	Pulse regenerative output limit setup	Range	Unit	Default	Related control mode			
		0 to 1	—	0	P	S	T	F

Enable/disable detection of Err28.0 Pulse regenerative limit protection.

Setup value	Content
[0]	Invalid
1	Valid

Pr5.34	For manufacturer's use	Range	Unit	Default	Related control mode			
		—	—	4				

Fixed to 4.

Pr5.35 *	Front panel lock setup	Range	Unit	Default	Related control mode			
		0 to 1	—	0	P	S	T	F

Lock the operation on the front panel.

Setup value	Content
[0]	No limit on the front panel operation
1	Lock the operation on the front panel

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.
- P.3-30... “Inputs and outputs on connector X4”

Related page

1. Details of parameter

[Class 6] Special setting

Default: []

Pr6.00	Analog torque feed forward conversion gain	Range	Unit	Default	Related control mode		
		0 to 100	0.1V/100%	0	P	S	F

• Set the input gain of analog torque feed forward.
 0 to 9 are invalid.

<Usage example of Analog torque feed forward>

• Setting bit 5 place of Pr6.10 Function expansion setup to 1 enables the analog torque feed forward. When the analog input 3 is used by another function (e.g. analog torque limit), the function becomes invalid.

• The voltage (V) applied to the analog input 3 is converted to the torque via Pr6.00 Analog torque feed forward conversion gain setup and added to the torque command (%): in CCW direction if it is positive voltage or in CW direction if negative.

• The conversion of analog input 3, input voltage [V], to the torque command [%] to the motor may be expressed mathematically as follows:


$$\text{Torque command (\%)} = 100 \times \text{input voltage (V)} / (\text{Pr6.00 setup value} \times 0.1)$$

Pr6.02	Velocity deviation excess setup	Range	Unit	Default	Related control mode		
		0 to 100	r/min	0	P		

When the speed deviation (difference between internal positional command and actual speed) exceeds this value, Err24.1 Speed over deviation protection occurs.
 This protection is not detected when the setup value is 0.

Pr6.04	JOG trial run command speed	Range	Unit	Default	Related control mode			
		0 to 500	r/min	300	P	S	T	F

Set up the command speed used for JOG trial run (velocity control).

 Before using, refer to P.4-59 Preparation Trial Run.

Pr6.05	Position 3rd gain valid time	Range	Unit	Default	Related control mode			
		0 to 10000	0.1ms	0	P			F


• Set up the time at which 3rd gain becomes valid.
 • When not using this parameter, set Pr6.05 to 0 and Pr6.06 to 100.
 • This is valid for only position control/full-closed control.

Pr6.06	Position 3rd gain scale factor	Range	Unit	Default	Related control mode			
		50 to 1000	%	100	P			F

• Set up the 3rd gain by a multiplying factor of the 1st gain:
 • 3rd gain = 1st gain × Pr6.06/100

Note 

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

 **Related page**

- P.3-30... “Inputs and outputs on connector X4” • P.6-2 “Protective Function”

1. Details of parameter

[Class 6] Special setting

Default: []

Pr6.07	Torque command additional value	Range	Unit	Default	Related control mode		
		−100 to 100	%	0	P	S	F
<ul style="list-style-type: none">• Set up the offset load compensation value usually added to the torque command in a control mode except for the torque control mode.• Update this parameter when the vertical axis mode for real time auto-tuning is valid.							

Pr6.08	Positive direction torque compensation value	Range	Unit	Default	Related control mode		
		−100 to 100	%	0	P		F
<div><ul style="list-style-type: none">• Set up the dynamic friction compensation value to be added to the torque command when forward positional command is fed.• Update this parameter when the friction compensation mode for real time auto-tuning is valid.</div>							

Pr6.09	Negative direction torque compensation value	Range	Unit	Default	Related control mode		
		−100 to 100	%	0	P		F
<div><ul style="list-style-type: none">• Set up the dynamic friction compensation value to be added to the torque command when negative direction positional command is fed.• Update this parameter when the friction compensation mode for real time auto-tuning is valid.</div>							

Pr6.10	Function expansion setup	Range	Unit	Default	Related control mode			
		0 to 63	—	0	P	S	T	F
Set up the function in unit of bit.								
	Function	Setup value						
		[0]	1					
bit 0	Speed observer	Invalid	Valid					
bit 1	Disturbance observer	Invalid	Valid					
bit 2	Disturbance observer operation setup	Always valid	Valid only when 1st gain is selected.					
bit 3	Inertia ratio switching	Invalid	Valid					
bit 4	Current response improvement	Invalid	Valid					
bit 5	Analog torque FF	Invalid	Valid					
* bit 0 = LSB								

Pr6.11	Current response setup	Range	Unit	Default	Related control mode			
		50 to 100	%	100	P	S	T	F
Fine tune the current response with respect to default setup (100%).								

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”, changed contents will be validated when you turn on the control power.
- P.3-30... “Inputs and outputs on connector X4”

Related page

1. Details of parameter

[Class 6] Special setting

Default: []

Pr6.13	2nd Inertia ratio	Range	Unit	Default	Related control mode									
		0 to 10000	%	250	P	S	T	F						
<p>Set 2nd inertia ratio.</p> <p>You can set up the ratio of the load inertia against the rotor (of the motor) inertia.</p> <div>Pr6.13 = (load inertia/ rotor inertia) × 100 [%]</div> <p>Caution If the inertia ratio is correctly set, the setup unit of Pr1.01 and Pr1.06 becomes (Hz). When the inertia ratio of Pr0.04 is larger than the actual, the setup unit of the velocity loop gain becomes larger, and when the inertia ratio of Pr0.04 is smaller than the actual, the setup unit of the velocity loop gain becomes smaller.</p>														
Pr6.14	Emergency stop time at alarm	Range	Unit	Default	Related control mode									
		0 to 1000	1ms	200	P	S	T	F						
<p>Set up the time allowed to complete emergency stop in an alarm condition. Exceeding this time puts the system in alarm state.</p> <p>When setup value is 0, immediate stop is disabled and the immediate alarm stop is enabled.</p>														
Pr6.15	2nd over-speed level setup	Range	Unit	Default	Related control mode									
		0 to 20000	r/min	0	P	S	T	F						
<p>When the motor speed exceeds this setup time during emergency stop sequence in an alarm condition, Err26.1 2nd overspeed protection will be activated.</p> <p>The over-speed level becomes 1.2 times of the motor max. speed by setting up this to 0.</p>														
Pr6.17 *	Front panel parameter writing selection	Range	Unit	Default	Related control mode									
		0 to 1	—	0	P	S	T	F						
<p>Specify the EEPROM writing procedure when parameter is edited form the front panel.</p> <table><tr><th>Setup value</th><th>Writing</th></tr><tr><td>[0]</td><td>Do not write to EEPROM at the same time</td></tr><tr><td>1</td><td>Write to EEPROM at the same time</td></tr></table>									Setup value	Writing	[0]	Do not write to EEPROM at the same time	1	Write to EEPROM at the same time
Setup value	Writing													
[0]	Do not write to EEPROM at the same time													
1	Write to EEPROM at the same time													
Pr6.18 *	Power-up wait time	Range	Unit	Default	Related control mode									
		0 to 100	0.1s	0	P	S	T	F						
<p>Set up the standard initialization time (1.5 s + α) after power-up.</p>														

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.
- P.2-107 “EEPROM Writing Mode” • P.3-30... “Inputs and outputs on connector X4”

Related page

1. Details of parameter

[Class 6] Special setting

Default: []

Pr6.19 *	Encoder Z phase setup	Range	Unit	Default	Related control mode			
		0 to 32767	pulse	0	P	S	T	F

If the number of output pulses per one motor revolution after division of pulse output is not an integer, fine adjust the width of encoder Z phase.

Pr6.20 *	Z-phase setup of external scale	Range	Unit	Default	Related control mode			
		0 to 400	μs	0				F

Set up the Z phase regenerative width of external scale in unit of time. Even if the width of Z phase signal cannot be detected because the width equivalent of the travel distance from the external scale is too short, the Z phase signal will be output for at least the period set to this parameter.

Pr6.21 *	Serial absolute external scale Z phase setup	Range	Unit	Default	Related control mode			
		0 to 2 ²⁸	pulse	0				F

Full-closed control using serial absolute external scale. When outputting pulses by using the external scale as the source of the output, set the Z phase output interval in units of A phase output pulses of the external scale (before multiplied by 4).

Setup value	Content
[0]	Output Z phase only at absolute 0 position of external scale.
1 to 268435456	After the power is fed to the driver, the Z phase, as it crosses the zero at the absolute position of external scale, is output in synchronous with the A phase. Subsequently, the Z phase is output at the A phase output pulse intervals set to this parameter.

Pr6.22 *	A, B phase external scale pulse output method selection	Range	Unit	Default	Related control mode			
		0 to 1	—	0				F

Select the pulse regeneration method of A, B and Z parallel external scale.

Setup value	Regenerating method
[0]	Directly output the signals from A, B and Z parallel external scales.
1	Output A and B phase signals recovered from A, B and Z parallel external scales. Z-phase is output directly.

Pr6.23	Disturbance torque compensating gain	Range	Unit	Default	Related control mode			
		-100 to 100	%	0	P	S		

- Set up -100 to 100% compensating gain against disturbance torque.
- After setting up Pr6.24, increase Pr6.23.

The disturbance suppressing capability increases by increasing the gain, but it is associated with increasing volume of operation noise.

This means that well balanced setup can be obtained by adjusting Pr6.24 and Pr6.23.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.
- P.3-30... “Inputs and outputs on connector X4”

Related page

1. Details of parameter

[Class 6] Special setting

Default: []

Pr6.24	Disturbance observer filter	Range	Unit	Default	Related control mode			
		0 to 2500	0.01ms	53	P	S		

- Set up the filter time constant according to the disturbance torque compensation.
- First, set up Pr6.24 to a larger value and check the operation with Pr6.23 Disturbance torque compensating gain set to a low value, and then gradually decrease the setup value of Pr6.24. A low filter setup value assures disturbance torque estimation with small delay and effectively suppresses effects of disturbance. However, this results in larger operation noise. Well balanced setup is required.

Pr6.27 *	Alarm latch time selection	Range	Unit	Default	Related control mode			
		0 to 10	—	5	P	S	T	F

Set up the latch time.

Setup value	Content	
0	Latch time: infinite	
1	Latch time	1 [s]
2		2 [s]
3		3 [s]
4		4 [s]
[5]		5 [s]
6		6 [s]
7		7 [s]
8		8 [s]
9		9 [s]
10		10 [s]

Pr6.31	Real time auto tuning estimation speed	Range	Unit	Default	Related control mode			
		0 to 3	—	1	P	S	T	F

Set up the load characteristics estimation speed with the real time auto tuning being valid. A higher setup value assures faster response to a change in load characteristics but increases variations in disturbance estimation. Result of estimation is saved to EEPROM every 30 minutes.

Setup value	Mode	Description
0	No change	Stop estimation of load characteristics.
[1]	Almost constant	Response to changes in load characteristics in every minute.
2	Slower change	Response to changes in load characteristics in every second.
3 *	Faster change	Obtain best suitable estimation in response to changes in load characteristics.

* If the automatic oscillation detection is enabled by the support software PANATERM, the setup value 3 is used.

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- For parameters which No. have a suffix of “ * ”**, changed contents will be validated when you turn on the control power.
- The setup support software PANATERM can be downloaded from our web site.

Related page

- P.3-30... “Inputs and outputs on connector X4”

1. Details of parameter

[Class 6] Special setting

Pr6.32	Real time auto tuning custom setup	Range	Unit	Default	Related control mode					
		-32768 to 32767	—	0	P	S	T	F		
When the operation mode of real time auto tuning is set to the customize (Pr0.02 = 6), set the automatic adjusting function as shown below.										
Bit	Content	Description								
1 to 0	Load characteristics estimation *	Enable/disable the load characteristics estimation function.								
		Setup value	Function							
		[0]	Disable							
		1	Enable							
* If the load characteristics estimation is disabled, the current setup cannot be changed even if the inertia ratio is updated according to the estimated value. When the torque compensation is updated by the estimated value, it is cleared to 0 (invalid).										
3 to 2	Inertia ratio update	Set up update to be made based on result of the load characteristics estimation of Pr0.04 Inertia ratio.								
		Setup value	Function							
		[0]	Use the current setup.							
		1	Update by the estimated value.							
6 to 4	Torque compensation	Set up the update to be made according to the results of load characteristics estimation of Pr6.07 Torque command additional value, Pr6.08 positive direction torque compensation value and Pr6.09 negative direction torque compensation value.								
		Setup value	Function	Compensation setup						
		[0]	Use current setup	Pr6.07	Pr6.08	Pr6.09				
		1	Disable torque compensation	0 clear	0 clear	0 clear				
		2	Vertical axis mode	Update	0 clear	0 clear				
		3	Friction compensation (low)	Update	Low	Low				
		4	Friction compensation (middle)	Update	Middle	Middle				
		5	Friction compensation (high)	Update	High	High				
		7	Stiffness setup	Enable/disable the basic gain setup to be made according to Pr0.03 Real time auto tuning mechanical stiffness selection.						
				Setup value	Function					
[0]	Disable									
1	Enable									
8	Fixed parameter setup	Enable/disable the change of parameter that is normally set at a fixed value.								
		Setup value	Function							
		[0]	Use the current setup.							
		1	Set to a fixed value.							
10 to 9	Gain switching setup	Select the gain switching related parameter to be used when the real time auto tuning is enabled.								
		Setup value	Function							
		[0]	Use the current setup.							
		1	Disable gain switching.							
		2	Enable gain switching.							

(continued)

(continued)

1. Details of parameter

[Class 6] Special setting

Default: []

Caution

This parameter should be setup bit by bit. To prevent setting error, use of the setup support software is recommended when editing parameter.

<Setup procedure of bitwise parameter>

When setting parameter to a value other than 0, calculate the setup value of Pr6.32 in the following procedure.

- 1) Identify the LSB of the setup.

Example: LSB of the torque compensation function is 4.

- 2) Multiply the setup value by power of 2 (LSB).

Example: To set the torque compensation function to friction compensation (middle):

$$2^4 \times 4 = 64.$$

- 3) Perform steps 1) and 2) for every setups, sum up the values which are to be Pr6.32 setup value.

Example: Load characteristics measurement = enable, inertia ratio update = enable, torque compensation = friction compensation (middle), stiffness setup = enable, fixed parameter = set to a fixed value, gain switching setup = enable, then,

$$2^0 \times 1 + 2^2 \times 1 + 2^4 \times 4 + 2^7 \times 1 + 2^8 \times 1 + 2^9 \times 2 = 1477$$

Pr6.34	Hybrid vibration suppression gain	Range	Unit	Default	Related control mode			
		0 to 30000	0.1/s	0				F
Set up the hybrid vibration suppression gain for full-closed controlling. First set it to the value identical to that of poison loop gain, and then fine tune as necessary.								

Pr6.35	Hybrid vibration suppression filter	Range	Unit	Default	Related control mode			
		0 to 6400	0.01ms	10				F
Set up the time constant of the hybrid vibration suppression filter for full-closed controlling. While driving under full-closed control, gradually increase the setup value and check changes in the response.								

Pr6.37	Oscillation detecting level	Range	Unit	Default	Related control mode			
		0 to 1000	0.1%	0	P	S	T	F
Set up the oscillation detecting level. Upon detection of a torque vibration whose level is higher than this setup value, the oscillation detection alarm will be issued.								

Pr6.38 *	Alarm mask setup	Range	Unit	Default	Related control mode			
		-32768 to 32767	—	0	P	S	T	F
Set up the alarm detection mask. Placing 1 to the corresponding bit position disables detection of the alarm condition.								

Pr6.39	For manufacturer's use	Range	Unit	Default	Related control mode			
		—	—	0				
Fixed to 0.								

Note

- A parameter is designated as follows: Class Pr0.00 Parameter No.
- **For parameters which No. have a suffix of “*”,** changed contents will be validated when you turn on the control power.

Related page

- P.3-30... “Inputs and outputs on connector X4”

(1) Inspection on wiring


- Miswiring ? (Especially power input and motor output)
- Short or grounded ?
- Loose connection ?

(2) Confirmation of power supply and voltage

- Rated voltage ?

(3) Fixing of the servo motor

- Unstable mounting ?


(4) Separation from the mechanical system**(5) Release of the brake****(6) Turn to Servo-OFF after finishing the trial run by pressing .****Note**

- Details of wiring, refer to P.2-12... "Overall Wiring"
- The figure above shows connections on velocity, position, torque and full-closed mode driver.
- Only for position control type is not provided with X2 (Communication connector), X3 (Safety function connector), X5 (External scale connector).

Trial Run (JOG run) at Position Control Mode

- (1) Connect the Connector X4.
- (2) Enter the power (DC12 to 24V) to control signal (COM+, COM–)
- (3) Enter the power to the driver.
- (4) Confirm the default values of parameters.
- (5) Match to the output format of the host controller with Pr0.07 (Command pulse input mode setup).
- (6) Write to EEPROM and turn off/on the power (of the driver).
- (7) Connect the Servo-ON input (SRV-ON) and COM– (Connector X4, Pin-41) to bring the driver to Servo-ON status and energize the motor.
- (8) Enter low frequency from the host controller to run the motor at low speed.
- (9) Check the motor rotational speed at monitor mode whether, rotational speed is as per the setup or not, and the motor stops by stopping the command (pulse) or not.
- (10) If the motor does not run correctly, refer to P.2-100, "Display of Factor for No-Motor Running" of Preparation.

• Wiring Diagram



• Parameter

Pr No.	Title	Setup value
0.01	Control mode setup	0
5.04	Over-travel inhibit input setup	1
0.05	Selection of command pulse input	0/1
0.07	Command pulse input mode setup	1
5.18	Invalidation of command pulse inhibit input	1
5.17	Counter clear input mode	2

• Input signal status

No.	Title of signal	Monitor display
0	Servo-ON	+A

2.Trial Run (JOG run)


Trial Run by Connecting the Connector X4

Trial Run (JOG run) at Velocity Control Mode

- 1) Connect the Connector X4.
- 2) Enter the power (DC12 to 24V) to control signal (COM+, COM–)
- 3) Enter the power to the driver.
- 4) Confirm the default values of parameters.
- 5) Connect the Servo-ON input (SRV-ON, Connector X4, Pin-29) and COM– (Connector X4, Pin-14) to turn to Servo-ON and energize the motor.
- 6) Close the speed zero clamp input (ZEROSPD) and apply DC voltage between velocity command input , SPR (Connector X4, Pin-14) and GND (Connector X4, Pin-15), and gradually increase from 0V to confirm the motor runs.
- 7) Confirm the motor rotational speed in monitor mode.
 - Whether the rotational speed is per the setup or not.
 - Whether the motor stops with zero command or not.
- 8) If the motor does rotate at a micro speed with command voltage of 0.
- 9) When you want to change the rotational speed and direction, set up the following parameters again.
 - Pr3.00: Speed setup, Internal/External switching
 - Pr3.01: Speed command rotational direction selection
 - Pr3.03: Reversal of speed command input
- 10) If the motor does not run correctly, refer to P.2-100, "Display of Factor for No-Motor Running" of Preparation.

Refer to P.4-25, 26 "Parameter Setup" (Parameters for Velocity/Torque Control)

• Wiring Diagram



Run with ZEROSPD switch close, and Stop with open

In case of bi-directional operation (Positive/Negative), provide a bipolar power supply, or use with Pr3.15 = 3.

In case of one-directional operation

• Parameter

Pr No.	Title	Setup value
0.01	Control mode setup	1
5.04	Over-travel inhibit input setup	1
3.15	Speed zero-clamp function selection	1
3.00	Speed setup, Internal/External switching	Set up as required
3.01	Speed command rotational direction selection	
3.02	Input gain of speed command	
3.03	Reversal of speed command input	
4.22	Analog input 1 (AI1) offset setup	
4.23	Analog input 1 (AI1) filter	

• Input signal status

No.	Title of signal	Monitor display
0	Servo-ON	+A
5	Speed zero clamp	—

Note

- Only for position control type is not provided with analog input.

2.Trial Run (JOG run)


Trial Run by Connecting the Connector X4

Trial Run (JOG run) at Torque Control Mode

- 1) Connect the Connector X4.
- 2) Enter the power (DC12-24V) to control signal (COM+, COM–)
- 3) Enter the power to the driver.
- 4) Confirm the default values of parameters.
- 5) Set a lower value to Pr3.07 (4th speed of speed setup).
- 6) Energize the motor by connecting the Servo-ON input (SRV-ON, Connector X4, Pin-29) and COM– (Pin-41 of Connector X4) to turn to Servo-ON status.
- 7) Confirm that the motor runs as per the setup of Pr3.07 by applying DC voltage (positive/negative) between the torque command input (Pin-14 of Connector X4) and GND (Pin-15 of Connector X4).
- 8) If you want to change the torque magnitude, direction and velocity limit value against the command voltage, set up the following parameters.
Pr3.19: Input gain of torque command
Pr3.20: Input reversal of torque command
Pr3.21: Speed limit value 1
- 9) If the motor does not run correctly, refer to P.2-100, "Display of factor for No-motor running" of Preparation.

Refer to P.4-29, 30, "Parameter Setup"
(Parameters for Velocity/Torque Control)

• Wiring Diagram



For bi-directional running (Positive/Negative),
provide a bipolar power supply.

In case of one way running

• Parameter

Pr No.	Title	Setup value
0.01	Control mode setup	2
5.04	Over-travel inhibit input setup	1
3.15	Speed zero-clamp function selection	0
3.17	Selection of torque command	0
3.19	Input gain of torque command	Set up as required
3.20	Input reversal of torque command	
3.21	Speed limit value 1	lower value

• Input signal status

No.	Title of signal	Monitor display
0	Servo-ON	+A
5	Speed zero clamp	—

Note

- Only for position control type is not provided with analog input.


Input pulse frequency (pps)	Motor rotational speed (r/min)	Pr0.08	
		17-bit	20-bit
2M	3000	$\frac{2^{17}}{40000}$	$\frac{2^{20}}{40000}$
500K	3000	$\frac{2^{17}}{10000}$	$\frac{2^{20}}{10000}$
250K	3000	$\frac{2^{17}}{5000}$	$\frac{2^{20}}{5000}$
100K	3000	$\frac{2^{17}}{2000}$	$\frac{2^{20}}{2000}$
500K	1500	$\frac{2^{17}}{20000}$	$\frac{2^{20}}{20000}$

Note

When setting Pr0.08, and encoder resolution is automatically set up as numerators. For full closed controlling, setting of Pr0.08 is ignored and settings of Pr0.09 and Pr0.10 are always applied.

Caution

- Max. input pulse frequency varies depending on input terminals.
- The desired setting can be determined by selecting value of numerator and denominator of electronic gear. However, an excessively high division or multiplication ratio cannot guarantee the operation. The ratio should be in a range between 1/1000 and 1000. Excessively high multiplication ratio will cause Err27.2 (command pulse multiplication error protection) due to varying command pulse input or noises, even if the other settings are within the specified range.

Relation between the motor rotational speed and input pulse counts


Pulley ratio : $\frac{18}{60}$
 Gear ratio : $\frac{12}{73}$
 Total reduction ratio : $\frac{18}{365}$

When setting the command division and multiplication ratio as numerator/denominator, express it as Pr0.09/Pr0.10 with Pr0.08 = 0. For full closed controlling, setting of Pr0.08 is ignored and settings of Pr0.09 and Pr0.10 are always applied.

e.g.) When you want to rotate the motor by 60° with the load of total reduction ratio of 18/365.

	Encoder	
	17-bit	20-bit
Pr0.09	$\frac{5840}{108}$	$\frac{5840}{67500}$
Pr0.10	$\frac{108}{67500}$	$\frac{67500}{67500}$
Command pulse	To rotate the output shaft by 60°, enter the command of 8192 (2 ¹³) pulses from the host controller.	To rotate the output shaft by 60°, enter the command of 10000 pulses from the host controller.
How to determine parameter	$\frac{365}{18} \times \frac{1 \times 2^{17}}{2^{13}} \times \frac{60^\circ}{360^\circ} = \frac{5840}{108}$	$\frac{365}{18} \times \frac{1 \times 2^{20}}{10000} \times \frac{60^\circ}{360^\circ} = \frac{5840}{67500}$

2 ⁿ	Decimal figures
2 ⁰	1
2 ¹	2
2 ²	4
2 ³	8
2 ⁴	16
2 ⁵	32
2 ⁶	64
2 ⁷	128
2 ⁸	256
2 ⁹	512
2 ¹⁰	1024
2 ¹¹	2048
2 ¹²	4096
2 ¹³	8192
2 ¹⁴	16384
2 ¹⁵	32768
2 ¹⁶	65536
2 ¹⁷	131072
2 ¹⁸	262144
2 ¹⁹	524288
2 ²⁰	1048576

* Refer to P.2-84 "Setup of command division and multiplication ratio (electronic gear ratio)" of Supplement.

MEMO

Handwriting practice lines consisting of 20 sets of three horizontal dashed lines.

5. Adjustment

1. Gain Adjustment

Outline	5-2
---------------	-----

2. Real-Time Auto-Gain Tuning

Basic	5-4
-------------	-----

3. Adaptive filter

Adaptive filter	5-10
-----------------------	------

4. Manual Gain Tuning (Basic)

Outline	5-13
Adjustment in Position Control Mode	5-14
Adjustment in Velocity Control Mode	5-15
Adjustment in Torque Control Mode	5-15
Adjustment in Full-Closed Control Mode	5-16
Gain Switching Function	5-17
Suppression of Machine Resonance	5-20

5. Manual Gain Tuning (Application)

Damping Control	5-24
Feed forward function	5-26
Instantaneous Speed Observer	5-28
Disturbance observer	5-30
3rd gain switching function	5-32
Friction torque compensation	5-34
Inertia ratio switching function	5-36
Hybrid vibration damping function	5-38


6. About Homing Operation

Caution on Homing Operation	5-39
Homing with Hit & Stop	5-40
Press & Hold Control	5-41


Purpose

It is required for the servo driver to run the motor in least time delay and as faithful as possible against the commands from the host controller. You can make a gain adjustment so that you can run the motor as closely as possible to the commands and obtain the optimum performance of the machine.

<e.g. : Ball screw>



Procedures



Note

For safety operation, first adjust the gain by referring to P.6-18 Setup protective function before gain adjustment.

1. Gain Adjustment

Outline

Type


Function		Explanation	Pages to refer
Automatic adjustment	Real-time auto-gain tuning	Estimates the load inertia of the machine in real time, and automatically sets up the optimum gain corresponding to this result.	P.5-4
	Adaptive filter	Reduces the resonance vibration point by automatically setting up the notch filter coefficient which removes the resonance component from the torque command while estimating the resonance frequency from the vibrating component which appears in the motor speed in actual operating condition.	P.5-10
Manual adjustment	Manual gain tuning (basic)	Execute the manual adjustment or fine-tuning when real-time auto-gain tuning cannot be activated due to the limitation of operation or load condition, or when you want to obtain an optimum response and stability under these conditions.	P.5-13
	Basic procedure	Adjustment of position control mode	P.5-14
		Adjustment of velocity control mode	P.5-15
		Adjustment of torque control mode	P.5-15
		Adjustment of full-closed control mode	P.5-16
	Gain switching function	You can expect to reduce vibration at stopping and settling time and to improve command compliance by switching the gains by internal data or external signals.	P.5-17
	Suppression of machine resonance	When the machine stiffness is low, vibration or noise may be generated due to the distorted axis, hence you cannot set the higher gain. You can suppress the resonance with two kinds of filter.	P.5-20
	Manual gain tuning (application)	You can obtain the higher performance while you are not satisfied with the performance obtained with the basic adjustment, using the following application functions.	
	Damping control	Function which reduces vibration by removing the vibration frequency component while the front end of the machine vibrates.	P.5-24
	Feed forward function	Velocity feed forward function improves responsiveness during position control and full closed control. Torque feed forward improves the response of velocity control system.	P.5-26
	Instantaneous speed observer	Function which obtains both high response and reduction of vibration at stopping by estimating the motor speed with the load model, and hence improves the accuracy of speed detection.	P.5-28
	Disturbance observer	Function which uses estimated disturbance torque to reduce effects of the disturbance torque and to reduce vibration.	P.5-30
	3rd gain switching function	By using this function in addition to the normal gain switching function, the gain can be changed at the moment of stop to further shorten the positioning time.	P.5-32
	Friction torque compensation	Offset load compensation and dynamic friction compensation are used to reduce effects of mechanical friction.	P.5-34
	Inertia ratio switching function	This function can be used when selectable 2 inertia ratios are provided.	P.5-36
	Hybrid vibration damping function	This function, when used in full closed control mode, prevents vibration resulting from torsion on motor and load.	P.5-38

Remarks

- Pay extra attention to safety, when oscillation (abnormal noise and vibration) occurs, shut off the main power, or turn to Servo-OFF.

Outline

The system estimates the load characteristics in real time, and automatically performs basic gain setting and friction compensation by referring to stiffness parameter.



Applicable Range

Real time auto-gain tuning is applicable to all control modes.

	Real-time auto-tuning condition
Control Mode	Specific real-time auto-tuning mode is selected according to the currently active control mode. For details, refer to the description of Pr0.02 Real-time auto-tuning setup.
Others	<ul style="list-style-type: none"> • Should be in servo-on condition • Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

Caution

Real-time auto-gain tuning may not be executed properly under the conditions described in the table below. Under these conditions, change the load condition or operation pattern, or start manual gain tuning (see P.5-24).

	Conditions which obstruct real-time auto-gain tuning action
Load inertia	<ul style="list-style-type: none"> • The load is too small or large compared to the rotor inertia. (less than 3 times or more than 20 times). • The load inertia changes too quickly.
Load	<ul style="list-style-type: none"> • The machine stiffness is extremely low. • Nonlinear characteristics such as backlash exist.
Action pattern	<ul style="list-style-type: none"> • The motor is running continuously at low speed of (100 [r/min] or lower). • Acceleration/deceleration is slow (2000 [r/min] per 1[s] or low). • Acceleration/deceleration torque is smaller than unbalanced weighted/viscous friction torque. • When the speed condition of 100 [r/min] or more and acceleration/deceleration condition of 2000 [r/min] per 1 [s] are not maintained for 50 [ms].

How to Operate

- 1) Bring the motor to stall (Servo-OFF).
- 2) Set up Pr0.02 (Setup of real-time auto-gain tuning mode) to 1-6.

Default is set to 1.

Setup value	Real-time auto-gain tuning
0	Invalid
1	Standard
2	Positioning ^{*1}
3	Vertical axis ^{*2}
4	Friction compensation ^{*3}
5	Load characteristic measurement
6	Customize ^{*4}

- *1 Velocity and torque controls are the same as in the standard mode.
- *2 Torque control is the same as in the standard mode.
- *3 Velocity control is the same as in the vertical axis mode. Torque control is the same as in the standard mode.
- *4 Certain function(s) is not available in a specific control mode. Refer to description in Pr6.32.



Control parameter is automatically set according to Pr0.03 Real-time auto-tuning stiffness setup. For details, see P.5-6 and 5-7.

- 3) Turn on servo, and start the machine.



Estimation of load characteristics starts.

- 4) When the load characteristics are determined, Pr0.04 Inertia ratio is updated.
In a specific mode, the following parameters are changed:
Pr6.07 Torque command additional value
Pr6.08 Positive direction torque compensation value
Pr6.09 Negative direction torque compensation value
- 5) When value of Pr0.03 Real-time auto-tuning stiffness setup is increased, the motor responsiveness will be improved.
Determine the most appropriate stiffness in relation to the positioning setup time and vibration condition.
- 6) To save the result to memory, write the data to EEPROM.

Caution

If power is turned off within 30 minutes after the end of tuning process, the result of the real-time auto-tuning is not saved. If the result is not saved, manually write parameters to EEPROM and then turn off power.

Note

- While the auto-tuning is valid, parameters that are to be automatically adjusted cannot be changed.

Related page

- P.2-107 "EEPROM Writing Mode" • P.4-5, 4-6, 4-53, 4-57 "Details of parameter"

2. Real-Time Auto-Gain Tuning

Basic

Parameters set/changed by real-time auto-gain tuning

• Parameters which are updated

The real-time auto-tuning function updates the following parameters according to Pr0.02 Real-time auto-tuning setup and Pr6.32 Real-time auto-tuning custom setup and by using the load characteristic estimate values.

Class	No.	Title	Function
0	04	Inertia ratio	Updates this parameter when the real-time auto-tuning inertia ratio update is enabled.
6	07	Torque command additional value	Update this parameter when the vertical axis mode for real time auto-tuning is valid.
6	08	Positive direction torque compensation value	Update this parameter when the friction compensation mode for real time auto-tuning is valid.
6	09	Negative direction torque compensation value	Update this parameter when the friction compensation mode for real time auto-tuning is valid.

• Parameters which are updated to setup value corresponding to stiffness setup

The real-time auto-tuning function updates the following basic gain setup parameters according to Pr0.03 Real-time auto-tuning stiffness setup.

Class	No.	Title	Function
1	00	1st gain of position loop	When stiffness setup is valid, updates the parameter based on the setup value. Refer to P.5-9 Basic gain parameter setup table.
1	01	1st gain of velocity loop	
1	02	1st time constant of velocity loop integration	
1	04	1st time constant of torque filter	
1	05	2nd gain of position loop	
1	06	2nd gain of velocity loop	
1	07	2nd time constant of velocity loop integration	
1	09	2nd time constant of torque filter	

• Parameters which are set to fixed value

Real-time auto-tuning function sets the following parameters to the fixed value.

Class	No.	Title	Setup value when fixed parameter setup is valid.
1	03	1st filter of speed detection	0
1	08	2nd filter of speed detection	
1	10	Velocity feed forward gain	300 (30%)
1	11	Velocity feed forward filter	50 (0.5ms)
1	12	Torque feed forward gain	0
1	13	Torque feed forward filter	

2. Real-Time Auto-Gain Tuning

Basic

• Parameters which are set in response to gain switching setup

The real-time auto-tuning function sets the following parameters as the gain is switched.

Class	No.	Title	Function
1	14	2nd gain setup	Sets to 1 if the current setting is not maintained.
1	15	Mode of position control switching	Sets to 10 to enable the gain switching. Sets to 0 to disable the gain switching.
1	16	Delay time of position control switching	Sets to 50 if the current setting is not maintained.
1	17	Level of position control switching	
1	18	Hysteresis at position control switching	Sets to 33 if the current setting is not maintained.
1	19	Position gain switching time	
1	20	Mode of velocity control switching	Sets to 0 if the current setting is not maintained.
1	21	Delay time of velocity control switching	
1	22	Level of velocity control switching	
1	23	Hysteresis at velocity control switching	
1	24	Mode of torque control switching	
1	25	Delay time of torque control switching	
1	26	Level of torque control switching	
1	27	Hysteresis at torque control switching	

• Parameters which are always set to invalid.

The following settings are always set to invalid when Pr0.02 Real-time auto-tuning setup is not 0.

Class	No.	Title	Function
6	10	Function expansion setup	Instantaneous speed observer function enable bit (bit 0), disturbance observer function enable bit (bit 1) and inertia ratio switching function enable bit (bit 3) are internally disabled.
6	13	2nd Inertia ratio	Parameter setup can be changed, but disturbance observer is disabled.
6	23	Disturbance torque compensating gain	
6	24	Disturbance observer filter	

2. Real-Time Auto-Gain Tuning

Basic

Caution

- (1) Immediately after the first servo-on upon start up; or after increasing Pr0.03 Real-time auto-tuning stiffness setup, abnormal sound or oscillation may be generated until the load characteristics estimation is stabilized. If such abnormality lasts or repeats for 3 or more reciprocating operations, take the following countermeasures.
 - 1) Lower the setup of Pr0.03 (Selection of machine stiffness at real-time auto-gain tuning).
 - 2) Set Pr0.02 Real-time auto-tuning setup to 0 to disable the real-time auto-tuning.
 - 3) Set Pr0.04 Inertial ratio to the calculational value of the equipment and set Pr6.07 Torque command addition value, Pr6.08 Positive direction compensation value and Pr6.09 Negative direction compensation value to 0.
- (2) When abnormal noise and oscillation occur, Pr0.04 (Inertia ratio) or Pr6.07 (Torque command additional value), Pr6.08(Positive direction torque compensation value), Pr6.09(Negative direction torque compensation value) might have changed to extreme values. Take the same measures as the above in these cases.
- (3) Among the results of real-time auto-gain tuning, Pr0.04 (Inertia ratio) and Pr6.07 (Torque command additional value), Pr6.08(Positive direction torque compensation value), Pr6.09(Negative direction torque compensation value) will be written to EEPROM every 30 minutes. When you turn on the power again, the auto-gain tuning will be executed using the latest data as initial values.
- (4) Because the control gain is updated while the motor stops, changed setting value of Pr0.03 “Real-time auto-tuning stiffness setup” may not be reflected if the motor cannot stop due to excessively low gain or application of a command that directs the motor to turn in the same direction continuously. If the changed stiffness setting value is reflected after motor stops, it may generate abnormal sound or oscillate.
After changing stiffness, stop the motor and check to see that the new stiffness setting is made effective.

Invalidation of Real-Time Auto-Gain Tuning

You can stop the automatic calculation of Pr0.04 (Inertia ratio) and invalidate the real-time auto-gain tuning by setting up Pr0.02 (Real-time auto-gain tuning setup) to 0. Note that the calculation result of Pr0.04 (Inertia ratio) will be held, and if this parameter becomes abnormal value, use the normal mode auto-gain tuning or set up proper value manually obtained from formula or calculation.

Caution

If power is turned off within 30 minutes after the end of tuning process, the result of the real-time auto-tuning is not saved. If the result is not saved, manually write parameters to EEPROM and then turn off power.

2. Real-Time Auto-Gain Tuning

Basic

Basic gain parameter setup table

Stiffness	1st gain				2nd gain				A4 Series Stiffness setup (reference) *1
	Pr1.00	Pr1.01	Pr1.02	Pr1.04 *2	Pr1.05	Pr1.06	Pr1.07	Pr1.09 *2	
	Gain of position loop [0.1/s]	Gain of velocity loop [0.1Hz]	Time constant of velocity loop integration [0.1ms]	Time constant of torque filter [0.01ms]	Gain of position loop [0.1/s]	Gain of velocity loop [0.1Hz]	Time constant of velocity loop integration [0.1ms]	Time constant of torque filter [0.01ms]	
0	20	15	3700	1500	25	15	10000	1500	—
1	25	20	2800	1100	30	20	10000	1100	—
2	30	25	2200	900	40	25	10000	900	—
3	40	30	1900	800	45	30	10000	800	—
4	45	35	1600	600	55	35	10000	600	—
5	55	45	1200	500	70	45	10000	500	—
6	75	60	900	400	95	60	10000	400	—
7	95	75	700	300	120	75	10000	300	—
8	115	90	600	300	140	90	10000	300	0
9	140	110	500	200	175	110	10000	200	—
10	175	140	400	200	220	140	10000	200	—
11 *3	320	180	310	126	380	180	10000	126	1
12	390	220	250	103	460	220	10000	103	2
13 *3	480	270	210	84	570	270	10000	84	3
14	630	350	160	65	730	350	10000	65	4
15	720	400	140	57	840	400	10000	57	5
16	900	500	120	45	1050	500	10000	45	6
17	1080	600	110	38	1260	600	10000	38	7
18	1350	750	90	30	1570	750	10000	30	8
19	1620	900	80	25	1880	900	10000	25	9
20	2060	1150	70	20	2410	1150	10000	20	10
21	2510	1400	60	16	2930	1400	10000	16	11
22	3050	1700	50	13	3560	1700	10000	13	12
23	3770	2100	40	11	4400	2100	10000	11	13
24	4490	2500	40	9	5240	2500	10000	9	14
25	5000	2800	35	8	5900	2800	10000	8	—
26	5600	3100	30	7	6500	3100	10000	7	15
27	6100	3400	30	7	7100	3400	10000	7	—
28	6600	3700	25	6	7700	3700	10000	6	—
29	7200	4000	25	6	8400	4000	10000	6	—
30	8100	4500	20	5	9400	4500	10000	5	—
31	9000	5000	20	5	10500	5000	10000	5	—

*1 Stiffness setting of A4 series refers to the setup value (0-15) of A4 series parameter Pr22 Real-time auto-tuning machine stiffness selection.


*2 When 17-bit absolute encoder, limited by the minimum value 10.

*3 Default stiffness setting: 13 for frames A, B and C, 11 for frames D, E, F, G and H.

Note For details of parameters, refer to P.4-13 "Details of parameter".
Download the A4 series manual from the website.

Outline

Estimates the resonance frequency out of vibration component presented in the motor speed in motion, then removes the resonance component from the torque command by setting up the notch filter coefficient automatically, hence reduces the resonance vibration.



Applicable Range

This function works under the following condition.

	Conditions under which the Adaptive filter is activated
Control Mode	<ul style="list-style-type: none"> • Applies to other control modes than torque control.
Others	<ul style="list-style-type: none"> • Should be servo-on status. • Elements other than control parameters, such as deviation counter clear command inhibit and torque limit are appropriately set, enabling the motor to run normally.

Caution

In the following condition, normal operation may not be expected - manually set the notch filter to prevent resonance.

	Conditions which obstruct adaptive filter action
Resonance point	<ul style="list-style-type: none"> • Resonance frequency is lower than 3 times. • Resonance peak is low, or control gain is low where the motor speed is not affected by this. • Multiple resonance of 3 or more points exist.
Load	<ul style="list-style-type: none"> • Motor speed variation with high harmonic component is generated due to non-linear factors such as backlash.
Command pattern	<ul style="list-style-type: none"> • Acceleration/deceleration is rapid such as 30000[r/min] per 1[s].

3. Adaptive filter

Adaptive filter

How to Operate

Enter the action command with Pr2.00 Adaptive filter mode set to a value other than 0.

If the resonance point affects the motor speed, parameters of 3rd notch filter and/or 4th notch filters are automatically set according to the number of adaptive filters.

Set the operation of the adaptive filter to the following parameter.

Class	No.	Title	Setup value	Function
2	00	Adaptive filter mode setup	0	[Adaptive filter: invalid] The adaptive filter is disabled. Parameters related to the 3rd and 4th notch filter hold the current value.
			1	[Adaptive filter: 1 filter is valid] One adaptive filter is enabled. Parameters related to the 3rd notch filter will be updated based on adaptive performance.
			2	[Adaptive filter: 2 filters are valid] Two adaptive filters are enabled. Parameters related to the 3rd and 4th notch filters will be updated based on adaptive performance.
			3	[Resonance frequency measurement mode] Measure the resonance frequency. Result of measurement can be checked with PANATERM. Parameters related to the 3rd and 4th notch filter hold the current value.
			4	[Clear result of adaptation] Parameters related to the 3rd and 4th notch filter are disabled and results of adaptive operation are cleared.

At the same time, the following parameters are automatically set.

Class	No.	Title	Function
2	07	3rd notch frequency	In no resonance point is found, the frequency is set to 5000.
2	08	3rd notch width selection	Automatically set when the adaptive filter is active.
2	09	3rd notch depth selection	
2	10	4th notch frequency	Notch frequency is automatically set to the 2nd resonance frequency estimated by the adaptive filter. In no resonance point is found, the frequency is set to 5000.
2	11	4th notch width selection	Automatically set when 2 adaptive filters are active.
2	12	4th notch depth selection	

3. Adaptive filter

Adaptive filter

Caution

- (1) Immediately after the first servo-on at start up; or after increasing stiffness setting with the real-time auto-tuning enabled, abnormal sound or oscillation may be generated until the adaptive filter stabilizes. If such abnormality lasts or repeats for 3 or more reciprocating operations, take the following countermeasures.
 - 1) Write the parameters which have given the normal operation into EEPROM.
 - 2) Lower the setup of Pr0.03 (Selection of machine stiffness at real-time auto-gain tuning).
 - 3) Invalidate the adaptive filter by setting up Pr2.00 (Setup of adaptive filter mode) to 0. (Reset of inertia calculation and adaptive action)
 - 4) Set up the notch filter manually.
- (2) Abnormal sound or oscillation may excessively change the setup value of 3rd and 4th notch filters. If such change occurs, disable the adaptive filter as described in step 3) above, change setup value of Pr2.07 3rd notch frequency and Pr2.10 4th notch frequency to 5000 (disable), and then enable the adaptive filter again.
- (3) The 3rd filters (Pr2.07-Pr2.09) and 4th notch filters (Pr2.10-Pr2.12) are written to EEPROM every 30 minutes. Upon power up, these data are used as default values during adaptive process.

As explained previously, MINAS-A5 series features the automatic gain tuning function, however, there might be some cases where this automatic gain tuning cannot be adjusted properly depending on the limitation on load conditions. Or you might need to readjust the tuning to obtain the optimum response or stability corresponding to each load.


Here we explain this manual gain tuning method by each control mode and function.

Before Making a Manual Adjustment

By monitoring waveforms using the waveform graphic function of the setup support software PANATERM installed on the PC or by measuring the analog voltage waveform with the help of the monitor function, accurate adjustment can be positively, quickly and easily done when compared with that performed on the front panel.


1. Analog monitor output

You can measure the actual motor speed, commanded speed, torque and deviation pulses by analog voltage level by using an oscilloscope. Set up the types of the signals or the output voltage level with Pr4.16 (Selection of speed monitor) and Pr4.21 (Selection of torque monitor).



2. Waveform graphic function of the PANATERM

You can display the command to the motor, motor movement (speed, torque command and deviation pulses) as a waveform graphic on PC display. Refer to P.7-26, "Outline of the Setup Support Software, PANATERM" of Supplement.



Caution

Please download the Setup support software "PANATERM" from our web site and use after install to the PC.

Related page

• P.4-36, 4-37... "Details of parameter" • P.7-26 "Outline of Setup support software "PANATERM"

Position control of MINAS-A5 series is described in Block diagram of P.3-14.

Make adjustment in position control per the following procedures.

(1) Set up the following parameters to the values of the table below.

Parameter No. (Pr□□)	Title of parameter	Standard value
1.00	1st gain of position loop	270
1.01	1st gain of velocity loop	150
1.02	1st time constant of velocity loop integration	370
1.03	1st filter of velocity detection	0
1.04	1st time constant of torque filter time	152
1.10	Velocity feed forward	0
1.11	Time constant of feed forward filter	0
1.05	2nd gain of position loop	270
1.06	2nd gain of velocity loop	150
1.07	2nd time constant of velocity loop integration	370
1.08	2nd filter of speed detection	0
1.09	2nd time constant of torque filter	152
2.01	1st notch frequency	5000
2.02	1st notch width selection	2

Parameter No. (Pr□□)	Title of parameter	Standard value
0.04	Inertia ratio	100
0.02	Setup of real time auto-gain tuning mode	0
2.00	Adaptive filter setup mode	0
2.14	1st damping frequency	0
2.15	Setup of 1st damping filter	0
2.16	2nd damping frequency	0
2.17	Setup of 2nd damping filter	0
1.14	2nd gain setup	0
1.15	Mode of position control switching	0
1.16	Delay time of position control switching delay	0
1.17	Level of position control switching	0
1.18	Hysteresis at position control switching	0
1.19	Position gain switching time	0
2.22	Positional command smoothing filter	1
2.23	Positional command FIR filter	0

(2) Enter the inertia ratio of Pr0.04. Measure the ratio or setup the calculated value.

(3) Make adjustment using the standard values below.

Order	Parameter No. (Pr□□)	Title	Standard value	How to adjust
1	Pr1.01	1st gain of velocity loop	300	Increase the value within the range where no abnormal noise and no vibration occur. If they occur, lower the value.
2	Pr1.04	1st time constant of torque filter	50	When vibration occurs by changing Pr1.01, change this value. Setup so as to make Pr1.01 x Pr1.04 becomes smaller than 10000. If you want to suppress vibration at stopping, setup larger value to Pr1.04 and smaller value to Pr1.01. If you experience too large vibration right before stopping, lower than value of Pr1.04.
3	Pr1.00	1st gain of position loop	500	Adjust this observing the positioning time. Larger the setup, faster the positioning time you can obtain, but too large setup may cause oscillation.
4	Pr1.02	1st time constant of velocity loop integration	250	Setup this value within the range where no problem occurs. If you setup smaller value, you can obtain a shorter positioning time, but too small value may cause oscillation. If you setup too large value, deviation pulses do not converge and will be remained. Increase the value within the range where no abnormal noise occurs.
5	Pr1.10	Velocity feed forward gain	300	Too large setup may result in overshoot or chattering of position complete signal, hence does not shorten the settling time. If the command pulse is not even, you can improve by setting up Pr1.11 (Feed forward filter) to larger value.

Velocity control of MINAS-A5 series is described in Block Diagram of P.3-15 of Velocity Control Mode.

Adjustment in velocity control is almost same as that in position control described in "Adjustment in Position Control Mode", and make adjustments of parameters per the procedures except the gain setup of position loop gain (Pr1.00, Pr1.05) and the setup of velocity feed forward gain (Pr1.10).

Torque control of MINAS-A5 series is described in P.3-16, "Block Diagram" of Torque Control Mode.

This torque control is based on velocity control while making Pr3.21 [Speed limit value 1], Pr3.22 [Speed limit value 2] or SPL input as a speed limit. Here we explain the setup of speed limiting value.

• Setup of speed limiting value

The torque command selection (Pr3.17) specifies the setup method.

Pr3.17 = 0 Set up by using speed limit value 1 (Pr3.21)

Pr3.17 = 1 Set up by using analog input (SPL)

Pr3.17 = 2 For positive direction, set up by using the speed limit value 1 (Pr3.21)

For negative direction, set up by using the speed limit value 2 (Pr3.22)

- When the motor speed approaches to the speed limiting value, torque control following the analog torque command shifts to velocity control based on the speed limiting value.
- In order to stabilize the movement under the speed limiting, you are required to set up the parameters according to the above-mentioned "Adjustment in Velocity Control Mode".
- When the speed limiting value is too low or the velocity loop gain is too low, or when the time constant of the velocity loop integration is 10000 (invalid), the input to the torque limiting portion of the above fig. becomes small and the output torque may not be generated as the analog torque command.

Note



Only for position control type is not provided with analog input.

Related page

• P.3-43 "Inputs and outputs on connector X4"

Full-closed control of MINAS-A5 series is described in Block diagram of P.3-17 of Full-Closed Control.

Adjustment in full-closed control is almost same as that in position control described in P.3-12 "Adjustment in Position Control Mode", and make adjustments of parameters per the procedures except cautions of P.5-14, "Outline of Full-Closed Control" (difference of command unit and difference of electronic gear).

Here we explain the setup of feedback scale ratio and hybrid deviation excess of full-closed control.

1) Setup of external scale ratio

Setup the external scale ratio using the numerator of external scale division (Pr3.24) and denominator of external scale division (Pr3.25).

- Check the encoder feedback pulse counts per one motor revolution and the external scale pulse counts per one motor revolution, then set up the numerator of external scale division (Pr3.24), and denominator of external scale division (Pr3.25) so that the following formula can be established.

$$\frac{\text{Pr3.24}}{\text{Pr3.25}} = \frac{\text{Number of encoder feedback pulses per motor rotation}}{\text{Number of external scale pulses per motor rotation}}$$

- If this ratio is incorrect, a gap between the position calculated from the encoder feedback pulse counts and that of calculated from the external scale pulse counts will be enlarged and hybrid deviation excess (Err25.0) will be triggered when the work or load travels a long distance.
- When you set up Pr3.24 to 0, the encoder feedback pulse counts will be automatically set up.

2) Setup of hybrid deviation excess

Set up the minimum value of hybrid deviation excess (Pr3.28) within the range where the gap between the motor (encoder) position and the load (feedback scale) position will be considered to be an excess.

- Note that the hybrid deviation excess (Err25.0) may be generated under other conditions than the above 1), such as reversed connection of the external scale or loose connection of the motor and the load.

Caution

- (1) Enter the command pulses based on the feedback scale reference.
- (2) The feedback scales to used for full-closed control are as follows.
When A- and B-phase parallel, or serial scale,
 - ABS ST770A, ST770AL, AT573A series by Mitsutoyo Corp.
 - SR77, SR87, SL700, SL710 by Magnescale Co., Ltd.
- (3) To prevent the runaway and damage of the machine due to the setup of the feedback scale, setup the hybrid deviation excess (Pr3.28) to the appropriate value, in the unit of feedback scale resolution.

- (4) **We recommend the external scale as $1/40 \leq \text{external scale ratio} \leq 160$.**

Even within this range, if you setup the external scale ratio to smaller value than 50/position loop gain (Pr1.00 and 1.05), you may not be able to control by one pulse unit. If you set up too large external scale ratio, you may expect larger noise in movement.

Note


- Only for position control type is not provided with X5 (For external scale connector).

Related page

- P.3-30 "Inputs and outputs on connector X4" • P.6-2 "Protective Function"

By selecting appropriate gain based on internal data or external signal, the following effects can be obtained.

- Decrease the gain at the time of stoppage (servo lock) to reduce vibration.
- Increase the gain at the time of stoppage (setting) to shorten the settling time.
- Increase the gain during operation to improve command compliance.
- Based on condition of the equipment, change the gain with external signal.



<Example>

Following is the example when you want to reduce the noise at motor in stall (Servo-Lock), by setting up to lower gain after the motor stops.

- Make adjustment referring to the basic gain parameter setup table (P.5-9) as well.

Parameter No. (Pr□□)	Title of parameter	Execute manual gain-tuning without gain switching	Set up the same value as Pr1.05 to 1.09 (2nd gain) to Pr1.00 to 1.04 (1st gain)	Set up Pr1.14 to 1.19 (Gain switching condition)	Adjust Pr1.01 and 1.04 at stopping (1st gain)
1.00	1st gain of position loop	630			
1.01	1st gain of velocity loop	350			270
1.02	1st time constant of velocity integration	160			
1.03	1st filter of velocity detection	0			
1.04	1st time constant of torque filter	65			84
1.10	Velocity feed forward	300			
1.11	Filter of velocity feed forward	50			
1.05	2nd gain of position loop		630		
1.06	2nd gain of velocity loop		350		
1.07	2nd time constant of velocity integration		160		
1.08	2nd filter of velocity detection		0		
1.09	2nd time constant of torque filter time		65		
1.14	Action setup of 2nd gain	0		1	
1.15	1st mode of control switching			7	
1.16	1st delay time of control switching			30	
1.17	1st level of control switching			0	
1.18	1st hysteresis of control switching			0	
1.19	Switching time of position gain			0	
0.04	Inertia ration	<ul style="list-style-type: none"> • Enter the known value from load calculation • Measure the inertia ratio by executing normal auto-gain tuning • Default is 250 			

Related page • P.4-6... "Details of parameter"

4. Manual Gain Tuning (Basic)

Gain Switching Function

Setup of Gain Switching Condition

- **Positing control mode, Full-closed control mode** (○: Corresponding parameter is valid, – : invalid)

Setup of gain switching condition			Setup parameters at position control, full-closed control		
Pr1.15	Switching condition to 2nd gain	Fig.	Delay time ^{*1}	Level	Hysteresis ^{*2}
			Pr1.16	Pr1.17	Pr1.18
0	Fixed to 1st gain		–	–	–
1	Fixed to 2nd gain		–	–	–
2	Gain switching input		–	–	–
3	Torque command	A	○	○ [%]	○ [%]
4	Invalid (Fixed to 1st gain)		–	–	–
5	Speed command	C	○	○ [r/min]	○ [r/min]
6	Position deviation	D	○	○ ^{*3} [pulse]	○ ^{*3} [pulse]
7	Position command exists.	E	○	–	–
8	Not in positioning complete	F	○	–	–
9	Speed	C	○	○ [r/min]	○ [r/min]
10	Command exists + velocity	G	○	○ [r/min] ^{*5}	○ [r/min] ^{*5}

- **Velocity control mode**

Setup of gain switching condition			Setup parameters at velocity control mode		
Pr1.20	Switching condition to 2nd gain	Fig.	Delay time ^{*1}	Level	Hysteresis ^{*2}
			Pr1.16, 1.21	Pr1.17, 1.22	Pr1.18, 1.23
0	Fixed to 1st gain		–	–	–
1	Fixed to 2nd gain		–	–	–
2	Gain switching input		–	–	–
3	Torque command	A	○	○ [%]	○ [%]
4	Variation of speed command is large.	B	–	○ ^{*4} [10(r/min)/s]	○ ^{*4} [10(r/min)/s]
5	Speed command	C	○	○ [r/min]	○ [r/min]

- **Torque control mode**

Setup of gain switching condition			Setup parameters at torque control mode		
Pr1.24	Switching condition to 2nd gain	Fig.	Delay time ^{*1}	Level	Hysteresis ^{*2}
			Pr1.16, 1.25	Pr1.17, 1.26	Pr1.18, 1.27
0	Fixed to 1st gain		–	–	–
1	Fixed to 2nd gain		–	–	–
2	Gain switching input, GAIN ON		–	–	–
3	Variation of torque command is large.	A	○	○ [%]	○ [%]


*1 Delay time (Pr1.16, 1.12 and 1.25) will be valid only when returning from 2nd to 1st gain.

*2 Hysteresis (Pr1.18, 1.23 and 1.27) is defined as the fig. below shows.

*3 Designate with either the encoder resolution or the external scale resolution depending on the control mode.








*4 When you make it a condition that there is speed variation of 10r/min in 1s, set up the value to 1.

*5 When Pr1.15=10, the meanings of delay time, level and hysteresis are different from the normal. (refer to Fig. G)



4. Manual Gain Tuning (Basic)

Gain Switching Function



Caution

Above Fig. does not reflect a timing lag of gain switching due to hysteresis (Pr1.18, 1.23 and 1.27).

In case of a low machine stiffness, you cannot set up a higher gain because vibration and noise occur due to oscillation caused by axis distortion or other causes. By suppressing the resonance peak at the notch filter, higher gain can be obtained or the level of vibration can be lowered.

1. Torque command filter (Pr1.04 and Pr1.09)

Sets up the filter time constant so as to damp the frequency at vicinity of resonance frequency. You can obtain the cut off frequency of the torque command filter in the following formula.

Cut off frequency (Hz) $f_c = 1 / (2\pi \times \text{parameter setup value} \times 0.00001)$

2. Notch filter (Pr2.00, 2.07 to Pr2.12)

• Adaptive filter

MINASA-5 series feature the adaptive filter. With this filter you can control vibration of the load which resonance points vary by machine by machine and normal notch filter or torque filter cannot respond. Enter the action command with Pr2.00 Adaptive filter mode set to a value other than 0.

If the resonance point affects the motor speed, parameters of 3rd notch filter and/or 4th notch filters are automatically set according to the number of adaptive filters.

Pr2.00	Adaptive filter mode	1: Adaptive filter is valid 2: 2 adaptive filters are valid.
Pr2.07	3rd notch frequency	In no resonance point is found, the frequency is set to 5000.
Pr2.08	3rd notch width selection	Automatically set when the adaptive filter is active.
Pr2.09	3rd notch depth selection	
Pr2.10	4th notch frequency	Notch frequency is automatically set to the 2nd resonance frequency estimated by the adaptive filter. In no resonance point is found, the frequency is set to 5000.
Pr2.11	4th notch width selection	Automatically set when 2 adaptive filters are active.
Pr2.12	4th notch depth selection	

• Notch filter (Pr2.01 to 2.12)



MINASA-5 series feature 4 normal notch filters. You can adjust frequency and width and depth.

Pr2.01	1st notch frequency	Set the center frequency of the 1st notch filter. *1
Pr2.02	1st notch width selection	Set the width of notch at the center frequency of the 1st notch filter.
Pr2.03	1st notch depth selection	Set the depth of notch at the center frequency of the 1st notch filter.
Pr2.04	2nd notch frequency	Set the center frequency of the 2nd notch filter. *1
Pr2.05	2nd notch width selection	Set the width of notch at the center frequency of the 2nd notch filter.
Pr2.06	2nd notch depth selection	Set the depth of notch at the center frequency of the 2nd notch filter.
Pr2.07	3rd notch frequency	Set the center frequency of the 3rd notch filter. *1
Pr2.08	3rd notch width selection	Set the width of notch at the center frequency of the 3rd notch filter.
Pr2.09	3rd notch depth selection	Set the depth of notch at the center frequency of the 3rd notch filter.
Pr2.10	4th notch frequency	Set the center frequency of the 4th notch filter. *1
Pr2.11	4th notch width selection	Set the width of notch at the center frequency of the 4th notch filter.
Pr2.12	4th notch depth selection	Set the depth of notch at the center frequency of the 4th notch filter.


*1 The notch filter function will be invalidated by setting up this parameter to "5000".

4. Manual Gain Tuning (Basic)

Suppression of Machine Resonance



Example of application machine



4. Manual Gain Tuning (Basic)

Suppression of Machine Resonance


Notch width and depth

The width of the notch filter is the ratio of the width of -3dB attenuation frequency band with respect to the notch frequency at its center when depth is 0, and the value is as shown in the table below.

The notch filter depth indicates I:O ratio where the input at the center frequency is completely shut with setup value 0 but fully received with setup value 100. The table below shows this value in dB on the right.

Notch width	Band width/center frequency		Notch depth	I/O ratio	[dB]
	A4 series (reference)	A5 series			
0	0.41	0.5	0	0	$-\infty$
1	0.56	0.59	1	0.01	-40
2	0.71	0.71	2	0.02	-34
3	0.86	0.84	3	0.03	-30.5
4	1.01	1	4	0.04	-28
5	—	1.19	5	0.05	-26
6	—	1.41	6	0.06	-24.4
7	—	1.68	7	0.07	-23.1
8	—	2	8	0.08	-21.9
9	—	2.38	9	0.09	-20.9
10	—	2.83	10	0.1	-20
11	—	3.36	15	0.15	-16.5
12	—	4	20	0.2	-14
13	—	4.76	25	0.25	-12
14	—	5.66	30	0.3	-10.5
15	—	6.73	35	0.35	-9.1
16	—	8	40	0.4	-8
17	—	9.51	45	0.45	-6.9
18	—	11.31	50	0.5	-6
19	—	13.45	60	0.6	-4.4
20	—	16	70	0.7	-3.1
			80	0.8	-1.9
			90	0.9	-0.9
			100	1	0

Notch filter frequency characteristics



4. Manual Gain Tuning (Basic)

Suppression of Machine Resonance

How to Check the Resonance Frequency of the Machine

- (1) Start up the Setup Support Software, "PANATERM" and bring the frequency characteristics measurement screen.
- (2) Set up the parameters and measurement conditions. (Following values are standard.)
 - Set up Pr1.01 (1st gain of velocity loop) to 25 or so. (to lower the gain and make it easy to identify the resonance frequency)
 - Set up the amplitude to 50 (r/min) or so. (not to saturate the torque)
 - Make the offset to 100 (r/min) or so. (to increase the speed detecting data and to avoid the measurement error in the vicinity of speed-zero)
 - Polarity is made positive direction with "+" and negative direction with "-".
 - Setup the sampling rate to 0. (setup range to be 0 to 7.)
- (3) Execute the frequency characteristic analysis.

Remarks

- Make sure that the revolution does not exceed the travel limit before the measurement. Standard revolutions are,
 $\text{Offset (r/min)} \times 0.017 \times (\text{sampling rate} + 1)$
Larger the offset, better measurement result you can obtain, however, revolutions may be increased.
- Set up Pr2.00 (Setup of adaptive filter mode) to 0 while you make measurement.

Note

- When you set a larger value of offset than the amplitude setup and make the motor run to the one direction at all time, you can obtain a better measurement result.
- Set up a smaller sampling rate when you measure a high frequency band, and a larger sampling rate when you measure a low frequency band in order to obtain a better measurement result.
- When you set a larger amplitude, you can obtain a better measurement result, but noise will be larger. Start a measurement from 50 [r/min] and gradually increase it.

Relation of Gain Adjustment and Machine Stiffness

In order to enhance the machine stiffness,

- (1) Install the base of the machine firmly, and assemble them without looseness.
- (2) Use a coupling designed exclusively for servo application with high stiffness.
- (3) Use a wider timing belt. Belt tension to be within the permissible load to the motor shaft.
- (4) Use a gear reducer with small backlash.
 - Inherent vibration (resonance frequency) of the machine system has a large effect to the gain adjustment of the servo.You cannot setup a higher response of the servo system to the machine with a low resonance frequency (machine stiffness is low).

Note

Please download the Setup support software "PANATERM" from our website and use install to the PC.

Related page

P.7-26 "Outline of setup support software "PANATERM"

5


Adjustment

5. Manual Gain Tuning (Application)

Damping Control

Outline

This function reduces the vibration at the top or on whole of the equipment by removing the vibration frequency components specified by the positional command. Up to 2 among 4 frequency settings can be used at the same time.



Applicable Range

This function can only be applicable when the following conditions are satisfied.

	Conditions under which the damping control is activated
Control mode	<ul style="list-style-type: none"> Control mode to be either or both position control or/and full-closed control. Pr0.01 = 0 : Position control Pr0.01 = 3 : 1st control mode of position and velocity control Pr0.01 = 4 : 1st control mode of position control and torque control Pr0.01 = 6 : Full-closed control

Caution

This function does not work properly or no effect is obtained under the following conditions.

	Conditions which obstruct the damping control effect
Load	<ul style="list-style-type: none"> Vibration is triggered by other factors than command (such as disturbance). Ratio of resonance frequency and anti-resonance frequency is large. Vibration frequency is out of the range of 1.0-200.0 [Hz].


5. Manual Gain Tuning (Application)

Damping Control

How to Use

(1) Setup of damping frequency (1st: Pr2.14, 2nd: Pr2.16, 3rd: Pr2.18, 4th: Pr2.20)

Measure the vibration frequency of the front edge of the machine. When you use such instrument as laser displacement meter, and can directly measure the load end vibration, read out the vibration frequency from the measured waveform and enter the correct value to the damping frequency parameter.




If no suitable measuring instrument is available, use our setup support software "PANATERM" that can graphically display the position deviated waveform as shown in the figure below. Determine the frequency (Hz) of the residual vibration and set the damping frequency.

(2) Setup of damping filter (1st: Pr2.15, 2nd: Pr2.17, 3rd: Pr2.19, 4th: Pr2.21)

First, set up 0.

You can reduce the settling time by setting up larger value, however, the torque ripple increases at the command changing point as the right fig. shows. Setup within the range where no torque saturation occurs under the actual condition. If torque saturation occurs, damping control effect will be lost.



Caution

Setting range of the damping filter should be limited as follows:

10.0 Hz – damping frequency ≤ damping filter setting ≤ damping frequency

(3) Setup of damping filter switching selection (Pr2.13)

You can switch the 1st or the 2nd damping filter depending on the vibration condition of the machine.

Pr2.13	VS-SEL2	VS-SEL1	1st damping	2nd damping	3rd damping	4th damping
0	—	—	<input type="radio"/>	<input type="radio"/>		
1	—	OFF	<input type="radio"/>		<input type="radio"/>	
	—	ON		<input type="radio"/>		<input type="radio"/>
2	OFF	OFF	<input type="radio"/>			
	OFF	ON		<input type="radio"/>		
	ON	OFF			<input type="radio"/>	
	ON	ON				<input type="radio"/>

Pr2.13	Position command direction	1st damping	2nd damping	3rd damping	4th damping
3	Positive direction	<input type="radio"/>		<input type="radio"/>	
	Negative direction		<input type="radio"/>		<input type="radio"/>

Damping control is switched over on the rising edge of the command while the positioning complete is being output and the number of command pulses/0.166 ms changes from 0 to non-0 state.

If higher damping frequency is selected or damping is disabled and positioning complete range is wide, and if the pulse (the area of the pulse = value of position command before filter minus value of position command after filter, integrated with respect to time) remains in the filter at the rising edge of the command, the pulse is rapidly discharged immediately after damping change. This causes the motor to run at a rate higher than the commanded speed for a while to return to the predetermined position.

Outline

When position control or full closed control is used, positional deviation can be further reduced when compared with deviation where control is made only by feedback, and response is also improved, by calculating the velocity control command necessary for operation based on the internal positional command, and by adding velocity feed forward to the speed command calculated by comparison with position feedback.

The response time of the velocity control system is also improved by calculating torque command necessary for operation based on the velocity control command and by adding torque feed forward calculated by comparison with velocity feedback to the torque command.

Related Parameter


For A5 series, the velocity feed forward and torque feed forward can be used.

Class	No.	Title	Function
1	10	Velocity feed forward gain	Multiply the velocity control command calculated according to the internal positional command by the ratio of this parameter and add the result to the speed command resulting from the positional control process.
1	11	Velocity feed forward filter	Set the time constant of 1st delay filter which affects the input of velocity feed forward.
1	12	Torque feed forward gain	Multiply the torque command calculated according to the velocity control command by the ratio of this parameter and add the result to the torque command resulting from the velocity control process.
1	13	Torque feed forward filter	Set up the time constant of 1st delay filter which affects the input of torque feed forward.
6	0	Analog torque feed forward conversion gain	Set the input gain of analog torque feed forward. 0 to 9 are invalid.
6	10	Function expansion setup	Set up the function in unit of bit. bit5 0: Analog torque feed forward is invalid. 1: Analog torque feed forward is Valid. * bit 0 = LSB

Usage example of velocity feed forward

The velocity feed forward will become effective as the velocity feed forward gain is gradually increased with the velocity feed forward filter set at approx. 50 (0.5 ms). The positional deviation during operation at a constant velocity is reduced as shown in the equation below in proportion to the value of velocity feed forward gain.

$$\text{Positional deviation [unit of command]} = \frac{\text{command speed [unit of command/s]} / \text{positional loop gain [1/s]} \times (100 - \text{velocity feed forward gain [\%]})}{100}$$



5. Manual Gain Tuning (Application)


Feed forward function

With the gain set at 100%, calculatory positional deviation is 0, but significant overshoot occurs during acceleration/deceleration.

If the updating cycle of the positional command input is longer than the driver control cycle, or the pulse frequency varies, the operating noise may increase while the velocity feed forward is active. If this is the case, use positional command filter (1st delay or FIR smoothing), or increase the velocity forward filter setup value.

Usage example of torque feed forward

- To use the torque feed forward, correctly set the inertia ratio.
Use the value that was determined at the start of the real time auto tuning, or set the inertia ratio that can be calculated from the machine specification to Pr0.04 Inertia ratio.
- The torque feed forward will become effective as the torque feed forward gain is gradually increased with the torque feed forward filter is set at approx. 50 (0.5 ms).
- Positional deviation at a constant acceleration/deceleration can be minimized close to 0 by increasing the torque forward gain. This means that positional deviation can be maintained at near 0 over entire operation range while driving in trapezoidal speed pattern under ideal condition where disturbance torque is not active .



Zero positional deviation is impossible in actual situation because of disturbance torque. As with the velocity feed forward, large torque feed forward filter time constant decreases the operating noise but increases positional deviation at acceleration change point.


Usage example of analog torque feed forward

Setting bit 5 place of Pr6.10 Function expansion setup to 1 enables the analog torque feed forward. When the analog input 3 is used by another function (e.g. analog torque limit), the function becomes invalid.

The voltage (V) applied to the analog input 3 is converted to the torque via Pr6.00 Analog torque feed forward conversion gain setup and added to the torque command (%): in CCW direction if it is positive voltage or in CW direction if negative.

The voltage (V) applied to the analog input 3 is converted to the motor torque command (%) through the process as shown in the graph below.


The slope represents when Pr6.00 = 30. The slope changes as the setup value changes.



$$\text{Torque command (\%)} = 100 \times \text{input voltage (V)} / (\text{Pr6.00 setup value} \times 0.1)$$

Outline

This function enables both realization of high response and reduction of vibration at stopping, by estimating the motor speed using a load model, hence improving the accuracy of the speed detection.



Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the instantaneous speed observer is activated
Control mode	<ul style="list-style-type: none"> Control mode to be either or both position control or/and velocity control. Pr0.01 = 0 : Position control Pr0.01 = 1 : Velocity control
Others	<ul style="list-style-type: none"> Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly. Real-time auto-tuning should be disabled. (Pr0.02=0)

Caution

This function does not work properly or no effect is obtained under the following conditions.

	Conditions which obstruct instantaneous speed observer action
Load	<ul style="list-style-type: none"> Gap between the estimated total load inertia (motor + load) and actual machine is large. e.g.) Large resonance point exists in frequency band of 300[Hz] or below. Non-linear factor such as large backlash exists. Load inertia varies. Disturbance torque with harmonic component is applied.
Others	<ul style="list-style-type: none"> Settling range is very small.

5. Manual Gain Tuning (Application)

Instantaneous Speed Observer

Related Parameter

Class	No.	Title	Function
6	10	Function expansion setup	Speed observer enable bit (bit 0) valid/invalid the function. bit0 0: Invalid 1: Valid * bit 0 = LSB

How to Use

(1) Setup of inertia ratio (Pr0.04)

Set up as exact inertia ratio as possible.

- When the inertia ratio (Pr0.04) is already obtained through real-time auto-gain tuning and is applicable at normal position control, use this value as Pr0.04 setup value.
- When the inertia ratio is already known through calculation, enter this calculated value.
- When the inertia ratio is not known, execute the normal mode auto-gain tuning and measure the inertia ratio.

(2) Adjustment at normal position control


- Adjust the position loop gain, velocity loop gain, etc.

(3) Setup of instantaneous velocity observer (Pr6.10)

- By enabling instantaneous speed observer function through function expansion setup (Pr6.10), the speed detection method changes to the instantaneous speed observer.
- When you experience a large variation of the torque waveform or noise, return this to 0, and reconfirm the above cautions and (1).
- When you obtain the effect such as a reduction of the variation of the torque waveform and noise, search an optimum setup by making a fine adjustment of Pr0.04 (Inertia ratio) while observing the position deviation waveform and actual speed waveform to obtain the least variation. If you change the position loop gain and velocity loop gain, the optimum value of the inertia ratio (Pr0.04) might have been changed, and you need to make a fine adjustment again.

Outline

This function uses the disturbance torque determined by the disturbance observer to reduce effect of disturbance torque and vibration.



Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the disturbance observer is activated
Control mode	<ul style="list-style-type: none"> Control mode to be either or both position control or/and velocity control. <ul style="list-style-type: none"> Pr0.01 = 0 : Position control Pr0.01 = 1 : Velocity control
Others	<ul style="list-style-type: none"> Should be in servo-on condition Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly. Real-time auto-tuning should be disabled. (Pr0.02=0) Instantaneous speed observer should be disabled. (Pr6.10 bit0=0)

Caution

Effect may not be expected in the following condition.

	Conditions which obstruct disturbance observer action
Load	<ul style="list-style-type: none"> Resonant frequency is lower than the cutoff frequency estimated by the disturbance observer. Disturbance torque contains many high frequency components.

5. Manual Gain Tuning (Application)

Disturbance observer

Related Parameter

Class	No.	Title	Function
6	10	Function expansion setup	Sets bits related to disturbance observer. bit1 0: Invalid 1: Valid bit2 0: Always valid 1: alid only when 1st gain is selected. * bit 0 = LSB Example) To use the disturbance observer in the enabled mode only when 1st gain is selected: Setup value = 6 To use the disturbance observer always in the enabled mode: Setup value = 2
6	23	Disturbance torque compen- sating gain	Set up compensating gain against disturbance torque.
6	24	Disturbance observer filter	Set up the filter time constant according to the disturbance torque compensation.

How to Use

1) With Pr6.10 Function enhancement setup, set observer enable/disable and operation mode (always enable/enable only when 1st gain is selected).

2) Setup of Pr6.24 (Disturbance observer filter)

First, set up Pr6.24 to a larger value and check the operation with Pr6.23 Disturbance torque compensating gain set to a low value, and then gradually decrease the setup value of Pr6.24. A low filter setup value assures disturbance torque estimation with small delay and effectively suppresses effects of disturbance. However, this results in larger operation noise. Well balanced setup is required.

3) Setup of Pr6.23 (Disturbance torque compensating gain)

After setting up Pr6.24, increase Pr6.23.

The disturbance suppressing capability increases by increasing the gain, but it is associated with increasing volume of operation noise.

This means that well balanced setup can be obtained by adjusting Pr6.24 and Pr6.23.

1 Before Using the Products

2 Preparation

3 Connection

4 Setup

5 Adjustment

6 When in Trouble

7 Supplement

5

Adjustment

5. Manual Gain Tuning (Application)

3rd gain switching function

Outline

In addition to the normal gain switching function described on P.5-17, 3rd gain switching function can be set to increase the gain just before stopping. The higher gain shortens positioning adjusting time.

Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the 3rd gain switching function is activated
Control mode	<ul style="list-style-type: none">Control mode to be either or both position control or/and full-closed control. Pr0.01 = 0 : Position control Pr0.01 = 6 : Full-closed control
Others	<ul style="list-style-type: none">Should be in servo-on conditionInput signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

Related Parameter

Class	No.	Title	Function
6	5	Position 3rd gain valid time	Set up the time at which 3rd gain becomes valid.
6	6	Position 3rd gain scale factor	Set up the 3rd gain by a multiplying factor of the 1st gain: 3rd gain = 1st gain × Pr6.06/100

5. Manual Gain Tuning (Application)

3rd gain switching function

How to Use

While in the condition under which the normal gain switching functions, set the 3rd gain application time to Pr6.05 Position 3rd gain enable time, and set the 3rd gain (scale factor with reference to 1st gain) to Pr6.06 Position 3rd gain magnification ratio.


- If 3rd gain is not used, set Pr6.05 to 0 and Pr6.06 to 100.
- The 3rd gain is enabled only for position control or full closed control.
- During the 3rd gain period, only position loop gain/speed proportional gain becomes 3rd gain, during other periods, 1st gain setting is used.
- When the 2nd gain switching condition is established during 3rd gain period, 2nd gain is used.
- During transition from 2nd gain to 3rd gain, Pr1.19 Position gain switching time is applied.

Caution

When the gain is switched from 2nd to 1st by the change in parameter, the 3rd gain period appears.

Example)

Pr1.15 Position control switching mode = 7 switching condition: with positional command:



5

Adjustment

5. Manual Gain Tuning (Application)

Friction torque compensation

Outline

To reduce effect of friction represented by mechanical system, 2 types of friction torque compensation can be applied: offset load compensation that cancels constant offset torque and the dynamic friction compensation that varies direction as the operating direction varies.

Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the Friction torque compensation is activated
Control mode	• Specific to individual functions. Refer to "Related parameters" shown below.
Others	• Should be in servo-on condition • Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

Related Parameter

Combine the following 3 parameters to setup appropriate friction torque compensation.


Class	No.	Title	Function
6	7	Torque command additional value	Set up the offset load compensation value usually added to the torque command in a control mode except for the torque control mode.
6	8	Positive direction torque compensation value	Set up the dynamic friction compensation value to be added to the torque command when forward positional command is fed.
6	9	Negative direction torque compensation value	Set up the dynamic friction compensation value to be added to the torque command when negative direction positional command is fed.

5. Manual Gain Tuning (Application)

Friction torque compensation

How to Use

The friction torque compensation will be added in response to the entered positional command direction as shown below.



The friction compensation torque is the sum of the offset load compensation value which is set according to the torque command additional value (always constant) and the dynamic friction compensation torque which is set according to positive/negative direction torque compensation value.

The command speed direction is reset upon power-up or when the motor is de-energized.

- Pr6.07 [Torque command additional value] reduces variations in positioning operation (performance is affected by direction of movement). These variations occur when constant offset torque resulting from weight on vertical axis is applied to the motor.
- Certain loads such as belt driven shaft requires high dynamic friction torque, which lengthens positioning setting time or varies positioning accuracy. These problems can be minimized by setting the friction torque of every rotating direction into individual parameters. Pr6.08 [Positive direction torque compensation value] and Pr6.09 [Negative direction torque compensation value] can be used for this purpose.

Caution

The offset load compensation and dynamic friction compensation can be used individually or in combination. However, some control modes impose limit on application.

- For torque control: Offset load compensation and dynamic friction compensation are set at 0 regardless of parameter setting.
- For velocity control with servo-off: Offset load compensation per Pr6.07 is enabled. Dynamic friction compensation is set at 0 regardless of parameter setting.
- For position control or full closed control with servo-on: Previous offset load compensation and dynamic friction compensation values are maintained until the first positional command is applied where the offset load compensation value is updated according to Pr6.07. The dynamic friction compensation value is updated to parameters Pr6.08 and Pr6.09 depending on command direction.

5

Adjustment

5. Manual Gain Tuning (Application)

Inertia ratio switching function

Outline

Inertia ratio can be switched between No.1 and No.2 by the switching input (J-SEL). This feature is useful in application where the load inertia changes in two steps.

Applicable Range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the Inertia ratio switching function is activated
Control mode	<ul style="list-style-type: none">• Can be used in all control modes. Pr0.01 = 0 : Position control Pr0.01 = 1 : Velocity control Pr0.01 = 2 : Torque control Pr0.01 = 3 : Position/Velocity control Pr0.01 = 4 : Position/Torque control Pr0.01 = 5 : Velocity/Torque control Pr0.01 = 6 : Full-closed control
Others	<ul style="list-style-type: none">• Should be in servo-on condition• Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.• Real-time auto-tuning should be disabled. (Pr0.02=0)• Adaptive filter should be disabled. (Pr2.00=0)• Instantaneous speed observer should be disabled. (Pr6.10 bit0=0)• Disturbance observer should be disabled. (Pr6.24=0 bit1=0)

Caution

- Be sure to change the inertia ratio while the motor is in stop state. Otherwise, vibration or oscillation will occur.
- If the difference between the 1st inertial ratio and 2nd inertia ratio is large, vibration, etc., may occur even in stop mode. These potential problems should be identified on the actual model.

5. Manual Gain Tuning (Application)

Inertia ratio switching function

Related Parameter

Combine the following 3 parameters to setup appropriate inertia ratio switching function.

Class	No.	Title	Function
6	10	Function expansion setup	Sets bits related to inertia ratio switching function. bit1 0: Invalid 1: Valid bit2 0: Always valid 1: Valid only when 1st gain is selected. * bit 0 = LSB Example) To enable inertial ratio switching Setup value = 8
0	04	Inertia ratio	Set 1st inertia ratio. You can set up the ratio of the load inertia against the rotor (of the motor) inertia.
6	13	2nd Inertia ratio	Set 1st inertia ratio. You can set up the ratio of the load inertia against the rotor (of the motor) inertia.

How to Use

- Selects 1st inertia ratio or 2nd inertia ratio according to the inertia ratio select input (J-SEL).

Inertia ratio switching input (J-SEL)	Applicable inertia ratio
OFF	1st Inertia ratio (Pr0.04)
ON	2nd Inertia ratio (Pr6.13)

5

Adjustment

5. Manual Gain Tuning (Application)

Hybrid vibration damping function

Outline

This function suppresses vibration due to amount of twist between the motor and load in the full closed control mode. This function enables high gain setting.

Applicable range

This function can be applicable only when the following conditions are satisfied.

	Conditions under which the Hybrid vibration damping function is activated
Control mode	• Full-closed control mode
Others	• Should be in servo-on condition • Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

Caution

The effect of this function will be proportional to the amount of twist between the motor and load.

Related Parameter

Class	No.	Title	Function
6	34	Hybrid vibration suppression gain	Set up the hybrid vibration suppression gain for full-closed controlling. First set it to the value identical to that of poison loop gain, and then fine tune as necessary.
6	35	Hybrid vibration suppression filter	Set up the time constant of the hybrid vibration suppression filter for full-closed controlling.

How to Use


- [1] Set Pr6.34 Hybrid vibration suppression gain to the value equal to that of positional loop gain.
- [2] Driving under full closed control, gradually increase the setup value of Pr6.35 Hybrid vibration suppression filter while checking response change.
When the response is improved, adjust Pr6.34 and Pr6.35 to determine the combination that provides the best response.

- In homing action by using the host controller, stop position might not be stabilized if the origin input (Z-phase of the encoder) is entered while the motor is not decelerated enough after the proximity input is turned on. Set up the ON-positions of proximity input and the position of origin point, considering the necessary pulse counts for deceleration. Take the positioning action and homing action into account when you set up acceleration/deceleration time with parameter, since this affects these actions as well.


For the details of homing, observe the instruction manual of the host controller.

• Example of Homing Action

Proximity dog on... .Decelerates at an entry of the proximity input, and stops at an entry of the first origin input (Z-phase)





Proximity dog off... .Decelerates at an entry of the proximity input, and stops at an entry of the first origin input (Z-phase) after the input is turned off



You can set up the homing position with "Hit & Stop" where it is not easy to install a sensor due to environment.

(1) when you make a point where the work (load) hits as an origin

(2) when you stop the work (load) using Z-phase after making a hitting point as a starting point, then make that stopping point as an origin.



Parameter No.	Title	Setup example
5.22	Setup of 2nd torque limit	50 (Set up to less than 100%)
0.14	Excess setup of position deviation	25000
5.13	Setup of over-speed level	0 (6000r/min)
5.21	Selection of torque limit	3


Remarks

Assign TL-SEL to the input signal.

Upon completion of the homing with hit and stop, turn off TL-SEL (open if logical setting is a-contact; close if b-contact).

Related page • P.4-11, 46, 48 "Details of parameter"

Application example



Parameter No.	Title	Setup example
5.21	Selection of torque limit	3
0.13	Setup of 1st torque limit	200
5.22	Setup of 2nd torque limit	50
0.14	Excess setup of position deviation	25000
5.13	Setup of over-speed level	0

TL-SEL (Factory setting: ^{*)}1
: Torque limit switching input


TLC (Factory setting: ^{*)}40-pin
: Torque in-limit output

Setup value of 2nd torque limit

Torque

Command

Motor speed



Remarks

Assign TL-SEL to the input signal.

This image shows a full page of white paper with horizontal ruling lines. The word "MEMO" is printed at the top center in a bold, black, sans-serif font. Below it, there are numerous evenly spaced horizontal dashed lines extending across the width of the page, providing a guide for writing.

6. When in Trouble

1. When in Trouble

What to Check ?	6-2
Protective Function (What is Error Code ?)	6-2
Protective function (Detail of error code)	6-4

2. Setup of gain pre-adjustment protection6-18

3. Troubleshooting


Motor Does Not Run	6-21
Unstable Rotation (Not Smooth) ,	
Motor Runs Slowly Even with Speed Zero at Velocity Control Mode	6-23
Positioning Accuracy Is Poor	6-24
Origin Point Slips	6-25
Abnormal Motor Noise or Vibration	6-25
Overshoot/Undershoot,	
Overheating of the Motor (Motor Burn-Out)	6-26
Motor Speed Does Not Reach to the Setup,	
Motor Revolutions (Travel) Is Too Large or Small	6-26
Parameter Returns to Previous Setup	6-27

6

When in Trouble

1. When in Trouble

What to Check ?



6

When in Trouble

1. When in Trouble

Protective Function (What is Error Code ?)

- Various protective functions are equipped in the driver. When these are triggered, the motor will stall due to error, the driver will turn the Servo-Alarm output (ALM) to off (open).
- Error status and their measures
 - During the error status, the error code No. will be displayed on the front panel LED, and you cannot turn Servo-ON.
 - You can clear the error status by Alarm clear input(A-CLR) in 120ms or longer.
 - When overload protection is triggered, you can clear it by Alarm clear input(A-CLR) in 10sec or longer after the error occurs. You can clear the Overload protection time characteristics (refer to P.6-14) by turning off the control power supply between L1C and L2C (100V, 200V) , 24V and 0V (400V) of the driver.
 - You can clear the above error by operating the front panel keys and setup support software "PANATERM". Refer to P.2-109 "Alarm Clear Screen" of Preparation.
 - Be sure to clear the alarm during stop after removing the cause of the error and securing safety.

Note

- The figure above shows connections on velocity, position, torque and full-closed mode driver.
- Only for position control type is not provided with X2 X3 and X5.

Related page

- P.2-86 ... "How to Use the Front Panel" • P.3-30 "Inputs and outputs on connector X4"
- P.7-26 "Outline of Setup support software "PANATERM"

1. When in Trouble

Protective Function (What is Error Code ?)

<List of error code No.>

Error code		Protective function	Attribute			Detail page
Main	Sub		History	Can be cleared	Immediate stop	
11	0	Control power supply under-voltage protection		○		6-4
12	0	Over-voltage protection	○	○		
13	0	Main power supply under-voltage protection (between P and N)		○		
	1	Main power supply under-voltage protection (AC interception detection)		○		6-5
14	0	Over-current protection	○			
	1	IPM error protection	○			6-6
15	0	Over-heat protection	○		○	
16	0	Over-load protection	○	○		6-7
18	0	Over-regeneration load protection	○		○	
	1	Over-regeneration Tr error protection	○			6-7
21	0	Encoder communication disconnect error protection	○			
	1	Encoder communication error protection	○			
23	0	Encoder communication data error protection	○			6-8
24	0	Position deviation excess protection	○	○	○	
	1	Velocity deviation excess protection	○	○	○	
25	0	Hybrid deviation excess error protection	○		○	6-8
26	0	Over-speed protection	○	○	○	
	1	2nd over-speed protection	○	○		
27	0	Command pulse input frequency error protection	○	○	○	6-8
	2	Command pulse multiplier error protection	○	○	○	
28	0	Limit of pulse replay error protection	○	○	○	6-9
29	0	Deviation counter overflow protection	○	○		
30	0	Safety detection		○		
33	0	IF overlaps allocation error 1 protection	○			6-10
	1	IF overlaps allocation error 2 protection	○			
	2	IF input function number error 1 protection	○			
	3	IF input function number error 2 protection	○			
	4	IF output function number error 1 protection	○			
	5	IF output function number error 2 protection	○			
	6	CL fitting error protection	○			
	7	INH fitting error protection	○			

Error code		Protective function	Attribute			Detail page
Main	Sub		History	Can be cleared	Immediate stop	
34	0	Software limit protection	○	○		6-10
36	0 to 2	EEPROM parameter error protection				
37	0 to 2	EEPROM check code error protection				
38	0	Over-travel inhibit input protection		○		
39	0	Analog input1 excess protection	○	○	○	
	1	Analog input2 excess protection	○	○	○	6-11
	2	Analog input3 excess protection	○	○	○	
40	0	Absolute system down error protection	○	○		
41	0	Absolute counter over error protection	○			
42	0	Absolute over-speed error protection	○	○		
43	0	Initialization failure	○			6-12
44	0	Absolute single turn counter error protection	○			
45	0	Absolute multi-turn counter error protection	○			
47	0	Absolute status error protection	○			
48	0	Encoder Z-phase error protection	○			
49	0	Encoder CS signal error protection	○			6-12
50	0	Feedback scale connection error protection	○			
	1	Feedback scale communication error protection	○			
51	0	Feedback scale status 0 error protection	○			
	1	Feedback scale status 1 error protection	○			
	2	Feedback scale status 2 error protection	○			
	3	Feedback scale status 3 error protection	○			
	4	Feedback scale status 4 error protection	○			6-13
55	0	A-phase connection error protection	○			
	1	B-phase connection error protection	○			
	2	Z-phase connection error protection	○			
87	0	Compulsory alarm input protection		○		
95	0 to 4	Motor automatic recognition error protection				
99	0		○			6-13
Other number		Other error	○			

Note

History...The error will be stored in the error history.

Can be cleared...To cancel the error, use the alarm clear input (A-CLR).

If the alarm clear input is not effective, turn off power, remove the cause of the error and then turn on power again.

Immediate stop...Instantaneous controlled stop upon occurrence of an error.

(Setting of "Pr.5.10 Sequence at alarm" is also required.)

Note

• Only for position control type is not provided with X2, X3, X5 and analog input.

6

When in Trouble

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
Control power supply under-voltage protection	11	0	<p>Voltage between P and N of the converter portion of the control power supply has fallen below the specified value.</p> <p>100 V version: approx. 70 VDC (approx. 50 VAC)</p> <p>200 V version: approx. 145 VDC (approx. 100 VAC)</p> <p>400 V version: approx. 15 VDC</p> <p>1) Power supply voltage is low. Instantaneous power failure has occurred</p> <p>2) Lack of power capacity...Power supply voltage has fallen down due to inrush current at the main power-on.</p> <p>3) Failure of servo driver (failure of the circuit)</p>	<p>Measure the voltage between lines of connector and terminal block.</p> <p>100V, 200V driver: L1C - L2C</p> <p>400V driver: 24V - 0V</p> <p>1) Increase the power capacity. Change the power supply.</p> <p>2) Increase the power capacity.</p> <p>3) Replace the driver with a new one.</p>
Over-voltage protection	12	0	<p>Voltage between P and N of the converter portion of the control power supply has exceeded the specified value</p> <p>100 V version: approx. 200 VDC (approx. 140 VAC)</p> <p>200 V version: approx. 400 VDC (approx. 280 VAC)</p> <p>400 V version: approx. 800 VDC (approx. 560 VAC)</p> <p>1) Power supply voltage has exceeded the permissible input voltage. Voltage surge due to the phase-advancing capacitor or UPS (Uninterruptible Power Supply) have occurred.</p> <p>2) Disconnection of the regeneration discharge resistor</p> <p>3) External regeneration discharge resistor is not appropriate and could not absorb the regeneration energy.</p> <p>4) Failure of servo driver (failure of the circuit)</p>	<p>Measure the voltage between lines of connector (L1, L2 and L3).</p> <p>1) Enter correct voltage. Remove a phase-advancing capacitor.</p> <p>2) Measure the resistance of the external resistor connected between terminal B1 - B2 of the driver. Replace the external resistor if the value is ∞.</p> <p>3) Change to the one with specified resistance and wattage.</p> <p>4) Replace the driver with a new one.</p>
Main power supply under-voltage protection (PN)	13	0	<p>Instantaneous power failure has occurred between L1 and L3 for longer period than the preset time with Pr5.09 (Main power off detecting time) while Pr5.08 (LV trip selection at the main power-off) is set to 1. Or the voltage between P and N of the converter portion of the main power supply has fallen below the specified value during Servo-ON.</p> <p>100 V version: approx. 80 VDC (approx. 55 VAC)</p> <p>200 V version: approx. 110 VDC (approx. 75 VAC)</p> <p>400 V version: approx. 180 VDC (approx. 125 VAC)</p> <p>1) Power supply voltage is low. Instantaneous power failure has occurred</p> <p>2) Instantaneous power failure has occurred.</p> <p>3) Lack of power capacity...Power supply voltage has fallen down due to inrush current at the main power-on.</p> <p>4) Phase lack...3-phase input driver has been operated with single phase input.</p> <p>5) Failure of servo driver (failure of the circuit)</p>	<p>Measure the voltage between lines of connector (L1, L2 and L3).</p> <p>1) Increase the power capacity. Change the power supply. Remove the causes of the shutdown of the magnetic contactor or the main power supply, then re-enter the power.</p> <p>2) Set up the longer time to Pr5.09 (Main power off detecting time). Set up each phase of the power correctly.</p> <p>3) Increase the power capacity. For the capacity, refer to P.2-10, "Driver and List of Applicable Peripheral Equipments" of Preparation.</p> <p>4) Connect each phase of the power supply (L1, L2 and L3) correctly. For single phase, 100V and 200V driver, use L1 and L3.</p> <p>5) Replace the driver with a new one.</p>
Main power supply under-voltage protection (AC)		1		

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
* Over-current protection	14	0	Current through the converter portion has exceeded the specified value. 1) Failure of servo driver (failure of the circuit, IGBT or other components)	1) Turn to Servo-ON, while disconnecting the motor. If error occurs immediately, replace with a new driver. 2) Check that the motor wire (U, V and W) is not shorted, and check the branched out wire out of the connector. Make a correct wiring connection. 3) Measure the insulation resistance between motor wires, U, V and W and earth wire. In case of poor insulation, replace the motor. 4) Check the balance of resistor between each motor line, and if unbalance is found, replace the motor. 5) Check the loose connectors. If they are, or pulled out, fix them securely. 6) Replace the servo driver. Do not use Servo-ON/Servo-OFF as a means of starting/stopping the operation. 7) Enter the pulses 100ms or longer after Servo-ON. 8) Replace the driver.
* IPM error protection [IPM: Intelligent Power Module]		1	2) Short of the motor wire (U, V and W) 3) Earth fault of the motor wire 4) Burnout of the motor 5) Poor contact of the motor wire. 6) Welding of contact of dynamic braking relay due to frequent servo ON/OFF operations. 7) Timing of pulse input is same as or earlier than Servo-ON. 8) Blowout of thermal fuse due to overheating dynamic brake circuit. (Only F and G frames)	
* Over-heat protection	15	0	Temperature of the heat sink or power device has been risen over the specified temperature. 1) Ambient temperature has risen over the specified temperature. 2) Over-load	1) Improve the ambient temperature and cooling condition. 2) Increase the capacity of the driver and motor. Set up longer acceleration/deceleration time. Lower the load.

Note

- When protective function marked with * in the protective function table is activated, it cannot be disabled by the alarm clear input (A-CLR). To return to the normal operation, turn off power, remove the cause, and then turn on power again.

Related page

- P.2-12 "System Configuration and Wiring" • P.4-45 "Details of parameter"

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
Over-load protection	16	0	<p>Torque command value has exceeded the over-load level set with Pr5.12 (Setup of over-load level) and resulted in overload protection according to the time characteristics (described later)</p> <ol style="list-style-type: none"> 1) Load was heavy and actual torque has exceeded the rated torque and kept running for a long time. 2) Oscillation and hunching action due to poor adjustment. Motor vibration, abnormal noise. Inertia ratio (Pr0.04) setup error. 3) Miswiring, disconnection of the motor. 4) Machine has collided or the load has gotten heavy. Machine has been distorted. 5) Electromagnetic brake has been kept engaged. 6) While wiring multiple axes, miswiring has occurred by connecting the motor cable to other axis. 	<p>Check that the torque (current) does not oscillates nor fluctuate up and down very much on the analog output and via communication. Check the over-load alarm display and load factor with the analog output and via communication..</p> <ol style="list-style-type: none"> 1) Increase the capacity of the driver and motor. Set up longer acceleration/ deceleration time. Lower the load. 2) Make a re-adjustment. 3) Make a wiring as per the wiring diagram. Replace the cables. 4) Remove the cause of distortion. Lower the load. 5) Measure the voltage between brake terminals. Release the brake 6) Make a correct wiring by matching the correct motor and encoder wires.
			<p>• The over-load protection time characteristics are described on P.6-14.</p>	
			<p>Caution ⚠ Once this error occurs, it cannot be cleared at least for 10 sec.</p>	
* Over-regeneration load protection	18	0	<p>Regenerative energy has exceeded the capacity of regenerative resistor.</p> <ol style="list-style-type: none"> 1) Due to the regenerative energy during deceleration caused by a large load inertia, converter voltage has risen, and the voltage is risen further due to the lack of capacity of absorbing this energy of the regeneration discharge resistor. 2) Regenerative energy has not been absorbed in the specified time due to a high motor rotational speed. 3) Active limit of the external regenerative resistor has been limited to 10% duty. 	<p>Check the load factor of the regenerative resistor from the front panel or via communication. Do not use in the continuous regenerative brake application.</p> <ol style="list-style-type: none"> 1) Check the running pattern (velocity monitor). Check the load factor of the regenerative resistor and over-regeneration warning display. Increase the capacity of the driver and the motor, and loosen the deceleration time. Use the external regenerative resistor. 2) Check the running pattern (speed monitor). Check the load factor of the regenerative resistor. Increase the capacity of the driver and the motor, and loosen the deceleration time. Lower the motor rotational speed. Use an external regenerative resistor. 3) Set up Pr0.16 to 2.
			<p>Caution ⚠ Install an external protection such as thermal fuse without fail when you set up Pr0.16 to 2. Otherwise, regenerative resistor loses the protection and it may be heated up extremely and may burn out.</p>	

Note

- When protective function marked with * in the protective function table is activated, it cannot be disabled by the alarm clear input (A-CLR). To return to the normal operation, turn off power, remove the cause, and then turn on power again.

Related page

- P.4-6... "Details of parameter"

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
* Regenerative transistor error protection	18	1	Regenerative driver transistor on the servo driver is defective.	Replace the driver.
* Encoder communication disconnection error protection	21	0	Communication between the encoder and the driver has been interrupted in certain times, and disconnection detecting function has been triggered.	Make a wiring connection of the encoder as per the wiring diagram. Correct the miswiring of the connector pins.
* Encoder communication error protection		1	Communication error has occurred in data from the encoder. Mainly data error due to noise. Encoder cables are connected, but communication data has some errors.	<ul style="list-style-type: none"> Secure the power supply for the encoder of DC4.90V to 5.25V)...pay an attention especially when the encoder cables are long. Separate the encoder cable and the motor cable if they are bound together. Connect the shield to FG.
* Encoder communication data error protection	23	0	Data communication between the encoder is normal, but contents of data are not correct. Mainly data error due to noise. Encoder cables are connected, but communication data has some errors.	
Position deviation excess protection	24	0	Deviation pulses have exceeded the setup of Pr0.14. 1) The motor movement has not followed the command. 2) Setup value of Pr0.14 (Position deviation excess setup) is small.	1) Check that the motor follows to the position command pulses. Check that the output torque has not saturated in torque monitor. Make a gain adjustment. Set up maximum value to Pr0.13 and Pr5.22. Make a encoder wiring as per the wiring diagram. Set up the longer acceleration/deceleration time. Lower the load and speed. 2) Set up a larger value to Pr0.14.
Velocity deviation excess protection		1	The difference between the internal positional command speed and actual speed (speed deviation) exceeds the setup vale of Pr6.02. Note) If the internal positional command speed is forcibly set to 0 due to instantaneous stop caused by the command pulse inhibit input (INH) or CW/CCW over-travel inhibit input, the speed deviation rapidly increases at this moment. Pr6.02 setup value should have sufficient margin because the speed deviation also largely increases on the rising edge of the internal positional command speed.	<ul style="list-style-type: none"> Increase the setup value of Pr6.02. Lengthen the acceleration/deceleration time of internal positional command speed, or improve the follow-up characteristic by adjusting the gain. Disable the excess speed deviation detection (Pr6.02 = 0).

1 Before Using the Products

2 Preparation

3 Connection

4 Setup

5 Adjustment

6 When in Trouble

7 Supplement

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
* Hybrid deviation excess error protection	25	0	<ul style="list-style-type: none"> Position of load by the external scale and position of the motor by the encoder slips larger than the setup pulses with Pr3.28 (Setup of hybrid deviation excess) at full-closed control. During full closed control, numerator of command division/multiplication is changed or switched over. 	<ul style="list-style-type: none"> Check the connection between the motor and the load. Check the connection between the external scale and the driver. Check that the variation of the motor position (encoder feedback value) and the load position (external scale feedback value) is the same sign when you move the load. Check that the numerator and denominator of the external scale division (Pr3.24 and 3.25) and reversal of external scale direction (Pr3.26) are correctly set. Do not change command division/multiplication during full closed control.
Over-speed protection	26	0	The motor rotational speed has exceeded the setup value of Pr5.13.	<ul style="list-style-type: none"> Do not give an excessive speed command. Check the command pulse input frequency and division/multiplication ratio. Make a gain adjustment when an overshoot has occurred due to a poor gain adjustment. Make a wiring connection of the encoder as per the wiring diagram.
2nd Over-speed protection		1	The motor rotational speed has exceeded the setup value of Pr6.15.	
Command pulse input frequency error protection	27	0	The frequency of command pulse input is more than 1.2 times the setting in Pr5.32.	Check the command pulse input for frequency.
Electronic gear error protection		2	<p>Division and multiplication ratio which are set up with the command pulse counts per single turn and the 1st and the 4th numerator/denominator of the electronic gear are not appropriate.</p> <p>The command pulses per 0.167 ms multiplied by the command division and multiplication ratio exceeds 3000 Mpps.</p> <p>The command pulse input fluctuates.</p> <p>Noises mixed with the command pulse input cause counting error.</p>	<ul style="list-style-type: none"> Set the command division and multiplication ratio to a value as small as possible e.g. between 1/1000 and 1000. Check the setup value of electronic gear. If possible, use the line driver I/F. Set Pr5.32 (setting of max. command pulse input) to a value less than 1000 and enable digital filter.
Pulse regeneration limit protection	28	0	The output frequency of pulse regeneration has exceeded the limit.	<ul style="list-style-type: none"> Check the setup values of Pr0.11 and 5.03. To disable the detection, set Pr5.33 to 0.

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
Deviation counter overflow protection	29	0	Positional deviation of encoder pulse reference has exceeded 2 ²⁹ (536870912).	<ul style="list-style-type: none"> • Check that the motor runs as per the position command pulses. • Check that the output torque has not saturated in torque monitor. • Make a gain adjustment. • Set up maximum value to Pr0.13 and Pr5.22. • Make a wiring connection of the encoder as per the wiring diagram.
Safety input protection	30	0	Input photocoupler of both or one of safety input 1 and 2 is OFF.	Check wiring of safety input 1 and 2.
* I/F input duplicated allocation error 1 protection	33	0	Input signals (SI1, SI2, SI3, SI4, SI5) are assigned with two functions.	Allocate correct function to each connector pin.
* I/F input duplicated allocation error 2 protection		1	Input signals (SI6, SI7, SI8, SI9, SI10) are assigned with two functions.	
* I/F input function number error 1 protection		2	Input signals (SI1, SI2, SI3, SI4, SI5) are assigned with undefined number.	
* I/F input function number error 2 protection		3	Input signals (SI6, SI7, SI8, SI9, SI10) are assigned with undefined number.	
* I/F output function number error 1 protection		4	Output signals (SO1, SO2, SO3) are assigned with undefined number.	
* I/F output function number error 2 protection		5	Output signals (SO4, SO5, SO6) are assigned with undefined number.	

Note

- When protective function marked with * in the protective function table is activated, it cannot be disabled by the alarm clear input (A-CLR). To return to the normal operation, turn off power, remove the cause, and then turn on power again.
- Only for position control type is not provided with X3 and analog input.

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
* CL assignment error	33	6	Counter clear function is assigned to a signal number other than SI7.	Allocate correct function to each connector pin.
* INH assignment error		7	Command pulse inhibit input function is assigned to a signal number other than SI10.	
Software limit protection	34	0	When a position command within the specified input range is given, the motor operates outside its working range specified in Pr5.14. 1) Gain is not appropriate. 2) Pr5.14 setup value is low.	1) Check the gain (balance between position loop gain and speed loop gain) and inertia ratio. 2) Increase the setup value of Pr5.14. Or, Set Pr5.14 to 0 to disable the protective function.
* EEPROM parameter error protection	36	0	Data in parameter storage area has been damaged when reading the data from EEPROM at power-on.	<ul style="list-style-type: none"> Set up all parameters again. If the error persists, replace the driver (it may be a failure.) Return the product to the dealer or manufacturer.
		1		
		2		
* EEPROM check code error protection	37	0	Data for writing confirmation to EEPROM has been damaged when reading the data from EEPROM at power-on.	Replace the driver. (it may be a failure). Return the product to a dealer or manufacturer.
		1		
		2		
* Over-travel inhibit input protection	38	0	With Pr5.04, over-travel inhibit input setup = 0, both positive and negative over-travel inhibit inputs (POT/NOT) have been ON. With Pr5.04 = 2, positive or negative over-travel inhibit input has turned ON.	Check that there are not any errors in switches, wires or power supply which are connected to positive direction/ negative direction over-travel inhibit input. Check that the rising time of the control power supply (DC12 to 24V) is not slow.
Analog input 1 (AI1) excess protection	39	0	Higher voltage has been applied to the analog input 1 than the value that has been set by Pr4.24.	<ul style="list-style-type: none"> Set up Pr4.24 correctly. Check the connecting condition of the connector X4. Set up Pr4.24 to 0 and invalidate the protective function.
Analog input 2 (AI2) excess protection		1	Higher voltage has been applied to the analog input 2 than the value that has been set by Pr4.27.	<ul style="list-style-type: none"> Set up Pr4.27 correctly. Check the connecting condition of the connector X4. Set up Pr4.27 to 0 and invalidate the protective function.
Analog input 3 (AI3) excess protection		2	Higher voltage has been applied to the analog input 3 than the value that has been set by Pr4.30.	<ul style="list-style-type: none"> Set up Pr4.30 correctly. Check the connecting condition of the connector X4. Set up Pr4.30 to 0 and invalidate the protective function.

Note

- Only for position control type is not provided with analog input.

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
Absolute system down error protection	40	0	Voltage of the built-in capacitor has fallen below the specified value because the power supply or battery for the absolute encoder has been down. Caution ⚠ Once this error occurs, the alarm cannot be cleared until the absolute encoder is reset.	After connecting the power supply for the battery, clear the absolute encoder.
* Absolute counter over error protection	41	0	Multi-turn counter of the absolute encoder has exceeded the specified value.	<ul style="list-style-type: none"> • Set Pr0.15 to 2 to ignore the multi-turn counter over. • Limit the travel from the machine origin within 32767 revolutions.
Absolute over-speed error protection	42	0	The motor speed has exceeded the specified value when only the supply from the battery has been supplied to 17-bit encoder during the power failure. Caution ⚠ Once this error occurs, the alarm cannot be cleared until the absolute encoder is reset.	<ul style="list-style-type: none"> • Check the supply voltage at the encoder side (5V±5%) • Check the connecting condition of the connector X2.
* Encoder initialization error protection *1	43	0	Encoder initialization error was detected.	Replace the motor.
* Absolute single turn counter error protection *1	44	0	Single turn counter error of encoder has been detected.	Replace the motor.
* Absolute multi-turn counter error protection *1	45	0	Multi turn counter error of encoder has been detected.	Replace the motor.
* Absolute status error protection *1	47	0	Encoder has been running at faster speed than the specified value at power-on.	Arrange so as the motor does not run at power-on.
* Encoder Z-phase error protection*1	48	0	Missing pulse of Z-phase of serial incremental encoder has been detected. The encoder might be a failure.	Replace the motor.

Note

- When protective function marked with * in the protective function table is activated, it cannot be disabled by the alarm clear input (A-CLR). To return to the normal operation, turn off power, remove the cause, and then turn on power again.

1. When in Trouble

Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
* Encoder CS signal error protection*1	49	0	CS signal logic error of serial incremental encoder has been detected. The encoder might be a failure.	Replace the motor.
* Feedback scale wiring error protection	50	0	Communication between the external scale and the driver has been interrupted in certain times, and disconnection detecting function has been triggered.	<ul style="list-style-type: none"> • Make a wiring connection of the external scale as per the wiring diagram. • Correct the miswiring of the connector pins.
* External communication data error protection		1	Communication error has occurred in data from the external scale. Mainly data error due to noise. External scale cables are connected, but communication data has some error.	<ul style="list-style-type: none"> • Secure the power supply for the external scale of DC5±5% (4.75 to 5.25V)...pay attention especially when the external scale cables are long. • Separate the external scale cable and the motor cable if they are bound together. • Connect the shield to FG...refer to wiring diagram.
* External scale status 0 error protection *1	51	0	Bit 0 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	Remove the causes of the error, then clear the external scale error from the front panel. And then, shut off the power to reset.
* External scale status 1 error protection *1		1	Bit 1 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	
* External scale status 2 error protection *1		2	Bit 2 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	
* External scale status 3 error protection *1		3	Bit 3 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	
* External scale status 4 error protection *1		4	Bit 4 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	
* External scale status 5 error protection *1		5	Bit 5 of the external scale error code (ALMC) has been turned to 1. Check the specifications of the external scale.	

Note

- When protective function marked with * in the protective function table is activated, it cannot be disabled by the alarm clear input (A-CLR). To return to the normal operation, turn off power, remove the cause, and then turn on power again.
- Only for position control type is not provided with X5.

1. When in Trouble


Protective function (Detail of error code)

Protective function	Error code No.		Causes	Measures
	Main	Sub		
* A-phase wiring error protection	55	0	A-phase wiring in the external scale is defective, e.g. discontinued.	Check the A-phase wiring connection.
* B-phase wiring error protection		1	B-phase wiring in the external scale is defective, e.g. discontinued.	Check the B-phase wiring connection.
* Z-phase wiring error protection		2	Z-phase wiring in the external scale is defective, e.g. discontinued.	Check the Z-phase wiring connection.
Forced alarm input protection	87	0	Forced alarm input (E-STOP) is applied.	Check the wiring of forced alarm input (E-STOP).
* Motor automatic recognition error protection	95	0 to 4	The motor and the driver has not been matched.	Replace the motor which matches to the driver.
* Other error	99	0	Excessive noise or the like is detected as an abnormal signal. This type of error will occur if the alarm clear is attempted while the safety input 1/safety input 2 is not in normal state (input photocoupler is ON).	<ul style="list-style-type: none"> • Turn off the power once, then re-enter. • If error repeats, this might be a failure. Stop using the products, and replace the motor and the driver. Return the products to the dealer or manufacturer. • Adjust the condition of the safety input 1/ safety input 2 and then start the alarm clear.
	Other No.		Control circuit has malfunctioned due to excess noise or other causes. Some error has occurred inside of the driver while triggering self-diagnosis function of the driver.	<ul style="list-style-type: none"> • Turn off the power once, then re-enter. • If error repeats, this might be a failure. Stop using the products, and replace the motor and the driver. Return the products to the dealer or manufacturer.

1. When in Trouble

Protective function (Detail of error code)

Time characteristics of Err16.0 (Overload protection)



Caution

Use the motor so that actual torque stays in the continuous running range shown in “S-T characteristic” of the motor. For the S-T characteristics, see P.7-55 Motor characteristics (S-T characteristics).

1. When in Trouble

Protective function (Detail of error code)

Software Limit Function (Err34.0)

1) Outline

You can make an alarm stop of the motor with software limit protection (Err34.0) when the motor travels exceeding the movable range which is set up with Pr5.14 (Motor working range setup) against the position command input range.

You can prevent the work from colliding to the machine end caused by motor oscillation.

2) Applicable range

This function works under the following conditions.

	Conditions under which the software limit works
Control mode	• Position control, Full-closed control
Others	• Should be in servo-on condition • Input signals such as the deviation counter clear and command input inhibit, and parameters except for controls such as torque limit setup, are correctly set, assuring that the motor can run smoothly.

3) Cautions

- This function is not a protection against the abnormal position command.
- When this software limit protection is activated, the motor decelerates and stops according to Pr5.10 (sequence at alarm).
The work (load) may collide to the machine end and be damaged depending on the load during this deceleration, hence set up the range of Pr5.14 including the deceleration movement.
- This software limit protection will be invalidated during the trial run and frequency characteristics functioning of the PANATERM.

Note

- Only for position control type is not provided with X5.

Related page

- P.4-55, 4-56 "Details of parameter"


1. When in Trouble

Protective function (Detail of error code)

4) Example of movement


(1) When no position command is entered (Servo-ON status),

The motor movable range will be the travel range which is set at both sides of the motor with Pr5.14 since no position command is entered. When the load enters to the Err34.0 occurrence range (oblique line range), software limit protection will be activated.




(2) When the load moves to the right (at Servo-ON),

When the position command to the right direction is entered, the motor movable range will be expanded by entered position command, and the movable range will be the position command input range + Pr5.14 setups in both sides.



(3) When the load moves to the left (at Servo-ON),

When the position command to the left direction, the motor movable range will be expanded further.



5) Condition under which the position command input range is cleared

The position command input range will be 0-cleared under the following conditions.

- when the power is turned on.
- while the position deviation is being cleared (Deviation counter clear is valid, Pr5.05 (Sequence at over-travel inhibition) is 2 and over-travel inhibition input is valid.)
- At the beginning and ending of trial run via communication.

1. When in Trouble

Protective function (Detail of error code)

Warning Function

When an error condition e.g. overloading occurs, the alarm code is issued to indicate that the corresponding protective function will be triggered if suitable corrective action is not taken. The alarm will be cleared as the cause of the error is removed. However, certain alarm will remain latched for predetermined period as shown in the table below. To forcibly clear the alarm, take the normal alarm clear procedure.

Alarm	Alarm No.	Pr6.27 *1	Content
Overload protection	A0	○	Load factor is 85% or more the protection level.
Over-regeneration alarm	A1	○	Regenerative load factor is 85% or more the protection level.
Battery alarm	A2	Fixed at no time limit.	Battery voltage is 3.2 V or lower.
Fan alarm	A3	○	Fan has stopped for 1 sec. *2
Encoder communication alarm	A4	○	The number of successive encoder communication errors exceeds the specified value.
Encoder overheat alarm	A5	○	The encoder detects overheat alarm.
Oscillation detection alarm	A6	○	Oscillation or vibration is detected.
Lifetime detection alarm	A7	Fixed at no time limit.	The life expectancy of capacity or fan becomes shorter than the specified time.
External scale error alarm	A8	○	The feedback scale detects the alarm.
External scale communication alarm	A9	○	The number of successive feedback scale communication errors exceeds the specified value.

- *1 The “circle” means that a time in the range 1 to 10s or no time limit can be selected through Pr6.27 “Warning latching time”. Note that the battery warning and the end of life warning have no time limit.
- *2 The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal and no fan alarm is displayed.

Before starting gain adjustment, set the following parameters based on the conditions of use, to assure safe operation.

1) Setup of over-travel inhibit input

By inputting the limit sensor signal to the driver, the bumping against mechanical end can be prevented. Refer to interface specification, positive/negative direction over-travel inhibit input (POT/NOT). Set the following parameters which are related to over-travel inhibit input.

Pr5.04 Setup of over-travel inhibit input

Pr5.05 Sequence at over-travel inhibit

Related page P.3-38 (POT/NOT), P.4-43 (Pr5.04, Pr5.05)

2) Setup of torque limit

By limiting motor maximum torque, damage caused by failure or disturbance such as bite of the machine and collision will be minimized. To apply standardized limit through parameters, set Pr0.13 The 1st torque limit.

If the torque limit setup is lower than the value required during the actual application, the following two protective features will be triggered: over-speed protection when overshoot occurs, and excess positional deviation protection when response to the command delays.

By allocating the torque in-limit output (TLC) of interface specification to the output signal, torque limit condition can be detected externally.

Related page P.3-46 (TLC), P.4-11 (Pr0.13), P.4-48 (Pr5.21)

3) Setup of over-speed protection

Generates Err26.0 Over-speed protection when the motor speed is excessively high.

Default setting is the applicable motor maximum speed [r/min] × 1.2.

If your application operates below the motor maximum speed, set Pr5.13 Setup of over-speed level by using the formula below.

Pr5.13 Setup of over-speed level = $V_{max} \times (1.2 \text{ to } 1.5)$

V_{max} : motor maximum speed [r/min] in operating condition

Factor in () is margin to prevent frequent activation of over-speed protection.

When running the motor at a low speed during initial adjustment stage, setup the over-speed protection by multiplying the adjusting speed by a certain margin to protect the motor against possible oscillation.

Related page P.4-46 (Pr5.13)

(Continued ...)

4) Setup of the excess positional deviation protection

During the position control or full-closed control, this function detects potential excessive difference between the positional command and motor position and issues Err24.0 Excess positional deviation protection.

Excess positional deviation level can be set to Pr0.14 Setup of positional deviation excess. The deviation can be detected through command positional deviation [pulse (command unit)] and encoder positional deviation [pulse (encoder unit)], and one of which can be selected by Pr5.20 Position setup unit select. (See the control block diagram.)

Default setting is 100000[pulse (command unit)].

Because the positional deviation during normal operation depends on the operating speed and gain setting, fill the equation below based on your operating condition and input the resulting value to Pr0.14.

• When Pr5.20 = 0 (detection through command positional deviation)

Pr0.14 Setup of positional deviation excess = $V_c/k_p \times (1.2 \text{ to } 2.0)$

V_c : maximum frequency of positional command pulse [pulse (command unit)/s]

K_p : position loop gain [1/s]

Factor in () is margin to prevent frequent activation of excess positional deviation protection.

Note 1) When switching position loop gain K_p , select the smallest value for calculation.

Note 2) When using the positional command filter and damping control, add the following values.

Positional command smoothing filter: $V_c \times \text{filter time constant [s]}$

Positional command FIR filter: $V_c \times \text{filter time constant [s]}/2$

Damping control: $V_c/(\pi \times \text{damping frequency [Hz]})$

• When Pr5.20 = 1 (detection through encoder positional deviation, full-closed positional deviation)

Pr0.14 Setup of positional deviation excess = $V_e/K_p \times (1.2 \text{ to } 2.0)$

V_e : maximum operation frequency [pulse/s] in encoder unit or full-closed unit

K_p : position loop gain [1/s]

Note 3) When switching position loop gain K_p , select the smallest value for calculation.

Note 4) When Pr5.20 = 1, setups of positional command filter and damping control have no effect.

Related page

P.4-11 (Pr0.14), P.4-48 (Pr5.20)

5) Setup of motor working range

During the position control or full-closed control, this function detects the motor position which exceeds the revolutions set to Pr5.14 Motor working range setup, and issues Err34.0 Software limit protection.

Related page


P.4-46 (Pr5.14)

6) Setup of hybrid deviation excess error protection

At the initial operation with full-closed control, operation failure may occur due to reverse connection of external scale or wrong external scale division ratio.

To indicate this type of defect, Err25.0 Hybrid deviation excess error protection is issued when the deviation of motor position (encoder unit) and load position (external scale unit) exceed Pr3.28 Setup of hybrid deviation excess.

Default setting is 16000 pulse (command unit). Because the deviation in normal operation varies with the operation speed and gain setup. Add a margin to this setting according to your operating condition.

Related page  P.4-32 (Pr3.28)

When the motor does not run, refer to P.2-100, "Display of Factor of No-Motor Running" of Preparation as well.

Classification	Causes		Measures
Parameter	Setup of the control mode is not correct	Check that the present control mode is correct with monitor mode of the front panel.	1) Set up Pr0.01 again. 2) Check that the input to control mode switching (C-MODE) of the Connector X4 is correct, when Pr0.01 is set to 3 to 5.
	Selection of torque limit is not correct	Check that the external analog input (N-ATL/ P-ATL) is not used for the torque limit.	1) Set up Pr05.21 to 0 and apply -9 [V] to N-ATL and +9 [V] to P-ATL when you use the external input. 2) Set up Pr05.21 to 1 and set up the max. value to Pr0.13 when you use the parameter value.
	Setup of electronic gear is not correct. (Position/Full-closed)	Check that the motor moves by expected revolution against the command pulses.	1) Check the setups of Pr0.09, Pr0.10 and Pr5.00 to Pr5.02 again. 2) Connect the electronic gear switching input (DIV) of Connector X4 to COM-, or invalidate the division/multiplication switching by setting up the same value to Pr0.09 and Pr5.00.
Wiring	Servo-ON input of Connector X4 (SRV-ON) is open.	In the front panel monitor mode, is the Pin No. corresponding to SRV-ON in " - " state?	Check and make a wiring so as to connect the SRV-ON input to COM-.
	Positive/negative direction over-travel inhibit input of Connector X4 (NOT/POT) is open.	In the front panel monitor mode, is the Pin No. corresponding to NOT/POT in " A " state?	1) Check and make a wiring so as to connect both NOT/POT inputs to COM-. 2) Set up Pr5.04 to 1 (invalid) and reset the power.
	Command pulse input setup is incorrect. (Position/Full-closed)	Check that the input pulse counts and variation of command pulse sum does not slips, with monitor mode of the front panel.	1) Check that the command pulses are entered correctly to the direction selected with Pr0.05. 2) Check that the command pulses are entered correctly in the format selected with Pr0.07.
	Command pulse input inhibition (INH) of Connector X4 is open. (Position/Full-closed)	In the front panel monitor mode, is the Pin No. corresponding to INH in " A " state?	1) Check and make a wiring so as to connect the INH input to COM-. 2) Set up Pr5.18 to 1 (invalid).
	Counter clear input (CL) of Connector X4 is connected to COM-. (Position/Full-closed)	In the front panel monitor mode, is the Pin No. corresponding to CL in " A " state?	1) Check and make wiring so as to open the CL input 2) Set up Pr5.17 to 0 (invalid).

Related page

- P.2-91 ... "How to Use the Front Panel"
- P.3-30 "Inputs and outputs on connector X4"
- P.4-4... "Details of parameter"

3. Troubleshooting

Motor Does Not Run

When the motor does not run, refer to P.2-100, "Display of Factor of No-Motor Running" of Preparation as well.

Classification	Causes		Measures
Wiring	Speed command is invalid (Velocity)	Check that the velocity command input method (external analog command/internal velocity command) is correct.	1) Check the setups of Pr3.02 to Pr3.03 again by setting up Pr3.00 to 0, when you use the external analog command. 2) Set up Pr3.04 to Pr3.07 and Pr3.08 to Pr3.11 by setting up Pr3.00 to either one of 1, 2 or 3, when you use the internal speed command.
	Speed zero clamp input (ZEROSPD) of Connector X4 is open. (Velocity/Torque)	In the front panel monitor mode, is the Pin No. corresponding to ZEROSPD in "A" state?	1) Check and make wiring so as to connect speed zero clamp input to COM-. 2) Set up Pr3.15.
	Torque command is invalid (Torque)	Check that the torque command input method (SPR/TRQR input, P-ATL/TRQR input) is correct.	1) Check that the input voltage is applied correctly by setting up Pr3.17 to 0, when you use SPR/TRQR input. 2) Check that the input voltage is applied correctly by setting up Pr3.17 to 1, when you use the P-ATL/TRQR input.
	Velocity control is invalid (Torque)	Check that the velocity limit input method (parameter velocity, SPR/TRQR/SPL input) is correct.	1) Set up the desired value to Pr3.21 by setting up Pr3.17 to 0, when you use the parameter speed. 2) Check that the input voltage is applied correctly by setting up Pr3.17 to 1, when you use the SPR/TRQR/SPL input.
Installation	Main power is shut off.	In the front panel monitor mode, is the Pin No. corresponding to S-RDY in "-" state?	Check the wiring/voltage of main power of the driver (L1, L2 and L3).
	The motor shaft drags, the motor does not run.	1) Check that you can turn the motor shaft, after turning off the power and separate it from the machine. 2) Check that you can turn the motor shaft while applying DC24V to the brake in case of the motor with electromagnetic brake.	If you cannot turn the motor shaft, consult with the dealer for repair.

Classification	Causes	Measures
Parameter	Setup of the control mode is not correct.	If you set up Pr0.01 to 1 (Velocity control mode) by mistake at position control mode, the motor runs slowly at servo-ON due to speed command offset. Change the setup of Pr0.01 to 0.
Adjustment	Gain adjustment is not proper.	Increase the setup of Pr1.01, 1st velocity loop gain. Enter torque filter of Pr1.04 and increase the setup of Pr1.01 again.
	Velocity and position command are not stable.	Check the motor movement with connector X7 of the front panel or the waveform graphic function of the PANATERM. Review the wiring, connector contact failure and controller.
Wiring	Each input signal of Connector X4 is chattering. 1) Servo-ON signal	1) Check the wiring and connection between Pin29 and 41 of the Connector X4 using the display function of I/O signal status. Correct the wiring and connection so that the Servo-ON signal can be turned on normally. Review the controller.
	2) Positive/Negative direction torque limit input signal	2) Check the wiring and connection between Pin-18 and 17, 16 and 17 of the Connector X4 using tester or oscilloscope. Correct the wiring and connection so that Positive/Negative direction torque limit input can be entered normally.
	3) Deviation counter input signal	3) Check the wiring and connection between Pin-30 and 41 of the Connector X4 using display function of I/O signal status. Correct the wiring and connection so that the deviation counter input can be turned on normally. Review the controller.
	4) Speed zero clamp signal	4) Check the wiring and connection between Pin-26 and 41 of the Connector X4 using Display function of I/O signal status. Correct the wiring and connection so that the speed zero clamp input can be entered normally. Review the controller.
	5) Command pulse inhibition input	5) Check the wiring and connection between Pin-33 and 41 of the Connector X4 using display function of I/O signal status. Correct the wiring and connection so that the command pulse inhibition input can be entered normally. Review the controller.
	Noise is on the velocity command.	Use a shield cable for connecting cable to the Connector X4. Separate the power line and signal line (30cm or longer) in the separate duct.
	Slip of offset	Check the voltage between Pin-14 and 15 (speed command input) using a tester or an oscilloscope.
	Noise is on the position command.	Use a shield cable for connecting cable to the Connector X4. Separate the power line and signal line (30cm or longer) in the separate duct.

Related page

- P.4-4 "Details of parameter" • P.3-30 "Inputs and outputs on connector X4"
- P.7-26 "Outline of Setup support software "PANATERM"

Classification	Causes	Measures
System	Position command is not correct. (Amount of command pulse)	Count the feedback pulses with a monitor function of the PANATERM or feedback pulse monitor mode of the console while repeating the movement of the same distance. If the value does not return to the same value, review the controller. Make a noise measure to command pulse.
	Captures the positioning complete signal at the edge.	Monitor the deviation at positioning complete signal reception with the Connector X7 or the waveform graphic function of the PANATERM. Make the controller capture the signal not at the edge but with some time allowance.
	Shape or width of the command pulse is not per the specifications.	If the shape of the command pulse is broken or narrowed, review the pulse generating circuit. Make a noise measure.
	Noise is superposed on deviation counter clear input CL (Connector X4, Pin-30).	Make a noise measure to external DC power supply and make no wiring of the unused signal lines.
Adjustment	Position loop gain is small.	Check the position deviation with the monitor function of the PANATERM or at the monitor mode of the console. Increase the setup of Pr1.00 within the range where no oscillation occurs.
Parameter	Setup of the positioning complete range is large.	Lower the setup of Pr4.31 within the range where no chattering of complete signal occurs.
	Command pulse frequency have exceeded 500kpps or 4Mpps.	Lower the command pulse frequency. Change the division/multiplication ratio of 1st and 2nd numerator of command division/multiplication, Pr0.09 and Pr0.10. Use a pulse line interface exclusive to line driver when pulse line interface is used.
	Setup of the division/multiplication is not correct.	Check if the repetition accuracy is same or not. If it does not change, use a larger capacity motor and driver.
	Velocity loop gain is proportion action at motor in stall.	<ul style="list-style-type: none"> Set up Pr1.02 and Pr1.07 of time constant of velocity loop integration to 9999 or smaller. Review the wiring and connection so that the connection between Pin-27 and 41 of the gain switching input connector, Connector X4 becomes off while you set up Pr1.14 of 2nd gain setup, to 1.
Wiring	Each input signal of Connector X4 is chattering. 1) Servo-ON signal 2) Deviation counter clear input signal 3) Positive/Negative direction torque limit input signal 4) Command pulse inhibition input	<ol style="list-style-type: none"> 1) Check the wiring and connection between Pin29 and 41 of the connector, Connector X4 using the display function of I/O signal status. Correct the wiring and connection so that the servo-On signal can be turned on normally. Review the controller. 2) Check the wiring and connection between Pin-30 and 41 of the connector, Connector X4 using display function of I/O signal status. Correct the wiring and connection so that the deviation counter clear input can be turned on normally. Review the controller. 3 Check the wiring and connection between Pin-18 and 17, 16 and 17 of the connector, Connector X4 using tester or oscilloscope. Correct the wiring and connection so that Positive/Negative direction torque limit input can be entered normally. 4) Check the wiring and connection between Pin-33 and 41of the connector, Connector X4 using display function of I/O signal status. Correct the wiring and connection so that the command pulse inhibition input can be entered normally. Review the controller.
Installation	Load inertia is large.	Check the overshoot at stopping with graphic function of the PANATERM. If no improvement is obtained, increase the driver and motor capacity.

Related page

- P.4-4 "Details of parameter"
- P.3-30 "Inputs and outputs on connector X4"
- P.7-26 "Outline of Setup support software "PANATERM"

Classification	Causes	Measures
System	Z-phase is not detected.	Check that the Z-phase matches to the center of proximity dog. Execute the homing matching to the controller correctly.
	Homing creep speed is fast.	Lower the homing speed at origin proximity. Or widen the origin sensor.
Wiring	Chattering of proximity sensor (proximity dog sensor) output .	Check the dog sensor input signal of the controller with oscilloscope. Review the wiring near to proximity dog and make a noise measure or reduce noise.
	Noise is on the encoder line.	Reduce noise (installation of noise filter or ferrite core), shield treatment of I/F cables, use of a twisted pair or separation of power and signal lines.
	No Z-phase signal output.	Check the Z-phase signal with oscilloscope. Check that the Pin-13 of the connector, connector X4 is connected to the earth of the controller. Connect the earth of the controller because the open collector interface is not insulated. Replace the motor and driver. Request for repair.
	Miswiring of Z-phase output.	Check the wiring to see only one side of the line driver is connected or not. Use a CZ output (open collector if the controller is not differential input.

Classification	Causes	Measures
Wiring	Noise is on the speed command.	Measure the speed command inputs of Pin-14 and 15 of the connector, Connector X4 with an oscilloscope. Reduce noise (installation of noise filter or ferrite core), shield treatment of I/F cables, use of a twisted pair, separation of power and signal lines.
Adjustment	Gain setup is large.	Lower the gain by setting up lower values to Pr1.01 and 1.06, of velocity loop gain and Pr1.00 and Pr1.05 of position loop gain.
Installation	Resonance of the machine and the motor.	Re-adjust Pr1.04 and 1.09. Check if the machine resonance exists or not with frequency characteristics analyzing function of the PANATERM. Set up the notch frequency to Pr2.01, Pr2.04, Pr2.07 or Pr2.10 if resonance exists.
	Motor bearing	Check the noise and vibration near the bearing of the motor while running the motor with no load. Replace the motor to check. Request for repair.
	Electro-magnetic sound, gear noise, rubbing noise at brake engagement, hub noise or rubbing noise of encoder.	Check the noise of the motor while running the motor with no load. Replace the motor to check. Request for repair.

6

When in Trouble

3. Troubleshooting

Overshoot/Undershoot,
Overheating of the Motor (Motor Burn-Out)

Classification	Causes	Measures
Adjustment	Gain adjustment is not proper.	Check with graphic function of PANATERM or monitor (connector X7). Make a correct gain adjustment. Refer to "Adjustment".
Installation	Load inertia is large.	Check with graphic function of PANATERM or monitor (Connector X7). Make an appropriate adjustment. Increase the motor and driver capacity and lower the inertia ratio. Use a gear reducer.
	Looseness or slip of the machine.	Review the mounting to the machine.
	Ambient temperature, environment.	Lower the temperature with cooling fan if the ambient temperature exceeds the predications.
	Stall of cooling fan, dirt of fan ventilation duct.	Check the cooling fans of the driver and the machine. Replace the driver fan or request for repair. (The upper fan on the H-frame driver stops during servo OFF to save energy. This is normal.)
	Mismatching of the driver and the motor.	Check the name plates of the driver and the motor. Select a correct combination of them referring to the instruction manual or catalogue.
	Failure of motor bearing.	Check that the motor does not generate rumbling noise while turning it by hand after shutting off the power. Replace the motor and request for repair if the noise is heard.
	Electromagnetic brake is kept engaged (left un-released).	Check the voltage at brake terminals. Apply the power (DC24V) to release the brake.
	Motor failure (oil, water or others)	Avoid the installation place where the motor is subject to high temperature, humidity, oil, dust or iron particles.
	Motor has been turned by external force while dynamic brake has been engaged.	Check the running pattern, working condition and operating status, and inhibit the operation under the condition of the left.

6

When in Trouble

3. Troubleshooting

Motor Speed Does Not Reach to the Setup,
Motor Revolutions (Travel) Is Too Large or Small

Classification	Causes	Measures
Parameter	Velocity command input gain is not correct.	Check that the setup of Pr3.02, speed command input gain, is made so as to make the setup of 500 makes 3000 r/min/6V.
Adjustment	Position loop gain is low.	Set up Pr1.00and Pr1.05, position loop gain to approx. 1000.
	Division/Multiplication is not proper.	Set up correct values to Pr0.09, 1st numerator of electronic gear, Pr0.11, numerator multiplier of electronic gear and Pr0.10, denominator of electronic gear. Refer to parameter setup at each mode.

Related page

• P.4-8... "Details of parameter" • P.7-26 "Outline of Setup support software "PANATERM"

Classification	Causes	Measures
Parameter	No writing to EEPROM has been carried out before turning off the power.	Refer to P.2-107, "EEPROM Writing Mode" of Preparation.

This image shows a full page of white paper with horizontal ruling lines. The lines are evenly spaced and extend across the width of the page. At the top center, there is a header area containing the word "MEMO" in a bold, black, sans-serif font.

7. Supplement

1. Safety function

Outline	7-2
Input & output signals	7-3
Safety Circuit Block Diagram	7-5
Timing Chart	7-6
Example of connection	7-8

2. Absolute system

Outline	7-10
Configuration	7-11
Battery (for Backup) Installation	7-12
Setup (Initialization) of Absolute Encoder	7-16
Transferring absolute data	7-16
Transferring external scale absolute data	7-21
Display of Battery Alarm	7-25

3. Outline of Setup Support Software, "PANATERM"

Setup on the PC	7-26
-----------------------	------

4. Communication

Outline	7-27
Specifications	7-28
List of Communication Command	7-39
Details of Communication Command	7-40

5. Motor Characteristics (S-T Characteristics)

Motor	7-55
-------------	------

6. Dimensions

Driver A-frame, B-frame	7-73
C-frame, D-frame (200 V)	7-74
D-frame (400 V), E-frame (200 V)	7-75
E-frame (400 V), F-frame	7-76
G-frame	7-77
H-frame	7-78
Motor	7-79

7. Options

Noise Filter	7-94
Surge Absorber	7-98
Noise Filter for Signal Lines	7-99
Junction Cable for Encoder	7-100
Junction Cable for Motor (Without brake)	7-103
Junction Cable for Motor (With brake)	7-106
Junction Cable for Brake	7-108
Connector Kit	7-109
Battery For Absolute Encoder	7-118
Mounting Bracket	7-119
Reactor	7-120
External Regenerative Resistor	7-122
Recommended components(Surge absorber for motor brake)	7-124
List of Peripheral Equipments	7-125

Outline description of safe torque off (STO)

The safe torque off (STO) function is a safety function that shuts the motor current and turns off motor output torque by forcibly turning off the driving signal of the servo driver internal power transistor. For this purpose, the STO uses safety input signal and hardware (circuit).

When STO function operates, the servo driver turns off the servo ready output signal (S-RDY) and enters safety state.

This is an alarm condition and the 7-seg LED on the front panel displays the error code number.

Safety precautions

- When using the STO function, be sure to perform equipment risk assessment to ensure that the system conforms to the safety requirements.
- Even while the STO function is working, the following potential safety hazards exist. Check safety in risk assessment.
 - The motor may move when external force (e.g. gravity force on vertical axis) is exerted on it. Provide an external brake, etc., as necessary to secure the motor. Note that the purpose of motor with brake is holding and it cannot be used for braking application.
 - When parameter Pr5.10 Sequence at alarm is set to free run (disable dynamic brake), the motor is free run state and requires longer stop distance even if no external force is applied. Make sure that this does not cause any problem.
 - When power transistor, etc., becomes defective, the motor will move to the extent equivalent of 180 electrical angle (max.). Make sure that this does not cause any problem.
 - The STO turns off the current to the motor but does not turn off power to the servo driver and does not isolate it. When starting maintenance service on the servo driver, turn off the driver by using a different disconnecting device.
- External device monitor (hereafter EDM) output signal is not a safety signal. Do not use it for an application other than failure monitoring.
- Dynamic brake and external brake release signal output are not related to safety function. When designing the system, make sure that the failure of external brake release during STO condition does not result in danger condition.
- When using STO function, connect equipment conforming to the safety standards.

Note



• Only for position control type is not provided with X3 (Safety function connector).

Related page



• P.2-2 "Conformance to international standards" • P.2-96 "How to Use the Front Panel"
• P.3-30 "Inputs and outputs on connector X4"

Safety input signal

For list of connector pin numbers, refer to P.2-53,

Signal	Symbol	Pin No.	Contents	Control mode
Safety input 1	SF1+	4	<ul style="list-style-type: none">• Input 1 that triggers STO function. This input turns off the upper arm drive signal of power transistor.• When using the function, connect this pin in a way so that the photocoupler of this input circuit turns off to activate STO function.	Compatible all control mode
	SF1–	3		
Safety input 2	SF2+	6	<ul style="list-style-type: none">• Input 2 that triggers STO function. This input turns off the lower arm drive signal of power transistor.• When using the function, connect this pin in a way so that the photocoupler of this input circuit turns off to activate STO function.	
	SF2–	5		

<Response time>

Safety input 1 or 2 enables STO to operate: within 5 ms of response time, the motor output torque will be turned off.


Caution• **Safety equipment self-diagnosis L pulse**

Safety output signal from the safety controller and safety sensor may include L pulse for self-diagnosis.

To prevent the L pulse from mis-triggering STO function, the safety input circuit has built-in filter that removes the self-diagnosis L pulse.

Therefore, if the off period of safety input signal less than 1 ms, the safety input circuit does not detect this “off” event.

To validate this “off” period, turn off the input signal for more than 5 ms.

**Note**

• Only for position control type is not provided with X3 (Safety function connector).

1. Safety function

Input & output signals

External device monitor (EDM) output signal

The monitor output signal is used by the external device to monitor the state of the safety input signal. Connect the monitor output to the external device monitor terminal of the safety devices such as safety controller and safety sensor.

Signal	Symbol	Pin No.	Contents	Control mode
EDM output	EDM+	8	Outputs monitor signal that is used to check the safety function.	Compatible all control mode
	EDM-	7	Caution ⚠ This output signal is not a safety output.	

Logical relationship between safety input signal and EDM output signal


When both safety input 1 and 2 are off, i.e. when STO function of 2 safety input channels are active, the photocoupler in EDM output circuit turns on.

Signal	Symbol	Photocoupler logic			
Safety input	SF1	ON	ON	OFF	OFF
	SF2	ON	OFF	ON	OFF
EDM output	EDM	OFF	OFF	OFF	ON

By monitoring the logics (all 4 states) of photocoupler shown in the table above, the external device can determine the status (normal or abnormal) of safety input circuit and EDM output circuit.


Note ⚠ Maximum delay time from input of safety 1 and 2 signals to output of EDM signal is 6 ms.

Note ⚠ • Only for position control type is not provided with X3 (Safety function connector).

**Note**

• Only for position control type is not provided with X3 (Safety function connector).

Operating timing for safety status



*1 $t1$ is the value set to Pr4.38 Setup of mechanical brake action at running or the time at which the motor revolution speed drops below the time set to Pr4.39 Brake release speed setup, whichever comes first.

*2 Dynamic brake operates to the setting of Pr5.10 Sequence at alarm.

*3 When safety input 1 or 2 turns off, the state changes to STO condition.

Note

• Only for position control type is not provided with X3 (Safety function connector).


Related page

• P.4-41, 4-42 "Pr4.38, Pr4.39" • P.4-45 "Pr5.10"

1. Safety function

Timing Chart

Return timing from safety state



*1 Photocouplers for safety input 1 and 2 should be turned on again with servo-on input turned off. Otherwise, alarm occurs, and should be cleared.

Alarm clear should be performed after the safety input 1 and 2 have been turned back to on.

Otherwise, alarm occurs.

*2 This is an alarm condition and the dynamic brake operates according to Pr5.10 Sequence at alarm.

*3 This is normal servo-off condition and the dynamic brake operates according to Pr5.06 Sequence at servo-off.

Note




• Only for position control type is not provided with X3 (Safety function connector).

• P.4-44 "Pr5.06" • P.4-45 "Pr5.10"


1. Safety function

Example of connection


Example of connection to safety switch



Example of connection to safety sensor



Example of connection to safety controller



Note

• Only for position control type is not provided with X3 (Safety function connector).

1. Safety function

Example of connection

Example of connection when using multiple axes



- Capacity requirement per safety output (source) channel: $50 \times \text{No. of connected axes}$ (mA)
- 24 VDC supply allowable voltage: $24 \text{ V} \pm 15\%$
- Maximum No. of connectable axes: 8

Note

- Only for position control type is not provided with X3 (Safety function connector).

Outline of Absolute System

When you compose an absolute system using an absolute encoder, you are not required to carry out homing operation at the power-on, and this function suits very well to such an application as a robot.

Connect the host controller with the MINAS-A5 with absolute specifications. (motor with absolute encoder and driver with absolute spec) and set up the parameter, Pr0.15 to 0 or 2, then connect the battery for absolute encoder to compose an absolute system with which you can capture the exact present position information after the power-ON.

Shift the system to origin once after installing the battery and clear the multi-turn data by clearing the absolute encoder, then you can detect the absolute position without carrying out homing operation.

Via RS232 or RS485 communication, the host controller can connect up to 32 MINAS-A5 and capture the present position information as serial data to obtain the absolute position of each axis by processing each data.

Applicable Mode

You can use all of MINAS A5 series driver in absolute specifications by setting up parameter. Use the motor which 8th place (designated for rotary encoder specifications) is "S" (7-wire type).

M * M * * * * S * * * *

8th place

Rotary encoder specifications

Absolute Specifications

There are 3 connecting methods of the host controller and MINAS-A5 driver as described below, and select a method depending on the interface of the host controller specs or number of axis to be connected. Designate a module ID to Pr5.31 of each MINAS-A5 driver when you connect multiple MINAS-A5 in communication to one host controller as shown below.


[Parameter Pr5.31]

- When you connect each MINAS-A5 to the host separately with RS232 and switch the communication individually, designate 0 to 31 to each MINAS-A5.
- When you connect one MINAS-A5 to the host with RS232 and connect each MINAS-A5 with RS485, designate 0 to the MINAS-A5 connected with the host, and designate 1 to 31 to other MINAS-A5. (Max 32 axis are connectable.)
- When you connect MINAS-A5 to the host with RS485, the host is given module ID of 0, and designate 1 to 31 to MINAS-A5. (Max 31 axis are connectable.)

Note


- Only for position control type is not provided with X2 (Communication connector).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Configuration of absolute system of scale using RS232 interface



Related page P.7-28 "Connection of Communication Line"

Configuration of absolute system of scale using RS485 interface



Related page P.7-29 "Connection of Communication Line"

Note

- * Battery for absolute encoder is required to store the multi-turn data into the encoder. Connect the battery between BAT+ and BAT- of the motor.
- Only for position control type is not provided with X2 (Communication connector).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

First Installation of the Battery

After installing and connecting the back-up battery to the motor, execute an absolute encoder setup. Refer to P.7-16, "Setup (initialization) of Absolute Encoder".

It is recommended to perform ON/OFF action once a day after installing the battery for refreshing the battery.

A battery error might occur due to voltage delay of the battery if you fail to carry out the battery refreshment.

Caution

Use the following battery for absolute encoder.

BatteryPart No. : DV0P2990 (3.6V 2000mAh)

Battery boxPart No. : DV0P4430

Replacement of the Battery

It is necessary to replace the battery for absolute encoder when battery alarm occurs.

Replace while turning on the control power. Data stored in the encoder might be lost when you replace the battery while the control power of the driver is off.

After replacing the battery, clear the battery alarm. Refer to P.7-25, "How to Clear the Battery Alarm".


Caution

When you execute the absolute encoder with the front panel (refer to P.2-113 of Preparation), or via communication (refer to P.7-54), all of error and multi-turn data will be cleared together with alarm, and you are required to execute "Setup (Initialization) of absolute encoder" (refer to P.7-16).


How to Replace the Battery

1) Refresh the new battery.

Connector with lead wire of the battery to CN601 and leave of 5 min. Pull out the connector from CN601 5 min after.



2) Take off the cover of the battery box.



Note

- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.


Related page

- P.7-118 "Battery For Absolute Encoder"


2. Absolute system

Battery (for Backup) Installation

3) Install the battery to the battery box.



4) Close the cover of the battery box.



Caution

- Be absolutely sure to follow the precautions below since improper use of the battery can cause electrolyte to leak from the battery, giving rise to trouble where the product may become corroded, and/or the battery itself may rupture.
 - 1) Insert the battery with its “+” and “-” electrodes oriented correctly.
 - 2) Leaving a battery which has been used for a long period of time or a battery which is no longer usable sitting inside the product can cause electrolyte leakage and other trouble. For this reason, ensure that such a battery is replaced at an early date. (As a general guideline, it is recommended that the battery be replaced every two years.)
 - The electrolyte inside the battery is highly corrosive, and if it should leak out, it will not only corrode the surrounding parts but also give rise to the danger of short-circuiting since it is electrically conductive. For this reason, ensure that the battery is replaced periodically.
 - 3) Do not disassemble the battery or throw it into a fire.
 - Do not disassemble the battery since fragments of the interior parts may fly into your eyes, which is extremely dangerous. It is also dangerous to throw a battery into a fire or apply heat to it as doing so may cause it to rupture.
 - 4) Do not cause the battery to be short-circuited. Under no circumstances must the battery tube be peeled off.
 - It is dangerous for metal items to make contact with the “+” and “-” electrodes of the battery since such objects may cause a high current to flow all at once, which will not only reduce the battery performance but also generate considerable heat, possibly leading to the rupture of the battery.
 - 5) This battery is not rechargeable. Under no circumstances must any attempt be made to recharge it.

Caution

The disposal of used batteries after they have been replaced may be subject to restrictions imposed by local governing authorities. In such cases, ensure that their disposal is in accordance with these restrictions.

2. Absolute system

Battery (for Backup) Installation

Life of the battery

Following example shows the life calculation of the back-up battery used in assumed robot operation.

2000[mAh] of battery capacity is used for calculation.


Note that the following value is not a guaranteed value, but only represents a calculated value.

Caution

The values below were calculated with only the current consumption factored in. The calculations do not factor in electrolyte leakage and other forms of battery deterioration.

Life time may be shortened depending on ambient condition.

1) 2 cycles/day



a : Current consumption in normal mode 3.6[μA]

b : Current consumption at power failure timer mode 280[μA]

* Power failure timer mode...Action mode in time period when the motor can respond to max. speed even the power is off (5sec).

c : Current consumption at power failure mode 110[μA]

Annual consumption capacity =

$$(10h \times a + 0.0014h \times b + 2h \times c) \times 2 \times 313 \text{ days} + 24h \times c \times 52 \text{ days} = 297.8[\text{mAh}]$$

$$\text{Battery life} = 2000[\text{mAh}] / 297.8[\text{mAh}] = 6.7 (6.7159) [\text{year}]$$

2) 1 cycle/day

(2nd cycle of the above 1) is for rest.

Annual consumption capacity =

$$(10h \times a + 0.0014h \times b + 14h \times c) \times 313 \text{ days} + 24h \times c \times 52 \text{ days} = 640.6[\text{mAh}]$$

$$\text{Battery life} = 2000[\text{mAh}] / 640.6[\text{mAh}] = 3.1 (3.1715) [\text{year}]$$

2. Absolute system

Battery (for Backup) Installation

When you make your own cable for 17-bit absolute encoder

When you make your own cable for 17-bit absolute encoder, connect the optional battery for absolute encoder, DV0P2990 as per the wiring diagram below. Connector of the battery for absolute encoder shall be provided by customer as well.

Caution


Install and fix the battery securely. If the installation and fixing of the battery is not appropriate, it may cause the wire breakdown or damage of the battery.

Refer to the instruction manual of the battery for handling the battery.

• Installation Place

- 1) Indoors, where the products are not subjected to rain or direct sun beam.
- 2) Where the products are not subjected to corrosive atmospheres such as hydrogen sulfide, sulfurous acid, chlorine, ammonia, chloric gas, sulfuric gas, acid, alkaline and salt and so on, and are free from splash of inflammable gas, grinding oil, oil mist, iron powder or chips and etc.
- 3) Well-ventilated and humid and dust-free place.
- 4) Vibration-free place

• Wiring Diagram



Note

- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Related page

- P.7-118 "Battery For Absolute Encoder"

Absolute multi-turn data will be maintained by the absolute encoder battery.

When operating the machine for the first time after installing the battery to the absolute encoder, clear the encoder data (multi-turn data) to 0 at the origin by following the procedure described below.

Clear the absolute encoder from the front panel (see P.2-113) or PANATERM. Turn off power and then on again.

Transfer the absolute data (absolute data of external scale) from the servo driver to the host controller: turn on power and wait until the servo ready output (S-RDY) is turned on, and then start transfer.

Setup of serial communication interface on host controller

• RS232

Baud rate	2400, 4800, 9600, 19200, 38400, 57600, 115200bps
Data	8 bit
Parity	none
Start bit	1 bit
Stop bit	1 bit

The baud rate is set according to Pr5.29 Baud rate setup of RS232 communication.

• RS485

Baud rate	2400, 4800, 9600, 19200, 38400, 57600, 115200bps
Data	8 bit
Parity	none
Start bit	1 bit
Stop bit	1 bit

The baud rate is set according to Pr5.30 Baud rate setup of RS485 communication.

Note

- Only for position control type is not provided with X2 (Communication connector).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Related page


- P.3-30 "Inputs and outputs on connector X4"
- P.4-50 "Details of parameter"

2. Absolute system

Transferring absolute data

RS232 Communication Protocol

Refer to the instruction manual of the host for the transmission/reception method of command.



Data of *1 and *2 are determined by the setup of Pr5.31 "Axis address".

Axis address (example)	Data of *1	Data of *2
0	00h	2Eh
1	01h	2Dh
2	02h	2Ch
3	03h	2Bh
4	04h	2Ah
5	05h	29h
6	06h	28h
7	07h	27h
8	08h	26h
9	09h	25h
10	0Ah	24h
11	0Bh	23h
12	0Ch	22h
13	0Dh	21h
14	0Eh	20h
15	0Fh	1Fh
16	10h	1Eh
17	11h	1Dh
18	12h	1Ch
19	13h	1Bh
20	14h	1Ah
21	15h	19h
22	16h	18h
23	17h	17h
24	18h	16h
25	19h	15h
26	1Ah	14h
27	1Bh	13h
28	1Ch	12h
29	1Dh	11h
30	1Eh	10h
31	1Fh	0Fh

Check sum becomes OK'ed when the lower 8-bit of the sum of the received absolute data (15 characters) is 0.

Enter the Pr5.31 value of the driver to which you want to communicate from the host to axis (*1 data) of the command block, and transmit the command according to the RS232 communication protocol. For details of communication, refer to P.7-27, "Communication".

Caution

- Allow 50ms or longer interval for axis switching when you want to capture multiple axes data.
- It is recommended for you to repeat the above communication more than 2 times to confirm the absolute data coincide, in order to avoid mis-operation due to unexpected noise.

Note


- Only for position control type is not provided with X2 (Communication connector).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

2. Absolute system

Transferring absolute data

RS485 Communication Protocol

Refer to the instruction manual of the host for the transmission/reception method of command. Following shows the communication example of the driver to Pr5.31 "Axis address = 1".



Data of *1, *2 and *3 are determined by the setup of Pr5.31 "Axis address".

Axis address (example)	Data of *1	Data of *2	Data of *3
0	not usable with RS485 communication		
1	81h	01h	2Dh
2	82h	02h	2Ch
3	83h	03h	2Bh
4	84h	04h	2Ah
5	85h	05h	29h
6	86h	06h	28h
7	87h	07h	27h
8	88h	08h	26h
9	89h	09h	25h
10	8Ah	0Ah	24h
11	8Bh	0Bh	23h
12	8Ch	0Ch	22h
13	8Dh	0Dh	21h
14	8Eh	0Eh	20h
15	8Fh	0Fh	1Fh
16	90h	10h	1Eh
17	91h	11h	1Dh
18	92h	12h	1Ch
19	93h	13h	1Bh
20	94h	14h	1Ah
21	95h	15h	19h
22	96h	16h	18h
23	97h	17h	17h
24	98h	18h	16h
25	99h	19h	15h
26	9Ah	1Ah	14h
27	9Bh	1Bh	13h
28	9Ch	1Ch	12h
29	9Dh	1Dh	11h
30	9Eh	1Eh	10h
31	9Fh	1Fh	0Fh

Check sum becomes OK'ed when the lower 8-bit of the sum of the received absolute data (15 characters) is 0.

Command from the host will be transmitted to the desired driver based on RS485 transmission protocol. For details of communication, refer to P.7-27, "Communication".

Caution

- Allow 50ms or longer interval for axis switching when you want to capture multiple axes data.
- It is recommended for you to repeat the above communication more than 2 times to confirm the absolute data coincide, in order to avoid mis-operation due to unexpected noise.

Note


- Only for position control type is not provided with X2 (Communication connector).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

2. Absolute system


Transferring absolute data

Composition of Absolute Data


Absolute data consists of single-turn data which shows the absolute position per one revolution and multi-turn data which counts the number of revolution of the motor after clearing the encoder.



Single-turn data and multi-turn data are composed by using 15-character data (hexadecimal binary code) which are received via RS232 or RS485.



• Details of multi-turn data



Single-turn data ← Single-turn data (H) × 10000h + Single-turn data (M) × 100h + Single-turn data (L)

multi-turn data ← multi-turn data (H) × 100h + multi-turn data (L)

Remarks

If the multi-turn data of the above fig. is between 32768 to 65535, convert it to signed date after deducting 65536.

Note

- Only for position control type is not provided with X2 (Communication connector).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

2. Absolute system

Transferring absolute data

- Encoder status (L)-----1 represents error occurrence.

Encoder status (L)							
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
			0				
(1)	(2)	(3)		(4)	(5)	(6)	(7)

- (1) Over-speed → Err42.0 (Absolute over-speed error protection)
- (2) Full absolute status → Err47.0 (Absolute status error protection)
- (3) Counter error → Err44.0 (Absolute single-turn counter error protection)
- (4) Counter overflow → Err41.0 (Absolute counter over error protection)
- (5) Multi-turn error → Err45.0 (Absolute multi-turn counter error protection)
- (6) Battery error → Err40.0 (Absolute system down error protection)
- (7) Battery alarm → Alarm No.A2 "Battery alarm"

- Encoder status (L)-----1 represents error occurrence.

Encoder status (H)							
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
0	0			0	0	0	0

Battery error

One of the following has occurred.

Battery alarm, multi-turn error, counter overflow, counter error, full absolute status, Counter overflow multi-turn error, battery error or battery alarm

Remarks For detail of the Encoder status, refer to the Encoder specification.

Remarks • Transmit the absolute data while fixing the motor with brake by turning to Servo-Off.


Note

- Only for position control type is not provided with X2 (Communication connector).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Related page • P.6-4 "Protective Function" • P.7-25 "Display of Battery Alarm"

External scale RS232 communication procedure

Refer to the instruction manual of the host for the transmission/reception method of command. Following shows the communication example of the driver to Pr5.31 "Axis address = 1".



Data of *1 and *2 are determined by the setup of Pr5.31 "Axis address".

Axis address (example)	Data of *1	Data of *2
0	00h	3Eh
1	01h	3Dh
2	02h	3Ch
3	03h	3Bh
4	04h	3Ah
5	05h	39h
6	06h	38h
7	07h	37h
8	08h	36h
9	09h	35h
10	0Ah	34h
11	0Bh	33h
12	0Ch	32h
13	0Dh	31h
14	0Eh	30h
15	0Fh	2Fh
16	10h	2Eh
17	11h	2Dh
18	12h	2Ch
19	13h	2Bh
20	14h	2Ah
21	15h	29h
22	16h	28h
23	17h	27h
24	18h	26h
25	19h	25h
26	1Ah	24h
27	1Bh	23h
28	1Ch	22h
29	1Dh	21h
30	1Eh	20h
31	1Fh	1Fh

Check sum becomes OK'ed when the lower 8-bit of the sum of the received absolute data (15 characters) is 0.

Enter the Pr5.31 value of the driver to which you want to communicate from the host to axis (*1 data) of the command block, and transmit the command according to the RS232 communication protocol. For details of communication, refer to P.7-27, "Communication".

Caution

- Allow 50ms or longer interval for axis switching when you want to capture multiple axes data.
- It is recommended for you to repeat the above communication more than 2 times to confirm the absolute data coincide, in order to avoid mis-operation due to unexpected noise.

Note


- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

2. Absolute system

Transferring external scale absolute data

External scale RS485 communication procedure

Refer to the instruction manual of the host for the transmission/reception method of command. Following shows the communication example of the driver to Pr5.31 "Axis address = 1".



Data of *1, *2 and *3 are determined by the setup of Pr5.31 "Axis address".

Axis address (example)	Data of *1	Data of *2	Data of *3
0	Not usable with RS485 communication		
1	81h	01h	3Dh
2	82h	02h	3Ch
3	83h	03h	3Bh
4	84h	04h	3Ah
5	85h	05h	39h
6	86h	06h	38h
7	87h	07h	37h
8	88h	08h	36h
9	89h	09h	35h
10	8Ah	0Ah	34h
11	8Bh	0Bh	33h
12	8Ch	0Ch	32h
13	8Dh	0Dh	31h
14	8Eh	0Eh	30h
15	8Fh	0Fh	2Fh
16	90h	10h	2Eh
17	91h	11h	2Dh
18	92h	12h	2Ch
19	93h	13h	2Bh
20	94h	14h	2Ah
21	95h	15h	29h
22	96h	16h	28h
23	97h	17h	27h
24	98h	18h	26h
25	99h	19h	25h
26	9Ah	1Ah	24h
27	9Bh	1Bh	23h
28	9Ch	1Ch	22h
29	9Dh	1Dh	21h
30	9Eh	1Eh	20h
31	9Fh	1Fh	1Fh

Check sum becomes OK'ed when the lower 8-bit of the sum of the received absolute data (15 characters) is 0.

Command from the host will be transmitted to the desired driver based on RS485 transmission protocol. For details of communication, refer to P.7-27, "Communication".

Caution

- Allow 50ms or longer interval for axis switching when you want to capture multiple axes data.
- It is recommended for you to repeat the above communication more than 2 times to confirm the absolute data coincide, in order to avoid mis-operation due to unexpected noise.

Note


- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

2. Absolute system

Transferring external scale absolute data

Composition of external scale absolute data

Using 15-character data received through RS232/RS485, organize 1-turn data and multi-turn data.



External scale absolute data

← Absolute data (6)×1000000000h
 +Absolute data (5)×100000000h
 +Absolute data (4)×1000000h
 +Absolute data (3)×10000h
 +Absolute data (2)×100h
 +Absolute data (1)

Absolute data of external scale is represented as 48 bit number (negative value is represented as two's complement).

Remarks

If the multi-turn data of the above fig. is between 32768 to 65535, convert it to signed date after deducting 65536.

Note

- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

2. Absolute system

Transferring external scale absolute data

- **External scale status (L)-----1 represents error occurrence.**

External scale status (L)							
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
			0				
(1)	(2)	(3)	(4)	(5)	(6)	(7)	(8)

- (1) Alarm No. A8 “External scale error alarm”
- (2) Alarm No. A8 “External scale error alarm”
- (3) Err51.5 “External scale status 5 error protection”
- (4) Err51.4 “External scale status 4 error protection”
- (5) Err51.3 “External scale status 3 error protection”
- (6) Err51.2 “External scale status 2 error protection”
- (7) Err51.1 “External scale status 1 error protection”
- (8) Err51.0 “External scale status 0 error protection”

- **External scale status (H)-----1 represents error occurrence.**

External scale status (H)							
bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
0	0			0	0	0	0

└── Logical sum of bit6 and bit 7 of external scale status (L)

└── Logical sum of bit0 to bit 5 of external scale status (L)


Remarks For detail of the external scale status, refer to the external scale specification.

Remarks • **Transmit the External scale absolute data while fixing the motor with brake by turning to Servo-Off.**


Note • Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Related page • P.6-4 “Protective Function” • Next page “Display of Battery Alarm”

Following alarm will be displayed when making the front panel to alarm execution mode of monitor mode.



• Press to scroll alarm conditions.



• Kinds of alarm

alarm No.	Alarm	Content	Latched time *1
A0	Overload protection	Load factor is 85% or more the protection level.	1 to 10s or ∞
A1	Over-regeneration alarm	Regenerative load factor is 85% or more the protection level.	10s or ∞
A2	Battery alarm	Battery voltage is 3.2 V or lower.	Fixed at ∞
A3	Fan alarm	Fan has stopped for 1 sec.	1 to 10s or ∞
A4	Encoder communication alarm	The number of successive encoder communication errors exceeds the specified value.	1 to 10s or ∞
A5	Encoder overheat alarm	The encoder detects overheat alarm.	1 to 10s or ∞
A6	Oscillation detection alarm	Oscillation or vibration is detected.	1 to 10s or ∞
A7	Lifetime detection alarm	The life expectancy of capacity or fan becomes shorter than the specified time.	Fixed at ∞
A8	External scale error alarm	The external scale detects the alarm.	1 to 10s or ∞
A9	External scale communication alarm	The number of successive external scale communication errors exceeds the specified value.	1 to 10s or ∞

*1 Alarms can be cleared by using the alarm clear. Because the all existing alarms are kept cleared while the alarm clear input (A-CLR) is kept ON, be sure to turn it OFF during normal operation. Either 1-10s or ∞ can be selected by using user parameter.

Exception: Battery alarm is fixed at ∞ because it is latched by the encoder.

Because the end of life alarm means that the life expectancy cannot be extended, the alarm is set at ∞.

How to Clear the Battery Alarm

Replace the battery for absolute encoder when battery alarm occurs according to P.7-12, "How to Replace the Battery". After replacement, clear the battery alarm in the following 3 methods.

- "Connector X4" Connecting Alarm clear input (A-CLR) to COM– for more than 120ms.
- Executing the alarm clear function in auxiliary function mode by using the front panel.
- Click the "Battery warning" Clear button, after select the "Absolute encoder" tab in the monitor display window by using the PANATERM (option).

Note

• Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Related page

- P.2-109 "Alarm Clear Screen" • P.3-30 "Inputs and outputs on connector X4"
- P.7-26 "Outline of Setup Support Software, "PANATERM""

3. Outline of Setup Support Software, "PANATERM"

Setup on the PC

Connector X1 of MINAS A5 can be connected to your PC through USB cable for computer. Once you download the setup support software PANATERM from our web site and install it to your PC, the following tasks can be easily performed.

Outline of PANATERM


With the PANATERM, you can execute the followings.

- (1) Setup and storage of parameters, and writing to the memory (EEPROM).
- (2) Monitoring of I/O and pulse input and load factor.
- (3) Display of the present alarm and reference of the error history.
- (4) Data measurement of the wave-form graphic and bringing of the stored data.
- (5) Normal auto-gain tuning
- (6) Frequency characteristic measurement of the machine system.

Note

Distribution media such as CD-ROM for this software are not prepared. Download the software from our web site and install it to your PC.

How to Connect



• USB cable

The connection cable should be provided with USB mini-B connector at the driver side and the PC compatible connector on the other end.

If the cable has no noise filter, install a signal noise filter (DV0P1460) to both ends of the cable.

System required for PANATERM

To use PANATERM, the following system components are required.

• PC

OS	Windows® XP SP3 (32-bit Ver.) Windows® VISTA SP1 (32-bit Ver.) Windows® 7 (32-bit Ver., 64-bit Ver.) (Japanese, English, Chinese or Korean version)
CPU	Pentium III 512 MHz or better
Memory	256 MB or more (512 MB recommended)
Hard disk	512 MB or more free space
Serial communication	USB port

• Display

Resolution	1024 × 768 pixel or more
No. of colors	24-bit color (True Color) or better

* Please confirm the latest system requirements on the homepage.

You can connect up to 32 MINAS-A5 series with your computer or NC via serial communication based on RS232 and RS484, and can execute the following functions.

- (1) Change over of the parameters
- (2) Referring and clearing of alarm data status and history
- (3) Monitoring of control conditions such as status and I/O.
- (4) Referring of the absolute data
- (5) Saving and loading of the parameter data

• Merits

- You can write parameters from the host to the driver in batch when you start up the machine.
- You can display the running condition of machine to improve serviceability.
- You can compose multi-axis absolute system with simple wiring.

Note

- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

Related page


- P.2-51 "Wiring to the Connector, X1" • P.7-10 "Absolute system"
- P.7-26 "Outline of Setup Support Software, "PANATERM""

Connection of Communication Line

MINAS-A5 series provide 2 types of communications ports of RS232 and RS485, and support the following 3 types of connection with the host.

• RS232 communication


Connect the host and the driver in one to one with RS232, and communicate according to RS232 transmission protocol.



- Set up the module ID of MINAS-A5. In the above case, you can set any value of 0 to 31. You can set the same module ID as long as the host has no difficulty in control.

• RS232 and RS485 communication

When you connect one host to multiple MINAS-A5s, connect the host to connector X2 of one driver with RS232 communication, and connect each MINAS-A5 with RS485 communication. Set up the Pr5.31 of the driver to 0 which is connected to the host, and set up 1 to 31 to other drivers each.



Note


- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

4. Communication

Specifications

• RS485 communication

Connect the host to multiple MINAS-A5s with RS485 communication, set up the Pr5.31 of each front panel of MINAS-A5 to 1 to 31.



Allow 50ms or longer interval for switching the axes while capturing data of multiple axes.

Note




- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

4. Communication


Specifications

Interface of Communication Connector

• Connection to the host with RS232



• Connection to the host with RS485



Communication Method

	RS232	RS485
	Full duplex, asynchronous	Half duplex, asynchronous
Communication baud rate	2400, 4800, 9600, 19200, 38400, 57600, 115200bps	2400, 4800, 9600, 19200, 38400, 57600, 115200bps
Data	8 bit	8 bit
Parity	none	none
Start bit	1 bit	1 bit
Stop bit	1 bit	1 bit

- Set up the RS232 communication baud rate with Pr5.29, and RS485 communication baud rate with Pr5.30. The change of these parameters will be validated after the control power entry. For details, refer to the following list of parameters related to communication.

Note

- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

4. Communication

Specifications

List of User Parameters for Communication

Class	No.	Title	Setup value	Function
5	31	Axis address	0 to 127	Set the axis number for serial communication to 0 to 31. This parameter setup value has no effect on servo operation.
5	29	Baud rate setup of RS232 communication	0 to 6	Set up the communication speed of RS232 communication. 0 : 2400[bps], 1 : 4800[bps], 2 : 9600[bps], 3 : 19200[bps], 4 : 38400[bps], 5 : 57600[bps], 6 : 115200[bps] Updated setup of is validated upon turning on of control power.
5	30	Baud rate setup of RS485 communication	0 to 6	Set up the communication speed of RS485 communication. 0 : 2400[bps], 1 : 4800[bps], 2 : 9600[bps], 3 : 19200[bps], 4 : 38400[bps], 5 : 57600[bps], 6 : 115200[bps] Updated setup of is validated upon turning on of control power.

- Required time for data transmission per 1 byte is calculated in the following formula in case of 9600[bps].

$$\frac{1000}{9600} \times (\underbrace{1}_{\text{Start bit}} + \underbrace{8}_{\text{Data}} + \underbrace{1}_{\text{Stop bit}}) = 1.04 \text{ [ms/byte]}$$

Note that the time for processing the received command and time for switching the line and transmission/reception control will added to the actual communication time.

• Handshake code

Following codes are used for line control.

Title	Code	Function
ENQ	05h (Module recognition byte of the transmitted)	Enquire for transmission
EOT	04h (Module recognition byte of the transmitted)	Ready for receiving
ACK	06h	Acknowledgement
NAK	15h	Negative acknowledgement

ENQ The module (host or driver) sends out ENQ when it has a block to send.

EOT The module (host or driver) sends out EOT when it is ready to receive a block. The line enters to a transmission mode when ENQ is transmitted and EOT is received.

ACK When the received block is judged normal, the module (host or driver) will send out ACK.

NAK When the received block is judged abnormal, NAK will be sent. A judgment is based on checksum and timeout.

Caution

1 byte of module recognition is added to ENQ and EOT at RS485 communication.

Module recognition byte... Make the Pr5.31 value of the front panel as a module ID, and data which makes its bit7 as 1, becomes a module recognition byte.

bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
1	0	0	0	Module ID			

Module ID : The module ID of the host side will be 0 in case of RS485 communication, therefore set up Pr5.31 of MINAS-A5 to 1 to 31.

Note

- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.


4. Communication

Specifications


Transmission Sequence

• Transmission protocol

• In case of RS232



• In case of RS485



• Line control

Decides the direction of transmission and solves the contention.

Reception mode... From when the module (host or driver) returns EOT after receiving ENQ.

Transmission mode... From when the module (host or driver) receives EOT after transmitting ENQ.

At contention of transmission and reception... Slave side will enter to reception mode when it receives ENQ while waiting for EOT after transmitting ENQ, by giving priority to ENQ (of master side).

• Transmission control

On entering to transmission mode, the module transmits the command block continuously and then waits for ACK reception. Transmission completes at reception of ACK.. ACK may not be returned at transmission failure of command byte counts. If no ACK is received within T2 period, or other code than NAK or ACK is received, sequence will be retried. Retry will start from ENQ.

• Reception control


On entering to reception mode, the module receives the transmitted block continuously. It will receive the command byte counts from the first byte, and continuously receive extra 3 bytes. It will return ACK when the received data sum becomes 0, by taking this status as normal. In case of a check sum error or a timeout between characters, it will return NAK.

Note

- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

• Data Block Composition

Below shows the composition of data block which is transmitted in physical phase.



- N : Command byte counts (0 to 240)
Shows the number of parameters which are required by command.
- axis : Sets up the value of Pr5.31.(0 to 127)
- command : Control command (0 to 15)
- mode : Command execution mode (0 to 15)
Contents vary depending on the mode.
- check sum : 2's complement of the total number of bytes, ranging from the top to the end of the block

• Protocol Parameter

Following parameters are used to control the block transmission. You can set any value with the INIT command (described later).

Title	Function		Initial value	Setup range	Unit
T1	Time out between characters	RS232	5 (0.5 sec)	1 to 255	0.1 sec
		RS485	1 (0.1 sec)		
T2	Protocol time out	RS232	5 (0.5 sec)	1 to 255	1 sec
		RS485	1 (0.1 sec)		
T6	Driver response time	RS232	0 (0ms)	0 to 255	1 ms
		RS485	6 (6ms)	2 to 255	
RTY	Retry limit		1 (once)	1-8	Once
M/S	Master/Slave		0 (Slave)	0, 1 (Master)	

- T1: • Permissible time interval for this driver to receive the consecutive character codes which exists between the module recognition bytes and ENQ/EOT, or in the transmission/reception data block. Time out error occurs and the driver returns NAK to the transmitter when the actual reception time has exceeded this setup time.
- T2: • Permissible time interval for the driver to transmit ENQ and to receive EOT. If the actual reception time exceeds this setup, this represents that the receiver is not ready to receive, or it has failed to receive ENQ code in some reason, and the driver will re-transmit ENQ code to the receiver. (retry times)
- Permissible time interval for the driver to transmit EOT and to receive the reception of the 1st character code. The driver will return NAK and finishes the reception mode if the actual reception has exceeded this setup time.
- Permissible time interval for the module to transmit the check sum bytes and to receive ACK. The module will re-transmit ENQ code to the receiver in the same way as the NAK reception, if the actual reception time exceeds this setup time.
- T6: • Permissible time interval for the driver to receive ENQ and to transmit EOT; Permissible time interval for the driver to receive the check sum bytes and to transmit ACK; and Permissible time interval for the driver to receive EOT and to transmit the 1st character.
- RTY: Maximum value of retry times. Transmission error occurs if the actual retry has exceeds this setup value.
- M/S: Switching of master and slave. When contention of ENQ has occurred, the module decides which is to be given priority.
Priority is given to the transmitter which is set up as a master. (0: Slave mode, 1 : Master mode)

Note

- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

4. Communication


Specifications

Example of Data Communication

• e.g. Reference of Absolute Data

When you connect the host to one driver with RS232 communication, and connect multiple MINAS-A5s with RS485 communication. Following flow chart describes the actual flow of the communication data when you want to capture the absolute data of the module ID=1.


e.g. of system composition




e.g. of capturing the absolute data

Following shows the communication data in time series when you want to capture the absolute data. Data is presented in hexadecimal.

RS232 communication



* RS485 communication



Caution

See the below for the captured data. Refer to P.7-48, "Read out of Absolute Encoder " of details of communication command, for the data composition.

Multi-turn data : 0000h = 0

Single turn data : 01FFD8h = 131032


Allow 50ms or longer interval for switching the axis while capturing data of multiple axes.

Note

- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

• Example of Parameter Change

Following shows the communication data in time series when you change parameters. Communication in general will be carried out in sequence of (1) Request for capturing of execution right, (2) Writing of individual parameter, and (3) Writing to EEPROM when saving of data is required, and (4) Release of execution right. Here the hardware connection shows the case that the driver (user ID=1) is directly connected to the host with RS232. Data is presented in hexadecimal.



Caution For details of command, refer to P.7-40, "Details of Communication Command".

Note


- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

4. Communication

Specifications

Status Transition Chart

• RS232 Communication




Note

- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

4. Communication

Specifications

• RS485 Communication



Note


- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

4. Communication

Specifications

Timing of Data Communication

• In case of RS485 (RS232 to follow)



Symbol	Title	Minimum	Maximum
T3	Continuous inter-character time	Stop bit length	Protocol parameter T1
T4	Response time of driver	Protocol parameter T6	Protocol parameter T2
T5	Response time of host	2ms	Protocol parameter T2

Caution Above time represents a period from the rising edge of the stop bit.

Note

- Only for position control type is not provided with X2 (Communication connector) and X5 (Connector for External Scale).
- Only for position control type does not support the 17-bit absolute specification. It supports only 20-bit incremental specification.

4. Communication

List of Communication Command

command	mode	Content
0		NOP
	1	Read out of CPU version
	5	Read out of driver model
	6	Read out of motor model
1		INIT
	7	Capture and release of execution right
	8	Setup of RS232 protocol parameter
	9	Setup of RS485 protocol parameter
2		POS, STATUS, I/O
	0	Read out of status
	1	Read out of command pulse counter
	2	Read out of feedback pulse counter
	4	Read out of present speed
	5	Read out of present torque output
	6	Read out of present deviation counter
	7	Read out of input signal
	8	Read out of output signal
	9	Read out of present speed, torque and deviation counter
	A	Read out of status, input signal and output signal
	C	Read out of external scale
	D	Read out of absolute encoder
	E	Read out of external scale deviation and sum of pulses
7		PARAMETER
	0	Individual read out of parameter
	1	Individual writing of parameter
	2	Writing of parameter to EEPROM
	6	Individual read out of user parameter
	7	Read out of two or more user parameter
	8	Writing of two or more user parameter
9		ALARM
	0	Read out of present alarm data
	2	Batch read out of alarm history
	3	Clear of user alarm history
	4	Alarm clear
	B	Absolute clear

- Use the above commands only. If you use other commands, action of the driver cannot be guaranteed.
- When the reception data counts are not correct in the above command, transmission byte1 (Error code only) will be returned regardless of communication command.

4. Communication

Details of Communication Command

command	mode
0	1

• Read out of CPU version

Reception data	
0	
axis	
1	0
checksum	

Transmission data	
3	
axis	
1	0
Version (upper)	
Version (lower)	
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Version information will be returned in upper data and lower data.
(Decimal point will be returned by making the lower 4 bit of the upper data as 0.)
- Version will be displayed in figures from 0 to 9. (e.g. Version 3.1 will be upper data 30h, lower data 13h.)

command	mode
0	5

• Read out of driver mode

Reception data	
0	
axis	
5	0
checksum	

Transmission data	
0Dh	
axis	
5	0
Model of driver (upper)	
Model of driver (lower)	
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Driver model consist of 12-characters, and will be transmitted in ASCII code.
(e.g.) "MADHT1105****"

command	mode
0	6

• Read out of Motor Model

Reception data	
0	
axis	
6	0
checksum	

Transmission data	
0Dh	
axis	
6	0
Model of motor (upper)	
Model of motor (lower)	
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Motor model consist of 12-characters, and will be transmitted in ASCII code.
(e.g.) "MSME012S1****"

4. Communication

Details of Communication Command

command	mode
1	7

• Capture and release of execution right

Reception data	
1	
axis	
7	1
mode	
checksum	

Transmission data	
1	
axis	
7	1
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		Command error	RS485 error	mode error			in use

- Capture the execution right to prevent the conflict of the operation via communication and that with the front panel.
- Enquires for the capture of the execution right at parameter writing and EEPROM writing, and release the execution right after the action finishes.
- mode = 1 : Enquires for the capture of the execution right mode = 0 : Enquires for the release of the execution right
- You cannot operate with the front panel at other than monitor mode while the execution right is captured via communication.
- When the module fails to capture the execution right, it will transmit the error code of in use.

command	mode
1	8

• Setup of RS232 protocol parameter

Reception data	
4	
axis	
8	1
T1	
T2	
T6	
0	RTY
checksum	

Transmission data	
1	
axis	
8	1
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		T6error	RS485 error	RTYerror	T2error	T1error	

- Until this command completes, previous set up protocol parameter will be processed.
After this command has been executed, this parameter setup will be valid from the next command.
- RTY is 4-bit.
- Unit... T1 : 0.1s, T2 : 0.1s, T6 : 1ms

command	mode
1	9

• Setup of RS485 protocol parameter

Reception data	
4	
axis	
9	1
T1	
T2	
T6	
0	RTY
checksum	

Transmission data	
1	
axis	
9	1
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		T6error	RS485 error	RTYerror	T2error	T1error	

- Until this command completes, previously set up protocol parameter will be processed.
After this command has been executed, this parameter setup will be valid from the next command.
- RTY is 4-bit.
- Unit... T1 : 0.1s, T2 : 0.1s, T6 : 1ms

4. Communication

Details of Communication Command

command	mode
2	0

• Read out of status

Reception data	
0	
axis	
0	2
checksum	

Transmission data	
3	
axis	
0	2
control mode	
status	
error code	
checksum	

status

bit7	6	5	4	3	2	1	0
				Positive direction running	Negative direction running	Slower than DB permission	Torque in-limit

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Control modes are defined as follows.

0	Position control mode
1	Velocity control mode
2	Torque control mode
3	Full-closed control mode

- positive direction/negative direction running : This becomes 1 when motor speed (after converted to r/min) is positive (positive direction) or negative (negative direction).
- Slower than DB permission : This becomes 1 when motor speed (after converted to r/min) is below 30r/min.
- Torque in-limit : This becomes 1 when torque command is limited by analog input or parameter.

command	mode
2	1

• Read out of command pulse counter

Reception data	
0	
axis	
1	2
checksum	

Transmission data	
5	
axis	
1	2
counter value L	

H	
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Module returns the present position in absolute coordinates from the starting point. (Total sum of accumulated command pulses)
- Counter value in 32 bit.
- Counter value will be "-" for negative direction and "+" for positive direction.

4. Communication

Details of Communication Command

command	mode
2	2

• Read out of feedback pulse counter

Reception data	
0	
axis	
2	2
checksum	

Transmission data	
5	
axis	
2	2
counter value L	

H	
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Module returns the present position of feedback pulse counter in absolute coordinates from the starting point.
- Counter value will be "-" for negative direction and "+" for positive direction.
- Feedback pulse counter is the total pulse counts of the encoder and represents the actual motor position traveled

command	mode
2	4

• Read out of present speed

Reception data	
0	
axis	
4	2
checksum	

Transmission data	
3	
axis	
4	2
Data (present speed) L	

H	
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Reads out the present speed. (Unit : [r/min])
- Output value in 16 bit
- Speed will be "-" for negative direction and "+" for positive direction.

command	mode
2	5

• Read out of present torque output

Reception data	
0	
axis	
5	2
checksum	

Transmission data	
3	
axis	
5	2
Data (present torque) L	

H	
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Reads out the present torque output. (Unit : Converted with "Rated motor torque = 2000)
- Output value in 16 bit
- Torque command will be "-" value for negative direction and "+" value for positive direction.

4. Communication

Details of Communication Command

command	mode
2	6

• Read out of present positional command deviation

Reception data	
0	
axis	
6	2
checksum	

Transmission data	
5	
axis	
6	2
data (deviation) L	
H	
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Reads out the present positional command deviation. (Unit : [command unit])
- Output value in 32 bit
- Becomes "+" when the encoder is located at negative direction against position command, and "-" when it is located at positive direction.

command	mode
2	7

• Read out of input signal

Reception data	
0	
axis	
7	2
checksum	

Transmission data	
5	
axis	
7	2
data L	
data H	
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

Data

bit7	6	5	4	3	2	1	0
For manufacturer's use	Switching of electronic gear 1	Speed zero clamp	Control mode switching	CCW over-travel inhibit	CW over-travel inhibit	Alarm clear	Servo-ON

bit15	14	13	12	11	10	9	8
For manufacturer's use	For manufacturer's use	Internal speed command selection 2	Internal speed command selection 1	For manufacturer's use	Counter clear	Gain switching	Command pulse input inhibition

bit23	22	21	20	19	18	17	16
Switching of electronic gear 2	Damping control switching 2	Torque limit switching	Internal speed command selection 3	Damping control switching 1	For manufacturer's use	For manufacturer's use	For manufacturer's use

bit31	31	29	28	27	26	25	24
For manufacturer's use	For manufacturer's use	For manufacturer's use	Safety input 2	Safety input 1	For manufacturer's use	Torque command sign	Speed command sign

- Logic of input signal is based on assignment set in the parameter.
- Because of the internal logical data after conversion of input, it does not directly correspond to the input signal from the connector X5.
- CW over-travel inhibit input and CCW over-travel inhibit input will change according to the input logic, even if they have been disabled by the parameter,

4. Communication

Details of Communication Command

command	mode
2	8

• Read out of output signal

Reception data	
0	
axis	
8	2
checksum	

Transmission data	
7	
axis	
8	2
data L	
data H	
alarm data L	
H	
error code	
checksum	

error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

Data

bit7	6	5	4	3	2	1	0
For manufacturer's use	In-speed	Torque in-limit	Zero speed detection	Mechanical brake released	Positioning complete (In-position)	Servo-Alarm	Servo-Ready

bit15	14	13	12	11	10	9	8
Excite motor	Control power latch	Dynamic brake engagement	Control inrush suppression relay	Control regeneration brake	Full-closed positioning complete	At-speed	For manufacturer's use

bit23	22	21	20	19	18	17	16
Safety EDM	Speed command ON/OFF	Alarm attribute output	Speed in-limit output	2nd positioning complete (In-position)	Positional command ON/OFF	Alarm output 2	Alarm output 1

bit31	31	29	28	27	26	25	24
For manufacturer's use	For manufacturer's use	For manufacturer's use	For manufacturer's use	For manufacturer's use	For manufacturer's use	For manufacturer's use	For manufacturer's use

alarm data

bit7	6	5	4	3	2	1	0
Overload protection	Fan alarm	Over-regeneration alarm	Encoder communication alarm	Encoder overheat alarm	Lifetime detection alarm	For manufacturer's use	Battery alarm

bit15	14	13	12	11	10	9	8
For manufacturer's use	For manufacturer's use	For manufacturer's use			External scale communication alarm	Oscillation detection alarm	External scale error alarm

• The table below shows the relation of the signals and actions.

Signal title	0	1
Servo-Ready	Servo-Not Ready	At Servo-Ready
Servo-Alarm	Normal	At Servo-Alarm
Positioning completed	Positioning not completed	Positioning in-complete
Mechanical brake released	Mechanical brake engaged	Mechanical brake released
Zero speed detection	Zero speed not detected	Zero speed detected
Torque in-limit	Torque not in-limit	Torque in-limit
At-speed (Speed arrival)	Not at-speed(Speed not arrived)	Speed arriving
In-speed (Speed coincidence)	Not in-speed(Speed not coincided)	In-speed (Speed coincided)
Full-closed positioning complete	Full-closed positioning not completed	Full-closed positioning completed
Control regeneration brake	Turn off regeneration Tr	Turn on regeneration Tr
Control inrush suppression relay	Release inrush suppression relay	Operate inrush suppression relay
Dynamic brake engagement	Dynamic brake released	Dynamic brake engaged
Control power latch	Release power latch	Power abnormal latching
Excite motor	Energize motor	Servo free

- Because of the internal logical data before output conversion, it does not directly correspond to the output signal to the connector X5.
- Names and functions shown above are for MINAS-A5 (general-purpose model). Some of input signals will have different meaning for different series.

4. Communication

Details of Communication Command

command	mode
2	9

• Read out of present speed, torque and positional command deviation

Reception data	
0	
axis	
9	2
checksum	

Transmission data	
9	
axis	
9	2
data L	
(speed) H	
data L	
(torque) H	
data L	
(deviation) H	
error code	
checksum	

Error cod

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Output value of speed and torque are in 16 bit and deviation in 32 bit.
- Unit and sign of the output data is as same as that of command No. 24 (command = 2, mode = 4), 25 (mode = 5) and 26 (mode = 6).

command	mode
2	A

• Read out of status, input signal and output signal

Reception data	
0	
axis	
A	2
checksum	

Transmission data	
13 (0Dh)	
axis	
A	2
control mode	
status	
input signal L	
input signal H	
output signal L	
output signal H	
alarm data L	
alarm data H	
error code	
checksum	

Error cod

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Meaning of each bit of control mode, status, input signal, output signal and alarm data is as same as that of command No. 20 (command = 2, mode = 0), 27 (mode = 7) and 28 (mode = 8).

4. Communication

Details of Communication Command

command	mode
2	C

• Read out of feedback scale

Reception data	
0	
axis	
C	2
checksum	

Transmission data	
11 (0Bh)	
axis	
C	2
encoder ID (L)	
(H)	
status (L)	
(H)	
(L)	
absolute position data (48bit)	
(H)	
error code	
checksum	

Encoder ID

	Encoder ID (L)	Encoder ID (H)
ST771	Address "0" data of EEPROM	32h
AT500series	Address "0" data of EEPROM	31h

- Command error occurs at other control modes than full-closed control.

• ST771

Status (L)

bit7	6	5	4	3	2	1	0
Thermal alarm	Signal intensity alarm	Signal intensity error	Transducer error	ABS detection error	Hardware error	Initialization error	Over speed

Status (H)

bit7	6	5	4	3	2	1	0
0	0	Encoder error *1	Encoder error *2	0	0	0	0

*1 bit5 : Logical sum of bit0 to bit 5 of status (L)

*2 bit4 : logical sum of bit6 and bit 7 of status (L)

• AT500 series

Status (L)

bit7	6	5	4	3	2	1	0
Thermal alarm	0	Communication error	CPU, memory error	Capacity and photoelectric error	Encoder non-matching error	Initialization error	Over speed

Status (H)

bit7	6	5	4	3	2	1	0
0	0	Encoder error *3	Encoder alarm *4	0	0	0	0

*3 bit5 : Logical sum of bit0 to bit 5 of status (L)

*4 bit4 : logical sum of bit6 and bit 7 of status (L)

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		Command error	RS485 error				

- Absolute position data = 48bit (800000000000 to 7FFFFFFFh)

4. Communication

Details of Communication Command

command	mode
2	D

• Read out of absolute encoder

Reception data	
0	
axis	
D	2
checksum	

Transmission data	
11 (0Bh)	
axis	
D	2
encoder ID (L)	
(H)	
status (L)	
(H)	
(L)	
single-turn data	
(H)	
multi-turn data (L)	
(H)	
0	
Error code	
checksum	

	Encoder ID (L)	Encoder ID (H)
17bit absolute	3	11h

Status (L)

bit7	6	5	4	3	2	1	0
Battery alarm	System down	Multi-turn error	0	Counter overflow	Count error	Full absolute status	Over speed

Status (H)

- bit4 : System down
- bit5 : Battery alarm, multi-turn error, counter overflow, count error, full absolute status and logical sum of over speed

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- Command error will occur when you use the above encoder or absolute encoder as an incremental encoder.
- Single turn data = 17bit (000000h to 01FFFFh)
- Multi-turn data = 16bit (0000h to FFFFh)

command	mode
2	E

• Read out of external scale deviation and sum of pulses

Reception data	
0	
axis	
E	2
checksum	

Transmission data	
9	
axis	
E	2
(L)	
external scale	
FB pulse sum	
(H)	
(L)	
external scale deviation	
(H)	
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error				
1 : Error							

- External scale FB pulse sum will return the present position of the external scale counter in absolute coordinates from the starting point.
- External scale FB pulse sum will be "-" for negative direction and "+" for positive direction.
- External scale deviation becomes "+" when the external scale is positioned at negative direction against position command, and "-" when it is positioned at positive direction.

4. Communication

Details of Communication Command

command	mode
7	0

• Individual read out of parameter

Reception data	
2	
axis	
0	7
parameter type	
parameter No.	
checksum	

Transmission data	
5	
axis	
0	7
(L)	
parameter value	
(H)	
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal		Command error	RS485 error	No.Error			
1 : Error							

- If the parameter type or the parameter No. is outside the range, returns No. error.
- Parameter value is sign-extended to 32 bits and returned.

command	mode
7	1

• Individual writing of parameter

Reception data	
6	
axis	
1	7
parameter type	
parameter No.	
(L)	
parameter value	
(H)	
checksum	

Transmission data	
1	
axis	
1	7
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal	Data Error	Command error	RS485 error	No.Error			
1 : Error							

- If the parameter type or the parameter No. is outside the range, returns No. error.
- This command change parameters only temporarily. If you want to write into EEPROM, execute the parameter writing to EEPROM (mode = 2).
- Set up parameters not in use to 0 without fail, or it leads to data error. Data error also occurs when the parameter value exceeds the setup range.
- Parameter value should be sign-extended to 32 bits before being transmitted.

command	mode
7	2

• Writing of parameter to EEPROM

Reception data	
0	
axis	
2	7
checksum	

Transmission data	
1	
axis	
2	7
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal	Data Error	Command error	RS485 error			Control LV	
1 : Error							

- Writes the preset parameters to EEPROM.
- Transmission data will be returned after EEPROM writing completes. It may take max. 5sec for EEPROM writing (when all parameters have been changed.)
- Data error will occur when writing fails.
- When under-voltage occurs, error code of control LV will be returned instead of executing writing.

4. Communication

Details of Communication Command

command	mode
7	6

• Individual read out of user parameter

Reception data

2	
axis	
6	7
parameter type	
parameter No.	
checksum	

Transmission data

17 (11h)	
axis	
6	7
parameter type	
parameter No.	
(L)	
parameter value	
(H)	
(L)	
MIN value	
(H)	
(L)	
MAX value	
(H)	
Property L	
H	
Error code	
checksum	

Property

bit7	6	5	4	3	2	1	0
Parameter not in use	Display inhibited		Change at initialization				

bit15	14	13	12	11	10	9	8
							Read only

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		Command error	RS485 error	No.Error			

- If the parameter type or the parameter No. is outside the range, returns No. error.
- Parameter value, MIN value and MAX value should be sign-extended to 32 bits before being transmitted.

4. Communication

Details of Communication Command

command	mode
7	7

• Read out of two or more user parameter

Reception data	
10h (16)	
axis	
7	7
(1) parameter type	
(1) parameter No.	
(2) parameter type	
(2) parameter No.	
⋮	
(8) parameter type	
(8) parameter No.	
checksum	

Transmission data	
129 (81h)	
axis	
7	7
(1) parameter type	
(1) parameter No.	
(1) parameter value (L)	
(H)	
(1) MIN value (L)	
(H)	
(1) MAX value (L)	
(H)	
(1) Property (L)	
(H)	
⋮	
(8) parameter type	
(8) parameter No.	
⋮	
(8) Property (L)	
(H)	
error code	
checksum	

Property

bit7	6	5	4	3	2	1	0
Parameter not in use	Display inhibited		Change at initialization				

bit15	14	13	12	11	10	9	8
							Read only

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		Command error	RS485 error	No.Error			

- If the parameter type or the parameter No. is outside the range, returns No. error.
- Parameter value, MIN value and MAX value should be sign-extended to 32 bits before being transmitted.

1 Before Using the Products

2 Preparation

3 Connection

4 Setup

5 Adjustment

6 When in Trouble

7 Supplement

4. Communication

Details of Communication Command

command	mode
7	8

• Writing of two or more user parameter

Reception data

30h(48)	
axis	
8	7
(1) parameter type	
(1) parameter No.	
(L)	
(1) parameter value	
(H)	
⋮	
(8) parameter type	
(8) parameter No.	
(L)	
(8) parameter value	
(H)	
checksum	

Transmission data

17(11h)	
axis	
8	7
(1) parameter type	
(1) parameter No.	
(2) parameter type	
(2) parameter No.	
⋮	
(8) parameter type	
(8) parameter No.	
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error	Data Error	Command error	RS485 error	No.Error			

- Set 0 to unused parameter. Otherwise data error occurs. When data outside the specified setting range is sent, data error occurs.
- If the parameter type or the parameter No. is outside the range, returns No. error.

command	mode
9	0

• Read out of present alarm data

Reception data

0	
axis	
0	9
checksum	

Transmission data

3	
axis	
0	9
alarm No. (Main)	
alarm No. (Sub)	
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		Command error	RS485 error				

- If no alarm occurs, alarm No. becomes 0.
(For alarm No., refer to P.6-2, "Protective function (What is alarm code ?)" of When in Trouble.

4. Communication

Details of Communication Command

command	mode
9	2

• Batch read out of alarm history

Reception data	
0	
axis	
2	9
checksum	

1st. latest

2nd. latest

14th. latest

Transmission data	
29 (1Dh)	
axis	
2	9
alarm No. (Main)	
alarm No. (Sub)	
alarm No. (Main)	
alarm No. (Sub)	
alarm No. (Main)	
alarm No. (Sub)	
error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		Command error	Command error				

- You can read out last 14 error events.

command	mode
9	3

• Clear of user alarm history

Reception data	
0	
axis	
3	9
checksum	

Transmission data	
1	
axis	
3	9
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error	Data Error	Command error	RS485 error			Control LV	

- Clears the alarm data history.
- Data error will occur when you fail to clear.
- When under-voltage of control power supply occurs, error code of control LV will be returned instead of executing writing.

command	mode
9	4

• Alarm clear

Reception data	
0	
axis	
4	9
checksum	

Transmission data	
1	
axis	
4	9
Error code	
checksum	

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		Command error	RS485 error				

- Clears the present alarm. (only those you can clear)

1 Before Using the Products

2 Preparation

3 Connection

4 Setup

5 Adjustment

6 When in Trouble

7 Supplement

4. Communication

Details of Communication Command

command	mode
9	B

• Absolute clear

Reception data

0
axis
B9
checksum

Transmission data


1
axis
B9
Error code
checksum

Error code

bit7	6	5	4	3	2	1	0
0 : Normal 1 : Error		Command error	RS485 error				

- Clears absolute encoder error and multi-turn data
- Command error will be returned when you use other encoder than 17bit absolute encoder.


- Note that the motor characteristics may vary due to the existence of oil seal or brake.
- Continuous torque vs. ambient temperature characteristics have been measured with an aluminum flange attached to the motor (approx. twice as large as the motor flange).




* These are subject to change. Contact us when you use these values for your machine design.

* Ratio to the rated torque at ambient temperature of 40°C is 100% in case of without oil seal, without brake.


- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.







* These are subject to change. Contact us when you use these values for your machine design.

- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.






* These are subject to change. Contact us when you use these values for your machine design.




* These are subject to change. Contact us when you use these values for your machine design.


* Ratio to the rated torque at ambient temperature of 40°C is 100% in case of without oil seal, without brake.



* These are subject to change. Contact us when you use these values for your machine design.

- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.





* These are subject to change. Contact us when you use these values for your machine design.

MSME series (1.0kW to 2.0kW)


With oil seal

• MSME102 * 1 *

Input voltage to driver: AC200V

(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.




• MSME104 * 1 *

Input voltage to driver: AC400V

(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.




• MSME152 * 1 *

Input voltage to driver: AC200V

(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.




• MSME154 * 1 *

Input voltage to driver: AC400V

(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.




• MSME202 * 1 *

Input voltage to driver: AC200V

(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.




• MSME204 * 1 *

Input voltage to driver: AC400V


(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.



* These are subject to change. Contact us when you use these values for your machine design.

- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.



5. Motor Characteristics (S-T Characteristics)

MSME series (3.0kW to 5.0kW)


MSME series (3.0kW to 5.0kW)

With oil seal

• MSME302 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MSME304 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MSME402 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MSME404 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MSME502 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MSME504 * 1 *


Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.



* These are subject to change. Contact us when you use these values for your machine design.

- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.




MDME series (400W to 2.0kW)

With oil seal

• MDME044 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MDME064 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MDME102 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MDME104 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MDME152 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MDME154 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MDME202 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MDME204 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.




* These are subject to change. Contact us when you use these values for your machine design.

MDME series (3.0kW to 5.0kW)

With oil seal


• MDME302 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)




• MDME304 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)




• MDME402 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)




• MDME404 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)




• MDME502 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)




• MDME504 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)



* These are subject to change. Contact us when you use these values for your machine design.

- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.




MDME series (7.5kW to 15.0kW)

With oil seal


• MDME752 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)




• MDME754 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)




• MDMEC12 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)




• MDMEC14 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)




• MDMEC52 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)



• MDMEC54 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)



* These are subject to change. Contact us when you use these values for your machine design.


MFME series (1.5kW to 4.5kW)

With oil seal

• MFME152 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MFME154 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MFME252 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MFME254 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MFME452 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MFME454 * 1 *


Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.



* These are subject to change. Contact us when you use these values for your machine design.

- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.




MGME series (0.9kW to 3.0kW)

With oil seal

• MGMA092 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MGMA094 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MGMA202 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MGMA204 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MGMA302 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MGMA304 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.



* These are subject to change. Contact us when you use these values for your machine design.

5. Motor Characteristics (S-T Characteristics)

MGME series (4.5kW to 6.0kW)


MDME series (4.5kW to 6.0kW)

With oil seal

• MGME452 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MGME454 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MGME602 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MGME604 * 1 *


Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



* These are subject to change. Contact us when you use these values for your machine design.

- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.





* These are subject to change. Contact us when you use these values for your machine design.


MHME series (400W to 750W)

Without oil seal

• MHMD041 * 1 *

Input voltage to driver: AC100V
(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.




With oil seal

• MHMD041 * 1 *

Input voltage to driver: AC100V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MHMD042 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MHMD042 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MHMD082 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MHMD082 * 1 *


Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.



* These are subject to change. Contact us when you use these values for your machine design.

- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.




MHME series (1.0kW to 3.0kW)

With oil seal


• MHME102 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)




• MHME104 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)




• MHME152 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)




• MHME154 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)




• MHME202 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)




• MHME204 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)




• MHME302 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)



• MHME304 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)



* These are subject to change. Contact us when you use these values for your machine design.

5. Motor Characteristics (S-T Characteristics)

MHME series (4.0kW to 7.5kW)


MHME series (4.0kW to 7.5kW)

With oil seal

• MHME402 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MHME404 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MHME502 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MHME504 * 1 *

Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MHME752 * 1 *

Input voltage to driver: AC200V
(Dotted line represents torque at 10% less voltage.)


* Continuous torque vs. ambient temp.



• MHME754 * 1 *


Input voltage to driver: AC400V
(Dotted line represents torque at 10% less voltage.)

* Continuous torque vs. ambient temp.




* These are subject to change. Contact us when you use these values for your machine design.


- When you lower the torque limit setup (P0.13 and 5.22), running range at high speed might be lowered as well.



A-frame




B-frame




6. Dimensions

Driver

C-frame



D-frame (200 V)




Related page • P.1-3 "Driver" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.2-10 "Driver and List of Applicable Peripheral Equipments"


6. Dimensions

Driver

D-frame (400 V)




E-frame (200 V)




6. Dimensions

Driver

E-frame (400 V)



F-frame (200/ 400 V)



Driver

Before Using the Products




6 When in Trouble

• P.1-3 “Driver” • P.1-23 “Check of the Combination of the Driver and the Motor”
• P.2-10 “Driver and List of Applicable Peripheral Equipments”

6. Dimensions

Driver


H-frame (200/ 400 V)



Related page

- P.1-3 "Driver" • P.1-23 "Check of the Combination of the Driver and the Motor"
- P.2-10 "Driver and List of Applicable Peripheral Equipments"

MSMD 50W to 100W



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MSMD series (Low inertia)			
Motor output		50W	100W
Motor model MSMD		5A ** 1 □ *	01 ** 1 *
LL	Without brake	72	92
	With brake	102	122
LR		25	
S		8	
LA		45	
LB		30	
LC		38	
LE		3	
LF		6	
LH		32	
LN		26.3	46.5
LZ		3.4	
D カット 法 Key way dimensions	LW	25	
	LK	20	
	RH	7.5	
	LW	14	
	LK	12.5	
	KW	3h9	
	KH	3	
	RH	6.2	
	TP	M3 depth 6	
Mass (kg)	Without brake	0.32	0.47
	With brake	0.53	0.68
Connector specifications		Refer to P.2-48 "Specifications of Motor connector"	

Caution

Reduce the moment of inertia ratio if high speed response operation is required.


Related page

- P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
- P.7-55 "S-T Characteristics"

6. Dimensions

Motor

MSMD 200W to 750W



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MSMD series (Low inertia)				
Motor output		200W	400W	750W
Motor model MSMD		02 * * 1 □ *	04 * * 1 □ *	08 * * 1 □ *
LL	Without brake	79.5	99	112.2
	With brake	116	135.5	149.2
LR		30		35
S		11	14	19
LA		70		90
LB		50		70
LC		60		80
LE		3		
LF		6.5		8
LH		43		53
LZ		4.5		6
D カ ン ナ ル 寸 法	LW	30		35
	LK	22		25
	RH	10	12.5	17.5
Key way dimensions	LW	20	25	25
	LK	18	22.5	22
	KW	4h9	5h9	6h9
	KH	4	5	6
	RH	8.5	11	15.5
	TP	M4 depth 8	M5 depth 10	
Mass (kg)	Without brake	0.82	1.2	2.3
	With brake	1.3	1.7	3.1
Connector specifications		Refer to P.2-48 "Specifications of Motor connector"		

Caution Reduce the moment of inertia ratio if high speed response operation is required.

Related page • P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
• P.7-56, 57 "S-T Characteristics"

Motor

Before Using the Products



3 Connection

4 Setup

5 Adjustmen


6 When in Trou

6. Dimensions


Motor

MSME 750W(400V), 1.0kW to 5.0kW (DesignOrder: 1)

<MSME 750W(400V), 1.0kW to 2.0kW>



<MSME 3.0kW to 5.0kW> * All sizes are identical to those of MSME 1.0 to 2.0 kW versions except for LF.



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MSME series (Low inertia)									
Motor output		750W	1.0kW	1.5kW	2.0kW	3.0kW	4.0kW	5.0kW	
Motor model		MSME	084 * 1 *	10 * 1 *	15 * 1 *	20 * 1 *	30 * 1 *	40 * 1 *	50 * 1 *
LL	Without brake	131.5	141	159.5	178.5	190	208	243	
	With brake	158.5	168	186.5	205.5	215	233	268	
LR		55					65		
S		19				22	24		
LA		115				145			
LB		95				110			
LC		100				120	130		
LD		135				162	165		
LE		3					6		
LF		10				12			
LG		60							
LH		101				113	118		
LM	Without brake	87.5	97	115.5	134.5	146	164	199	
	With brake	114.5	124	142.5	161.5	171	189	224	
LZ		9							
Key way dimensions	LW	45					55		
	LK	42				41	51		
	KW	6h9				8h9			
	KH	6				7			
	RH	15.5				18	20		
Mass (kg)	Without brake	3.1	3.5	4.4	5.3	8.3	11.0	14.0	
	With brake	4.1	4.5	5.4	6.3	9.4	12.6	16.0	
Connector specifications		Refer to P.2-49 “Specifications of Motor connector”							

Caution Reduce the moment of inertia ratio if high speed response operation is required.


Related page • P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
• P.7-60, 7-62 "S-T Characteristics"

6. Dimensions


Motor

MSME 1.0kW to 5.0kW (DesignOrder: C)

<MSME 1.0kW to 2.0kW>



<MSME 3.0kW to 5.0kW> * All sizes are identical to those of MSME 1.0 to 2.0 kW versions except for LF.



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MSME series (Low inertia)							
Motor output		1.0kW	1.5kW	2.0kW	3.0kW	4.0kW	5.0kW
Motor model MSME		10 ** C *	15 ** C *	20 ** C *	30 ** C *	40 ** C *	50 ** C *
LL	Without brake	143	161.5	180.5	192	210	245
	With brake	170	188.5	207.5	217	235	270
LR		55				65	
S		19			22	24	
LA		115			145		
LB		95			110		
LC		100			120	130	
LD		135			162	165	
LE		3				6	
LF		10			12		
LG		84					
LH		101			113	118	
LM	Without brake	97	115.5	134.5	146	164	199
	With brake	124	142.5	161.5	171	189	224
LZ		9					
Key way dimensions	LW	45				55	
	LK	42			41	51	
	KW	6h9			8h9		
	KH	6			7		
	RH	15.5			18	20	
Mass (kg)	Without brake	3.5	4.4	5.3	8.3	11.0	14.0
	With brake	4.5	5.4	6.3	9.4	12.6	16.0
Connector specifications		Refer to P.2-49 “Specifications of Motor connector”					

Caution

Reduce the moment of inertia ratio if high speed response operation is required.


Related page

- P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
- P.7-61, 7-62 "S-T Characteristics"

6. Dimensions

Motor

MDME 400W to 5.0kW (DesignOrder: 1)




* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MDME series (Middle inertia)										
Motor output		400W	600W	1.0kW	1.5kW	2.0kW	3.0kW	4.0kW	5.0kW	
Motor model		MDME	044 * 1 *	064 * 1 *	10 * * 1 *	15 * * 1 *	20 * * 1 *	30 * * 1 *	40 * * 1 *	50 * * 1 *
LL	Without brake	131.5	141	138	155.5	173	208	177	196	
	With brake	158.5	168	163	180.5	198	233	202	221	
LR		55					65	70		
S		19		22				35		
LA		115		145				200		
LB		95		110				114.3		
LC		100		130				176		
LD		135		165				233		
LE		3		6				3.2		
LF		10		12				18		
LG		60								
LH		101		116			118	140		
LM	Without brake	87.5	97	94	111.5	129	164	133	152	
	With brake	114.5	124	119	136.5	155	189	158	177	
LZ		9						13.5		
Key way dimensions	LW	45					55			
	LK	42		41			51	50		
	KW	6h9		8h9					10h9	
	KH	6		7					8	
	RH	15.5		18			20	30		
Mass (kg)	Without brake	3.1	3.5	5.2	6.7	8.0	11.0	15.5	18.6	
	With brake	4.1	4.5	6.7	8.2	9.5	12.6	18.7	21.8	
Connector specifications		Refer to P.2-49 “Specifications of Motor connector”								



Caution Reduce the moment of inertia ratio if high speed response operation is required.




Related page • P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor" • P.7-63, 7-64 "S-T Characteristics"

6. Dimensions

Motor

MDME 400W to 5.0kW (DesignOrder: C)



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MDME series (Middle inertia)							
Motor output		1.0kW	1.5kW	2.0kW	3.0kW	4.0kW	5.0kW
Motor model MDME		10 ** C *	15 ** C *	20 ** C *	30 ** C *	40 ** C *	50 ** C *
LL	Without brake	140	157.5	175	210	179	198
	With brake	165	182.5	200	235	204	223
LR		55			65	70	
S		22				35	
LA		145				200	
LB		110				114.3	
LC		130				176	
LD		165				233	
LE		6				3.2	
LF		12				18	
LG		84					
LH		116			118	140	
LM	Without brake	94	111.5	129	164	133	152
	With brake	119	136.5	155	189	158	177
LZ		9			13.5		
Key way dimensions	LW	45			55		
	LK	41			51	50	
	KW	8h9				10h9	
	KH	7				8	
	RH	18			20	30	
Mass (kg)	Without brake	5.2	6.7	8.0	11.0	15.5	18.6
	With brake	6.7	8.2	9.5	12.6	18.7	21.8
Connector specifications		Refer to P.2-49 “Specifications of Motor connector”					

Caution

Reduce the moment of inertia ratio if high speed response operation is required.

Related page



- P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
- P.7-63, 7-64 "S-T Characteristics"

6. Dimensions


Motor

MDME 7.5kW to 15.0kW



<MDME 7.5kW>




Shaft end spec.
(Key way shaft)



<MDME 11.0kW, 15.0kW>



Shaft end spec.
(Key way shaft)



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MDME series (Middle inertia)				
Motor output		7.5kW	11.0kW	15.0kW
Motor model		75 ** 1 *	C1 ** 1 *	C5 ** 1 *
LL	Without brake	312	316	348
	With brake	337	364	432
LR		113		116
S		42		55
LA		200		235
LB		114.3		200
LC		176		220
LD		233		268
LE		3.2		4
LF		24		32
LG			60	
LH		184		205
LM	Without brake	268	272	340
	With brake	293	320	388
LZ			13.5	
Key way dimensions	LW	96		98
	LK	90	90	
	KW	12h9		16h9
	KH	8		10
	RH	37 ⁰ _{-0.2}		49 ⁰ _{-0.2}
Mass (kg)	Without brake	36.4	52.7	70.2
	With brake	40.4	58.9	76.3
Connector specifications		Refer to P.2-49 "Specifications of Motor connector"		

Caution

Reduce the moment of inertia ratio if high speed response operation is required.


Related page

- P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
- P.7-65 "S-T Characteristics"

6. Dimensions

Motor

MFME 1.5kW to 4.5kW



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MFME series (Middle inertia)				
Motor output		1.5kW	2.5kW	4.5kW
Motor model MFME		15 * * 1 *	25 * * 1 *	45 * * 1 *
LL	Without brake	142	136	156
	With brake	167	169	189
LR		70		
S		35		
LA		200	235	
LB		114.3	200	
LC		176	220	
LD		233	266	
LE		3.2	4	
LF		18	16	
LG		60		
LH		140	162	
LM	Without brake	98	91	111
	With brake	123	124	144
LZ		176		
Key way dimensions	LW	55		
	LK	50		
	KW	10h9		
	KH	8		
	RH	30		
Mass (kg)	Without brake	9.5	13.1	18.2
	With brake	12.5	17.2	23.1
Connector specifications		Refer to P.2-49 “Specifications of Motor connector”		

Caution

Reduce the moment of inertia ratio if high speed response operation is required.


Related page

- P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
- P.7-66 "S-T Characteristics"

6. Dimensions

Motor

MGME 900W to 3.0kW (DesignOrder: 1)



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MGME series (Middle inertia)				
Motor output		900W	2.0kW	3.0kW
Motor model MGME		09 * * 1 *	20 * * 1 *	30 * * 1 *
LL	Without brake	155.5	163.5	209.5
	With brake	180.5	188.5	234.5
LR		70	80	
S		22	35	
LA		145	200	
LB		110	114.3	
LC		130	176	
LD		165	233	
LE		6	3.2	
LF		12	18	
LG		60		
LH		116	140	
LM	Without brake	111.5	119.5	165.5
	With brake	136.5	144.5	190.5
LZ		9	13.5	
Key way dimensions	LW	45	55	
	LK	41	50	
	KW	8h9	10h9	
	KH	7	8	
	RH	18	30	
Mass (kg)	Without brake	6.7	14.0	20.0
	With brake	8.2	17.5	23.5
Connector specifications		Refer to P.2-49 “Specifications of Motor connector”		


Caution Reduce the moment of inertia ratio if high speed response operation is required.

Related page • P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
• P.7-67 "S-T Characteristics"

6. Dimensions

Motor

MGME 900W to 3.0kW (DesignOrder: C)



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MGME series (Middle inertia)				
Motor output		900W	2.0kW	3.0kW
Motor model MGME		09 * * C *	20 * * C *	30 * * C *
LL	Without brake	157.5	165.5	211.5
	With brake	182.5	190.5	236.5
LR		70	80	
S		22	35	
LA		145	200	
LB		110	114.3	
LC		130	176	
LD		165	233	
LE		6	3.2	
LF		12	18	
LG		84		
LH		116	140	
LM	Without brake	111.5	119.5	165.5
	With brake	136.5	144.5	190.5
LZ		9	13.5	
Key way dimensions	LW	45	55	
	LK	41	50	
	KW	8h9	10h9	
	KH	7	8	
	RH	18	30	
Mass (kg)	Without brake	6.7	14.0	20.0
	With brake	8.2	17.5	23.5
Connector specifications		Refer to P.2-49 “Specifications of Motor connector”		

Caution

Reduce the moment of inertia ratio if high speed response operation is required.

Related page



- P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
- P.7-67 "S-T Characteristics"

6. Dimensions


Motor

MGME 4.5kW, 6.0kW



<MGME 4.5kW>




Shaft end spec. (Key way shaft)



<MGME 6.0kW>



Shaft end spec. (Key way shaft)



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MGME series (Middle inertia)			
Motor output		4.5kW	6.0kW
Motor model MGME		45 ** 1 *	60 ** 1 *
LL	Without brake	266	312
	With brake	291	337
LR		113	
S		42	
LA		200	
LB		114.3	
LC		176	
LD		233	
LE		3.2	
LF		24	
LG		60	
LH		140	184
LM	Without brake	222	268
	With brake	247	293
LZ		13.5	
Key way dimensions	LW	96	
	LK	90	
	KW	12h9	
	KH	8	
	RH	37 $\frac{0}{-0.2}$	
Mass (kg)	Without brake	29.4	36.4
	With brake	33.0	40.4
Connector specifications		Refer to P.2-49 "Specifications of Motor connector"	

Caution

Reduce the moment of inertia ratio if high speed response operation is required.


Related page

- P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
- P.7-68 "S-T Characteristics"

6. Dimensions

Motor

MHMD 200W to 750W



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MHMD series (High inertia)				
Motor output		200W	400W	750W
Motor model MHMD		02 ** 1 *	04 ** 1 *	08 ** 1 *
LL	Without brake	99	118.5	164.2
	With brake	135.5	155	127.2
LR		30		35
S		11	14	19
LA		70		90±0.2
LB		50		70
LC		60		80
LE		3		
LF		6.5		8
LH		43		53
LZ		4.5		6
D カット 寸法 Key way dimensions	LW	30		35
	LK	22		25
	RH	10	12.5	17.5
	LW	20	25	25
	LK	18	22.5	22
	KW	4h9	5h9	6h9
	KH	4	5	6
	RH	8.5	11	15.5
	TP	M4 depth 8	M5 depth 10	
Mass (kg)	Without brake	0.96	1.4	2.5
	With brake	1.4	1.8	3.3
Connector specifications		Refer to P.2-48 "Specifications of Motor connector"		

Caution

Reduce the moment of inertia ratio if high speed response operation is required.

Related page



- P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
- P.7-69, 7-70 "S-T Characteristics"

6. Dimensions


Motor

MHME 1.0kW to 7.5kW (DesignOrder: 1)



<MHME 1.0kW~5.0kW>




Shaft end spec.
(Key way shaft)



<MHME 7.5kW>



Shaft end spec.
(Key way shaft)



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MHME series (High inertia)									
Motor output		1.0kW	1.5kW	2.0kW	3.0kW	4.0kW	5.0kW	7.5kW	
Motor model		MHME	10 ** 1 *	15 ** 1 *	20 ** 1 *	30 ** 1 *	40 ** 1 *	50 ** 1 *	75 ** 1 *
LL	Without brake	173	190.5	177	196	209.5	238.5	357	
	With brake	198	215.5	202	221	234.5	263.5	382	
LR		70		80				113	
S		22		35				42	
LA		145		200					
LB		110		114.3					
LC		130		176					
LD		165		233					
LE		6		3.2					
LF		12		18				24	
LG		60							
LH		116		140				184	
LM	Without brake	129	146.5	133	152	165.5	194.5	313	
	With brake	154	171.5	158	177	190.5	219.5	338	
LZ		9		13.5					
Key way dimensions	LW	45		55				96	
	LK	41		50				90	
	KW	8h9		10h9				12h9	
	KH	7		8					
	RH	18		30				37 ⁰ _{-0.2}	
Mass (kg)	Without brake	6.7	8.6	12.2	16.0	18.6	23.0	42.3	
	With brake	8.1	10.1	15.5	19.2	21.8	26.2	46.2	
Connector specifications		Refer to P.2-49 “Specifications of Motor connector”							

Caution

Reduce the moment of inertia ratio if high speed response operation is required.


Related page

• P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
• P.7-71, 7-72 "S-T Characteristics"

6. Dimensions

Motor

MHME 1.0kW to 5.0kW (DesignOrder: C)



* Dimensions are subject to change without notice. Contact us or a dealer for the latest information.

MHME series (High inertia)							
Motor output		1.0kW	1.5kW	2.0kW	3.0kW	4.0kW	5.0kW
Motor model MHME		10 * * C *	15 * * C *	20 * * C *	30 * * C *	40 * * C *	50 * * C *
LL	Without brake	175	192.5	179	198	211.5	240.5
	With brake	200	217.5	204	223	236.5	265.5
LR		70		80			
S		22		35			
LA		145		200			
LB		110		114.3			
LC		130		176			
LD		165		233			
LE		6		3.2			
LF		12		18			
LG		84					
LH		116		140			
LM	Without brake	129	146.5	133	152	165.5	194.5
	With brake	154	171.5	158	177	190.5	219.5
LZ		9		13.5			
Key way dimensions	LW	45		55			
	LK	41		50			
	KW	8h9		10h9			
	KH	7		8			
	RH	18		30			
Mass (kg)	Without brake	6.7	8.6	12.2	16.0	18.6	23.0
	With brake	8.1	10.1	15.5	19.2	21.8	26.2
Connector specifications		Refer to P.2-49 “Specifications of Motor connector”					

Caution

Reduce the moment of inertia ratio if high speed response operation is required.


Related page

• P.1-21 "Check of the Model" • P.1-23 "Check of the Combination of the Driver and the Motor"
• P.7-71, 72 "S-T Characteristics"

When you install one noise filter at the power supply for multi-axes application, contact to a manufacture of the noise filter. If noise margin is required, connect 2 filters in series to emphasize effectiveness.


• Options

Option part No.	Voltage specifications for driver	Manufacturer's part No.	Applicable driver (frame)	Manufacturer
DV0P4170	Single phase 100V, 200V	SUP-EK5-ER-6	A and B-frame	Okaya Electric Ind.



Option part No.	Voltage specifications for driver	Manufacturer's part No.	Applicable driver (frame)	Manufacturer
DV0PM20042	3-phase 200V	3SUP-HU10-ER-6	A and B-frame	Okaya Electric Ind.
	Single phase 100V, 200V		C-frame	
DV0P4220	Single/3-phase 200V	3SUP-HU30-ER-6	D-frame	
DV0PM20043	3-phase 200V	3SUP-HU50-ER-6	E-frame	

[DV0PM20042, DV0P4220]




[Size] [Unit: mm]


	A	B	C	D	E	F	G	H
DV0PM20042	115	105	95	70	43	10	52	5.5
DV0P4220	145	135	125	70	50	10	52	5.5
DV0PM20043	165	136	165	90	80	40	54	5.5

For single phase application, use 2 terminals among 3 terminals, leaving the remaining terminal unconnected.

[DV0PM20043]



Circuit diagram





Related page

- P.2-2 "Conformance to international standards"
- P.2-10 "Driver and List of Applicable Peripheral Equipments"

7. Options

Noise Filter


Option part No.	Voltage specifications for driver	Manufacturer's part No.	Applicable driver (frame)	Manufacturer
DV0P3410	3-phase 200V	3SUP-HL50-ER-6B	F-frame	Okaya Electric Ind.




• Recommended components

Part No.	Voltage specifications for driver	Current rating (A)	Applicable driver (frame)	Manufacturer
RTHN-5010	3-phase 200V	10	A, B, C-frame	TDK-Lambda Corp.
RTHN-5030		30	D-frame	
RTHN-5050		50	E, F-frame	


[RTHN-5010]



[RTHN-5030]



[RTHN-5050]



Remarks

- Select a noise filter of capacity that exceeds the capacity of the power source (also check for load condition).
- For detailed specification of the filter, contact the manufacturer.

Caution

Use options correctly after reading operation manuals of the options to better understand the precautions.


Take care not to apply excessive stress to each optional part.

7. Options

Noise Filter

part No.	Voltage specifications for driver	Current rating (A)	Applicable driver (frame)	Manufacturer
FS5559-60-34	3-phase 200V	60	G-frame	Schaffner
FS5559-80-34		80	H-frame	
FN258L-16-07	3-phase 400V	16	D, E-frame	
FN258L-30-07		30	F-frame	
FN258-42-07		42	G, H-frame	
FN258-42-33		42		


[FS5559-60-34, FS5559-80-34]




[Size]

	A	B	C	D
FS5559-60-34	410	170	370	388
FS5559-80-34	460	180	420	438


Circuit diagram




[FN258L-16-07]




[FN258L-30-07]



Circuit diagram




Circuit diagram




Noise Filter

[FN258-42-07]




[Unit: mm]

[FN258-42-33]



[Unit: mm]

Circuit diagram



Remarks

- Select a noise filter of capacity that exceeds the capacity of the power source (also check for load condition).
- For detailed specification of the filter, contact the manufacturer.


Caution

Use options correctly after reading operation manuals of the options to better understand the precautions.


Take care not to apply excessive stress to each optional part.

Provide a surge absorber for the primary side of noise filter.


Option part No.	Voltage specifications for driver	Manufacturer's part No.	Manufacturer
DV0P1450	3-phase 200V	R·A·V-781BXZ-4	Okaya Electric Ind.
DV0PM20050	3-phase 400V	R·A·V-801BXZ-4	




Circuit diagram



Option part No.	Voltage specifications for driver	Manufacturer's part No.	Manufacturer
DV0P4190	Single phase 100V, 200V	R·A·V-781BWZ-4	Okaya Electric Ind.



Circuit diagram



Remarks

Take off the surge absorber when you execute a dielectric test to the machine or equipment, or it may damage the surge absorber.

Related page


- P.2-2 "Conformance to international standards"
- P.2-10 "Driver and List of Applicable Peripheral Equipments"

Install noise filters for signal lines to all cables (power cable, motor cable, encoder cable and interface cable)


• Options

<24 V Power cable, Motor cable, Encoder cable, Interface cable, USB cable>

Option part No.	Manufacturer's part No.	Manufacturer
DV0P1460	ZCAT3035-1330	TDK Corp.



Mass: 62.8g



[Unit: mm]


Remarks

To connect the noise filter to the connector XB connection cable, adjust the sheath length at the tip of the cable, as required.

• Recommended components

<Power cable>


Part No.	Applicable driver (frame)	Manufacturer
RJ8035	E-frame 200 V, F-frame 200 V	KK-CORP.CO.JP
RJ8095	G-frame, H-frame	



Manufacturer's part No.	Current value	100kHz (μH)	Dimension [Unit: mm]							
			A	B	C	D1	D2	Core thickness	E	F
RJ8035	35A	9.9±3	170	150	23	80	53	24	R3.5	7
RJ8095	95A	7.9±3	200	180	34	130	107	35	R3.5	7

<Motor cable>

Part No.	Applicable driver (frame)	Manufacturer
T400-61D	G-frame, H-frame	MICROMETALS



[Unit: mm]

Remarks

Fix the signal line noise filter in place to eliminate excessive stress to the cables.


7

Supplement

7. Options

Junction Cable for Encoder


Part No.	MFECA0 ** 0EAM	Compatible motor output	MSMD 50W to 750W, MHMD 200W to 750W
Specifications	For 20-bit incremental encoder (Without battery box)		



Title	Part No.	Manufacturer	L (m)	Part No.
Connector (Driver side)	3E206-0100 KV	Sumitomo 3M *1	3	MFECA0030EAM
Shell kit	3E306-3200-008		5	MFECA0050EAM
Connector (Motor side)	172160-1	Tyco Electronics	10	MFECA0100EAM
Connector pin	170365-1		20	MFECA0200EAM
Cable	0.20mm ² ×3P (6-wire type)	Ok Electric Cable Co., Ltd.		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	MFECA0 ** 0MJD (Highly bendable type, Direction of motor shaft)	Compatible motor output	50W to 750W (200V)
	MFECA0 ** 0MKD (Highly bendable type, Opposite direction of motor shaft)		
	MFECA0 ** 0TJD (Standard bendable type, Direction of motor shaft)		
	MFECA0 ** 0TKD (Standard bendable type, Opposite direction of motor shaft)		
Specifications	For 20-bit incremental encoder (Without battery box) * Also for 17-bit version.		




Title	Part No.	Manufacturer	L (m)	Part No.
Connector (Driver side)	3E206-0100 KV	Sumitomo 3M *1	3	MFECA0030MJD
Shell kit	3E306-3200-008		5	MFECA0050MJD
Connector	JN6FR07SM1	Japan Aviation Electronics Ind.	10	MFECA0100MJD
Connector pin	LY10-C1-A1-10000		20	MFECA0200MJD
Cable	AWG24×4P, AWG22×2P	Hitachi Cable, Ltd.		

*1 Old model number: 55100-0670 (Japan Molex Inc.)



Caution Option cable does not conform to IP65 and IP67.




Related page • P.1-27 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"

7. Options

Junction Cable for Encoder


Part No.	MFECA0 ** 0MJE (Highly bendable type, Direction of motor shaft)	Compatible motor output	50W to 750W (200V)
	MFECA0 ** 0MKE (Highly bendable type, Opposite direction of motor shaft)		
	MFECA0 ** 0TJE (Standard bendable type, Direction of motor shaft)		
	MFECA0 ** 0TKE (Standard bendable type, Opposite direction of motor shaft)		
Specifications	For 17-bit absolute encoder (With battery box)		



Title	Part No.	Manufacturer	L (m)	Part No.
Connector (Driver side)	3E206-0100 KV	Sumitomo 3M ^{*1}	3	MFECA0030MJE
Shell kit	3E306-3200-008		5	MFECA0050MJE
Connector	ZMR-02	J.S.T Mfg. Co., Ltd.	10	MFECA0100MJE
Connector pin	SMM-003T-P0.5		20	MFECA0200MJE
Connector	JN6FR07SM1	Japan Aviation Electronics Ind.		
Connector pin	LY10-C1-A1-10000			
Cable	AWG24 ×4P, AWG22×2P	Hitachi Cable, Ltd.		

^{*1} Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	MFECA0 ** 0ETD	Compatible motor output	400W (400V), 600W (400V), 750W (400V), 0.9kW to 15.0kW
Specifications	For 20-bit incremental encoder (Without battery box), Design order: 1		



Title	Part No.	Manufacturer	L (m)	Part No.
Connector (Driver side)	3E206-0100 KV	Sumitomo 3M ^{*1}	3	MFECA0030ETD
Shell kit	3E306-3200-008		5	MFECA0050ETD
Connector	JN2DS10SL1-R	Japan Aviation Electronics Ind.	10	MFECA0100ETD
Connector pin	JN1-22-22S-PKG100		20	MFECA0200ETD
Cable	0.2mm ² ×3P	Oki Electric Cable Co., Ltd.		

^{*1} Old model number: 55100-0670 (Japan Molex Inc.)



Caution Option cable does not conform to IP65 and IP67.




• P.1-27 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"

7. Options

Junction Cable for Encoder


Part No.	MFECA0 ** 0ESD	Compatible motor output	0.9kW to 5.0kW (IP65 Motor)
Specifications	For 20-bit incremental encoder (Without battery box), Design order: C		



Title	Part No.	Manufacturer	L (m)	Part No.
Connector (Driver side)	3E206-0100 KV	Sumitomo 3M *1	3	MFECA0030ESD
Shell kit	3E306-3200-008		5	MFECA0050ESD
Connector (Motor side)	N/MS3106B20-29S	Japan Aviation Electronics Ind.	10	MFECA0100ESD
Cable clamp	N/MS3057-12A		20	MFECA0200ESD
Cable	0.2mm ² ×3P (6-wire type)	Oki Electric Cable Co., Ltd.		

*1 Old model number: 55100-0670 (Japan Molex Inc.)


Part No.	MFECA0 ** 0ETE	Compatible motor output	400W (400V), 600W (400V), 750W (400V), 0.9kW to 15.0kW
Specifications	For 17-bit absolute encoder (With battery box), Design order: 1		



Title	Part No.	Manufacturer	L (m)	Part No.
Connector (Driver side)	3E206-0100 KV	Sumitomo 3M *1	3	MFECA0030ETE
Shell kit	3E306-3200-008		5	MFECA0050ETE
Connector	ZMR-02	J.S.T Mfg. Co., Ltd.	10	MFECA0100ETE
Connector pin	SMM-003T-P0.5		20	MFECA0200ETE
Connector	JN2DS10SL1-R	Japan Aviation Electronics Ind.		
Connector pin	JN1-22-22S-PKG100			
Cable	0.2mm ² ×3P	Oki Electric Cable Co., Ltd.		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	MFECA0 ** 0ESE	Compatible motor output	0.9kW to 5.0kW (IP65 Motor)
Specifications	For 17-bit absolute encoder (With battery box), Design order: C		




Title	Part No.	Manufacturer	L (m)	Part No.
Connector (Driver side)	3E206-0100 KV	Sumitomo 3M *1	3	MFECA0030ESE
Shell kit	3E306-3200-008		5	MFECA0050ESE
Connector (Motor side)	N/MS3106B20-29S	Japan Aviation Electronics Ind.	10	MFECA0100ESE
Cable clamp	N/MS3057-12A		20	MFECA0200ESE
Cable	0.2mm ² ×4P (8-wire type)	Oki Electric Cable Co., Ltd.		

*1 Old model number: 55100-0670 (Japan Molex Inc.)


Caution Option cable does not conform to IP65 and IP67.

Part No.	MFMCA0 ** 0EED	Applicable model	MSMD 50W to 750W, MHMD 200W to 750W
----------	-----------------------	------------------	-------------------------------------



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	172159-1	Tyco Electronics	3	MFMCA0030EED
Connector pin	170366-1		5	MFMCA0050EED
Rod terminal	AI0.75-8GY	Phoenix Contact	10	MFMCA0100EED
Nylon insulated round terminal	N1.25-M4	J.S.T Mfg. Co., Ltd.	20	MFMCA0200EED
Cable	ROBO-TOP 600V 0.75mm ² 4-wire type	Daiden Co., Ltd.		

Part No.	MFMCA0 ** 0NJD (Highly bendable type, Direction of motor shaft)	Applicable model	MSME 50W to 750W
	MFMCA0 ** 0NKD (Highly bendable type, Opposite direction of motor shaft)		
	MFMCA0 ** 0RJD (Standard bendable type, Direction of motor shaft)		
	MFMCA0 ** 0RKD (Standard bendable type, Opposite direction of motor shaft)		



Caution ⚠ Motor cable for opposite direction of motor shaft cannot be used with a motor 50W and 100W.

Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JN8FT04SJ1	Japan Aviation Electronics Ind.	3	MFMCA0030NJD
Connector pin	ST-TMH-S-C1B-3500		5	MFMCA0050NJD
Rod terminal	AI0.75-8GY	Phoenix Contact	10	MFMCA0100NJD
Nylon insulated round terminal	N1.25-M4	J.S.T Mfg. Co., Ltd.	20	MFMCA0200NJD
Cable	AWG18×4P	Hitachi Cable, Ltd.		


Caution ⚠ Option cable does not conform to IP65 and IP67.

Related page ⚠ • P.1-27 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"

7. Options


Junction Cable for Motor (Without brake)

Part No.	MFMCD0 ** 2ECD	Applicable model	MSME 750W (400V), 1.0kW to 2.0kW, MDME 1.0kW to 2.0kW, MHME 1.0kW to 1.5kW, MGME 0.9kW
----------	----------------	------------------	--




Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A20-4SE-EB-R	Japan Aviation Electronics Ind.	3	MFMCD0032ECD
Cable clamp	JL04-2022CK(14)-R		5	MFMCD0052ECD
Rod terminal	NTUB-2	J.S.T Mfg. Co., Ltd.	10	MFMCD0102ECD
Nylon insulated round terminal	N2-M4	J.S.T Mfg. Co., Ltd.	20	MFMCD0202ECD
Cable	ROBO-TOP 600V 2.0mm ²	Daiden Co.,Ltd.		

Part No.	MFMCE0 ** 2ECD	Applicable model	MHME 2.0kW
----------	----------------	------------------	------------



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A22-22SE-EB-R	Japan Aviation Electronics Ind.	3	MFMCE0032ECD
Cable clamp	JL04-2022CK(14)-R		5	MFMCE0052ECD
Rod terminal	NTUB-2	J.S.T Mfg. Co., Ltd.	10	MFMCE0102ECD
Nylon insulated round terminal	N2-M4	J.S.T Mfg. Co., Ltd.	20	MFMCE0202ECD
Cable	ROBO-TOP 600V 2.0mm ²	Daiden Co.,Ltd.		

Part No.	MFMCA0 ** 3ECT	Applicable model	MSME 3.0kW to 5.0kW, MDME 3.0kW to 5.0kW MHME 3.0kW to 5.0kW, MGME 2.0kW to 3.0kW
----------	----------------	------------------	--



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A22-22SE-EB-R	Japan Aviation Electronics Ind.	3	MFMCA0033ECT
Cable clamp	JL04-2022CK(14)-R		5	MFMCA0053ECT
Nylon insulated round terminal	N5.5-5	J.S.T Mfg. Co., Ltd.	10	MFMCA0103ECT
			20	MFMCA0203ECT
Cable	ROBO-TOP 600V 3.5mm ²	Daiden Co.,Ltd.		


Caution Option cable does not conform to IP65 and IP67.

Related page • P.1-27 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"

7. Options


Junction Cable for Motor (Without brake)

Part No.	MFMCA0 ** 2ECD	Applicable model	MFME 1.5kW (200V)
-----------------	-----------------------	-------------------------	-------------------




Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A20-18SE-EB-R	Japan Aviation Electronics Ind.	3	MFMCA0032ECD
Cable clamp	JL04-2022CK(14)-R	Japan Aviation Electronics Ind.	5	MFMCA0052ECD
Rod terminal	AI2.5-8BU	Phoenix Contact	10	MFMCA0102ECD
Nylon insulated round terminal	N2-M4	J.S.T Mfg. Co., Ltd.	20	MFMCA0202ECD
Cable	ROBO-TOP 600V 2.0mm ²	Daiden Co.,Ltd.		

Part No.	MFMCF0 ** 2ECD	Applicable model	MFME 1.5kW (400V), 2.5kW
-----------------	-----------------------	-------------------------	--------------------------



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A24-11SE-EB-R	Japan Aviation Electronics Ind.	3	MFMCF0032ECD
Cable clamp	JL04-2428CK(14)-R	Japan Aviation Electronics Ind.	5	MFMCF0052ECD
Rod terminal	NTUB-2	Phoenix Contact	10	MFMCF0102ECD
Nylon insulated round terminal	N2-M4	J.S.T Mfg. Co., Ltd.	20	MFMCF0202ECD
Cable	ROBO-TOP 600V 2.0mm ²	Daiden Co.,Ltd.		

Part No.	MFMCD0 ** 3ECT	Applicable model	MFME 4.5kW
-----------------	-----------------------	-------------------------	------------



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A24-11SE-EB-R	Japan Aviation Electronics Ind.	3	MFMCA0033ECT
Cable clamp	JL04-2428CK(17)-R	Japan Aviation Electronics Ind.	5	MFMCA0053ECT
Nylon insulated round terminal	N5.5-5	J.S.T Mfg. Co., Ltd.	10	MFMCA0103ECT
Cable	ROBO-TOP 600V 3.5mm ²	Daiden Co.,Ltd.	20	MFMCA0203ECT

Caution Option cable does not conform to IP65 and IP67.

Related page • P.1-27 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"


7

Supplement

7. Options


Junction Cable for Motor (With brake)

Part No.	MFMCA0 ** 2FCD	Applicable model	MSME 1.0kW to 2.0kW (200V) MDME 1.0kW to 2.0kW (200V) MFME 1.5kW (200V) MHME 1.0kW to 1.5kW (200V) MGME 0.9kW (200V)
----------	----------------	------------------	--



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A20-18SE-EB-R	Japan Aviation Electronics Ind.	3	MFMCA0032FCD
Cable clamp	JL04-2022CK(14)-R		5	MFMCA0052FCD
Rod terminal	NTUB-2	J.S.T Mfg. Co., Ltd.	10	MFMCA0102FCD
Nylon insulated round terminal	Earth N2-M4	J.S.T Mfg. Co., Ltd.	20	MFMCA0202FCD
	Brake N1.25-M4			
Cable	ROBO-TOP 600V 0.75mm ² and ROBO-TOP 600V 2.0mm ²	Daiden Co.,Ltd.		


Part No.	MFMCE0 ** 2FCD	Applicable model	MSME 750W to 2.0kW (400V) MDME 400W to 2.0kW (400V) MFME 1.5kW (400V), 2.5kW MGME 0.9kW (400V) MHME 1.0kW (400V), 1.5kW (400V), 2.0kW
----------	----------------	------------------	---



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JL04V-6A24-11SE-EB-R	Japan Aviation Electronics Ind.	3	MFMCE0032FCD
Cable clamp	JL04-2428CK(17)-R		5	MFMCE0052FCD
Rod terminal	NTUB-2	J.S.T Mfg. Co., Ltd.	10	MFMCE0102FCD
Nylon insulated round terminal	Earth N2-M4	J.S.T Mfg. Co., Ltd.	20	MFMCE0202FCD
	Brake N1.25-M4			
Cable	ROBO-TOP 600V 0.75mm ² and ROBO-TOP 600V 2.0mm ²	Daiden Co.,Ltd.		



Option cable does not conform to IP65 and IP67.




• P.1-27 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"

7. Options

Junction Cable for Motor (With brake)

Part No.	MFMCA0 ** 3FCT	Applicable model	MSME 3.0kW to 5.0kW, MFME 4.5kW, MGME 2.0kW to 4.5kW	MDME 3.0kW to 5.0kW MHME 3.0kW to 5.0kW
----------	----------------	------------------	--	--



Title		Part No.	Manufacturer	L (m)	Part No.
Connector		JL04V-6A24-11SE-EB-R	Japan Aviation Electronics Ind.	3	MFMCA0033FCT
Cable clamp		JL04-2428CK(17)-R		5	MFMCA0053FCT
Nylon insulated round terminal	Earth	N5.5-5	J.S.T Mfg. Co., Ltd.	10	MFMCA0103FCT
	Brake	N1.25-M4		20	MFMCA0203FCT
Cable		ROBO-TOP 600V 0.75mm ² and ROBO-TOP 600V 3.5mm ²	Daiden Co.,Ltd.		

Caution

Option cable does not conform to IP65 and IP67.

Related page

• P.1-27 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"


7

Supplement

7. Options


Junction Cable for Brake

Part No.	MFMCB0 ** 0GET	Applicable model	MSMD 50W to 750W, MHMD 200W to 750W
-----------------	-----------------------	-------------------------	-------------------------------------



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	172157-1	Tyco Electronics	3	MFMCB0030GET
Connector pin	170366-1, 170362-1		5	MFMCB0050GET
Nylon insulated round terminal	N1.25-M4	J.S.T Mfg. Co., Ltd.	10	MFMCB0100GET
Cable	ROBO-TOP 600V 0.75mm ² ×2-wire type	Daiden Co., Ltd.	20	MFMCB0200GET

Part No.	MFMCB0 ** 0PJT (Highly bendable type, Direction of motor shaft)	Applicable model	MSME 50W to 750W
	MFMCB0 ** 0PKT (Highly bendable type, Opposite direction of motor shaft)		
	MFMCB0 ** 0SJT (Standard bendable type, Direction of motor shaft)		
	MFMCB0 ** 0SKT (Standard bendable type, Opposite direction of motor shaft)		



Title	Part No.	Manufacturer	L (m)	Part No.
Connector	JN4FT02SJMR	Japan Aviation Electronics Ind.	3	MFMCB0030PJT
Connector pin	ST-TMH-S-C1B-3500		5	MFMCB0050PJT
Nylon insulated round terminal	N1.25-M4	J.S.T Mfg. Co., Ltd.	10	MFMCB0100PJT
Cable	AWG22	Hitachi Cable, Ltd.	20	MFMCB0200PJT

Caution

Option cable does not conform to IP65 and IP67.

Related page

• P.1-27 "Junction cable for motor" • P.2-48 "Specifications of Motor connector"

Connector Kit for Interface


Part No. DV0P4350

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	10150-3000PE equivalent	1	Sumitomo 3M *1	For Connector X4 (50-pins)
Connector cover	10350-52A0-008 equivalent	1		

*1 Old model number: Connector 54306-5019, Connector cover 54331-0501 (Japan Molex Inc.)


• Pin disposition (50 pins) (viewed from the soldering side)



- 1) Check the stamped pin-No. on the connector body while making a wiring.
- 2) For the function of each signal title or its symbol, refer to the wiring example of the connector X4.
- 3) Do not connect anything to NC pins in the above table.

Interface Cable

Part No. DV0P4360



This 2 m connector cable contains AWG28 conductors.

• Table for wiring

Pin No.	color	Pin No.	color	Pin No.	color	Pin No.	color	Pin No.	color
1	Orange (Red1)	11	Orange (Black2)	21	Orange (Red3)	31	Orange (Red4)	41	Orange (Red5)
2	Orange (Black1)	12	Yellow (Black1)	22	Orange (Black3)	32	Orange (Black4)	42	Orange (Black5)
3	Gray (Red1)	13	Gray (Red2)	23	Gray (Red3)	33	Gray (Red4)	43	Gray (Red5)
4	Gray (Black1)	14	Gray (Black2)	24	Gray (Black3)	34	White (Red4)	44	White (Red5)
5	White (Red1)	15	White (Red2)	25	White (Red3)	35	White (Black4)	45	White (Black5)
6	White (Black1)	16	Yellow (Red2)	26	White (Black3)	36	Yellow (Red4)	46	Yellow (Red5)
7	Yellow (Red1)	17	Yel (Blk2)/Pink (Blk2)	27	Yellow (Red3)	37	Yellow (Black4)	47	Yellow (Black5)
8	Pink (Red1)	18	Pink (Red2)	28	Yellow (Black3)	38	Pink (Red4)	48	Pink (Red5)
9	Pink (Black1)	19	White (Black2)	29	Pink (Red3)	39	Pink (Black4)	49	Pink (Black5)
10	Orange (Red2)	20	-	30	Pink (Black3)	40	Gray (Black4)	50	Gray (Black5)

<Remarks>

Color designation of the cable e.g.) Pin-1 Cable color : Orange (Red1) : One red dot on the cable

The shield of this cable is connected to the connector shell but not to the terminal.

7. Options

Connector Kit


Connector Kit for Communication Cable (for RS485, RS232)

Part No. **DV0PM20024**


• Components

Title	Part No.	Manufacturer	Note
Connector	2040008-1	Tyco Electronics	For Connector X2 (8-pins)

• Pin disposition of connector, connector X2



• Dimensions




Connector Kit for Safety

Part No. **DV0PM20025**


• Components

Title	Part No.	Manufacturer	Note
Connector	2013595-1	Tyco Electronics	For Connector X3 (8-pins)

• Pin disposition of connector, connector X3



• Dimensions




Connector Kit for External Scale

Part No. **DV0PM20026**


• Components

Title	Part No.	Manufacturer	Note
Connector	MUF-PK10K-X	J.S.T Mfg. Co., Ltd.	For Connector X5

• Pin disposition of connector, connector X5




• Dimensions



Remarks

- Connector X1: use with commercially available cable.
- Configuration of connector X1: USB mini-B



- For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125 "List of Peripheral Equipments".

7. Options

Connector Kit

Connector Kit for Encoder


Part No. **DV0PM20010**

• Components

Title	Part No.	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	Sumitomo 3M ^{*1}	For Connector X6
Shell kit	3E306-3200-008		


^{*1} Old model number: 55100-0670 (Japan Molex Inc.)

• Pin disposition of connector, connector X6




• Dimensions

<Shell kit>



<Connector>




Connector Kit for Analog Monitor Signal

Part No. **DV0PM20031**


• Components

Title	Part No.	Number	Manufacturer	Note
Connector	510040600	1	Molex Inc	For Connector X7 (6-pins)
Connector pin	500118100	6		

• Pin disposition of connector, connector X7



• Dimensions



Connector Kit for Power Supply Input

Part No. **DV0PM20032** (For A to D-frame: Single row type)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	05JFAT-SAXGF	1	J.S.T Mfg. Co., Ltd.	For Connector XA
Handle lever	J-FAT-OT	2		

Remarks

- For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125 "List of Peripheral Equipments".

7. Options


Connector Kit

Part No. DV0PM20033 (For A to D-frame: double row type)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	05JFAT-SAXGSA-C	1	J.S.T Mfg. Co., Ltd.	For Connector XA
Handle lever	J-FAT-OT	2		

• Dimensions



Part No. DV0PM20044 (For E-frame 200 V)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	05JFAT-SAXGSA-L	1	J.S.T Mfg. Co., Ltd.	For Connector XA
Handle lever	J-FAT-OT-L	2		

Part No. DV0PM20053 (For D-frame 400 V, E-frame 400 V and 24 V Input power)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	02MJFAT-SAGF	1	J.S.T Mfg. Co., Ltd.	For Connector XD
Handle lever	MJFAT-OT	2		

Part No. DV0PM20051 (For D-frame 400 V)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	03JFAT-SAYGSA-M	1	J.S.T Mfg. Co., Ltd.	For Connector XA
Handle lever	J-FAT-OT-L	2		

Part No. DV0PM20052 (For E-frame 400 V)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	03JFAT-SAYGSA-L	1	J.S.T Mfg. Co., Ltd.	For Connector XA
Handle lever	J-FAT-OT-L	2		

7. Options

Connector Kit

Connector Kit for Regenerative Resistor Connection (E-frame)

Part No. DV0PM20045 (For E-frame)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	04JFAT-SAXGSA-L	1	J.S.T Mfg. Co., Ltd.	For Connector XC
Handle lever	J-FAT-OT-L	2		

Part No. DV0PM20055 (For D-frame 400 V)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	04JFAT-SAXGSA-M	1	J.S.T Mfg. Co., Ltd.	For Connector XC
Handle lever	J-FAT-OT-L	2		

Connector Kit for Motor Connection

Part No. DV0PM20034 (For A to D-frame)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	06JFAT-SAXGSA-M	1	J.S.T Mfg. Co., Ltd.	For Connector XB
Handle lever	J-FAT-OT	2		

Part No. DV0PM20046 (For E-frame)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	03JFAT-SAXGSA-L	1	J.S.T Mfg. Co., Ltd.	For Connector XB
Handle lever	J-FAT-OT-L	2		

Part No. DV0PM20054 (For D-frame 400 V)

• Components

Title	Part No.	Number	Manufacturer	Note
Connector	03JFAT-SAXGSA-M	1	J.S.T Mfg. Co., Ltd.	For Connector XB
Handle lever	J-FAT-OT-L	2		

7. Options

Connector Kit

Connector Kit for Motor/Encoder Connection


Part No.	DV0P4380	Applicable model	MSMD 50W to 750W, MHMD 200W to 750W (incremental encoder type)
-----------------	-----------------	-------------------------	--

• Components


Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M *1	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Connector	172160-1	1	Tyco Electronics	For Encoder cable (6-pins)
Connector pin	170365-1	6		
Connector	172159-1	1	Tyco Electronics	For Motor cable (4-pins)
Connector pin	170366-1	4		

*1 Old model number: 55100-0670 (Japan Molex Inc.)


• Pin disposition of connector, connector X6



• Pin disposition of connector for encoder cable



• Pin disposition of connector for motor cable




Part No.	DV0PM20035	Applicable model	MSME 50W to 750W
-----------------	-------------------	-------------------------	------------------

• Components


Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M *1	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder plug connector	JN6FR07SM1	1	Japan Aviation Electronics Ind.	For Encoder cable (7-pins)
Socket contact	LY10-C1-A1-10000	7		
Motor plug connector	JN8FT04SJ1	1	Japan Aviation Electronics Ind.	For Motor cable (4-pins)
Socket contact	ST-TMH-S-C1B-3500	4		

*1 Old model number: 55100-0670 (Japan Molex Inc.)


• Pin disposition of connector, connector X6





• Pin disposition of connector for encoder cable



• Pin disposition of connector for motor cable



[Opposite direction of motor shaft]



* Pins 2 and 5 are left unused (NC) with an incremental encoder.

Remarks

Secure the gasket in place without removing it from the connector. Otherwise, the degree of protection of IP67 will not be guaranteed.

Caution

• When IP65 or IP67 are necessary, the customer must give appropriate processing.

Remarks

• For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125

"List of Peripheral Equipments"

Phone: 800.894.0412 - Fax: 888.723.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

7. Options

Connector Kit

Part No.	DV0PM20036	Applicable model	MSME 750W (400V), 1.0kW to 2.0kW, MDME 400W (400V), 600W (400V), 1.0kW to 2.0kW MHME 1.0kW to 1.5kW, MGME 0.9kW	Without brake
Specifications	Design order: 1			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	JN2DS10SL1-R	1	Japan Aviation Electronics Ind.	For Encoder cable
Connector pin	JN1-22-22S-PKG100	5		
Motor connector	JL04V-6A-20-4SE-EB-R	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	JL04-2022CK(14)-R	1		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0P4310	Applicable model	MSME 1.0kW to 2.0kW, MDME 1.0kW to 2.0kW MHME 1.0kW to 1.5kW, MGME 0.9kW	Without brake
Specifications	Design order: C			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	N/MS3106B20-29S	1	Japan Aviation Electronics Ind.	For Encoder cable
Cable clamp	N/MS3057-12A	1		
Motor connector	N/MS3106B20-4S	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	N/MS3057-12A	1		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0PM20037	Applicable model	MSME 3.0kW to 5.0kW, MDME 3.0kW to 5.0kW MHME 2.0kW to 5.0kW, MGME 2.0kW to 3.0kW	Without brake
Specifications	Design order: 1			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	JN2DS10SL1-R	1	Japan Aviation Electronics Ind.	For Encoder cable
Connector pin	JN1-22-22S-PKG100	5		
Motor connector	JL04V-6A22-22SE-EB-R	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	JL04-2022CK(14)-R	1		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0P4320	Applicable model	MSME 3.0kW to 5.0kW, MDME 3.0kW to 5.0kW MHME 2.0kW to 5.0kW, MGME 2.0kW to 3.0kW	Without brake
Specifications	Design order: C			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	N/MS3106B20-29S	1	Japan Aviation Electronics Ind.	For Encoder cable
Cable clamp	N/MS3057-12A	1		
Motor connector	N/MS3106B22-22S	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	N/MS3057-12A	1		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Caution

• When IP65 or IP67 are necessary, the customer must give appropriate processing.

Remarks

• For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125

"List of Peripheral Equipments"

7. Options

Connector Kit

Part No.	DV0PM20038	Applicable model	MSME 1.0kW to 2.0kW (200V), MDME 1.0kW to 2.0kW (200V), MFME 1.5kW (Common to with/without brake) (200V), MHME 1.0kW to 1.5kW (200V), MGME 0.9kW (200V)	With brake
Specifications	Design order: 1			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	JN2DS10SL1-R	1	Japan Aviation Electronics Ind.	For Encoder cable
Connector pin	JN1-22-22S-PKG100	5		
Motor connector	JL04V-6A20-18SE-EB-R	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	JL04-2022CK(14)-R	1		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0P4330	Applicable model	MSME 1.0kW to 2.0kW, MDME 1.0kW to 2.0kW MHME 1.0kW to 1.5kW, MGME 0.9kW	With brake
Specifications	Design order: C			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	N/MS3106B20-29S	1	Japan Aviation Electronics Ind.	For Encoder cable
Cable clamp	N/MS3057-12A	1		
Motor connector	N/MS3106B20-18S	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	N/MS3057-12A	1		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0PM20039	Applicable model	MSME 750W to 2.0kW (400V), 3.0kW to 5.0kW MDME 400W to 2.0kW (400V), 3.0kW to 5.0kW MFME 1.5kW (400V), 2.5kW to 4.5kW (Common to with/without brake) MHME 1.0kW to 1.5kW (400V), 2.0kW to 5.0kW MGME 0.9kW (400V), 2.0kW to 4.5kW	With brake
Specifications	Design order: 1			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	JN2DS10SL1-R	1	Japan Aviation Electronics Ind.	For Encoder cable
Connector pin	JN1-22-22S-PKG100	5		
Motor connector	JL04V-6A24-11SE-EB-R	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	JL04-2428CK(17)-R	1		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Part No.	DV0P4340	Applicable model	MSME 3.0kW to 5.0kW, MDME 3.0kW to 5.0kW MHME 2.0kW to 5.0kW, MGME 2.0kW to 3.0kW	With brake
Specifications	Design order: C			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	N/MS3106B20-29S	1	Japan Aviation Electronics Ind.	For Encoder cable
Cable clamp	N/MS3057-12A	1		
Motor connector	N/MS3106B24-11S	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	N/MS3057-16A	1		

*1 Old model number: 55100-0670 (Japan Molex Inc.)

Caution

• When IP65 or IP67 are necessary, the customer must give appropriate processing.

Remarks

• For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125

"List of Peripheral Equipments"

Phone: 800.894.0412 - Fax: 888.728.4773 - Web: www.ctiautomation.net - Email: info@ctiautomation.net

7. Options

Connector Kit

Part No.	DV0PM20056	Applicable model	MDME 7.5kW to 15.0kW MGME 6.0kW, MHME 7.5kW	Without brake
Specifications	Design order: 1			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	JN2DS10SL1-R	1	Japan Aviation Electronics Ind.	For Encoder cable
Connector pin	JN1-22-22S-PKG100	5		
Motor connector	JL04V-6A32-17SE-EB-R	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	JL04-32CK(24)-R ^{*2}	1		

^{*1} Old model number: 55100-0670 (Japan Molex Inc.)

^{*2} Cable cover size: Φ22 to Φ25. Cable core material is not specified. The user can select the cable compatible with the connector to be used.

Part No.	DV0PM20057	Applicable model	MDME 7.5kW to 15.0kW MGME 6.0kW, MHME 7.5kW	With brake
Specifications	Design order: 1			

• Components

Title	Part No.	Number	Manufacturer	Note
Connector (Driver side)	3E206-0100 KV	1	Sumitomo 3M ^{*1}	For Connector X6 (6-pins)
Shell kit	3E306-3200-008	1		
Encoder connector	JN2DS10SL1-R	1	Japan Aviation Electronics Ind.	For Encoder cable
Connector pin	JN1-22-22S-PKG100	5		
Motor connector	JL04V-6A32-17SE-EB-R	1	Japan Aviation Electronics Ind.	For Motor cable
Cable clamp	JL04-32CK(24)-R ^{*2}	1		
Brake connector	N/MS3106B14S-2S	1	Japan Aviation Electronics Ind.	For Brake cable
Cable clamp	N/MS3057-6A	1		

^{*1} Old model number: 55100-0670 (Japan Molex Inc.)

^{*2} Cable cover size: Φ22 to Φ25. Cable core material is not specified. The user can select the cable compatible with the connector to be used.

Connector Kit for Motor/Brake Connection


Part No.	DV0PM20040
-----------------	-------------------

• Components


Title	Part No.	Number	Manufacturer	Note
Connector	JN4FT02SJM-R	1	Japan Aviation Electronics Ind.	
Socket contact	ST-TMH-S-C1B-3500	2		

• Pin disposition of connector for brake cable

[Direction of motor shaft]



[Opposite direction of motor shaft]



Remarks Secure the gasket in place without removing it from the connector. Otherwise, the degree of protection of IP67 will not be guaranteed.


Caution • When IP65 or IP67 are necessary, the customer must give appropriate processing.

Remarks • For crimp tool etc., necessary to produce a cable, access the web site of the manufacturer or consult with the manufacturer for details. For inquiries of manufacturer, refer to P.7-125 "List of Peripheral Equipments".

Battery For Absolute Encoder

Part No. DV0P2990

- Lithium battery: 3.6V 2000mAh




Caution This battery is categorized as hazardous substance, and you may be required to present an application of hazardous substance when you transport by air (both passenger and cargo airlines).

Battery Box For Absolute Encoder

Part No. DV0P4430

- Components



Related page • P.7-10 "Absolute system"

7. Options

Mounting Bracket

Part No.	DV0PM20027	Frame symbol of applicable driver	A-frame	Mounting screw	M4 × L6 Pan head 4pcs
Dimensions	Upper side				
	Bottom side				

Part No.	DV0PM20028	Frame symbol of applicable driver	B-frame	Mounting screw	M4 × L6 Pan head 4pcs
Dimensions	Upper side				
	Bottom side				

Part No.	DV0PM20029	Frame symbol of applicable driver	C-frame	Mounting screw	M4 × L6 Pan head 4pcs
Dimensions	Upper side				
	Bottom side				

Part No.	DV0PM20030	Frame symbol of applicable driver	D-frame	Mounting screw	M4 × L6 Pan head 4pcs
Dimensions	Upper side				
	Bottom side				

Caution

For E, F and G-frame, you can make a front end and back end mounting by changing the mounting direction of L-shape bracket (attachment).

Related page

• P.7-73... "Dimensions of driver"

Fig.1





Fig.2



	Part No.	A	B	C	D	E (Max)	F	G	H	I	Inductance (mH)	Rated current (A)
Fig.1	DV0P220	65±1	125±1	(93)	136 _{Max}	155	70+3/-0	85±2	4-7φ×12	M4	6.81	3
	DV0P221	60±1	150±1	(113)	155 _{Max}	130	60+3/-0	75±2	4-7φ×12	M4	4.02	5
	DV0P222	60±1	150±1	(113)	155 _{Max}	140	70+3/-0	85±2	4-7φ×12	M4	2	8
	DV0P223	60±1	150±1	(113)	155 _{Max}	150	79+3/-0	95±2	4-7φ×12	M4	1.39	11
	DV0P224	60±1	150±1	(113)	160 _{Max}	155	84+3/-0	100±2	4-7φ×12	M5	0.848	16
	DV0P225	60±1	150±1	(113)	160 _{Max}	170	100+3/-0	115±2	4-7φ×12	M5	0.557	25
Fig.2	DV0P227	55±0.7	80±1	66.5±1	110 _{Max}	90	41±2	55±2	4-5φ×10	M4	4.02	5
	DV0P228	55±0.7	80±1	66.5±1	110 _{Max}	95	46±2	60±2	4-5φ×10	M4	2	8
	DV0PM20047	55±0.7	80±1	66.5±1	110 _{Max}	105	56±2	70±2	4-5φ×10	M4	1.39	11

Motor series	Power supply	Rated output	Part No.	Motor series	Power supply	Rated output	Part No.
MSME	Single phase, 100V	50W to 100W	DV0P227	MSME	3-phase, 200V	2.0kW	DV0P223
		200W to 400W	DV0P228	MDME			
MSME	Single phase, 200V	50W to 200W	DV0P227	MHME			
		400W to 750W	DV0P228	MGME			
MSME MDME MHME	Single phase, 200V	1.0kW	DV0P228	MSME		3.0kW	DV0P224
		1.5kW	DV0PM20047	MDME			
MGME	Single phase, 200V	0.9kW	DV0P228	MHME			
				MGME			
MSME	3-phase, 200V	50W to 750W	DV0P220	MSME		4.0kW	DV0P225
MGME		0.9kW	DV0P221	MDME			
MSME		1.0kW 1.5kW	DV0P222	MHME			
MDME				MGME			
MHME							
MFME	Single phase, 200V	1.5kW	DV0PM20047				
	3-phase, 200V	1.5kW	DV0P222				
		2.5kW	DV0P224				

Harmonic restraint

Harmonic restraint measures are not common to all countries. Therefore, prepare the measures that meet the requirements of the destination country.

With products for Japan, on September, 1994, “Guidelines for harmonic restraint on heavy consumers who receive power through high voltage system or extra high voltage system” and “Guidelines for harmonic restraint on household electrical appliances and general-purpose articles” established by the Agency for Natural Resources and Energy of the Ministry of Economy, Trade and Industry (the ex-Ministry of International Trade and Industry). According to those guidelines, the Japan Electrical Manufacturers’ Association (JEMA) have prepared technical documents (procedure to execute harmonic restraint: JEM-TR 198, JEM-TR 199 and JEM-TR 201) and have been requesting the users to understand the restraint and to cooperate with us. On January, 2004, it has been decided to exclude the general-purpose inverter and servo driver from the “Guidelines for harmonic restraint on household electrical appliances and general-purpose articles”. After that, the “Guidelines for harmonic restraint on household electrical appliances and general-purpose articles” was abolished on September 6, 2004.

We are pleased to inform you that the procedure to execute the harmonic restraint on general-purpose inverter and servo driver was modified as follows.

1. All types of the general-purpose inverters and servo drivers used by specific users are under the control of the “Guidelines for harmonic restraint on heavy consumers who receive power through high voltage system or extra high voltage system”. The users who are required to apply the guidelines must calculate the equivalent capacity and harmonic current according to the guidelines and must take appropriate countermeasures if the harmonic current exceeds a limit value specified in a contract demand. (Refer to JEM-TR 210 and JEM-TR 225.)
2. The “Guidelines for harmonic restraint on household electrical appliances and general-purpose articles” was abolished on September 6, 2004. However, based on conventional guidelines, JEMA applies the technical documents JEM-TR 226 and JEM-TR 227 to any users who do not fit into the “Guidelines for harmonic restraint on heavy consumers who receive power through high voltage system or extra high voltage system” from a perspective on enlightenment on general harmonic restraint. The purpose of these guidelines is the execution of harmonic restraint at every device by a user as usual to the utmost extent.

7. Options

External Regenerative Resistor

Part No.	Manufacturer's part No.	Specifications					Activation temperature of built-in thermostat
		Resistance	cable core outside diameter	Mass	Rated power (reference) ^{*1}		
					Free air	with fan	
		Ω	mm	kg	W	W	
DV0P4280	RF70M	50	φ1.27 (AWG18 stranded wire)	0.1	10	25	140±5℃ B-contact Open/Close capacity (resistance load) 1A 125VAC 6000 times 0.5A 250VAC 10000 times
DV0P4281	RF70M	100		0.1	10	25	
DV0P4282	RF180B	25		0.4	17	50	
DV0P4283	RF180B	50		0.2	17	50	
DV0P4284	RF240	30		0.5	40	100	
DV0P4285	RH450F	20		1.2	52	130	
DV0PM20048	RF240	120		0.5	35	80	
DV0PM20049	RH450F	80		1.2	65	190	
DV0PM20058	RH450F × 6	3.3	— ^{*2}	16	— ^{*3}	780	
DV0PM20059	RH450F × 6	13.3	— ^{*2}	16	— ^{*3}	1140	

Manufacturer : Iwaki Musen Kenkyusho

*1 Power with which the driver can be used without activating the built-in thermostat.

A built-in thermal fuse and a thermal protector are provided for safety.

The circuit should be so designed that the power supply will be turned off as the thermal protector operates.

The built-in thermal fuse blows depending on changes in heat dissipation condition, operating temperature limit, power supply voltage or load.

Mount the regenerative resistor on a machine operating under aggressive regenerating condition (high power supply voltage, large load inertia, shorter deceleration time, etc.) and make sure that the surface temperature will not exceed 100°C.

Attach the regenerative resistor to a nonflammable material such as metal.

Cover the regenerative resistor with a nonflammable material so that it cannot be directly touched.

Temperatures of parts that may be directly touched by people should be kept below 70°C.

*2 Terminal block with screw tightening torque as shown below.

T1, T2, 24V, 0V, E: M4 : 1.2 to 1.4N·m


R1, R2 : M5 : 2.0 to 2.4N·m

Use the cable with the same diameter as the main circuit cable. (Refer to P.2-10).


*3 With built-in fan which should always be operated with the power supply connected across 24 V and 0 V.

Frame	Power supply		
	Single phase, 100V	Single phase, 200V 3-phase, 200V	3-phase, 400V
A	DV0P4280	DV0P4281 (50W, 100W) DV0P4283 (200W)	—
B	DV0P4283	DV0P4283	
C	DV0P4282		
D	—	DV0P4284	DV0PM20048
E		DV0P4284 × 2 in parallel or DV0P4285	DV0PM20049
F		DV0P4285 × 2 in parallel	DV0PM20049 × 2 in parallel
G		DV0P4285 × 3 in parallel	DV0PM20049 × 3 in parallel
H		DV0P4285 × 6 in parallel or DV0PM20058	DV0PM20049 × 6 in parallel or DV0PM20059

DV0P4280, DV0P4281




DV0P4282, DV0P4283




7. Options

External Regenerative Resistor




DV0P4284, DV0PM20048



DV0P4285, DV0PM20049



DV0PM20058, DV0PM20059



Remarks

Thermal fuse is installed for safety. Compose the circuit so that the power will be turned off when the thermostat is activated. The thermal fuse may blow due to heat dissipating condition, working temperature, supply voltage or load fluctuation.

Make it sure that the surface temperature of the resistor may not exceed 100°C at the worst running conditions with the machine, which brings large regeneration (such case as high supply voltage, load inertia is large or deceleration time is short) Install a fan for a forced cooling if necessary.

Caution

Regenerative resistor gets very hot.

Take preventive measures for fire and burns.
Avoid the installation near inflammable objects, and easily accessible place by hand.

7

Supplement

7. Options

Recommended components

Surge absorber for motor brake

Motor		Part No.	Manufacturer
MSME	50W to 750W (200V)	Z15D271	Ishizuka Electronics Co.
	750W (400V) 1.0kW to 5.0kW	Z15D151	
MDME	400W (400V) 600W (400V)		
	1.0kW to 3.0kW	NVD07SCD082	KOA CORPORATION
	4.0kW to 7.5kW	Z15D151	Ishizuka Electronics Co.
	11kW, 15kW	NVD07SCD082	KOA CORPORATION
MFME	1.5kW		
	2.5kW, 4.5kW		
MGME	0.9kW to 6.0kW	Z15D151	Ishizuka Electronics Co.
MHME	1.0kW, 1.5kW	NVD07SCD082	KOA CORPORATION
	2.0kW to 7.5kW	Z15D151	Ishizuka Electronics Co.

Warranty

Warranty period

- The warranty period is one year from the date of purchase or 18 months from the month of manufacture in our plant.
For a motor with brake, the axis accelerated and decelerated more times than the specified limit is not covered by warranty.

Warranty information

- Should any defect develop during warranty period under standard service conditions as described in the manual, the company agrees to make repairs free of charge. Even during warranty period, the company makes fee-based repair on product containing:
 - [1] Failure or damage due to misuse, improper repair or alteration.
 - [2] Failure or damage due to falling, or damage during transportation, after the original delivery
 - [3] Defects resulting from neglect of the specification in use of the product.
 - [4] Failure or damage due to unregulated voltage and fire, and act of natural disasters such as earthquake, lightning, wind, flood and salt pollution.
 - [5] Defects resulting from invasion of foreign materials such as water, oil and metal pieces.Parts exceeding their standard lifetime specified in this document are excluded.
- The company shall not be liable for any indirect, incidental or consequential damage or loss of any nature that may arise in connection with the product.

Cautions for Proper Use

- Practical considerations for exporting the product or assembly containing the product
When the end user of the product or end use of the product is associated with military affair or weapon, its export may be controlled by the Foreign Exchange and Foreign Trade Control Law. Complete review of the product to be exported and export formalities should be practiced.
- This product is intended to be used with a general industrial product, but not designed or manufactured to be used in a machine or system that may cause personal death when it is failed.
- Installation, wiring, operation, maintenance, etc., of the equipment should be done by qualified and experienced personnel.
- Apply adequate tightening torque to the product mounting screw by taking into consideration strength of the screw and the characteristics of material to which the product is installed. Overtightening can damage the screw and/or material; undertightening can result in loosening.

Example) Steel screw into steel section:

M4	1.35 to 1.65 N·m.
M5	2.7 to 3.3 N·m.
M6	4.68 to 5.72 N·m.
M8	11.25 to 13.75 N·m.
M10	22.05 to 26.95 N·m.
M11	37.8 to 46.2 N·m.

- Install a safety equipments or apparatus in your application, when a serious accident or loss of property is expected due to the failure of this product.
- Consult us if the application of this product is under such special conditions and environments as nuclear energy control, aerospace, transportation, medical equipment, various safety equipments or equipments which require a lesser air contamination.
- We have been making the best effort to ensure the highest quality of the products, however, application of exceptionally larger external noise disturbance and static electricity, or failure in input power, wiring and components may result in unexpected action. It is highly recommended that you make a fail-safe design and secure the safety in the operative range.
- If the motor shaft is not electrically grounded, it may cause an electrolytic corrosion to the bearing, depending on the condition of the machine and its mounting environment, and may result in the bearing noise. Checking and verification by customer is required.
- Failure of this product depending on its content, may generate smoke of about one cigarette. Take this into consideration when the application of the machine is clean room related.
- Please be careful when using in an environment with high concentrations of sulfur or sulfuric gases, as sulfuration can lead to disconnection from the chip resistor or a poor contact connection.
- Take care to avoid inputting a supply voltage which significantly exceeds the rated range to the power supply of this product. Failure to heed this caution may result in damage to the internal parts, causing smoking and/or a fire and other trouble.
- The user is responsible for matching between machine and components in terms of configuration, dimensions, life expectancy, characteristics, when installing the machine or changing specification of the machine. The user is also responsible for complying with applicable laws and regulations.
- The product will not be guaranteed when it is used outside its specification limits.
- Parts are subject to minor change to improve performance.

After-Sale Service (Repair)

Repair

Consult to a dealer from whom you have purchased the product for details of repair.
When the product is incorporated to the machine or equipment you have purchased,
consult to the manufacturer or the dealer of the machine or equipment.

Technical information

Technical information of this product (Operating Instructions, CAD data) can be downloaded from the following web site.

Panasonic Corporation, Motor Business Unit, Industrial Sales Group

Tokyo: Kyobashi MID Bldg, 2-13-10 Kyobashi, Chuo-ku, Tokyo 104-0031

Osaka: 1-1, Morofuku 7-chome, Daito, Osaka 574-0044

For your records:

The model number and serial number of this product can be found on either the back or the bottom of the unit.
Please note them in the space provided and keep for future reference.

Model No.	M <input type="checkbox"/> DH _____ M <input type="checkbox"/> ME _____	Serial No.	
Date of purchase			
Dealer	Name		
	Address		
	Phone	() -	

Panasonic Corporation, Motor Business Unit